



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for LA CROSSE TECHNOLOGY WS-9760U-IT. You'll find the answers to all your questions on the LA CROSSE TECHNOLOGY WS-9760U-IT in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual LA CROSSE TECHNOLOGY WS-9760U-IT
User guide LA CROSSE TECHNOLOGY WS-9760U-IT
Operating instructions LA CROSSE TECHNOLOGY WS-9760U-IT
Instructions for use LA CROSSE TECHNOLOGY WS-9760U-IT
Instruction manual LA CROSSE TECHNOLOGY WS-9760U-IT

Contents	Page	TABLE OF CONTENTS	Page
Language		TABLE OF CONTENTS	
English	1	TABLE OF CONTENTS	
French		TABLE OF CONTENTS	
Spanish		TABLE OF CONTENTS	

THE PRODUCT OFFER: INSTANT REACTIONS® is the state-of-the-art from which comes the most advanced technology, exclusively designed and developed by LA CROSSE TECHNOLOGY. INSTANT REACTIONS® offers you an immediate update (over 4 seconds) of all your outdoor data, measured from the 4 parameters: relative your climate variations in real-time!

INVENTORY OF CONTENTS

- Wireless Temperature Station
- Wireless Temperature Sensor (TK4021T) and mounting bracket
- Instruction Manual

FEATURES:

Temperature station

The Temperature Station

- Manual time setting (hour and minute display)
- Time display (24h) Outdoor time (battery) (day and night)
- Real-time outdoor temperature reading (regardless of whether °F or Celsius °C)
- Display MIN MAX outdoor temperature
- Display one of the 4 weather forecast temperature condition icons, featured by Weather-Git



[You're reading an excerpt. Click here to read official LA CROSSE TECHNOLOGY WS-9760U-IT user guide](http://yourpdfguides.com/dref/3643525)
<http://yourpdfguides.com/dref/3643525>

Manual abstract:

INSTANT TRANSMISSION offers you an immediate update (every 4 seconds!) of all your outdoor data measured from the transmitters: follow your climatic variations in real-time! Temperature station LCD Display Hanging hole Battery compartment INVENTORY OF CONTENTS 1. 2. 3. Wireless Temperature Station Wireless Temperature Sensor (TX40U-IT) and mounting bracket. Instruction Manual Function Keys Stand The Temperature Station Manual time setting (hour and minute display) Time display 12 or 24-hour time format Indoor and outdoor temperature reading in degree Fahrenheit (°F) or Celsius (°C) Display MIN/MAX outdoor temperature Display one of the 5 easy-to-read temperature condition icons featured by Weather Girl 3 4 Low battery indicator Wireless transmission at 915 MHz Signal reception intervals at 4 seconds Wall mounting or table standing (removable table stand included) 2. The Outdoor Temperature Transmitter Remote transmission of outdoor temperature to Temperature Station by 915 MHz signals Rain proof casing Wall mounting and table-standing Mounting at a sheltered place. Avoid direct rain and sunshine 3. 4. Within 30 seconds of powering up the transmitter, insert the batteries to the Temperature Station (see "How to install and replace batteries in the Temperature station" below). Once the batteries are in place, all segments of the LCD will light up briefly.

Following the indoor temperature, the Weather Girl icon and the time as 12:00 will be displayed. If they are not shown in LCD after 60 seconds, remove the batteries and wait for at least 60 seconds before reinserting them. Once the indoor data is displayed user may proceed to the next step. After the batteries are inserted, the Temperature Station will start receiving data signal from the transmitter. The outdoor temperature should then be displayed on the Temperature station.

@@@1. @@5 6 The Temperature Station uses 3 x AA, IEC LR6, 1.5V batteries. @@To install and replace the batteries, please follow the steps below: 1. Lift up the battery compartment cover.

2. Insert batteries observing the correct polarity (see marking). 3. Replace compartment cover. Note: In the event of changing batteries in any of the units, all units need to be reset by following the setup procedures. This is because a random security code is assigned by the transmitter at start-up and this code must be received and stored by the Temperature Station in the first few minutes of power supplying. BATTERY CHANGE: It is recommended to replace the batteries in all units regularly to ensure optimum accuracy of these units. (Battery life see Specifications) Please participate in the preservation of the environment. Return used batteries to an authorized depot. HOW TO INSTALL AND REPLACE BATTERIES IN THE TEMPERATURE TRANSMITTER The Temperature transmitter uses 2 x AAA, IEC LR3, 1.

5V batteries. When batteries will need to be replaced, the low battery icon will appear on the LCD of the Temperature Station. To install and replace the batteries, please follow the steps below: 1. Remove the battery compartment cover. 2. Insert the batteries, observing the correct polarity (see marking). 3. Replace the battery holder to the unit. FUNCTION KEYS: The Temperature Station has only two easy to use function keys. SET key + key 7 8 SET key Press and hold for about 3 seconds to enter the Manual setting mode.

+ key Press to make adjustment in the setting mode. Press and hold to reset all MIN/MAX records * When the signal from the transmitter is successfully received by the Temperature Station, this icon will be switched on. (If not successful, the icon will not be shown on the LCD). User can therefore easily see whether the last reception was successful ("ON" icon) or not ("OFF" icon). On the other hand, the short blinking of the icon shows that a reception is being done at that time.

For a better display clarity, the LCD screen is split into 3 sections. LCD SCREEN AND SETTINGS: Time Low battery indicator (temperature station) Indoor Temperature in °F/°C Outdoor Temperature in °F/°C Low battery indicator (transmitter) Outdoor Reception Signal icon* MIN/MAX Outdoor temperature Temperature icon (Weather Girl icon) Section 1 - TIME Display of time (manually set). Section 2 - INDOOR TEMPERATURE Display of indoor temperature. Section 3 - CURRENT OUTDOOR TEMPERATURE AND MIN/MAX OUTDOOR TEMPERATURE AND WEATHER GIRL ICON Display the current temperature. Display the outdoor minimum and maximum temperature.

@@@2. 3. The "12" or "24" digit will be flashing. Press the + key to set the desired time display mode. @@2. @@Press the + key to select the unit as F or C. @@2. @@@@Press SET key to confirm and go to the minute setting. The minute digit will be flashing. @@@@ @@@@2.

@@3. @@4. @@@@ @@@@If no reception is possible despite the observation of these factors, all system units have to be reset (see Setting up above). POSITIONING THE TEMPERATURE STATION: The Temperature Station comes attached with a table stand, which provides the option of table standing the unit in addition to wall mounting. Before wall mounting, please check that the outdoor temperature values can be received from the desired locations. To wall mount: 1. 2. Fix a screw (not supplied) into the desired wall, leaving the head extended out by about 5mm. Hang the Temperature Station onto the screw. Remember to ensure that it locks into place before releasing.

15 16 POSITIONING THE REMOTE TEMPERATURE TRANSMITTER: The remote temperature transmitter can be placed onto any flat surface or wall mounted using the bracket which doubles as a stand or wall mount base. in place, please ensure that the Temperature Station can receive the 915MHz signal from the temperature transmitter at the positions that you wish to place them. CARE AND MAINTENANCE: To wall mount: 1. Secure the bracket onto a desired wall using the screws and plastic anchors. 2.

Clip the remote temperature transmitter onto the bracket. Note: The mounting surface can affect the transmission range. If, for instance, the unit is attached to a piece of metal, it may then either reduce or increase the transmitting range. For this reason, we recommend not to place the unit on any metal surfaces or in any position where a large metal or highly polished surface is in the immediate vicinity (garage doors, double glazing, etc.).

Before securing 17 Extreme temperatures, vibrations and shocks should be avoided as these may cause damage to the unit and give inaccurate forecasts and readings. When cleaning the display and casings, use a soft damp cloth only. Do not use solvents or scouring agents as they may mark the LCD and casings. Do not submerge the units in water. Furthermore, fix all parts in place where the units are adequately protected against moisture and rain. Immediately remove all low powered batteries to avoid leakage and damage.



[You're reading an excerpt. Click here to read official LA CROSSE TECHNOLOGY WS-9760U-IT user guide](http://yourpdfguides.com/dref/3643525)
<http://yourpdfguides.com/dref/3643525>

Replace only with new batteries of the recommended type. Do not make any repair attempts to the unit. @@Opening and tampering with the unit may invalidate their guarantee. Do not expose the units to extrem.

@@@THIS PRODUCT IS NOT A TOY. KEEP OUT OF CHILDREN'S REACH. This warranty gives you specific legal rights. You may also have other rights specific to your State. @@For warranty work, technical support, or information contact: La Crosse Technology, Ltd 2809 Losey Blvd. S. La Crosse, WI 54601 Phone: 608.782.1610 Fax: 608.796.

1020 e-mail: support@lacrossetechnology.com (warranty work) sales@lacrossetechnology.com (information on other products) web: www.lacrossetechnology.com Question? Instructions? Please visit: www.

lacrossetechnology.com/9760 All rights reserved. This handbook must not be reproduced in any form, even in excerpts, or duplicated or processed using electronic, mechanical or chemical procedures without written permission of the publisher. This handbook may contain mistakes and printing errors. The information in this handbook is regularly checked and corrections made in the next issue.

We accept no liability for technical mistakes or printing errors, or their consequences. All trademarks and patents are acknowledged. 21 22 .



[You're reading an excerpt. Click here to read official LA CROSSE TECHNOLOGY WS-9760U-IT user guide](http://yourpdfguides.com/dref/3643525)
<http://yourpdfguides.com/dref/3643525>