

Manual abstract:

Use of non-Motorola-approved accessories may exceed FCC/Health Canada RF exposure guidelines. If you do not use one of the Motorola-supplied or approved body-worn accessories and are not using the radio held in the normal use position, ensure the radio and its antenna are at least 1 inch (2.5 cm) from your body when transmitting. Data Operation If applicable, when using any data feature of the radio with or without an accessory cable, position the radio and its antenna at least one inch (2.5 cm) from the body. Approved Accessories For a list of approved Motorola accessories, visit our Web site at www.motorola.com. Electromagnetic Interference/Compatibility Note: Nearly every electronic device is susceptible to electromagnetic interference (EMI) if inadequately shielded, designed or otherwise configured for electromagnetic compatibility. This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: 1. This device may not cause harmful interference; and 2. This device must accept any interference received, including interference that may cause undesired operation. Facilities To avoid electromagnetic interference and/or compatibility conflicts, turn off your radio in any facility where posted notices instruct you to do so. Hospitals or health care facilities may be using equipment that is sensitive to external RF energy.

Aircraft When instructed to do so, turn off your radio when onboard an aircraft. Any use of a radio must be in accordance with applicable regulations per airline crew instructions. Two-Way Radio User's Guide Potentially Explosive Atmospheres Turn off your radio prior to entering any area with a potentially explosive atmosphere. Only radio types that are especially qualified should be used in such areas as "Intrinsically Safe." Do not remove, install or charge batteries in such areas.

Sparks in a potentially explosive atmosphere can cause an explosion or fire resulting in bodily injury or even death. Note: The areas with potentially explosive atmospheres referred to above include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles (such as grain, dust or metal powders) and any other area where you would normally be advised to turn off your vehicle engine. Areas with potentially explosive atmospheres are often--but not always--posted. Blasting Caps and Areas To avoid possible interference with blasting operations, turn off your radio when you are near electrical blasting caps, in a blasting area, or in areas posted "Turn off two-way radios." Obey all signs and instructions. Operational Cautions Antennas Do not use any portable radio that has a damaged antenna. If a damaged antenna comes into contact with your skin, a minor burn can result. Batteries All batteries can cause property damage and/or bodily injury such as burns if a conductive material--like jewelry, keys or beaded chains-- touch exposed terminals. The conductive material may complete an electrical circuit (short circuit) and become quite hot. Exercise care in handling any charged battery, particularly when placing it inside a pocket, purse or other container with metal objects.

Exercise care when removing NiMH or AA batteries. Do not use sharp or conductive tools to remove either of these batteries. Battery Charger Safety Instructions: Save these Instructions 1. Do not expose the charger to rain or snow. 2. Do not operate or disassemble the charger if it has received a sharp blow, or has been dropped or damaged in any way. 3. Never alter the AC cord or plug provided with the unit. If the plug will not fit the outlet, have the proper outlet installed by a qualified electrician. An improper condition can result in a risk of electric shock.

4. To reduce the risk of damage to the cord or plug, pull the plug rather than the cord when disconnecting the charger from the AC receptacle. 5. To reduce the risk of electric shock, unplug the charger from the outlet before attempting any maintenance or cleaning. 6.

Use of an attachment not recommended or sold by Motorola may result in a risk of fire, electric shock or personal injury. 7. Make sure the cord is located so it will not be stepped on, tripped over or subjected to damage or stress. 8. An extension cord should not be used unless absolutely necessary.

Use of an improper extension cord could result in a risk of a fire and/or electric shock. If an extension cord must be used, make sure that: · The pins on the plug of the extension cord are the same number, size and shape as those on the plug of the charger. · The extension cord is properly wired and in good electrical condition. · The extension cord size is 18 AWG for lengths up to 100 feet, and 16 AWG for lengths up to 150 feet. 9. The supply cord of the AC adaptor cannot be replaced. If the cord is damaged, call customer service at 1-800-638-5119 (U.S. and Canada). Control Buttons Use to: Use to: · Turn radio on/off · Increase or decrease volume LED Indicator · Select Menu options · Exit the Menu (when pressed while in last Menu) · Lock and unlock the keypad (when held down and not in a Menu) Use Push to Talk to: · Talk · Save a setting · Boost the radio's power Accessory Jack Hi Lo Microphone Removing the Three AA Batteries 1.

Turn the radio off. 2. @@3. Pull the ribbon towards you. Carefully and slowly, lift the ribbon to remove the AA alkaline batteries. 4. Reposition the battery cover and press down to secure. Notes · Exercise care when removing NiMH or AA batteries. Do not use sharp or conductive tools to remove either of these batteries. · Remove the batteries before storing your radio for extended periods of time.

Batteries corrode over time and may cause permanent damage to your radio. Using the Battery Charger The battery charger provides drop-in charging convenience for NiMH batteries and can be placed on any flat surface, such as a desk or workbench. Charge the NiMH battery overnight (at least 16 hours) before using it for the first time. After the initial charge, an empty battery is fully charged within 14 hours. 1.

Follow the steps above to install a NiMH Battery Pack. 2. Plug the AC power supply cord into the jack on the desk stand. 3. Plug the AC power supply into a standard wall outlet.

4. With a radio facing forward, slide it into one of the charging pockets. Using the Car Charger (Optional accessory) 1. Plug DC cord into car's 13.8V DC outlet or cigarette lighter socket. 2. Snap charger to rear of radio over charging contacts. Charger fits in one direction only. 3. An empty battery is fully charged in 14 hours.

Notes · The red light will glow continuously to indicate the radio is correctly connected and charging. The light will remain red after the battery pack is fully charged. · When moving between hot and cold temperatures, do not charge the battery until the battery temperature acclimates (usually about 20 minutes).



[You're reading an excerpt. Click here to read official MOTOROLA TALKABOUT T9500 user guide](http://yourpdfguides.com/dref/2332563)
<http://yourpdfguides.com/dref/2332563>

· For optimal battery life, remove the radio from the charger within 16 hours. Do not store the radio while connected to the charger. · Turn radio off while charging. Attaching and Removing the Belt Clip 1. Attach belt clip to pocket or belt strap. 2. Align the belt clip post with the hole in the back of the radio. 3. Gently push until the clip clicks in place. To Remove 1. Push down on the release tab at the top of the belt clip to release the catch. 2. Pull the belt clip away from the back of the radio. Turning Your Radio On and Off Turn clockwise to turn the radio on and counterclockwise to turn the radio off. 1. In the ON position, the radio chirps and briefly shows all feature icons available on the radio. 2.

The display screen then shows the current channel, code and all features that are enabled. Setting the Volume Press and hold for three seconds while rotating until you reach a comfortable listening level. 1. Rotate clockwise to increase the volume. 2. Rotate counterclockwise to decrease the volume. Do not hold the radio close to your ear. If the volume is set to an uncomfortable level, it could hurt your ear. Menu Options Selecting the Channel Your radio has 22 channels. Channels 8-14 are FRS low power only and all other channels are GMRS.

(See the "Channels and Frequencies" table on overleaf for details.) all channels are low When you press the bottom portion of the . If you press the top portion of the to boost the power . power GMRS channels will be high power Note: When on FRS only channel top or bottom press of will only . be lower power . The current channel flashes. 1. With the radio on, press or and select an unused or quiet channel. 2. Press 3. Press to save the channel setting or to continue set up. Selecting The Interference Eliminator Code Interference Eliminator Codes help minimize interference by blocking transmissions from unknown sources. Your radio has 121 Interference Eliminator Codes. Codes 1 - 38 are the standard analog codes that appear on other FRS/GMRS radios. Codes 39 - 121 are additional digital codes added for superior interference protection. 0 is the off position, no analog or digital codes are enabled. To set the code for a channel: 1. Press until the code starts to flash. or to select the code. 2. Press to save the code setting or to continue set up. 3. Press You can set a different code for each channel using this procedure. An extended press of or allows you to scroll through the Interference Code rapidly so you can quickly reach the code you want. Note: You must set the Interference Eliminator Code to 0 on a radio that uses Interference Eliminator Codes to communicate with radios that do not have Interference Eliminator Codes. Select 0 for "no tone, no code" and OFF will flash on your radio's display. Setting and Transmitting Call Tones Your radio can transmit different call tones to other radios in your group so you can alert them that you want to talk. You have 10 call tones from which to choose. To set a call tone: three times until the current call tone 1. With the radio on, press setting (0 - 10) flashes and appears.

2. Press or to change and hear the call tone. 3. Press to set the new call tone or to continue set up. To transmit your call tone to other radios set to the same channel and Interference Eliminator Code as your radio, press . Note: Setting the call to 0 disables the call tone feature. Hands-Free Use Without Accessories (iVOX) You can use the iVOX feature to transmit hands-free without the need for any headset accessories. Once iVOX is turned on, the radio detects your voice and transmits when you speak into the internal microphone. 1. Press until iVOX appears on the display.

The current setting On/Off will flash. 2. Press or to select On or Off. 3. Press to set or to continue set up. Hands-Free Use With Accessories (VOX) You can transmit hands-free more reliably with the use of optional headset accessories. Once VOX is turned on, the radio detects your voice and transmits when you speak. Many accessories (sold separately) are available for your radio. For more information, visit our Web site at www.motorola.com or shop.giantintl.com. 1. Turn the radio off and plug the VOX accessory into the accessory port. 2. Turn the radio on. VOX shows on the display. 3. Adjust the volume appropriately by rotating .

Lower the volume before placing the accessory on your head or in your ear. 4. To turn off, simply remove accessory. Note: There is a short delay between the time you start talking and when the radio transmits. There is a short delay before the transmission is completed. Setting the Sensitivity Level When in VOX or iVOX Mode Adjusting the radio's sensitivity level helps minimize the possibility of unintended noises triggering a transmission and helps the radio pick up soft voices. 1. Press until VOX/iVOX and the level setti (PTT) button. Transmitting 50% of the time, or less, is important because the radio generates measurable RF energy exposure only when transmitting (in terms of measuring standards compliance). Exposure to Radio Frequency Energy Your Motorola two-way radio complies with the following RF energy exposure standards and guidelines: · United States Federal Communications Commission, Code of Federal Regulations; 47CFR part 2 sub-part J.

· American National Standards Institute (ANSI)/Institute of Electrical and Electronic Engineers (IEEE) C95. 1-1992. · Institute of Electrical and Electronics Engineers (IEEE) C95.1-1999 Edition. · International Commission on Non-Ionizing Radiation Protection (ICNIRP) 1998. · Ministry of Health (Canada) Safety Code 6. Limits of Human Exposure to Radiofrequency Electromagnetic Fields in the Frequency Range from 3 KHz to 300 GHz, 1999. · Australian Communications Authority Radiocommunications (Electromagnetic Radiation--Human Exposure) Standard, 2003. · ANATEL ANNEX to Resolution No. 303 of July 2, 2002 "Regulation of limitation of exposure to electrical, magnetic and electromagnetic fields in the radio frequency range between 9 KHz and 300GHz" and "Attachment to resolution #303 from July 2, 2002".

VOX Getting Started Installing the Batteries Each radio uses 1 NiMH rechargeable battery pack or 3 AA alkaline batteries and beeps when the batteries are low. Installing NiMH Rechargeable Battery Pack 1. Turn the radio off. 2. @ @3. Remove the battery pack from the clear plastic bag (Do not disassemble or unwrap the battery pack). 4. Insert the NiMH battery pack with the diagram facing you. (The ribbon should be underneath the battery pack and should wrap around the right side of the pack for easy removal.) 5.

Reposition the battery cover and press down to secure. Installing the Three AA Alkaline Batteries 1. Turn the radio off. 2. @ @3. @ @ @ @ Reposition the battery cover and press down to secure. @ @ @ @ Removing the NiMH Battery Pack 1. Turn the radio off. 2. @ @3. Pull the ribbon towards you. @ @4. @ @ @ @ @ @ @ @1. To talk, press and hold . 2. When you are finished talking, release . @ @ Do not cover the microphone while talking.



[You're reading an excerpt. Click here to read official MOTOROLA TALKABOUT T9500 user guide](http://yourpdfguides.com/dref/2332563)
<http://yourpdfguides.com/dref/2332563>

@@Do not use the radios closer than five feet apart. @@@@This allows you to adjust the volume, if necessary. @@@@This is useful in noisy environments.

When the alert is on, the radio vibrates once every 30 seconds when you receive a message on the channel and code you set. until is displayed. The 1. To turn vibrating alerts on, press current setting will flash. or to change the setting to On/Off. 2. Press 3. Press to set or to continue set up. QT Noise Filtering The QT noise-filtering feature helps to ensure uninterrupted communication with other Motorola radios that have this feature. This feature also filters out unwanted transmissions from other radios.

This is useful in places where there is heavy radio traffic, such as amusement parks or ski resorts. Note: QT noise filtering is not available when the radio is scanning. To turn QT noise filtering on or off: 1. Press until QT displays. The current setting On/Off will flash. or to turn noise filtering On or Off. 2. Press to confirm your selection or to continue set up. 3. Press To transmit to a radio that has QT noise filtering turned on: 1.

Select the same channel and Interference Eliminator Code as the other radio. to send a call tone. This allows your voice to pass through 2. Press the QT noise filter on the receiving radio. 3.

Press and speak normally. Note: If you skip step 2, the beginning of your message may not be heard on the receiving radio. For a 30-second period, starting after the last transmission, all transmissions received on the selected channel and code will pass through the QT noise filter. Keypad Tones You may enable or disable the speaker key tones. You will hear the key tone each time a button is pushed.

1. Press until appears. The current setting On/Off will flash. or to turn On or Off. 2. Press either to confirm or to continue set up. 3. Press Note: When the key tone feature is off, the following are not disabled: · transmit timeout alert tone, · call tone, · low battery alert tone, or · the transmitted talk confirmation tone. Transmitting a Talk Confirmation Tone You can set your radio to transmit a unique tone when you finish transmitting. It is like saying "Roger" or "Over" to let others know you are finished talking.

1. With the radio on, press until the appears. The current setting On/Off flashes. 2. Press or to turn On or Off. 3. Press to set or to quit menu mode. Special Features Keypad Lock To avoid accidentally changing your radio settings: until displays. 1. Press and hold 2.

When in lock mode, you can turn the radio on and off, adjust the volume, receive, transmit, send a call tone, and monitor channels. All other functions are locked. until is no longer displayed. To unlock the radio, press and hold Scanning Channels Use scan to search the 22 channels for transmissions from unknown parties, to find someone in your group who has accidentally changed channels, or to quickly find unused channels for your own use. There is a priority feature and 2 modes of scanning (basic and advanced) to make your search more effective.

The basic scan mode uses the channel and code combinations for each of the 22 channels as you have set them (or with the default code value of 1). The "Advanced Scan" mode will scan all channels for any and all codes, detect any code in use, and use that code value temporarily for that channel. Priority is given to the "home channel," that is, the channel (and Interference Eliminator Code) your radio was set to when you started the scan. This means the initial channel (and code setting) is scanned more often than the other 21 channels, and your radio will respond quickly to any activity occurring on the home channel as a priority. To start Scanning: 1.

Briefly press the key. The scan will appear in the display, and the radio will begin to scroll through the channel and code combinations. 2. When the radio detects channel activity matching the channel and code combination, it stops scrolling and you can hear the transmission. 3. To respond and talk to the person transmitting, press within five seconds after the end of the transmission. 4. The radio will resume scrolling through the channels five seconds after the end of any received activity. 5. To stop scanning, briefly press the key.

To start Advanced Scanning: 1. Set the Interference Eliminator Code to "zero" or OFF. key. The scan will appear in the display, 2. Briefly press the and the radio will begin to scroll through the channels. No Interference Eliminator Codes will filter what is heard. 3. When the radio detects channel activity with ANY code (or NO code), it stops scrolling and you can hear the transmission. Any Interference Eliminator Code that may be in use by that party will be detected and displayed. 4.

To respond and talk to the person transmitting, press within five seconds of the end of the transmission. The radio will transmit using the newly detected Interference Eliminator Code. 5. The radio will resume scrolling through the channels five seconds after the end of any received activity. 6.

To stop scanning, briefly press the key. Scanning Notes: 1. If you press while the radio is scrolling through inactive channels, the transmission will be on the "home channel". Scanning will resume five seconds after the end of your transmission. You may press the key to stop scanning at any time.

2. If the radio stops on an undesired transmission, you may immediately resume the scan by briefly pressing or . 3. If the radio repeatedly stops on an undesired transmission, you may temporarily remove that channel from the scan list by pressing and holding or for three seconds. You may remove more than one channel in this way. 4. To restore the removed channel(s) to the scan list, turn the radio off and then back on, or exit and re-enter the scanning mode by pressing . 5. You cannot remove the home channel from the scan list. 6.

In Advanced Scan, the detected code will only be used for one transmission. You must note the code, exit scan, and set that detected code on that channel to permanently use the detected code. Faceplate Removal (relevant only for models that this applies to) The faceplates snap on. They are not screwed on. To remove the faceplate, lift at the indentation located at the center of the bottom section of the faceplate. Do not use a screwdriver. Weather Receiver Your radio can tune in to broadcasts by the United States National Oceanic and Atmospheric Administration (NOAA) Weather Radio and Environment Canada Weatheradio. You can listen to a weather channel (see "Weather Channels and Frequencies" table below) or set your radio to alert you to emergency weather broadcasts that interrupt routine broadcasts. When you listen to a weather channel, you cannot use your radio in scan mode or for twoway communications.

Both NOAA and Environment Canada have transmitters located throughout the United States and Canada, respectively.

These transmitters broadcast watches, forecasts, and other information 24 hours a day.



[You're reading an excerpt. Click here to read official MOTOROLA](http://yourpdfguides.com/dref/2332563)

[TALKABOUT T9500 user guide](http://yourpdfguides.com/dref/2332563)

<http://yourpdfguides.com/dref/2332563>

Note: NOAA weather radio stations are assigned to cover specific areas and service may be limited. Please check with your local weather office for frequency and details, or visit www.weather.gov/nwr in the US or www.msc.ec.gc.ca/msb/weatherradio in Canada to view the appropriate transmitter for your area. The use of the NOAA logo does not provide an endorsement or implied endorsement by NOAA's National Weather Service, nor does the use of the Weatheradio logo provide an endorsement or implied endorsement by Environment Canada.

Turning Weather Channel Reception On and Off and hold for three seconds. 1. To turn weather reception on, press or turn the radio off and then back on. 2. To turn off, press Setting the Weather Channel Your radio receives weather frequencies: 1. After turning weather reception on, press . The current channel flashes. 2. Press or to select the appropriate channel with good reception in your area. to save the weather channel setting.

3. Press 4. Press to return to two-way mode. Setting the Weather Alert Your radio can be set to respond to NOAA Weather Radio emergency messages. A special alarm tone sounds an alert and turns on the weather receiver to give you immediate weather and emergency information. twice. On/Off displays. 1. After turning weather reception on, press or to select On/Off. If you activate Weather Alert 2.

Press and return to two-way mode, will display. to save the weather alert setting. 3. Press 4. Press to return to two-way mode.

As with two-way radio reception, weather channel reception depends on how close you are to a transmitter and whether you are indoors or outdoors. Because weather channels are transmitted without codes, they may contain static or noise. Weather Alert will not function while actively transmitting or receiving in two-way mode. Weather Channels and Frequencies Weather Channel WX1 WX2 WX3 WX4 WX5 WX6 Frequency 162.550 MHz 162.

400 MHz 162.475 MHz 162.425 MHz 162.450 MHz 162.500 MHz Weather Channel WX7 WX8 WX9 WX10 WX11 Frequency 162.525 MHz 161.650 MHz 161.775 MHz 161.750 MHz 162.000 MHz Warranty Consumer Two-Way Radio Products and Accessories purchased in the United States or Canada.

What Does this Warranty Cover? Subject to the exclusions contained to the right, Giant International Ltd. warrants the Motorola branded consumer two-way radios that operate via Family Radio Service or General Mobile Radio Service that it manufactures ("Products"), the Motorola branded or certified accessories sold for use with these Products that it manufactures ("Accessories") to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola branded Products and Accessories manufactured by Giant International Ltd., and purchased by consumers in the United States or Canada, which are accompanied by this written warranty: Products Covered Products and Accessories as defined above, unless otherwise provided for below. 1. Decorative Accessories and Cases. Decorative covers and cases. 2. Monaural Headsets. Ear buds and boom headsets that transmit mono sound through a wired connection.

3. Consumer Two-Way Radio Accessories. Length of Coverage One (1) year from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below. 1. Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.

2. Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product. 3. @ @4. @ @ @ @ Batteries.

@ @ Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola or Giant International Ltd., are excluded from coverage. Use of Non-Motorola branded Products and Accessories. Defects or damage that result from the use of Non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage. Unauthorized Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola, Giant International Ltd. or its authorized service centers, are excluded from coverage. Altered Products.

Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola branded housings, or parts, are excluded from coverage.

Communication Services. Defects, damages, or the failure of Products or Accessories due to any communication service or signal you may subscribe to or use with the Products or Accessories is excluded from coverage. 4. Products and Accessories that are Repaired or Replaced. Who is covered? This warranty extends only to the first consumer purchaser, and is not transferable. What will GIANT INTERNATIONAL LTD. do? GIANT INTERNATIONAL LTD., at its option, will at no charge repair, replace or refund the purchase price of any Products or Accessories that does not conform to this warranty. We may use functionally equivalent reconditioned/ refurbished/ pre-owned or new Products, Accessories or parts.

How to Obtain Warranty Service or Other Information? To obtain service or information, please call: USA Two-Way Radios 1-800-638-5119 giantintl@callcenter.com Canada Two-Way Radios 1-800-638-5119 giantintl@callcenter.com For Accessories, please call the telephone number designated above for the product with which they are used. You will receive instructions on how to ship the Products or Accessories at your expense, to a GIANT INTERNATIONAL LTD. Authorized Repair Center.

To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number. What Other Limitations Are There? ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OF IMPLIED. IN NO EVENT SHALL MOTOROLA OR GIANT INTERNATIONAL LTD.



[You're reading an excerpt. Click here to read official MOTOROLA TALKABOUT T9500 user guide](http://yourpdfguides.com/dref/2332563)
<http://yourpdfguides.com/dref/2332563>

BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT OR ACCESSORY, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS OR ACCESSORIES TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another. Channels and Frequencies Channel Frequency 1 2 3 4 5 6 7 8 9 10 11 Description Channel 12 13 14 15 16 17 18 19 20 21 22 Frequency 467.6625 MHz 467.6875 MHz 467.7125 MHz 462.5500 MHz 462.5750 MHz 462.6000 MHz 462.6250 MHz 462.6500 MHz 462.

6750 MHz 462.7000 MHz 462.7250 MHz Description FRS FRS FRS GMRS GMRS GMRS GMRS GMRS GMRS GMRS GMRS GMRS 462.5625 MHz GMRS/FRS 462.5875 MHz GMRS/FRS 462.6125 MHz GMRS/FRS 462.6375 MHz GMRS/FRS 462.6625 MHz GMRS/FRS 462.6875 MHz GMRS/FRS 462.7125 MHz GMRS/FRS 467.

5625 MHz 467.5875 MHz 467.6125 MHz 467.6375 MHz FRS FRS FRS FRS Patent and Copyright Information Manufactured, distributed or sold by Giant International Ltd., official licensee for this product.

Motorola, the Stylized M Logo, and other Motorola trademarks and trade dress are owned by Motorola, Inc. and are used under license from Motorola, Inc. MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. All other product or service names are the property of their respective owners. ©Motorola, Inc.

2008. All rights reserved. Please contact customer service at 1-800-638-5119 or e-mail us at giantintl@callcenter.com for questions/comments, warranty, support or service related to this product. T9500 / T9550 / T9650 .



[You're reading an excerpt. Click here to read official MOTOROLA](#)

[TALKABOUT T9500 user guide](#)

<http://yourpdfguides.com/dref/2332563>