




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for MOTOROLA W218. You'll find the answers to all your questions on the MOTOROLA W218 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual MOTOROLA W218
User guide MOTOROLA W218
Operating instructions MOTOROLA W218
Instructions for use MOTOROLA W218
Instruction manual MOTOROLA W218



[You're reading an excerpt. Click here to read official MOTOROLA W218 user guide](http://yourpdfguides.com/dref/3771149)
<http://yourpdfguides.com/dref/3771149>

Manual abstract:

Please check with your local retailer for handset color availability. get started install SIM card & battery 1 2 3 4 5 6 get started charge battery New batteries are not fully charged. To charge your phone's battery, plug the battery charger into your phone and into an electrical outlet. When charging is finished, your display shows Charge Complete. For tips on battery life and charging, see the panel after "text messages". get started turn phone on & off Press and hold O for a few seconds, or until the display turns on or off. make a call Enter a phone number and press N. answer a call When your phone rings and/or vibrates, press N. end a call Press O. basics your phone 11/2 /07 1/25/07 s Note: Your phone may not appear exactly as the phone image in this picture; however, all key locations, sequences, and functions are the same.

Actual colour of handset may be different from illustration. Please check with your local retailer for handset colour availability. basics menus 1 Press M to open the Main Menu. 2 Press S up, down, right, & left to highlight a menu option. 3 Press SELECT to select the highlighted option.

SELECT & MESSAGE basics emergency calls To call the emergency number: Press keypad keys to enter the emergency number, then press N to call it. Your service provider programs one or more emergency phone numbers (such as 112 or 911) that you can call under any circumstances, even when your phone is locked or the SIM card is not inserted. Note: Emergency numbers vary by country. Your phone's preprogrammed emergency number(s) may not work in all locations. Sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

basics status indicators Status indicators show at the top of the home screen: Signal Strength Headset Active Roaming Active Line 1 or 2 6:35am 4 Sé J t z c

Motorola 11/25/07 Battery Level Ring Style New Message MESSAGE G SETTING basics menu map e Messages * · New Message · Voicemail · Text Msgs · Info Services · Quick Notes · Outbox · Drafts Contacts Recent Calls · Received Calls · Dialed Calls · Notepad · Call Times * · Call Cost * Games Extras · Calculator · MyMenu · Alarm Clock · Datebook · Stop Watch · Lantern · Quick Dial * · Fixed Dial · Service Dial · SIM Services * Ring Styles · Style · Ring Detail · My Tones w Settings · Call Divert * · Phone Status * · In-Call Setup · Security · Initial Setup · Network * · Headset Multimedia · Camera · Pictures · FM Radio * Personalise · Home Screen · Main Menu · Colour Style · Greeting · Wallpaper · Screen Saver · Quick Dial * n s h l Q É * Network and/or subscription dependent features * Headset is required for FM Radio to function The function available on this handset may vary in different regions and nations. Please contact your local customer service centers, agencies or retailers if you have any questions about the handset function. Motorola reserves all rights to revise and change this user's manual without obligation to notify any person of such revision or changes. The above gives an example of typical structure of main menu. @@@@Note: The radio won't work without the headset. @@Press ON (the left soft key). To tune in a station, press S left or right. To scan available stations, hold S left or right. To adjust volume, press S up or down. To turn the radio off, press FM RADIO or unplug the headset.

FM radio store favorite stations You can store up to nine FM stations as radio presets. When listening to a station, press and hold a number key 1 through 9 to store the station as a preset. To select a preset station, press the number key 1 through 9 for the station you want. camera take a picture Find it: Press M > h Multimedia > Camera 1 Point the camera lens at the photo subject, and press CAPTURE to take the photo. Press Store to save the photo or DISCARD to delete it. 2 view photos Find it: Press M > h Multimedia > Pictures contacts store contacts entry 1 2 3 4 5 Enter a phone number from the home screen. Press Store. Press CHANGE to open the Name entry area. Enter a name for the new contacts entry. Press DONE to store the entry.

call contacts entry Find it: Press M > n Contacts Scroll to the entry you want to call and press N. text messages send a text message Find it: Press M > e Messages > New Message 1 2 Type the message and press OK. In the To screen, enter the number you want to send to using the keypad keys and press OK. Press # to switch text entry mode to iTAP (predictive text entry), Tap Extended, Numeric, or Symbol. TIP 3 If you want a delivery receipt, scroll to Receipt: and press CHANGE.

Scroll to Yes and press CHANGE, then press DONE. Press SEND when ready to send the message. 4 text messages enter text You can enter text for text messages: Flashing cursor indicates insertion point. Press INSERT to insert a quick note. L P Msg 765 Character counter.

Press CANCEL to exit without saving any changes. INSERT CANCEL Press M to open sub-menu. Press 0 to capitalize letters continued text messages Press # to switch text entry modes: O P [iTAP: Press each letter's key once, then choose from the words your phone suggests. Tap: Press each letter's key repeatedly, until the letter appears. Numeric: Enter numbers only. Symbol: Enter symbols only. W read a text message When you receive a new text message, your phone shows New Message and the r indicator. To see received messages: Find it: Press M > e Messages > Text Msgs To see messages you have sent: Find it: Press M > e Messages > Outbox Battery Tips Battery life depends on the network, signal strength, temperature, features, and accessories you use. · Always use Motorola Original batteries and chargers. The warranty does not cover damage caused by non-Motorola batteries and/or chargers.

· New batteries or batteries stored for a long time may take more time to charge. · When charging your battery, keep it near room temperature. · When storing your battery, keep it uncharged in a cool, dark, dry place. · Never expose batteries to temperatures below -10°C (14°F) or above 45°C (113°F). Always take your phone with you when you leave your vehicle. · It is normal for batteries to gradually wear down and require longer charging times. If you notice a change in your battery life, it is probably time to purchase a new battery. Contact your local recycling center for proper battery disposal.



[You're reading an excerpt. Click here to read official MOTOROLA W218 user guide](http://yourpdfguides.com/dref/3771149)
<http://yourpdfguides.com/dref/3771149>

Warning: Never dispose of batteries in a fire because they may explode. Before using your phone, read the battery safety information in the "Safety and General Information" section.

032375o www.hellomoto.com Certain mobile phone features are dependent on the capabilities and settings of your service provider's network. Additionally, certain features may not be activated by your service provider, and/or the provider's network settings may limit the feature's functionality. Always contact your service provider about feature availability and functionality.

All features, functionality, and other product specifications, as well as the information contained in this user's guide are based upon the latest available information and are believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation. MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. All other product or service names are the property of their respective owners. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc.

under license. Java and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries. © Motorola, Inc., 2006. Your mobile device is a radio transmitter and receiver. (http://www.motorola.com/rfhealth).

1. The limit Motorola-supplied or approved accessories, visit our Web site at: www.motorola.com. RF Energy Interference/Compatibility Nearly every electronic device is subject to RF energy interference from external sources if inadequately shielded, designed, or otherwise configured for RF energy compatibility. DO NOT carry the mobile device in the breast pocket. In the event of such interference, you may want to consult your hearing aid manufacturer or physician to discuss alternatives. Other Medical Devices If you use any other personal medical device, consult your physician or the manufacturer of your device to determine if it is adequately shielded from RF energy. Driving Precautions Check the laws and regulations on the use of mobile devices in the area where you drive.

Always obey them. When using your mobile device while driving, please: · Give full attention to driving and to the road. Using a mobile device may be distracting. Discontinue a call if you can't concentrate on driving. · Use handsfree operation, if available.

· Pull off the road and park before making or answering a call if driving conditions so require. Responsible driving practices can be found in the "Smart Practices While Driving" section at the end of this guide and/or at the Motorola Web site: www.motorola.com/callsmart. Operational Warnings Obey all posted signs when using mobile devices in public areas, such as health care facilities or blasting areas.

Automobile Air Bags Do not place a mobile device in the air bag deployment area. Potentially Explosive Atmospheres Areas with potentially explosive atmospheres are often but not always posted, and can include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain, dust, or metal powders. When you are in such an area, turn off your mobile device, and do not remove, install, or charge batteries. In such areas, sparks can occur and cause an explosion or fire. Damaged Products If your mobile device or battery has been submerged in water, punctured, or subjected to a severe fall, do not use it until you take it to a Motorola Authorized Service Center. Do not attempt to dry it with an external heat source, such as a microwave oven. Batteries and Chargers If jewelry, keys, beaded chains, or other conductive materials touch exposed battery terminals, this could complete an electrical circuit (short circuit), become very hot, and could cause damage or injury. Be careful when handling a charged battery, particularly when placing it inside a pocket, purse, or other container with metal objects. Use only Motorola Original batteries and chargers. Caution: To avoid risk of personal injury, do not dispose of your battery in a fire.

Your battery, charger, or mobile device may contain symbols, defined as follows: Symbol 032374o Definition Important safety information follows. Do not dispose of your battery or mobile device in a fire. Your battery or mobile device may require recycling in accordance with local laws. Contact your local regulatory authorities for more information. Do not throw your battery or mobile device in the trash. 032376o Li Ion BATT 032378o Your mobile device contains an internal lithium ion battery. Do not let your battery, charger, or mobile device get wet. Listening at full volume to music or voice through a headset may damage your hearing. Choking Hazards Your mobile device or its accessories may include detachable parts, which may present a choking hazard to small children. Keep your mobile device and its accessories away from small children.

Glass Parts Some parts of your mobile device may be made of glass. This glass could break if the product is dropped on a hard surface or receives a substantial impact. If glass breaks, do not touch or attempt to remove. Stop using your mobile device until the glass is replaced by a qualified service center.

Seizures/Blackouts Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when playing video games. These may occur even if a person has never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult with your physician before playing video games or enabling a flashing-lights feature (if available) on your mobile device.

Discontinue use and consult a physician if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. It is always a good idea to hold the screen away from your eyes, leave the lights on in the room, take a 15-minute break every hour, and stop use if you are very tired. Caution About High Volume Usage Listening at full volume to music or voice through a headset may damage your hearing.

Repetitive Motion When you repetitively perform actions such as pressing keys or entering finger-written characters, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. If you continue to have discomfort during or after such use, stop use and see a physician. Information from the World Health Organization Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If you are concerned, you may want to limit your own or your children's RF exposure by limiting the length of calls or by using handsfree devices to keep mobile phones away from your head and body.



[You're reading an excerpt. Click here to read official MOTOROLA](http://yourpdfguides.com/dref/3771149)

[W218 user guide](http://yourpdfguides.com/dref/3771149)

<http://yourpdfguides.com/dref/3771149>

Source: WHO Fact Sheet 193 Further information: <http://www.who.int./peh-emf> Smart Practices While Driving Drive Safe, Call Smart SM Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas.

Go to www.motorola.com/callsmart for more information. Your mobile device lets you communicate by voice and data--almost anywhere, anytime, wherever wireless service is available and safe conditions allow. When driving a car, driving is your first responsibility. If you choose to use your mobile device while driving, remember the following tips: · Get to know your Motorola mobile device and its features such as speed dial and redial. If available, these features help you to place your call without taking your attention off the road. · When available, use a handsfree device. If possible, add an additional layer of convenience to your mobile device with one of the many Motorola Original handsfree accessories available today. · Position your mobile device within easy reach.

Be able to access your mobile device without removing your eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voice mail answer it for you. · Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions. @@@@ · Do not engage in stressful or emotional conversations that may be distracting. Make people you are talking with aware you are driving and suspend conversations that can divert your attention away from the road.

· Use your mobile device to call for help. Dial 911 or other local emergency number in the case of fire, traffic accident, or medical emergencies.* · Use your mobile device to help others in emergencies. If you see an auto accident, crime in progress, or other serious emergency where lives are in danger, call 911 or other local emergency number, as you would want others to do for you.* · Call roadside assistance or a special non-emergency wireless assistance number when necessary.

If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.* * Wherever wireless phone service is available. accessories Vehicle Power Headset Mono Adapter Hands-Free Headset One-Touch Stereo Travel Charger Headset 6809501A61-O 6802932J14 .



[You're reading an excerpt. Click here to read official MOTOROLA W218 user guide](http://yourpdfguides.com/dref/3771149)

<http://yourpdfguides.com/dref/3771149>