



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for NEC NEAX 2000 IPS. You'll find the answers to all your questions on the NEC NEAX 2000 IPS in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual NEC NEAX 2000 IPS
User guide NEC NEAX 2000 IPS
Operating instructions NEC NEAX 2000 IPS
Instructions for use NEC NEAX 2000 IPS
Instruction manual NEC NEAX 2000 IPS

NEC

NEAX 2000 IPS INTERNET PROTOCOL SERVER



Dterm Series i / Dterm IP
USER GUIDE



[You're reading an excerpt. Click here to read official NEC NEAX 2000 IPS user guide](http://yourpdfguides.com/dref/2311248)
<http://yourpdfguides.com/dref/2311248>

Manual abstract:

has prepared this document for use by its employees and customers. @@@@ Lamp lights steadily when a message has been left. LCD (Note 1) LCD (Liquid Crystal Display) provides Dterm activity information plus data, time and Soft Key Operation. The LCD has 24-character, 3-line capability. Exit The user can exit from the Help key mode by pressing this key. Soft Keys Any feature shown at the bottom of the LCD is available. The appropriate feature key is displayed on the screen according to the call handling process. Help Explanations of the Soft Keys can be called up on the LCD by pressing this key. 1 2 3 Exit Help 2 4 5 6 7 8 3 4 1 GHI ABC 2 DEF 3 6 Recall Feature Directory 9 10 Message 4 JKL 5 Conf Mic MNO PQRS 7 TUV 8 WXYZ 9 Redial OPER 0 # Transfer Answer 11 12 13 5 Hold Speaker 14 15 16 19 18 17 vii 6 Programmable Keys [Programmable by telephone system administrator (Flexible Line/Feature Keys)] · Station line access · Trunk line access · Feature access [Programmable by user (Flexible Line/One-Touch Speed Dial)] <Flexible Line> · Station line access · Trunk line access · Feature access <One-Touch Speed Dial> (Note 2) · Any feature can be assigned. · Direct station selection · Station speed dial Recall Press key to terminate established call and returns to the internal dial tone.

@@@@@ Press redial and scroll back through numbers that have been dialed. Until the desired number is displayed. Press the or # (Note 4) key to activate dialing. @@15 Up/Down (DOWN UP) Used to adjust LCD contrast, speaker/receiver volume, and ringer volume. · LCD Contrast: Press () or () key while idle.

· Speaker/Receiver Volume: Press () or () key during conversation. · Ringer Volume: Press () or () key during ringing. 16 Answer When LED on this key is lit, press key to answer a waiting call. 17 Speaker Controls the built-in speaker which can be used for Hands Free dialing/monitoring. LED on key lights when key is active.

* All standard IP versions include support for full duplex handsfree mode. All TDM and IP enabled versions are half duplex handsfree mode. 18 Transfer Allows the station user to transfer established calls to another station, without attendant assistance. 19 Hold Press key to place an internal or external call on hold. 7 8 9 10 Message (Note 3) Press key to access the voice mail system. * Not equipped on Dterm 4D IP. 11 Mic Press key to respond hands free. LED on this key lights during speakerphone operation. 12 Conf Press key to establish a three-way conversation. LED on key lights when key is active.

viii 20 Dterm IP Adapter Dterm IP adapter can be attached to Dterm Series i 8D/16D/32D terminals. It supports the same telephony service as the original Dterm terminal. 20 Note 1: Not applicable for Dterm 8. Note 2: Not applicable for Dterm 8/8D/16D. Note 3: Not available for Dterm 65/Dterm Series III mode, Dterm 75/Dterm Series E mode. (These keys must be enabled in system programming and must be used with the correct Firmware.) Dterm Series III/Dterm Series E: North America Dterm 65/Dterm 75: Australia, Asia, Latin America, Middle East, Russia Note 4: A-law Countries [Australia, Russia, Latin America, UK, Middle near East, other Asian nations]: # µ-law Countries [North America, Japan, Hong Kong, Taiwan]: ix Dterm16LD and Dterm16LD IP (16-LINE WITH MULTI-DISPLAY) 1 Call Indicator Lamp Lamp at top corner of Dterm Display flashes when a call terminates to the terminal. Lamp lights steadily when a message has been left. LCD (Note 1) LCD (Liquid Crystal Display) provides Dterm activity information plus data, time and Soft Key Operation. The LCD has 24-character, 3-line capability.

Exit The user can exit from the Help key mode by pressing this key. Soft Keys Any feature shown at the bottom of the LCD is available. The appropriate feature key is displayed on the screen according to the call handling process. Help Explanations of the Soft Keys can be called up on the LCD display by pressing this key. 2 D term Series i 1 2 3 3 Exit Help 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 4 5 6 21 4 20 1 GHI ABC 2 DEF 3 6 Recall Feature 7 8 9 Directory 5 4 JKL 5 Conf Mic MNO 10 Message 7 PQRS TUV 8 WXYZ 9 Redial OPER 0 # Transfer Answer 11 12 13 14 15 16 Hold Speaker 19 18 17 x 6 7 Programmable Keys [Programmable by telephone system administrator (Flexible Line/Feature Keys)] · Station line access · Trunk line access · Feature access [Programmable by user (Flexible Line)] <Flexible Line> · Station line access · Trunk line access · Feature access Recall Press key to terminate established call and returns to the internal dial tone.

@@@@@* Not equipped on Dterm 4D IP. Press the or # (Note 4) key to activate dialing. @@15 Up/Down (DOWN UP) Used to adjust LCD contrast, speaker/receiver volume, and ringer volume. · LCD Contrast: Press () or () key while idle. · Speaker/Receiver Volume: Press () or () key during conversation.

· Ringer Volume: Press () or () key during ringing. 16 Answer When LED on this key is lit, press key to answer a waiting call. 17 Speaker Controls the built-in speaker which can be used for Hands Free dialing/monitoring. LED on key lights when key is active. 18 Transfer Allows the station user to al or external call on hold. Transfer Allows the station user to transfer established calls to another station, without attendant assistance. Speaker Controls the built-in speaker which can be used for Hands Free dialing/monitoring. LED on key lights when key is active. Answer When LED on this key is lighted, press key to answer a waiting call. Redial Press key to activate redial feature.

Press redial and scroll back through numbers that have been dialed. Until the desired number is displayed. Press the * key to activate dialing. Conf Press key to establish a three-way conversation. LED on key lights when key is active. Recall Press key to terminate established call and resieze internal dial tone.

@@1 MIC Used to activate or deactivate the Microphone. The Mic LED will illuminate when Mic is on. Message To search Message Waiting. Directory Press key to display the directory of Dial by Name for Station Speed Dialing.

UP/DOWN Used to adjust LCD contrast, speaker/receiver volume, and ringer volume. LCD Contrast: Press up or down key while idle. Speaker/Receiver Volume: Press up or down key during conversation. Ringer Volume: Press up or down key during ringing. 2 Programmable Keys These are examples of Dterm® features available by pressing the programmable keys.

Some features may be programmed by the user. Keys must be programmed by the telephone system administrator.



[You're reading an excerpt. Click here to read official NEC NEAX](#)

[2000 IPS user guide](#)

<http://yourpdfguides.com/dref/2311248>

AICM Press key to activate Automatic Intercom. CB (Call Back) Press key to activate. DICM Press key to activate Dial Intercom. DND (Do Not Disturb) Press key to activate or cancel Privacy feature. FD-A (Call Forwarding- All Calls) Press key to activate or cancel Call Forwarding - All Calls feature. FD-B (Call Forwarding- Busy) Press key to activate, verify, or cancel Call Forwarding - Busy feature. FD-N (Call Forwarding- No Answer) Press key to activate, verify, or cancel Call Forwarding - No Answer feature. FD-DS (Call Forwarding- Destination Set) Press key to activate, Call Forwarding - Destination. FD-DC (Call Forwarding- Destination Cancel) Press key to deactivate, Call Forwarding - Destination. 3 MICM Press key to activate Manual Intercom. S&R (Save and Repeat) Press key to store a number or redial a stored number. SECONDARY APPEARANCE (Sub line) A programmable extra extension key, other than Primary extension. Press key to see status of extra extension.

Soft Keys (Factory Assigned Features) Headset Press the Soft Key below "Headset" to activate or deactivate Headset operation. Help Press the Help Key. Press desired Soft Key for helpful information about that key. Exit Press the Exit Key to exit the Help program. On Hook State (Telephone is idle) Off Hook State (Telephone is in use) 4 To Use Soft Keys Four soft keys are indicated in the LCD According to the status of the Multiline Terminal. Press the SCROLL (>>>) key to scroll the desired key if there are other functions available. Press a desired key under the indicated 4 Soft Keys on the LCD. The service feature of the pressed Soft Key is operated. To Use The Help Key Press the HELP key and the Soft Key. Explanation of the pressed Soft Key is indicated on the LCD.

Press the EXIT key to leave Help. 5 Lamps Call Indicator Lamp Lamp at top corner of Dterm Display flashes when a call terminates to the terminal. Lamp lights steadily when a message has been left. LCD Liquid Crystal Display (LCD) provides Dterm activity information plus date, time and Soft Key operation.

LED Some function keys have a built-in Light Emitting Diode (LED) that lights or flashes according to the activity of that function key.

MIC (Microphone) Lamp Lamp displays the status of the built-in microphone used for hands free operation. Feature Key Activities Feature + 1 = Turns microphone on or off. Feature + 3 = Selects ringer tone. Feature + 4 = Adjusts transmission/receiving volume. Feature + 0 = Activates ringer. (dependent on Systems Programming.) 6 LOGIN OPERATION (Dterm IP only) (1) Automatic Login Mode (Authentication by MAC Address) · When starting up the Dterm IP, the LCD displays the login screen. LOGIN: PASSWD: CANCEL BK SET OK · · · Enter the Station Number of the Dterm IP following "LOGIN:" Press the Set soft key. Press the OK soft key. The time and date appear on the LCD. Note: After the first registration, Login operation is not required. (2) Protected Login Mode · When starting up the Dterm IP, the LCD displays the login screen. LOGIN: PASSWD: CANCEL BK SET OK · · · Enter the Station Number of the Dterm IP following "LOGIN:" Press the Set soft key. Enter the password for initial setup following "PASSWD:" Press the OK soft key. The time and date appear on the LCD.

LOGOUT OPERATION (Dterm IP only) · · · Go off-hook or press the Speaker Key. Receive Dial Tone. Dial the Logout Feature Access Code or press the Logout Feature Access Key or Logout Soft Key. Receive Service Set Tone. The LCD displays the login screen. 7 TERMINAL SETUP WITH THE FEATURE KEY Microphone On/Off The MIC lamp shows the status of the built-in microphone. To change microphone status: · Press Soft Key associated with the MIC Display or press Feature and 1. To select ringer tone The Dterm Series i has 14 ringer tones that you can select. · Press Feature and 3. The LCD displays the selected tone number (n=1 ~ 14).

To adjust ringer tone NOTE: Access to feature is based on data assignment. · · · Press Feature and 0. Ringer activates. Press 3. The LCD displays the selected tone number (n=1~14).

Press 3. Next tone is selected. 8 To preset ringer volume NOTE: Access to feature is based on data assignment. · · · Press Feature and 0. Ringer activates. Press down or up Key. Ringer volume decreases or increases. Press Feature Key to stop ringing. TO ORIGINATE AN OUTSIDE CALL VIA EXTENSION LINE KEY · · · Lift handset or press Speaker key, receive dial tone. Dial the Central Office access code, e.g. 0. Dial desired telephone number. Use handset or MIC to converse. TO ORIGINATE AN INTERNAL CALL · · · Lift handset or press Speaker key.

Receive dial tone. Dial desired station number. Use handset or MIC to converse. OUTSIDE LINE APPEARANCE To originate: · · · Press the OUTSIDE LINE APPEARANCE dot; · · Lift handset or press Speaker key. Press DICM key. Dial desired intercom station number (0-9). Tone burst is sent. (Press 1 to change to ring tone signal. @@Tone burst or ring tone is heard. Press DICM.

Lift handset or press Speaker. LCD shows solid green. @@Enter up to the first four characters of a name using the keypad. Press the UP or DOWN key to start the search. The name and the number are shown on the LCD.

@@@@@Enter up to the first four characters of a name using the keypad. Press the UP or DOWN key to start the search. The name and the number are shown on the LCD. @@@@TO PLACE A CALL ON HOLD · Press Hold. Held line wink flashes.

@@To retrieve: · · Lift handset or press Speaker. Press held line. Use handset to converse. NOTE: Any station with this line appearance can retrieve the call.

@@@@15 NOTE: Hold shows as a flashing green LED on your phone. The same line on other phones shows as a flashing red LED. @@TO PLACE A CALL ON EXCLUSIVE HOLD · Press Hold twice. Line appearance indicates interrupted wink. @@To retrieve · · Lift handset or press Speaker. Press held line.

Use handset to converse. @@@@Exclusive Hold shows as a flashing green LED on your phone. @@Press Transfer key. Receive interrupted dial tone. @@Press Transfer, receive interrupted dial tone. Dial desired number. After call is answered, press Conf. Conf LED lights. Three-way conference is established. If one party hangs up, other two remain connected.

@@Caller is automatically placed on hold. Dial desired party to consult. Press Transfer to return to original caller. Third party is automatically placed on hold. @@@@Dial desired station number and receive busy tone or ring back tone.

Press Call Back or dial 2 and receive service set tone. Restore handset. @@Answer LED flashes. Press Answer. Call in progress is placed on hold. Connection to camped-on call is established.



[You're reading an excerpt. Click here to read official NEC NEAX](http://yourpdfguides.com/dref/2311248)

[2000 IPS user guide](http://yourpdfguides.com/dref/2311248)

<http://yourpdfguides.com/dref/2311248>

Press Answer to return to original call. Camped-on call is placed on hold. @@@@Depress Transfer button, feature dial tone is heard. Dial desired station number and receive busy tone. Dial 4 and receive service set tone. Camp-on tone (2 tone bursts) is sent to busy station. @@Station 2001 dials 2000, receives busy. Station 2001 can notify station 2000 that call is waiting. @@Receive dial tone.

Dial 2000 and receive busy. Press Transfer receive feature dial tone. Dial Camp-on (call waiting) access code. @@LCD display indicates CW and Answer button flashes. 2000 presses Answer button and converses with station 2001. @@Display shows HLD= (part location number nn=00-19). @@@@To retrieve a parked call: ··Dial Call Park local retrieval code and parked call location number (00-19). Station user is connected to parked call. CALL PICKUP (GROUP) When station within pickup group rings: ··Lift handset. Press CALL PICKUP or dial Call Pickup access code (may be stored on-one-touch speed calling key).

Connection to calling party is established. CALL PICKUP (DIRECT) ····Lift handset. Press Call Pickup Direct. Lift handset. Key or dial Call Pickup Direct access code (may be stored on one-touch key).

Dial extension number to be picked up. Connection to calling party is established. 20 OUTSIDE LINE QUEUING (FROM EXTENSION DIAL TONE) If outside line is busy ····Press Speaker of lift handset dial outgoing access code (e.g.9).

Receive Busy indication. Press Call Back key. Call is placed in queue for next available Outside Line. Replace handset. When Outside Line is available, setting station is alerted by ringing and flashing red LED. Press Speaker or lift handset. Dial tone is heard. Dial desired number. (No outgoing access code needed.) TIMED QUEUING (OUTSIDE LINE ONLY) ····Press Speaker, receive dial tone.

Dial Outside Line access code and desired number. Receive busy tone or ring no answer from distant end. Press Call Back key, LED flashes, leave speaker on. The desired number is automatically redialed. Pick up handset and converse. NOTE: When station is in Timed Queue mode callers receive busy indication. EXECUTIVE OVERRIDE If called station is busy: ·Press OVERRIDE key and converse. NOTE: Interrupted parties receive warning tone. 21 LAST NUMBER REDIAL To recall the last number dialed: ··Press Redial. Receive special dial tone.

Press #. The number dialed will be redialed and displayed. NOTE: Each time the Redial key is pressed the numbers dialed for the last five calls are displayed sequentially. CID CALL BACK To search, call back, or erase a Calling Number using soft-keys: ····Lift the handset or press Speaker key. Press MESSAGE key.

Press Search soft key to search for desired number. Press CB soft key to call back desired number. Press Erase soft key to erase desired number. To search, call back, or erase a Calling Number without using soft-keys: ····Lift the handset or press Speaker key. Press MESSAGE key.

Dial 1 to search for desired number. Dial 2 to call back desired number. Dial 3 to erase desired number. 22 CALL FORWARDING-ALL CALLS To Set: ····Press Speaker. Receive dial tone. Press FD-A or dial Call Forwarding access code. Receive special dial tone. Dial destination station or external telephone number. Receive service set tone. FWD LED lights (at your station if FD-A key was used).

Press Speaker. Call Forwarding for all calls is set. To verify (with 16 or 32-button Dterm): ··Press Speaker. Receive extension dial tone. Press FD-A or dial Call Forward-All access code. Display indicates the station number calls are forwarded to. ·NOTE: If recipient station is a 16- or 32-button Dterm, LCD displays: To cancel: ··Press Speaker. Receive dial tone. Press FD-A plus * or dial Call Forwarding cancel code. Receive service set tone.

LED goes out at your station (or the Dterm of the sub line station). Press Speaker. 23 CALL FORWARDING BUSY To set: ····Press Speaker. Receive dial tone. Press FD-B or dial Call Forwarding Busy access code.

Receive special dial tone. Dial destination station or external telephone number. Receive service set tone. FD-B LED lights (at your station or at the Dterm of the sub line station you are setting). Press Speaker.

Call Forwarding Busy is set. To verify (with Display Phone):) ···Press Speaker. Receive dial tone. Press FD-B or dial Call Forwarding Busy access code. Display indicates the station number calls are forwarded to. NOTE: If recipient station is a 16 or 32-button Dterm, LCD displays: To cancel: ··Press Speaker. Receive dial tone. Press FD-B plus * or dial Call Forwarding Busy cancel code. Receive service set tone. LED goes out at your station.

Press Speaker. Call Forwarding is canceled. 24 CALL FORWARDING -NO ANSWER To set: ····Press Speaker. Receive dial tone. Press FD-N or dial Call Forwarding No Answer access code. Receive special dial tone. Dial destination station or external telephone number. Receive service set tone. FD-N LED lights (at your station if FD-N key was used). Press Speaker.

Call Forwarding No Answer is set. To verify: ···Press Speaker. Receive extension dial tone. Press FD-N or dial Call Forwarding-No Answer access code. Display indicates destination number of call forward.

NOTE : Call Forwarding for Busy and No Answer may be combined depending upon system programming. CALL FORWARDING DESTINATION To set: ···Press Speaker. Receive dial tone. Press FD-DS or dial Call Forwarding Destination access code. Receive special dial tone.

Dial station number to be forwarded to this line. Wait for service set tone. 25 To cancel: ···Press Speaker. Receive dial tone. Press FD-DC or dial Call Forwarding Destination cancel code. Dial station number to cancel. Press Speaker. @@Receive dial tone. Press FD-L or dial Call Forwarding Logout access code. Receive special dial tone.

Dial destination station or external telephone number. "Set OK" is displayed. Receive service set tone. Press Speaker. @@Receive dial tone. Press FD-L or dial Call Forwarding Logout cancel code. Receive special dial tone. Call forwarding destination is displayed. Press *. "Reset OK" is displayed. Receive service set tone. @@Dial desired telephone number. Press S & R. Dialed number is now stored. S & R LED lights.

To repeat ···Press Speaker. Press S & R. Dterm automatically redials the programmed number. S & R automatically canceled. LED goes out. @@Example: Station A can page Station B.



[You're reading an excerpt. Click here to read official NEC NEAX](http://yourpdfguides.com/dref/2311248)

[2000 IPS user guide](http://yourpdfguides.com/dref/2311248)

<http://yourpdfguides.com/dref/2311248>

When Station B dials answer code, they are connected. @@Receive dial tone. @@Page Station B. Remain off hook. @@@@Ask calling party to hold. Press boss' line again. Voice Call is automatically established. Announce the call to the boss. If boss accepts call Secretary replaces handset.

Boss lifts handset, presses flashing line. @@@@Boss is connected to 2003. @@Press Boss' line. Outside line is placed on hold, Boss hears burst of tone and Boss' Answer key flashes. Boss · Hears burst of tone, Answer key flashes. LCD display indicates: Option 1 Boss presses Answer and converses with secretary.

Outside line is placed on hold. Secretary hangs up. Boss is connected to Outside line. Boss can alternate between the two parties by pressing Answer. Option 2 Boss does not respond to burst of tone, secretary presses Transfer key. Secretary is connected to Outside line. Option 3 Boss presses Answer and converses with Secretary. Outside line is placed on hold. Secretary is return to Outside line.

· · · · · 29 DO NOT DISTURB To set · · Press Speaker Receive dial tone. Press DND or dial DND access code. LED lights. To cancel · · Press Speaker Receive dial tone. Press DND.

LED goes out. TIMED REMINDER Example: Station 2000 wants to be reminded of a 9:00 a.m. meeting. To set · · · Press Speaker. Press Timed Reminder key or dial Timed Reminder access code. Dial the desired reminder time in military format, receive set tone. At 9:00 a.m. on the same day you will receive a reminder call.

Upon answering you will hear music source if available. To cancel · · · Press Speaker. Receive dial tone. Press Timed Reminder key and # or dial Timed Reminder access code. Receive set tone. Press Speaker key. 30 PRIVACY RELEASE Example: D term Station B is engaged in a conversation, and allows Dterm Station A to enter the call in progress. · · · Station 2000, while engaged in conversation, presses Conf key. Conf key flashes. Station 2001 lifts handset or presses Speaker.

Station 2001 presses the line appearance of Station 2000. A three-way conference is established. RETURN MESSAGE SCHEDULE NOTE: With Display Dterm Allows station user to register a return schedule when leaving the office and have the schedule display on the calling Dterm LCD. To set · · · Station Speaker. Receive dial tone.

Dial Return Schedule access code. Dial the number corresponding to desired message. Message IN:BACK OUT:BACK AWAY:BACK VACATION HH:MM HH:MM MM:DD MM:DD Dial 0 1 2 3 · · · If 0 or 1: dial desired military time. If 2 or 3: dial month and day. Example: June 24=0624.

Receive dial tone. Press Speaker. 31 To cancel · · · Press Speaker. Receive dial tone. Dial Return Message schedule cancel code. Receive set tone. Press Speaker. NOTE : Access to feature is based on data assignment. MESSAGE KEY To search, call back, or erase a Message using soft-keys: · · · · · Lift the handset or press Speaker key. Receive dial tone.

Press MESSAGE key, display shows: [MESSAGE XXXX 15:40], XXXX=Extension Number. Press 1 or Search soft key to scroll through messages if more than 1. Press 2 or CB soft key to call the desired number. Press 3 or Erase soft key to erase desired number. Replace handset or press Speaker key. 32 NAME

DISPLAY NOTE: Display Dterm A name with up to 8 characters can be entered to display the name on other Dterm telephones when making a call. · · · · · Press Speaker Receive dial tone. Dial the Name Assignment access code and receive special dial tone. Using the keypad, depress the key with the desired letter to display the first letter on the key. The display will indicate the numerical designation.

Subsequent depressions will advance through the letters on that key. The following TABLE can be used as a guide to indicate the key and the number of depressions required to display numbers, letters, spaces and periods. When the desired letter is displayed, depression of the Transfer key will change the letter to a lower case letter (default is upper case). Depress the Hold key to enter that letter and advance to the next entry. Repeat the previous two steps until the desired name is displayed and entered.

Press Speaker. For example, to enter "Paul": 33 Index A Account Code....

.....

.....

.....

.....

.....

.....

.... 11 Answering a Camped-on Call .

.....

.....

.....

.....

.. 18 Answering a Message...

.....

.....

.....

.....

.....

.. 32 Answering a Voice Call Hands Free

.....

.....

..... 12 Authorization Code.....

.....

.....

.....

.....

.....

.....

12 Automatic Intercom

.....

.....

.....

.....

.....

.... 12 B Boss/Secretary Calling.....

.....

.....

.....

.....

.....

... 28 Boss/Secretary Override ..

.....

.....

.....

.....

..... 28 Broker Call, Establishing .

.....

.....

.....

.....

.....

17 C Call Back

.....

.....

.....

.....

.....

.....

.....

.....

18 Call Forwarding All Calls

.....

.....

.....

.....

... 23 Call Forwarding Busy Line

.....

.....

.....

..... 24 Call Forwarding No Answer ..

.....

.....

.....

.....

. 25 Call Forwarding Destination

.....

.....

.....

.... 25 Call Park.....

.....
.....
.....

.....
.....
.....
.....

.....
19 Call Pick-up (Direct)

.....
.....

.....
.....
.....

..... 20 Call Pick-up (Group)..

.....
.....
.....
.....

.....
.....

. 20 Call Transfer....

.....
.....
.....
.....
.....

.....
.....

. 17 Call Waiting Originating....

.....
.....
.....

.....
.....

..... 19 Camped-on Call, Answering

.....
.....
.....
.....

. 18 Conference.....

.....
.....
.....

.....
.....
.....
.....

... 17 D Dial Intercom

.....
.....
.....

.....
.....

.....
.....

.. @@@@20 Exit

.....
.....
.....

.....
.....
.....

.....
.....

. 5, 8 F Forced Account Code

.....
.....
.....
.....

. 11 Function Keys and Lamps

.....
.....
.....

..... 1 H Headset Key.

.....
.....
.....
.....
.....
.....

..... 4 Help.

.....
.....
.....
.....
.....
.....

.....
.....
.....

.. @@@@22 Logged Out IP Station Call Destination

..... 26 Login/Logout (IP Enabled Dterm Only)...

.....
.....

..... @13 Meet-me Paging..

.....
.....
.....
.....

.....
.....
.....

.. 27 Message Key

.....
.....
.....

.....
.....
.....
32 Microphone Key

.....
.....
.....

.....
.... 8 34 N Name Display .
.....

.....
.....
.....

.....
.. 33 Number Save and Repeat..
.....

.....
.....
.....

. 27 O Off-hook Trunk Queuing.....

.....
.....
.....

... 49 Originating a Call Using Speed Calling (Individual/Group).....
.....
.....

.....
.....
.....

..... 11 Originating a Call Using Speed Calling (One-touch Buttons).....

.....
.....
.....

.....
... 10 Originating an Internal Call..
.....

.....
.....
.....

. 9 Originating an Outside Call

.....

.....
.....
.....
..... 9 Originating a Voice Call..

.....
.....
.....
.....

.....
.....
.....
..... 12 Outside Line Appearance....

.....
.....
.....
.....

.....
.....
.....
.....
..... 9 P Placing a Call on Exclusive Hold.....

.....
.....
.....
.....

.....
.....
.....
..... 16 Placing a Call on Hold.....

.....
.....
.....
.....

..... 15 Privacy Release

.....
.....
.....
.....

.....
.....
.....
.....

..... 31 R Return Message Schedule.

.....
.....
.....
.....

..... 31 S Saving and Repeating a Number...

.....
.....
.....
.....

..... 27 Speed Calling System.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 14 Speed Calling Call Origination (Individual/Group) ...

.....
.....
.....
.....

..... 11 Speed Calling Call Origination (One-touch Buttons)..

.....
.....
.....
.....

Logout Press preassigned Logout button to logout. O OG-Q SET Outgoing Trunk Queue call placed in queue for next available outgoing trunk 37 LCD Indication (continued) OVERRIDE X Overriding intercom call through bridging Automatic Intercom Dial Intercom Manual Intercom OVERRIDE Executive Override XXXX S SPEED SET Speed Calling number saved in memory T TRANSFER Ready to transfer a call TRANSFER XXXX Transferred station or trunk number Page Call Transfer TRANSFER XXXX X Transferring station number TRANSFER 3 Transferring page call to another station T/R VOL. SMALL/LARGE Transmission Receiving Volume status P PICK UP XXXX X Call Pickup of station within group showing called and calling stations PAGING X or PAGING DDD X Ready to page station, page waiting or page call connection P-RLS SET Privacy Release set P-RLS ? Prompt requesting privacy release for incoming call PRIVACY SET/CANCEL Privacy set or cancelled V VOICE XXXX Voice Call showing called or calling station number VOICE BUSY/REST Voice Call station called is busy or restricted R RCV VOL. SMALL/LARGE Receiver Volume status RINGER TONE X Ready for Ringer tone selection W WAIT P-RLS? Prompt when requesting privacy release at another station 38 The material contained herein is subject to change without prior notice at the sole discretion of NEC Business Solutions Ltd. Stock #: 4392813 Issue 3 October 2004 Copyright ©2004 NEC Business Solutions Ltd Document No. AD-29000801 Doc ID: NEC-7596 .



[You're reading an excerpt. Click here to read official NEC NEAX 2000 IPS user guide](http://yourpdfguides.com/dref/2311248)
<http://yourpdfguides.com/dref/2311248>