



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for ONKYO TX-SR508. You'll find the answers to all your questions on the ONKYO TX-SR508 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual ONKYO TX-SR508**  
**User guide ONKYO TX-SR508**  
**Operating instructions ONKYO TX-SR508**  
**Instructions for use ONKYO TX-SR508**  
**Instruction manual ONKYO TX-SR508**

**ONKYO®**

**AV Receiver**

***TX-SR508***

**Instruction Manual**

Thank you for purchasing an Onkyo AV Receiver. Please read this manual thoroughly before making connections and plugging in the unit. Following the instructions in this manual will enable you to obtain optimum performance and listening enjoyment from your new AV Receiver. Please retain this manual for future reference.

**Contents**

- Introduction .....2
- Connections.....11
- Turning On & Basic Operations .....20
- Advanced Operations .....34
- Controlling iPod & Other Components .....49
- Others.....56





[You're reading an excerpt. Click here to read official ONKYO TX-SR508 user guide](http://yourpdfguides.com/dref/2461179)

<http://yourpdfguides.com/dref/2461179>

**Manual abstract:**

*REFER SERVICING TO QUALIFIED SERVICE PERSONNEL. The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons. The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance. Important Safety Instructions 1. 2. 3. 4. 5. 6. 7.*

*8. Read these instructions. Keep these instructions. Heed all warnings. Follow all instructions.*

*Do not use this apparatus near water. Clean only with dry cloth. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. @@@@Only use attachments/accessories specified by the manufacturer. @@@@Unplug this apparatus during lightning storms or when unused for long periods of time. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped. 15. Damage Requiring Service Unplug the apparatus from the wall outlet and refer servicing to qualified service personnel under the following conditions: A.*

*When the power-supply cord or plug is damaged, B. If liquid has been spilled, or objects have fallen into the apparatus, C. If the apparatus has been exposed to rain or water, D. If the apparatus does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the apparatus to its normal operation, E. If the apparatus has been dropped or damaged in any way, and F. When the apparatus exhibits a distinct change in performance this indicates a need for service. 16. Object and Liquid Entry Never push objects of any kind into the apparatus through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. The apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases shall be placed on the apparatus.*

*Don't put candles or other burning objects on top of this unit. 17. Batteries Always consider the environmental issues and follow local regulations when disposing of batteries. 18. If you install the apparatus in a built-in installation, such as a bookcase or rack, ensure that there is adequate ventilation. Leave 20 cm (8") of free space at the top and sides and 10 cm (4") at the rear. The rear edge of the shelf or board above the apparatus shall be set 10 cm (4") away from the rear panel or wall, creating a flue-like gap for warm air to escape. 9. 10. 11.*

*12. 13. 14. En 2 Precautions 1. Recording Copyright--Unless it's for personal use only, recording copyrighted material is illegal without the permission of the copyright holder. 2. AC Fuse--The AC fuse inside the unit is not user-serviceable. If you cannot turn on the unit, contact your Onkyo dealer. 3. Care--Occasionally you should dust the unit all over with a soft cloth.*

*For stubborn stains, use a soft cloth dampened with a weak solution of mild detergent and water. Dry the unit immediately afterwards with a clean cloth.*

*Don't use abrasive cloths, thinners, alcohol, or other chemical solvents, because they may damage the finish or remove the panel lettering. 4. Power WARNING BEFORE PLUGGING IN THE UNIT FOR THE FIRST TIME, READ THE FOLLOWING SECTION CAREFULLY. AC outlet voltages vary from country to country. Make sure that the voltage in your area meets the voltage requirements printed on the unit's rear panel (e.g., AC 230 V, 50 Hz or AC 120 V, 60 Hz). The power cord plug is used to disconnect this unit from the AC power source.*

*Make sure that the plug is readily operable (easily accessible) at all times. Pressing ON/STANDBY to select Standby mode does not fully shutdown the unit. If you do not intend to use the unit for an extended period, remove the power cord from the AC outlet. Preventing Hearing Loss Caution Excessive sound pressure from earphones and headphones can cause hearing loss. Batteries and Heat Exposure Warning Batteries (battery pack or batteries installed) shall not be exposed to excessive heat as sunshine, fire or the like.*

*Never Touch this Unit with Wet Hands--Never handle this unit or its power cord while your hands are wet or damp. If water or any other liquid gets inside this unit, have it checked by your Onkyo dealer. Handling Notes · If you need to transport this unit, use the original packaging to pack it how it was when you originally bought it. · Do not leave rubber or plastic items on this unit for a long time, because they may leave marks on the case. · This unit's top and rear panels may get warm after prolonged use.*

*This is normal. · If you do not use this unit for a long time, it may not work properly the next time you turn it on, so be sure to use it occasionally. For U.S. models FCC Information for User CAUTION: The user changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: · Reorient or relocate the receiving antenna.*

*· Increase the separation between the equipment and receiver. · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.*



**[You're reading an excerpt. Click here to read official ONKYO TX-SR508 user guide](http://yourpdfguides.com/dref/2461179)**  
<http://yourpdfguides.com/dref/2461179>







.....  
.....  
.....

... 29 Selecting Listening Modes ..

.....  
.....

.....  
.....  
.....

..... 29 About Listening Modes.....

.....  
.....  
.....  
.....

.....  
.....

30 Others Troubleshooting .....

.....  
.....  
.....  
.....  
.....

.....  
.....

. 56 Specifications .....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

. 60 Abod -Compatible Remote Manufactured under license from Audyssey Laboratories<sup>TM</sup>. U.S. and foreign patents pending. Audyssey 2EQ<sup>®</sup>, Audyssey Dynamic Volume<sup>TM</sup> and Audyssey Dynamic EQ<sup>TM</sup> are trademarks of Audyssey Laboratories. \* \* Apple and iPod are trademarks of Apple Inc., registered in the U.S. and other countries.

"x.v.Color" is a trademark of Sony Corporation. En 6 Front & Rear Panels Front Panel North American models European and Asian models The actual front panel has various logos printed on it. They are not shown here for clarity. The page numbers in parentheses show where you can find the main explanation for each item. TUNING, PRESET ( 25 to 26), arrow and ON/STANDBY button ( 20) ENTER buttons STANDBY indicator ( 20) HDMI THRU indicator ( 42) ZONE 2 indicator ( 47) Remote control sensor ( 4) ZONE 2, OFF, ZONE 2 LEVEL/TONE LEVEL and TONE buttons ( 45, 47 to 48) Display ( 8) LISTENING MODE buttons ( 29) DIMMER button (North American models) ( 21) MEMORY button ( 26) TUNING MODE button ( 25) DISPLAY button ( 21) SETUP button ( 34) RETURN button MASTER VOLUME control ( 21) MUSIC OPTIMIZER button (North American models) ( 21, 43) PHONES jack ( 22) Input selector buttons ( 21) AUX INPUT LINE IN jack ( 17) AUX INPUT VIDEO jack ( 17) AUX INPUT AUDIO jacks ( 17) SETUP MIC jack ( 23) PURE AUDIO button and indicator (European and Asian models) ( 29) RT/PTY/TP button (European and Asian models) ( 26) En 7 Display For detailed information, see the pages in parentheses. Audio input indicators Listening mode and format indicators ( 21, 29) Audyssey indicators ( 23, 38) Tuning indicators ( 25) RDS indicator (excluding North American models) ( 26) SLEEP indicator ( 22) MUTING indicator ( 22) Message area Rear Panel DIGITAL IN COAXIAL and OPTICAL jacks HDMI IN and OUT jacks COMPONENT VIDEO IN and OUT jacks FM ANTENNA jack and AM ANTENNA terminal MONITOR OUT V jack UNIVERSAL PORT jack SPEAKERS terminals (CENTER, FRONT, SURR, SURR BACK OR FRONT HIGH) Power cord REMOTE CONTROL jack SIRIUS antenna jack (North American models) Composite video and analog audio jacks (BD/DVD IN, VCR/DVR IN and OUT, CBL/SAT IN, GAME IN, TV/CD IN) ZONE 2 LINE OUT jacks SUBWOOFER PRE OUT jack FRONT HIGH OR ZONE 2 SPEAKERS terminals See "Connecting the AV Receiver" for connection information ( 11 to 19). En 8 Remote Controller Controlling the AV Receiver To control the AV receiver, press RECEIVER to select Receiver mode. You can also use the remote controller to control Onkyo Blu-ray Disc/DVD player, CD player, and other components.

See "Entering Remote Control Codes" for more details ( 53). \*1 For detailed information, see the pages in parentheses. ON/STANDBY button ( 20) REMOTE MODE/INPUT SELECTOR buttons ( 21) SP LAYOUT button ( 22) \*2 Arrow / / / and ENTER buttons SETUP button ( 34) LISTENING MODE buttons ( 29) DIMMER button ( 21) DISPLAY button ( 21) MUTING button ( 22) VOL / button ( 21) RETURN button AUDIO button ( 43) SLEEP button ( 22) Controlling the tuner To control the AV receiver's tuner, press TUNER (or RECEIVER).



[You're reading an excerpt. Click here to read official ONKYO TX-SR508 user guide](http://yourpdfguides.com/dref/2461179)  
<http://yourpdfguides.com/dref/2461179>

You can select AM or FM by pressing TUNER repeatedly. Arrow / buttons ( 25) D.

TUN button ( 25) DISPLAY button CH +/- button ( 26) Number buttons ( 25) \*1 \*2 To control component, you must first enter remote control code. See "Entering Remote Control Codes" for more details ( 53). VIDEO is not used for this model. En 9 About Home Theater Enjoying Home Theater Thanks to the AV receiver's superb capabilities, you can enjoy surround sound with a real sense of movement in your own home--just like being in a movie theater or concert hall. With Blu-ray Discs, you can enjoy DTS and Dolby Digital.

With analog or digital TV, you can enjoy Dolby Pro Logic IIx, DTS Neo:6, or Onkyo's original DSP listening modes. Front speakers These output the overall sound. Their role in a home theater is to provide a solid anchor for the sound image. They should be positioned facing the listener at about ear level, and equidistant from the TV. Angle them inward so as to create a triangle, with the listener at the apex. Center speaker This speaker enhances the front speakers, making sound movements distinct and providing a full sound image. In movies it's used mainly for dialog. Position it close to your TV facing forward at about ear level, or at the same height as the front speakers. Surround speakers These speakers are used for precise sound positioning and to add realistic ambience. Position them at the sides of the listener, or slightly behind, about 2 to 3 feet (60 to 100 cm) above ear level.

Ideally they should be equidistant from the listener. Surround back speakers These speakers are necessary to enjoy Dolby Digital EX, DTS-ES Matrix, DTS-ES Discrete, etc. They enhance the realism of surround sound and improve sound localization behind the listener. Position them behind the listener about 2 to 3 feet (60 to 100 cm) above ear level. Front high speakers These speakers are necessary to enjoy Dolby Pro Logic IIz Height, etc. They enhance significantly the spatial experience. Position them at least 3.3 feet (100 cm) above the front speakers (and as high as possible). Although it is acceptable to left and right place at an angle slightly wider than the front speakers. Ideally they should be positioned directly above the front speakers.

Subwoofer The subwoofer handles the bass sounds of the LFE (Low-Frequency Effects) channel. The volume and quality of the bass output from your subwoofer will depend on its position, the shape of your listening room, and your listening position. In general, a good bass sound can be obtained by installing the subwoofer in a front corner, or at one-third the width of the wall, as shown. Corner position 1/3 of wall position Tip · To find the best position for your subwoofer, while playing a movie or some music with good bass, experiment by placing your subwoofer at various positions within the room, and choose the one that provides the most satisfying results. En 10 Connecting the AV Receiver Connecting Your Speakers Speaker Configuration The following table indicates the channels you should use depending on the number of speakers that you have.

For 7.1-channel surround-sound playback, you need seven speakers and a powered subwoofer. Number of channels Front speakers Center speaker Surround speakers Surround back speaker\*1\*2 Surround back speakers\*2 Front high speakers\*2 \*1 \*2 Speaker Connection Precautions Read the following before connecting your speakers: · (North American models) You can connect speakers with an impedance of between 6 and 16 ohms. If you use speakers with a lower impedance, and use the amplifier at high volume levels for a long period of time, the builtin amp protection circuit may be activated. · (European and Asian models) You can connect speakers with an impedance of between 4 and 16 ohms.

If the impedance of any of the connected speakers is 4 ohms or more, but less than 6 ohms, be sure to set the minimum speaker impedance to "4ohms" ( 40). If you use speakers with a lower impedance, and use the amplifier at high volume levels for a long period of time, the builtin protection circuit may be activated. · Disconnect the power cord from the wall outlet before making any connections. · Read the instructions supplied with your speakers. · Pay close attention to speaker wiring polarity. In other words, connect positive (+) terminals only to positive (+) terminals, and negative (-) terminals only to negative (-) terminals. If you get them the wrong way around, the sound will be out of phase and will sound unnatural. · Unnecessarily long, or very thin speaker cables may affect the sound quality and should be avoided. · Be careful not to short the positive and negative wires. Doing so may damage the AV receiver.

· Make sure the metal core of the wire does not have contact with the AV receiver's rear panel. Doing so may damage the AV receiver. 234567789 If you're using only one surround back speaker, connect it to the SURR BACK OR FRONT HIGH L terminals. Front high and surround back speakers cannot be used at the same time. If you use 4 or 5 speakers, connect each of the two surround speakers to the SURR L/R terminals. Do not connect them to the SURR BACK OR FRONT HIGH L/R or FRONT HIGH OR ZONE 2 L/R terminals. No matter how many speakers you use, a powered subwoofer is recommended for a really powerful and solid bass. To get the best from your surround sound system, you need to set the speaker settings. You can do this automatically ( 23) or manually ( 36). Attaching the Speaker Cable Labels The AV receiver's positive (+) speaker terminals are all red.

(The negative (-) speaker terminals are all black.) Speaker Front left, Zone 2 left, Front high left Front right, Zone 2 right, Front high right Center Surround left Surround right Surround back left Surround back right Color White Red Green Blue Gray Brown Tan The supplied speaker cable labels are also color-coded and you should attach them to the positive (+) side of each speaker cable in accordance with the table above. Then all you need to do is to match the color of each label to the corresponding speaker terminal. En 11 · Don't connect more than one cable to each speaker terminal. Doing so may damage the AV receiver.

· Don't connect one speaker to several terminals. Connecting the Speaker Cables Screw-type speaker terminals Strip 1/2" to 5/8" (12 to 15 mm) of insulation from the ends of the speaker cables, and twist the bare wires tightly, as shown. 1/2" to 5/8" (12 to 15 mm) Using Banana Plugs (North American models) · If you are using banana plugs, tighten the speaker terminal before inserting the banana plug. · Do not insert the speaker code directly into the center hole of the speaker terminal. Push-type speaker terminals Strip 3/8" to 1/2" (10 to 12 mm) of insulation from the ends of the speaker cables, and twist the bare wires tightly, as shown.



[You're reading an excerpt. Click here to read official ONKYO TX-SR508 user guide](http://yourpdfguides.com/dref/2461179)

<http://yourpdfguides.com/dref/2461179>

3/8" to 1/2" (10 to 12 mm) The following illustration shows which speaker should be connected to each pair of terminals. If you're using only one surround back speaker, connect it to the SURR BACK OR FRONT HIGH L terminals. Surround back right speaker Surround back left speaker Surround right speaker Surround left speaker En 12 Front high right speaker Front high left speaker Front right speaker Front left speaker Center speaker Connecting a Powered Subwoofer Using a suitable cable, connect the AV receiver's SUBWOOFER PRE OUT jack to an input on your powered subwoofer, as shown. If your subwoofer is unpowered and you're using an external amplifier, connect the SUBWOOFER PRE OUT jack to an input on the amp. L NE PUT LINE INPUT Powered subwoofer Bi-amping the Front Speakers The FRONT L/R and SURR BACK OR FRONT HIGH L/R terminal posts can be used with front speakers and surround back speakers respectively, or biamped to provide separate tweeter and woofer feeds for a pair of front speakers that support bi-amping, providing improved bass and treble performance. · When bi-amping is used, the AV receiver is able to drive up to a 5.1 speaker system in the main room. · For bi-amping, the FRONT L/R terminal posts connect to the front speakers' woofer terminals; the SURR BACK OR FRONT HIGH L/R terminal posts connect to the front speakers' tweeter terminals. · Once you've completed the bi-amping connections shown below and turned on the AV receiver, you must set the "Speakers Type" setting to "Bi-AMP" to enable bi-amping ( 40). Right speaker Left speaker Tweeter (high) Woofer (low) Important: · When making the bi-amping connections, be sure to remove the jumper bars that link the speakers' tweeter (high) and woofer (low) terminals.

· Bi-amping can be used only with speakers that support bi-amping. Refer to your speaker manual. En 13 About AV Connections Connected image with AV components HDMI cable : Video & Audio Other cables : Video : Audio AV receiver AV receiver TV, projector, etc. Blu-ray Disc/ DVD player Game console TV, projector, etc. Blu-ray Disc/ DVD player Game console · Before making any AV connections, read the manuals supplied with your AV components. · Don't connect the power cord until you've completed and double-checked all AV connections. · Push plugs in all the way to make good connections (loose connections can cause noise or malfunctions). · To prevent interference, keep audio and video cables away from power cords and speaker cables. Right! AV Cables and Jacks Signal Video and Audio Video Cable HDMI Component video Jack HDMI Wrong! Description HDMI connections can carry digital video and audio. The AV receiver is compliant with HDMI.

Component video separates the luminance (Y) and color difference signals (PB/CB, PR/CR), providing the best picture quality (some TV manufacturers label their component video sockets slightly differently). Composite video is commonly used on TVs, VCRs, and other video equipment. Optical digital connections allow you to enjoy digital sound such as PCM\*, Dolby Digital or DTS. The audio quality is the same as coaxial. Coaxial digital connections allow you to enjoy digital sound such as PCM\*, Dolby Digital or DTS.

The audio quality is the same as optical. Analog audio connections (RCA) carry analog audio. Y PB/CB PR/CR Green Blue Red V Composite video Audio Optical digital audio Coaxial digital audio Analog audio (RCA) 1/8" (3.5 mm) Stereo mini plug \* L Yellow OPTICAL Orange White Red R This cable carries analog audio. Available sampling rate for PCM input signal is 32/44.

1/48/88.2/96 kHz. Even 176.4/192 kHz is effective in case of the HDMI connection. Note · The AV receiver does not support SCART plugs. · The AV receiver's optical digital jacks have shutter-type covers that open when an optical plug is inserted and close when it's removed. Push plugs in all the way. Caution · To prevent shutter damage, hold the optical plug straight when inserting and removing. En 14 Connecting Components with HDMI VCR or DVD recorder/Digital Video Recorder Game console TV, projector, etc. Satellite, cable, set-top box, etc.

Blu-ray Disc/DVD player Connect your components to the appropriate jacks. The default input assignments are shown below. : Assignment can be changed ( 35). Jack Input HDMI IN1 HDMI IN2 HDMI IN3 HDMI IN4 Output HDMI OUT Signal Audio/Video Components Blu-ray Disc/DVD player VCR or DVD recorder/Digital Video Recorder Satellite, cable, set-top box, etc. Game console TV, projector, etc. Assignable Refer to "About HDMI" ( 61) and "Using an RIHD-compatible TV, Player, or Recorder" ( 62). Tip To listen to audio received by the HDMI IN jacks through your TV's speakers: · · · · Set the "TV Control" setting to "On" ( 42) for an -compatible TV. Set the "Audio TV OUT" setting to "On" ( 41) when the TV is not compatible with or the "TV Control" setting to "Off". Set your Blu-ray Disc/DVD player's HDMI audio output setting to PCM. To listen to TV audio through the AV receiver, see "Connecting External Components" ( 16).

Note · When listening to an HDMI component through the AV receiver, set the HDMI component so that its video can be seen on the TV screen (on the TV, select the input of the HDMI component connected to the AV receiver). If the TV power is off or the TV is set to another input source, this may result in no sound from the AV receiver or the sound may be cut off. · When the "Audio TV OUT" setting is set to "On" ( 41) to hear from your TV's speakers, by controlling the AV receiver's volume, the sound will be output from the AV receiver's speakers, too. When the "TV Control" setting is set to "On" ( 42) to hear from speakers of -compatible TV, by controlling the AV receiver's volume, the AV receiver's speakers will produce sound while the TV's speakers are muted. To stop the AV receiver's speakers producing sound, change the settings, change your TV's settings, or turn down the AV receiver's volume.

Audio return channel (ARC) function Audio return channel (ARC) function enables an HDMI capable TV to send the audio stream to the HDMI OUT of the AV receiver. To use this function, you must select the TV/CD input selector. · To use ARC function, you must select the TV/CD input selector, your TV must support ARC function and "HDMI Control" is set to "On" ( 42). En 15 Connecting External Components The on-screen setup menus appear only on a TV that is connected to the HDMI OUT.



[You're reading an excerpt. Click here to read official ONKYO TX-](http://yourpdfguides.com/dref/2461179)

[SR508 user guide](http://yourpdfguides.com/dref/2461179)

<http://yourpdfguides.com/dref/2461179>

If your TV is connected to the MONITOR OUT V or the COMPONENT VIDEO OUT, use the AV receiver's display when changing settings.

Connect your components to the appropriate jacks. The default input assignments are shown below. : Assignment can be changed ( 35). No. Jack COMPONENT VIDEO DIGITAL IN IN 1 (BD/DVD) IN 2 (CBL/SAT) OUT OPTICAL COAXIAL MONITOR OUT BD/DVD IN VCR/DVR IN CBL/SAT IN GAME IN TV/CD IN UNIVERSAL PORT Analog audio Analog audio/ Video IN 1 (GAME) IN 2 (TV/CD) IN 1 (BD/DVD) IN 2 (CBL/SAT) Composite video Digital audio Signal Component video Components Blu-ray Disc/DVD player Satellite, cable, set-top box, etc. TV, projector, etc. Game console TV, CD player Blu-ray Disc/DVD player Satellite, cable, set-top box, etc. TV, projector, etc. Assignable Analog audio Blu-ray Disc/DVD player and composite VCR or DVD recorder/Digital video Video Recorder Satellite, cable, set-top box, etc. Game console TV, CD player, Turntable\*1 Cassette tape deck, MD, CD-R Universal port optional dock (UP-A1 etc.

) \*1 Connect a turntable (MM) that has a phono preamp built-in. If your turntable (MM) doesn't have it, you'll need a commercially available phono preamp. If your turntable has a moving coil (MC) type cartridge, you'll need a commercially available MC head amp or MC transformer as well as a phono preamp. See your turntable's manual for details. · With connection , you can listen and record audio from the external components while you are in Zone 2. You can listen and record audio from the external components in the main room; you can listen to the audio in Zone 2 as well. · With connection , you can enjoy Dolby Digital and DTS. (To record or listen in Zone 2 as well, use and .) · If your Blu-ray Disc/DVD player has both the main stereo and multichannel outputs, be sure to connect the main stereo output using connection . How to record the video With the connections described above, you cannot record the video through the AV receiver.

To make a connection for video recording ( 28). En 16 Using the AUX INPUT jacks on the front panel Analog audio line output ( 14) Composite video output Analog audio L/R outputs Portable audio player Note Camcorder, etc. · When you connect to both AUX INPUT AUDIO jacks and AUX INPUT LINE IN jack at the same time, AUX INPUT LINE IN jack will be given a higher priority. · The AV receiver can output audio and video signals from the AUX INPUT jacks to the VCR/DVR OUT jacks. Connecting Onkyo Components Note · Use only cables for connections.

cables are supplied with Onkyo players (DVD, CD, etc.). · Some components have two jacks. You can connect either one to the AV receiver. The other jack is for connecting additional -capable components.

· Connect only Onkyo components to jacks. Connecting other manufacturer's components may cause a malfunction. · Some components may not support all functions. Refer to the manuals supplied with your other Onkyo components. · While Zone 2 is on, the System On/Auto Power On and Direct Change functions do not work. IN L R TV/CD Step 1: Make sure that each Onkyo component is connected with an analog audio cable (connection in the hookup examples) ( 16). Step 2: Make the connection (see illustration below). Step 3: If you're using an RI Dock, or cassette tape deck, change the Input Display ( 22). With (Remote Interactive), you can use the following special functions: System On/Auto Power On When you start playback on a component connected via , if the AV receiver is on Standby, it will automatically turn on and select that component as the input source. Direct Change When playback is started on a component connected via , the AV receiver automatically selects that component as the input source.

Remote Control You can use the AV receiver's remote controller to control your other -capable Onkyo components, pointing the remote controller at the AV receiver's remote control sensor instead of the component. You must enter the appropriate remote control code first ( 53). IN L REMOTE CONTROL R BD/DVD e.g., CD player R L ANALOG AUDIO OUT e.g., DVD player R L ANALOG AUDIO OUT En 17 Connecting Antenna This section explains how to connect the supplied indoor FM antenna and AM loop antenna. The AV receiver won't pick up any radio signals without any antenna connected, so you must connect the antenna to use the tuner. North American models European and Asian models Insert the plug fully into the jack. Insert the plug fully into the jack. Push. Insert wire. Release. Assembling the AM loop antenna Thumbtacks, etc. Indoor FM antenna (supplied) AM loop antenna (supplied) Caution · Be careful that you don't injure yourself when using thumbtacks.

Note · Once your AV receiver is ready for use, you'll need to tune into a radio station and position the antenna to achieve the best possible reception. · Keep the AM loop antenna as far away as possible from your AV receiver, TV, speaker cables, and power cords. Tip · If you cannot achieve good reception with the supplied indoor FM antenna, try a commercially available outdoor FM antenna instead. · If you cannot achieve good reception with the supplied indoor AM loop antenna, try using it with a commercially available outdoor AM antenna. En 18 Which Connections Should I Use? The AV receiver supports several connection formats for compatibility with a wide range of AV equipment.

The format you choose will depend on the formats supported by your components. Use the following sections as a guide. The on-screen setup menus appear only on a TV that is connected to the HDMI OUT. If your TV is connected to the MONITOR OUT V or the COMPONENT VIDEO OUT, use the AV receiver's display when changing settings. Note The on-screen setup menus are displayed when: · There is no video input, or · The video input is 480p, 576p, 720p, 1080i, or 1080p. Video Connection Formats Video component can be connected by using any one of the following video connection formats: composite video, component video, or HDMI, the latter offering the best picture quality. When choosing a connection format, bear in mind that the AV receiver doesn't convert between formats, so only outputs of the same format as the input will output the signal. Composite Video Signal Flow Chart Blu-ray Disc/DVD player, etc. Component HDMI IN AV receiver MONITOR OUT Composite Component HDMI TV, projector, etc. Audio Connection Formats Audio component can be connected by using any of the following audio connection formats: analog, optical, coaxial, or HDMI.

When choosing a connection format, bear in mind that the AV receiver does not convert digital input signals for analog line outputs and vice versa. For example, audio signals connected to an optical or coaxial digital input are not output by the analog VCR/DVR OUT.



[You're reading an excerpt. Click here to read official ONKYO TX-SR508 user guide](http://yourpdfguides.com/dref/2461179)

<http://yourpdfguides.com/dref/2461179>

If signals are present at more than one input, the inputs will be selected automatically in the following order of priority: HDMI, digital, analog. \*1 \*2 Audio Signal Flow Chart Blu-ray Disc/DVD player, etc. Analog Optical Coaxial HDMI IN AV receiver \*1 Analog \*1 OUT \*1 HDMI \*1 \*2 TV, projector, etc. Depends on the "Audio TV OUT" setting ( 41). This setting is available, when "Audio Return Ch" setting is set to "Auto" ( 42), you must select the TV/CD input selector and your TV must support ARC function. En 19 Turning On/Off the AV Receiver ON/STANDBY STANDBY indicator ON/STANDBY RECEIVER Front panel Remote controller Turning On Press ON/STANDBY on the front panel. or Press RECEIVER followed by ON/STANDBY on the remote controller. The AV receiver comes on, the display lights, and the STANDBY indicator goes off.

Turning Off Press ON/STANDBY on the front panel or the remote controller. The AV receiver will enter Standby mode. To prevent any loud surprises when you turn on the AV receiver, always turn down the volume before you turn it off. En 20 Basic Operations This manual describes the procedure using the remote controller unless otherwise specified. Displaying Source Information You can display various information about the current input source as follows. (Components connected to the UNIVERSAL PORT jack are excluded.) Press RECEIVER followed by DISPLAY repeatedly to cycle through the available information. Tip Playing the Connected Component Operating on the AV receiver 1 2 Use the input selector buttons to select the input source. Start playback on the source component. See also: · "Controlling Other Components" ( 53) · "Controlling iPod" ( 49) · "Listening to the Radio" ( 25) To adjust the volume, use the MASTER VOLUME control.

Select a listening mode and enjoy! See also: · "Using the Listening Modes" ( 29) · "Audyssey Settings" ( 38) \*1 \*2 · Alternatively, you can use the AV receiver's DISPLAY. The following information can typically be displayed. Input source & volume\*1 3 4 Signal format\*2 or sampling frequency Input source & listening mode\*3 When AM or FM radio is used, the band, preset number, and frequency are displayed. If the input signal is analog, no format information is displayed. If the input signal is PCM, the sampling frequency is displayed. If the input signal is digital but not PCM, the signal format is displayed. Information is displayed for about three seconds, then the previously displayed information reappears. The input source is displayed with the default name even when you have selected a name in "Name Edit" ( 40). Operating with the remote controller 1 2 Press RECEIVER followed by INPUT SELECTOR. Start playback on the source component.

See also: · "Controlling Other Components" ( 53) · "Controlling iPod" ( 49) · "Listening to the Radio" ( 25) To adjust the volume, use VOL / . Select a listening mode and enjoy! See also: · "Using the Listening Modes" ( 29) · "Audyssey Settings" ( 38) \*3 3 4 Using the Music Optimizer The Music Optimizer function enhances the sound quality of compressed music files. 1 2 Tip Press AUDIO and use / to select "M.Optimizer". Use / to select "On". The M.Opt indicator lights on the display. · Alternatively, you can use the AV receiver's MUSIC OPTIMIZER (North American models). · See "Music Optimizer" for more details ( 43). Setting the Display Brightness You can adjust the brightness of the AV receiver's display.

Press RECEIVER followed by DIMMER repeatedly to select: dim, dimmer, or normal brightness. Tip · Alternatively, you can use the AV receiver's DIMMER (North American models). En 21 Muting the AV Receiver You can temporarily mute the output of the AV receiver. Press RECEIVER followed by MUTING. The output is muted and the MUTING indicator flashes on the display.

Tip · To unmute, press MUTING again or adjust the volume. · The Mute function is cancelled when the AV receiver is set to Standby. Changing the Input Display When you connect an -capable Onkyo component, you must configure the input display so that can work properly. This setting can be done only from the front panel. 1 Press TV/CD, GAME or VCR/DVR on the front panel so that "TV/CD", "GAME" or "VCR/DVR" appears on the display.

Using the Sleep Timer With the sleep timer, you can set the AV receiver to turn off automatically after a specified period. Press RECEIVER followed by SLEEP repeatedly to select the required sleep time. The sleep time can be set from 90 to 10 minutes in 10 minute steps. The SLEEP indicator lights on the display when the sleep timer has been set. The specified sleep time appears on the display for about five seconds, then the previous display reappears. Tip · If you need to cancel the sleep timer, press SLEEP repeatedly until the SLEEP indicator goes off. · To check the time remaining until the AV receiver sleeps, press SLEEP. Note that if you press SLEEP while the sleep time is being displayed, you'll shorten the sleep time by 10 minutes. 2 Press and hold down TV/CD, GAME or VCR/DVR (about 3 seconds) to change the input display. Repeat this step to select "MD", "CDR", "DOCK" or "TAPE".

For the TV/CD input selector, the input display changes in this order: TV/CD MD CDR TAPE DOCK For the GAME input selector, the setting changes in this order: GAME DOCK For the VCR/DVR input selector, the setting changes in this order: VCR/DVR DOCK Using Headphones Connect a pair of stereo headphones with a standard plug (1/4 inch or 6.3 mm) to the PHONES jack. Note · Always turn down the volume before connecting your headphones. · While the headphones plug is inserted in the PHONES jack, the speakers are turned off. (The Powered Zone 2 speakers are not turned off.) · When you connect a pair of headphones, the listening mode is set to Stereo, unless it's already set to Stereo, Mono, Direct, or Pure Audio (European and Asian models). · Only the Stereo, Direct, Pure Audio (European and Asian models), and Mono listening modes can be used with headphones. Note · DOCK can be selected for the TV/CD, GAME or VCR/DVR input selector, but not at the same time. · Enter the appropriate remote control code before using the remote controller for the first time ( 53). Selecting Speaker Layout You can select the priority of the use of front high or surround back speakers. Press RECEIVER followed by SP LAYOUT repeatedly. FrontHigh: The sound from front high speakers is output by priority. SurroundBack: The sound from surround back speakers is output by priority.



[You're reading an excerpt. Click here to read official ONKYO TX-SR508 user guide](http://yourpdfguides.com/dref/2461179)

<http://yourpdfguides.com/dref/2461179>

Note · If the "Speakers Type" setting is set to "Bi-AMP" ( 40), or Powered Zone 2 is being used ( 47), this setting cannot be selected. · When the listening mode that doesn't support front high or surround back speakers is used, the setting cannot be selected.

En 22 Audyssey 2EQ® Room Correction and Speaker Setup With the supplied calibrated microphone, Audyssey 2EQ automatically determines the number of speakers connected, their size for purposes of bass management, optimum crossover frequencies to the subwoofer (if present), and distances from the primary listening position. Audyssey 2EQ then removes the distortion caused by room acoustics by capturing room acoustical problems over the listening area in both the frequency and time domain. The result is clear, well-balanced sound for everyone. Enabling Audyssey 2EQ allows you to also use Audyssey Dynamic EQTM, which maintains the proper octave-to-octave balance at any volume level ( 38). Before using this function, connect and position all of your speakers. If "Dynamic EQ" is set to "On" ( 39), the "Audyssey" setting will be set to "Off" ( 38). On the other hand, if it is set to "Off", the "Dynamic Volume" setting will be set to "Off" ( 39). It takes about 15 minutes to complete Audyssey 2EQ Room Correction and Speaker Setup for three positions. Total measurement time varies depending on the number of speakers. Note · Make the room as quiet as possible. Background noise and Radio Frequency Interference (RFI) can disrupt the room measurements. Close windows, televisions, radios, air conditioners, fluorescent lights, home appliances, light dimmers, or other devices. Silence the cell phone (even if it is not in use) or place it away from all audio electronics. · The microphone picks up test tones which played through each speaker as Audyssey 2EQ Room Correction and Speaker Setup run. · Audyssey 2EQ Room Correction and Speaker Setup cannot be performed while a pair of headphones is connected.

1 2 Turn on the AV receiver and the connected TV. On the TV, select the input to which the AV receiver is connected. Set the speaker setup microphone at the Main Listening Position 1, and connect it to the SETUP MIC jack. SETUP MIC jack Speaker setup microphone Using Audyssey 2EQ To create a listening environment in your home theater that all listeners will enjoy, Audyssey 2EQ takes measurements at up to three positions within the listening area. Position the microphone at ear height of a seated listener with the microphone tip pointed directly at the ceiling using a tripod. Do not hold the microphone in your hand during measurements as this will produce inaccurate results. First measurement position Also referred to as the Main Listening Position this refers to the most central position where one would normally sit within the listening environment. 2EQ uses the measurements from this position to calculate speaker distance, level, polarity, and the optimum crossover value for the subwoofer. Second measurement position The right side of the listening area. Third measurement position The left side of the listening area.

The distances from position at least 1 meter. to and to must be The speaker setting menu appears. Note · The on-screen setup menus appear only on a TV that is connected to the HDMI OUT. If your TV is connected to the MONITOR OUT V or the COMPONENT VIDEO OUT, use the AV receiver's display when changing settings. 3 When you've finished making the settings, press ENTER.

2EQ: Auto Setup Speakers Type Speaker Terminal Assign Front High/Zone2 SurrBk/FrontHigh Audyssey < Normal > Front High SurrBack If your front speakers are bi-amped, you must select "Bi-AMP" in the "Speakers Type" setting ( 40). For hookup information, see "Bi-amping the Front Speakers" ( 13). 4 TV Press ENTER. Audyssey 2EQ Room Correction and Speaker Setup starts. Test tones are played through each speaker as Audyssey 2EQ Room Correction and Speaker Setup runs.

This process takes a few minutes. Please refrain from talking during measurements and do not stand between speakers and the microphone. Do not disconnect the speaker setup microphone during Audyssey 2EQ Room Correction and Speaker Setup, unless you want to cancel the setup. · Listening area to : Listening position En 23 5 6 7 Place the setup microphone at the next position, and then press ENTER. Audyssey 2EQ® performs more measurements. This takes a few minutes. When prompted, place the setup microphone at the next position, and repeat step 5. Use / to select an option, and then press ENTER. 2EQ: Auto Setup Subwoofer Front Center Surround Front High Surr Back Surr Back CH Save Cancel : : : : : Audyssey Error Messages While Audyssey 2EQ Room Correction and Speaker Setup is in progress, one of the error messages below may appear. 2EQ: Auto Setup Audyssey Ambient noise is too high.

Error message <- Review Speaker Configuration -> Yes Small Small Small Small Small 2ch Retry Cancel The options are: Save: Save the calculated settings and exit Audyssey 2EQ Room Correction and Speaker Setup. Cancel: Cancel Audyssey 2EQ Room Correction and Speaker Setup. Note · You can view the calculated settings for the speaker configuration, speaker distances, and speaker levels by using /. 8 Disconnect the speaker setup microphone. Note · When Audyssey 2EQ Room Correction and Speaker Setup is complete, the "Audyssey" will be set to "On" ( 38). The Audyssey indicator will light ( 8). · You can cancel Audyssey 2EQ Room Correction and Speaker Setup at any point in this procedure simply by disconnecting the setup microphone. · Do not connect or disconnect any speakers during Audyssey 2EQ Room Correction and Speaker Setup. · If the AV receiver is muted, it will be unmuted automatically when Audyssey 2EQ Room Correction and Speaker Setup starts. · Changes to the room after Audyssey 2EQ Room Correction and Speaker Setup requires you run Audyssey 2EQ Room Correction and Speaker Setup again, as room EQ characteristics may have changed.

The options are: Retry: Try again. Cancel: Cancel Audyssey 2EQ Room Correction and Speaker Setup. · Ambient noise is too high. The background noise is too loud. Remove the source of the noise and try again.

· Speaker matching error! The number of speakers detected was different from that of the first measurement. Check the speaker connection. · Writing Error! This message appears if saving fails. Try saving again. If this message appears after 2 or 3 attempts, contact your Onkyo dealer.

· Speaker Detect Error This message appears if a speaker is not detected. "No" means that no speaker was detected. Tip · See "Speaker Configuration" for appropriate settings ( 11).



[You're reading an excerpt. Click here to read official ONKYO TX-SR508 user guide](http://yourpdfguides.com/dref/2461179)

<http://yourpdfguides.com/dref/2461179>

*Changing the Speaker Settings Manually You can manually make changes to the settings found during Audyssey 2EQ Room Correction and Speaker Setup. See also: · "Sp Config (Speaker Configuration)" ( 36) · "Sp Distance (Speaker Distance)" ( 37) · "Level Cal (Level Calibration)" ( 37) Using a Powered Subwoofer If you're using a powered subwoofer and it outputs very low-frequency sound at a low volume level, it may not be detected by Audyssey 2EQ Room Correction and Speaker Setup. If the "Subwoofer" appears on the "Review Speaker Configuration" screen as "No", increase the subwoofer's volume to the half-way point, set it to its highest crossover frequency, and then try running Audyssey 2EQ Room Correction and Speaker Setup again. Note that if the volume is set too high and the sound distorts, detection issues may occur, so use an appropriate volume level. If the subwoofer has a low-pass filter switch, set it to Off or Direct. Refer to your subwoofer's instruction manual for details. En 24 Listening to the Radio This section describes the procedure using the buttons on the front panel unless otherwise specified.*

*Manual tuning mode 1 2 Press TUNING MODE so that the AUTO indicator goes off on the display. Press and hold TUNING /. The frequency stops changing when you release the button. Press the buttons repeatedly to change the frequency one step at a time. Using the Tuner With the built-in tuner you can enjoy AM and FM radio stations. You can store your favorite stations as presets for quick selection. This model changes FM/AM frequency in 200/10kHz (or 50/9kHz) steps. In manual tuning mode, FM stations will be in mono. Listening to the Radio Press TUNER to select either "AM" or "FM". In this example, FM has been selected.*

*Each time you press TUNER, the radio band changes between AM and FM. Band Frequency Tuning into weak FM stereo stations If the signal from a stereo FM station is weak, it may be impossible to get good reception. In this case, switch to manual tuning mode and listen to the station in mono. Tuning into stations by frequency You can tune into AM and FM stations directly by entering the appropriate frequency. 1 (Actual display depends on the country.) ) On the remote controller, press TUNER repeatedly to select "AM" or "FM", followed by D.TUN. Tuning into Radio Stations Auto tuning mode (Actual display depends on the country.) 1 2 Press TUNING MODE so that the AUTO indicator lights on the display. Press TUNING /.*

*Searching stops when a station is found. 2 Within 8 seconds, use the number buttons to enter the frequency of the radio station. For example, to tune to 87.50 (FM), press 8, 7, 5, 0. If you have entered the wrong number, you can retry after 8 seconds. When tuned into a station, the TUNED indicator lights. When tuned into a stereo FM station, the FM STEREO indicator lights on the display, as shown. FM STEREO AUTO TUNED En 25 Presetting FM/AM Stations You can store a combination of up to 40 of your favorite FM/AM radio stations as presets. Using RDS (excluding North American models) RDS works only in areas where RDS broadcasts are available. When tuned into an RDS station, the RDS indicator lights.*

*1 2 Tune into the FM/AM station that you want to store as a preset. See the previous section. Press MEMORY. The preset number flashes. What is RDS? RDS stands for Radio Data System and is a method of transmitting data in FM radio signals. It was developed by the European Broadcasting Union (EBU) and is available in most European countries. Many FM stations use it these days. In addition to displaying text information, RDS can also help you find radio stations by type (e.g., news, sport, rock, etc.*

*) The AV receiver supports four types of RDS information: PS (Program Service) When tuned to an RDS station that's broadcasting PS information, the station's name will be displayed. Pressing DISPLAY will display the frequency for 3 seconds. RT (Radio Text) When tuned to an RDS station that's broadcasting text information, the text will be shown on the display as described in the next section. PTY (Program Type) This allows you to search for RDS radio stations by type ( 27).*

*TP (Traffic Program) This allows you to search for RDS radio stations that broadcast traffic information ( 27). Note · In some cases, the text characters displayed on the AV receiver may not be identical to those broadcast by the radio station. Also, unexpected characters may be displayed when unsupported characters are received. This is not a malfunction. · If the signal from an RDS station is weak, RDS data may be displayed intermittently or not at all. 3 4 While the preset number is flashing (about 8 seconds), use PRESET / to select a preset from 1 through 40. Press MEMORY again to store the station or channel. The station or channel is stored and the preset number stops flashing. Repeat this procedure for all of your favorite FM/ AM radio stations. Selecting Presets To select a preset, use PRESET / on the AV receiver, or the remote controller's CH +/- Tip · You can also use the remote controller's number buttons to select a preset directly. Deleting Presets 1 2 Select the preset that you want to delete. See the previous section. While holding down MEMORY, press TUNING MODE. The preset is deleted and its number disappears from the display.*

*When tuned to an RDS station that's broadcasting text information, the text can be displayed. Displaying Radio Text (RT) Press RT/PTY/TP once. The RT information scrolls across the display. Note · The message "Waiting" may appear while the AV receiver waits for the RT information. · If the message "No Text Data" appears on the display, no RT information is available. En 26 Finding Stations by Type (PTY) You can search for radio stations by type. RDS program types (PTY) Type None News reports Current affairs Information Sport Education Drama Culture Science and technology Varied Pop music Rock music Middle of the road music Light classics Serious classics Other music Weather Finance Children's programmes Social affairs Religion Phone in Travel Leisure Jazz music Country music National music Oldies music Folk music Documentary Alarm test Alarm Display None News Affairs Info Sport Educate Drama Culture Science Varied Pop M Rock M Easy M Light M Classics Other M Weather Finance Children Social Religion Phone In Travel Leisure Jazz Country Nation M Oldies Folk M Document TEST Alarm! 1 2 3 4 Press RT/PTY/TP twice. The current program type appears on the display. Use PRESET / to select the type of program you want. See the table shown later in this chapter.*

*To start the search, press ENTER. The AV receiver searches until it finds a station of the type you specified, at which point it stops briefly before continuing with the search.*



[You're reading an excerpt. Click here to read official ONKYO TX-SR508 user guide](http://yourpdfguides.com/dref/2461179)

<http://yourpdfguides.com/dref/2461179>

When a station you want to listen to is found, press ENTER. If no stations are found, the message "Not Found" appears. Listening to Traffic News (TP) You can search for stations that broadcast traffic news.

1 Press RT/PTY/TP three times. If the current radio station is broadcasting TP (Traffic Program), "[TP]" will appear on the display, and traffic news will be heard as and when it's broadcast. If "TP" without square brackets appears, this means that the station is not broadcasting TP. To locate a station that is broadcasting TP, press ENTER. The AV receiver searches until it finds a station that's broadcasting TP.

If no stations are found, the message "Not Found" appears. 2 En 27 Recording This section explains how to record the selected input source to a component with recording capability, and how to record audio and video from different sources. Connecting a Recording Component 3 On the source component, start playback. If you select another input source during recording, that input source will be recorded. Recording Separate AV Sources Here you can record audio and video from completely separate sources, allowing you to overdub audio onto your video recordings. This function takes advantage of the fact that when an audio-only input source (TV/CD) is selected, the video input source remains unchanged. In the following example, audio from the CD player connected to the TV/CD IN and video from the camcorder connected to the AUX INPUT VIDEO jack are recorded by the VCR connected to the VCR/DVR OUT jacks. Camcorder L AUDIO IN R VIDEO IN VCR, DVD recorder Note Cassette, CDR, MD, etc. · The AV receiver must be turned on for recording. Recording is not possible while it's in Standby mode.

· If you want to record directly from your TV or playback VCR to the recording VCR without going through the AV receiver, connect the TV/VCR's audio and video outputs directly to the recording VCR's audio and video inputs. See the manuals supplied with your TV and VCR for details. · Video signals connected to composite video inputs can be recorded only via composite video outputs. If your TV/VCR is connected to a composite video input, the recording VCR must be connected to a composite video output. · The surround sound and DSP listening modes cannot be recorded. · Copy-protected Blu-ray discs and DVDs cannot be recorded. · Sources connected to a digital input cannot be recorded. Only analog inputs can be recorded. · DTS signals will be recorded as noise, so don't attempt analog recording of DTS CDs or LDs. · While the listening mode is set to Pure Audio, no image is provided because the power is turned off for the video circuit.

If you want to make recordings, select other listening mode. (European and Asian models) CD player VCR : Video signal : Audio signal AV Recording Audio sources can be recorded to a recorder (e.g., cassette deck, CDR, MD) connected to the VCR/DVR OUT jacks. Video sources can be recorded to a video recorder (e.g., VCR, DVD recorder) connected to the VCR/DVR OUT jack. 1 2 3 4 5 Prepare the camcorder and CD player for playback. Prepare the VCR for recording. Press AUX input selector.

Press TV/CD input selector. This selects the CD player as the audio source, but leaves the camcorder as the video source. Start recording on the VCR and start playback on the camcorder and CD player. The video from the camcorder and the audio from the CD player are recorded by the VCR. 1 Use the input selector buttons to select the source that you want to record. You can watch the source while recording. The AV receiver's MASTER VOLUME control has no effect on recording. On your recorder, start recording. 2 En 28 Using the Listening Modes Selecting Listening Modes See "About Listening Modes" for detailed information about the listening modes ( 30). Listening Mode Buttons (North American models) Press RECEIVER first.

MOVIE/TV, MUSIC, GAME (European and Asian models) MUSIC MOVIE/TV GAME STEREO PURE AUDIO MOVIE/TV, MUSIC, GAME MOVIE/TV button This button selects the listening modes intended for use with movies and TV. MUSIC button This button selects the listening modes intended for use with music. GAME button This button selects the listening modes intended for use with video games. STEREO button This button selects the Stereo listening mode and All Channel Stereo listening mode. PURE AUDIO button and indicator (European and Asian models) This button selects the Pure Audio listening mode. When this mode is selected, the AV receiver's display and video circuitry are turned off. The indicator lights when this mode is selected. Pressing this button again will select the previous listening mode. · The Dolby Digital and DTS listening modes can only be selected if your Blu-ray Disc/DVD player is connected to the AV receiver with a digital audio connection (coaxial, optical, or HDMI). · The listening modes you can select depends on the format of the input signal.

To check the format, see "Displaying Source Information" ( 21). · While a pair of headphones is connected, you can select the following listening modes: Pure Audio (European and Asian models), Mono, Direct, and Stereo. En 29 About Listening Modes The AV receiver's listening modes can transform your listening room into a movie theater or concert hall, with high fidelity and stunning surround sound. Explanatory Notes SP LAYOUT Front speakers LISTENING MODE Center speaker Surround speakers Surround back speakers Front high speakers Subwoofer Input Source The following audio formats are supported by the listening mode. This is mono (monophonic) sound.

This is stereo (stereophonic) sound. Two independent audio signal channels are reproduced through two speakers. This is 5.1-channel surround sound. This surround system has five main channels of sound and a sixth subwoofer channel (called the point-one channel).

This is 7.1-channel surround sound. This is a further sound enhancement to 5.1 channel sound with two additional speakers that provide greater sound envelopment and more accurate positioning of sounds. This is DTS-ES surround sound. This surround system can produce a discrete or a matrix-encoded sixth channel from existing DTS 5.1 encoded material. This is Dolby Digital EX surround sound. This provides a center back surround channel from 5.1-channel sources.

Speaker Layout The illustration shows which speakers are activated in each channel. See "Sp Config (Speaker Configuration)" for the speaker setup ( 36). Press RECEIVER followed by SP LAYOUT repeatedly to select front high or surround back speakers. En 30 Listening Modes Listening Mode Pure Audio\*1 Description In this mode, the display and video circuitry are turned off, minimizing possible noise sources for the ultimate in high-fidelity audio reproduction.



[You're reading an excerpt. Click here to read official ONKYO TX-SR508 user guide](http://yourpdfguides.com/dref/2461179)

<http://yourpdfguides.com/dref/2461179>