



### Manual abstract:

Com/welcome i h g 6 10 f 14 7 11 User manual Safety leaflet Warranty Recipe 3 l k 15 m t 8 12 n s Specifications are subject to change without notice © 2013

Koninklijke Philips N. 0\_130903 o p q r English 1 Your multicooker Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at [www.philips.com](http://www.philips.com). 5 Press the lid release button to open the lid. 6 Wipe the outside of the inner pot dry, then put it in the multicooker. Check if the inner pot is in proper contact with the heating element. 7 Close the lid of the multicooker, and put the plug in the power socket. @@ □ • The default cooking time is 40 minutes, and is not adjustable. @@ • • The default cooking time is 30 minutes. You can select the cooking time between 5 to 30 minutes. making yogurt (fig.

11) 1 Whisk the ingredients for the yogurt well and put them in a glass container. 2 Put the glass container in the inner pot. Make sure that the container is sealed. 3 Pour some water in the inner pot. Make sure that half of the container is immersed in water.

@@@@@ 11 When the cooking is finished, you will hear a few beeps and the selected cooking function light will be off. 13) 1 Put the food and ingredients in the inner pot. 2 Follow step 6 in "Preparations before cooking". 3 Put the plug in the power socket. 14 Open the lid and carefully take out the steamed food from the plate or the steam basket.

Note Note • • When baking cake, keep the lid closed during cooking. Baking cake at • • 130°C and by 45 minutes usually delivers best cooking result. When baking food other than cake, the lid must be opened during cooking. 2 What's in the box (fig. 1) Steam basket Soup ladle Power cord Safety leaflet Recipe booklet Note • • Make sure that the outside of the inner pot is dry and clean, and that level indicated in the inner pot, as this may cause the multicooker to overflow. cooking plats en sauce (fig. 7) 1 Put food and ingredients in the inner pot. @@ 2 Press the menu button (Menu) until the plats en sauce cooking function (Plats en sauce) is selected. 3 Press the cooking time button (Temps de cuisson), and the hour unit starts flashing on the display. 5 After the hour unit is set, press the cooking time button (Temps de cuisson) again, and the minute unit starts flashing on the display.

8 When the cooking is finished, you will hear a few beeps and the selected cooking function light will be off. □ • The cooking time begins once the water is boiling, and the time is • • When removing the steamed food from the steam basket, use a kitchen • • When you cook rice and steam food at the same time, make sure you glove or a cloth, as the plate and steam basket will be very hot. Measure out an amount of rice that leaves enough room for the steam tray. displayed as a countdown. Multicooker main unit Rice scoop Measuring cup User manual Warranty card Silica gloves • • Do not exceed the volume indicated nor exceed the maximum water there is no foreign residue on the heating element or the magnetic switch. stewing (fig. 9) 1 Put the food and ingredients in the inner pot. @@ 3 Press the menu button (Menu) until the stewing function (Mijoter) is selected. 4 Press the cooking time button (Temps de cuisson), and the hour unit starts flashing on the display. 6 After the hour unit is set, press the cooking time button (Temps de cuisson) again, and the minute unit starts flashing on the display.

9 When the cooking is finished, you will hear a few beeps and the selected cooking function light will be off. Tip • • The level marked inside the inner pot is just an indication. you f Power socket g Heating element h Water level indications i Cooker handle j Detachable steam vent cap Overview (fig. 2) a Lid b Inner pot c Lid release button d Control panel e Main body can always adjust the water level for different types of rice and your own preference. Do not exceed the maximum quantities indicated on the inside of the inner pot.

□ • Besides following the water level indications, you may also add rice and water at 1:1-1. 2 ratio for rice cooking. @@ You can select the cooking time between 6 to 12 hours. 5) 1 Follow the steps in "Preparations before cooking". @@ 3 Press the start button (Start) to start cooking. @@@@ • • The default cooking time is 2 hours. You can select the cooking time from 1 to 4 hours. @@ • • The default cooking time is 1 hour. You can select the cooking time between 20 minutes to 10 hours. @@@@ • • The default steaming time is 30 minutes. You can select the cooking time between 5 minutes to 2 hours. preset time for delayed cooking (fig. @@ The preset timer is available from 10 minutes to 24 hours. @@@@ » The preset timer starts flashing on the display. 5 Press the start button (Start) to confirm the preset time.

6 The cooking will be finished when the preset time has elapsed. @@@ 2 Pour some water onto the rice to prevent it from becoming too dry. The quantity of the water depends on the amount of rice. @@@@ You can select the • • The default cooking temperature is 60°C. The available cooking time between 20 minutes to 2 hours. temperature options are 40°C , 60°C , 80°C , 100°C , 120°C , 150°C , and 180°C. Kitchen glove or a cloth, as the inner pot will be very hot. 3 Using the multicooker Tip • • You can press the cancel button (Off/Chaud) or unplug the multicooker to turn off the keep-warm function or when not in use. □ • The default cooking time is 40 minutes, and is not adjustable. boiling (fig.

8) 1 Put food and ingredients into the inner pot. @@ 3 Press the menu button (Menu) until the boiling function (Bouillir) is selected. 4 Press the cooking time button (Temps de cuisson), and the minute unit starts flashing on the display. 7 When the cooking is finished, you will hear a few beeps and the selected cooking function light will be off. 10) 1 2 3 4 Put food and ingredients into the inner pot.

Follow step 6 in "Preparations before cooking". Put the plug in the power socket. Press the menu button (Menu) until the frying function (Frيره) is selected. @@ 8 During cooking, stir the food constantly using a spatula. 9 When the cooking is finished, you will hear a few beeps and the selected cooking function light will be off.

Before first use 1 Take out all the accessories from the inner pot. Remove the sheet between the inner pot and the heating element. 2 Clean the parts of the multicooker thoroughly before using the multicooker for the first time (see chapter 'Cleaning'). steaming (fig. 14) 1 2 3 4 5 Measure a few cups of water with the measuring cup. Pour the water into the inner pot. Put the steam basket into the inner pot. Put the food into the steam basket. Close the lid of the multicooker, and put the plug in the power socket.



[You're reading an excerpt. Click here to read official PHILIPS](http://yourpdfguides.com/dref/5563808)

[HD3037/03 user guide](http://yourpdfguides.com/dref/5563808)

<http://yourpdfguides.com/dref/5563808>

6 Press the menu button (Menu) until the steaming function (Cuisson vapeur) is selected.

7 Press the cooking time button (Temps de cuisson), and the hour unit starts flashing on the display. 9 After the hour unit is set, press the cooking time button (Temps de cuisson) again, and the minute unit starts flashing on the display. 12 When the steaming is finished, you will hear a few beeps and the selected cooking function light will be off. note •• The preset timer is not available in fry (Frire) and bake (Four) modes. Tip •• After the preset time is set, you can press the cancel button •• You can press the cancel button (Off/Chaud) or unplug the (Off/Chaud) to deactivate the preset function. Multicooker to turn off the keep-warm function or when not in use. cooking ratatouille (fig. 6) Note •• Make sure all parts are completely dry before you start using the multicooker. preparations before cooking (fig. 4) Before using the multicooker, you need to follow below preparations: 1 Measure the rice using the measuring cup provided.

2 Wash the rice thoroughly. 3 Put the pre-washed rice in the inner pot. @@Then smooth the rice surface. 1 Put food and ingredients in the inner pot.

@@@@ 4 Press the start button (Start) to start cooking.

@@@@ •• The default cooking time is 25 minutes. You can select the cooking time between 8 to 25 minutes. Note •• The cooking time begins once the water is boiling, and the time is displayed as a countdown. Note •• This function must be operated with the lid opened. □• This function may be not used for deep fry, and the amount of oil may not •• The default cooking time is 42 minutes.

You can select the cooking time between 5 to 59 minutes. exceed marking "2". Keep-warm mode The multicooker provides you with easy control over the keep-warm mode. □ After you have selected the cooking function using the menu button (Menu), if you press the start button (Start) directly, the ker multicooker.

Take (E1, E2, E3, or E4) the appliance to your Philips dealer or a service appears on the center authorized by Philips. .



[You're reading an excerpt. Click here to read official PHILIPS HD3037/03 user guide](http://yourpdfguides.com/dref/5563808)  
<http://yourpdfguides.com/dref/5563808>