



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for POLAROID I835. You'll find the answers to all your questions on the POLAROID I835 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual POLAROID I835
User guide POLAROID I835
Operating instructions POLAROID I835
Instructions for use POLAROID I835
Instruction manual POLAROID I835



8.0 Megapixel Digital Camera
i835

User's Manual



**Questions?
Need Some Help?**

This manual should help you understand your new product.

If you still have questions, call our help line found on the insert with this icon:



or visit
www.polaroid.com/support.

DIGITAL QUALITY, POLAROID SIMPLICITY™



[You're reading an excerpt. Click here to read official POLAROID I835 user guide](http://yourpdfguides.com/dref/1222018)

<http://yourpdfguides.com/dref/1222018>

Manual abstract:

0 Megapixel Digital Camera i835 User's Manual Questions? @@@2. 3. 4. 5. 6. 7. 8. 9. @@Zoom out/ Thumbnail button 11. Mode button 12. Self-timer / Up button 13. Macro / Left button 14. LCD screen 15. LCD screen on/ off button 16. Scene mode button 17. Zoom in button 18. Flash LED 19. Menu button 20. Wrist strap holder 21. Flash / Right button 22. OK button 23. Delete / Down button 24. Tripod mount 25. @@.....

.....
.....
.....
.....

.....
.....
.....
.....

.....6 · Camera Package Contents ...

.....
.....
.....
.....
.....
.....

....7 · Attaching the Wrist Strap

.....
.....
.....
.....
.....
.....

..8 · Installing and Removing the Battery

.....
.....
.....
.....
.....

.8 · Using Your Batteries

.....
.....
.....
.....
.....
.....

.9 · Checking the Battery Level

.....
.....
.....
.....

.....
.....

10 · Turning the Camera On and Off

.....

.....
.....
.....
.....

..10 2 Camera Settings.....

.....
.....
.....

.....
.....
.....
.....

....11 · Checking Camera Status .

.....
.....

.....
.....
.....
.....

11 · Capture Modes

.....
.....

.....
.....
.....
.....

.....
.....
.....

11 · Playback Mode.....

.....
.....
.....
.....

.....
.....
.....
.....

.14 · Camera Modes

.....
.....
.....

.....
.....
.....
.....

..15 · How to Navigate Menus ...

.....
.....

.....
.....

.....
.....

.....
15 · Setup Menu

.....
.....

.....
.....
.....

.....
.....
.....

....16 · Setting Date and Time

.....
.....
.....

.....
.....
.....

...17 · Setting Auto Power Off

.....
.....
.....

.....
.....
.....

.18 · Setting the Beep Sound On / Off.

.....
.....
.....

.....19 · Adjusting volume control. .

.....
.....
.....

.....
.....
.....

....19 · Setting the Display Language

.....
.....
.....

.....
.....
.....

...20 · Setting the Date Stamp On / Off.

.....
.....
.....

.....21 · *Adjusting the LCD Brightness.*

.....
.....
.....
.....
.....
.....
.....

21 · *Turning Sequence Number On / Off*

.....
.....
.....
.....

..22 · *Resetting to Default Settings.* ..

.....
.....
.....
.....
.....

...23 · *Cancelling the Startup Image.*

.....
.....
.....
.....
.....

....24 · *Choosing the Media for Storage*

.....
.....
.....
.....
.....

.25 · *Turning the Information Display On/Off*

.....
.....
.....
.....

...26 3 *Taking Pictures* ..

.....
.....
.....
.....
.....
.....
.....
.....

.28 · *Taking Pictures in Normal Mode*

.....
.....
.....
.....

.....
...28 · Taking Pictures in Macro Mode ..

.....
.....
.....
.....
.....

.....30 · Taking Pictures in Different Scene Shooting Modes

.....
.....

.....31 Polaroid i835 Digital Camera User Guide www.polaroid.com 3 · Setting Face Tracking..

.....
.....
.....

.....34 · Setting Smile Detection.

.....
.....
.....

.....35 · Setting Flash Mode ..

.....
.....
.....

.....
.....
.....

...37 · Setting Self-timer

.....
.....
.....

.....
.....
.....

39 · Setting the Picture Resolution and Compression

.....
.....

.....40 · Setting the Sharpness

.....
.....
.....

.....
.....
.....

.....
.....43 · *Zoom Feature.* ...

.....
.....

.....
.....
.....

.....
.....
...44 · *Turning Digital Zoom On and Off.*

.....
.....
.....
.....

...46 · *Turning the Auto-focus Assist Beam On and Off*

.....
.....

.....47 · *Specifying the Quick Review Period* ..

.....
.....
.....
.....

.....48 · *Setting Focus Area.*

.....
.....

.....
.....
.....

.....
...49 · *Setting Blink Detection.*

.....
.....

.....
.....
.....

.....
...50 · *Setting Exposure Compensation* .

.....
.....

.....
.....
.....

.51 · *Setting ISO*.....

.....
.....
.....

.....
.....
.....
.....

.....
.....
..52 · Setting White Balance ...
.....

.....
.....
.....
.....

.....
.....
...53 · Setting Shutter Speed..
.....

.....
.....
.....
.....

.....
.....
....54 · Setting Light Metering.
.....

.....
.....
.....
.....

.....
.....
55 4 Recording Video Clips
.....

.....
.....
.....
.....

.....
.....
....56 · Recording Video Clips.
.....

.....
.....
.....
.....

.....
.....
.....56 · Setting Video Resolution
.....

.....
.....
.....
.....

.....
.....

.....
..57 · Setting Exposure Compensation for Video Clips

.....
.....
..58 · Setting White Balance for Video Clips ...
.....

.....
.....
.....59 5 Managing Pictures and Video Clips

.....
.....
.....
..60 · Reviewing Pictures. ..
.....
.....
.....
.....

.....
.....
..60 · Reviewing Pictures and Video Clip Files in Thumbnail ...
.....
.....
.....
.....

.....60 · Magnifying & Trimming the Displayed Picture
.....
.....
.....

..61 · Playing a Video Clip on LCD Screen
.....
.....
.....

.....
61 · Protecting/Unprotecting Pictures and Video Clips
.....

.....62 · Running a Slide Show ...
.....
.....
.....

.....
.....
.....
.....63 · Copy to a Memory Card ..
.....
.....
.....

.....
.....
.....

.....64 · Copy from a Memory Card.. ...

.....
.....

.....65 · Deleting Pictures or Video Clip .

.....
.....
.....

..66 · Image Cropping...

.....
.....
.....
.....

.....68 · Dynamic Lighting...

.....
.....
.....
.....
.....
.....

....69 · Red-eye Removal.....

.....
.....
.....
.....
.....

..70 · Saving Your Pictures Using SAVE...

.....
.....
.....
.....

.....71 · Saving Your Pictures Using SAVE AS...

.....
.....
.....

.....
.....
.....

.....
.....
.....
.....

..73 · Viewing Pictures and Video Clips on a TV...

.....
.....

74 6 Print Settings

.....
.....
.....
.....

.....
.....
.....
.....

.75 · About PictBridge

.....
.....
.....
.....
.....
.....
.....

.....75 · About DPOF .

.....
.....
.....
.....
.....
.....

.....
.....
.....

...83 7 Using the SD (Secure Digital) Card

.....
.....
.....
.....

.....85 · Using the SD Card .

.....
.....
.....
.....
.....

.....

.....

.....

85 · *Formatting a SD card*

.....

.....

.....

.....

.....

.....

.....

..88 8 *Installing the Software onto a Computer* ...

.....

.....

.....

.....

.....89 · *Installing the Software*

.....

.....

.....

.....

.....

.....

.....

.....89 · *Software Included with Your Camera*

.....

.....

.....

.....

.....91 · *About ArcSoft Panorama Maker® 4*

.....

.....

.....

.....

.....

...92 · *Computer System Requirements*..

.....

.....

.....

.....

.....

.....96 9 *Transferring Pictures and Video Clips to a Computer*

.....

.....

.....97 · *Before Transferring Files*

.....

.....

.....

.....

.....

.....

.....

...97 · *Connecting to Your Computer*

.....
.....
.....
.....

.....
...97 · *Transferring Pictures and Video Clips to a Computer* ..

.....
.....

..98 10 *Troubleshooting Problems*

.....
.....
.....

.....
.....
.....

..... 100 11 *Getting Help* ...

.....
.....
.....
.....

.....
.....
.....
.....

.....
103 · *Polaroid Online Services*

.....
.....

.....
.....
.....
.....

..... 103 · *ArcSoft Software Help*

.....
.....
.....

.....
.....
.....
.....

.... 103 12 *Appendix*

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

.. 104 · *Technical specifications*

.....
.....

.....

 .. 104 · Storage Capacities..

.....

 .. 106 · Uninstalling Polaroid i835 Driver (PC only)

.....

 ... 109 · Camera Default Settings.....

.....

 110 · Tips, Your Safety & Maintenance .

.....

 .. 112 · Regulatory Information

112 Polaroid i835 Digital Camera User Guide www.polaroid.com 5 1 Getting Started Thank you for selecting the new Polaroid i835 digital camera for your imaging needs. Incorporated with Polaroid's sophisticated technology, your exquisitely compact camera will offer a powerful range of high-end, easy-to-use functions. It will allow you to capture those special occasions with life-like clarity and beautiful color renditions. Outstanding features that your i835 digital camera has: · · · · · A high quality glass lens system for well exposed sharp pictures from 0.5m to infinity including a 4X digital zoom modes Built-in flash with four modes (Auto, Red-eye reduction, Off and Always on) Adjust your picture's resolution for printing or emailing Automatic white balance and exposure compensation to suit lighting conditions PictBridge capability to plug-and-print your images Large 3.0 inch LCD screen for easier image preview and review.

6 Polaroid i835 Digital Camera User Guide www.polaroid.

com · Camera Package Contents Quick Start Guide Guide de Démarrage rapide Schnellanleitung Guida Rapida Guía Rápida de Inicio Guia de Início Rápido XX XXXX Part no.: XXXXXXXXX Printed in China i835 Quick Start Guide Warranty Card Wrist Strap Polaroid i835 Camera Driver (PC) Arcsoft Panorama Maker® 4 (PC & Mac) ArcSoft PhotoStudio® 5.5 (PC) / 4.3 (Mac) ArcSoft VideoImpression® 2 (PC & Mac) Adobe® Acrobat® Reader™ (PC & Mac) User Guide (in PDF format) The CD-ROM includes USB Cable 2 x AA Battery Polaroid i835 Digital Camera User Guide www.polaroid.

com 7 · Attaching the Wrist Strap 1 · Installing and Removing the Battery 1. Open the camera battery door by pushing it outwards as illustrated. 2. Insert the batteries as shown. 3.

Close the battery door by pressing it downwards then slide it back to lock. 1 3 a b a 4. To remove the batteries, slide the battery lock in the direction of the arrow and the batteries will eject out of the battery slot. 5. Pull the batteries with your finger in the direction of the arrow. 1 a b 8 Polaroid i835 Digital Camera User Guide www.polaroid.com · Using Your Batteries Our laboratory testing has shown that our digital camera models comply with industry standard battery consumption levels (Camera & Imaging Products Association commonly known as CIPA). All digital cameras are high drain products. For the best performance and prolonged battery life, we recommend the use of high capacity batteries designed for such applications.

Here are some helpful hints to extend battery life considerably by limiting the following activities: · Reviewing the pictures on the LCD Screen · Using the optical viewfinder (if your camera has one) to frame the subject when taking pictures · Excessive use of 816X2112 2048X1536 1600X1200 1/2 Menu Settings SETUP Date /Time Auto Power Off Beep Sound Volume button to confirm your Video System 1/3 Setup Settings Polaroid i835 Digital Camera User Guide
www.



[You're reading an excerpt. Click here to read official POLAROID
i835 user guide](http://yourpdfguides.com/dref/1222018)

<http://yourpdfguides.com/dref/1222018>

polaroid.com 15 · Setup Menu You can change the basic settings of the camera in Capture and Video modes. Here we take the mode for an example. 1. Press the button and press the button to enter setup menu. 2. Press the and buttons to scroll up and down through menu bars. 3. Press the button to enter. Press the button to back to menu bars. 4. Press the options. 5. Press the choice.

6. Press the menu. and buttons to select button to confirm your button to exit the setup Menu Button SETUP Date /Time Auto Power Off Beep Sound Volume Video System LCD 1/3 1 Minute On Date /Time . 2007.01.

01 00:00:00 YY.MM.DD 16 Polaroid i835 Digital Camera User Guide www.polaroid.com · Setting the Date and Time 1. Access the setup menu. 2. Press or (Date / Time). 3. Press the button to select SETUP Date /Time Auto Power Off Beep Sound Volume Video System LCD 1/3 1 Minute On button to enter.

4. Press the or button to select a field, such as year, month, day, hour, minute, and date format. 5. Press or button to adjust the value in the field and select the date format. 6. Press the choice. button to confirm your Date /Time . 2007.01.01 00:00:00 YY.
MM.DD NOTE: · This setting is also available in (Video) mode. Need help with your digital camera? Call our toll-free customer service number. Look for the insert with this icon: Or visit www.polaroid.com. Polaroid i835 Digital Camera User Guide www.polaroid.com 17 · Setting Auto Power Off The camera performs the following power save operation to conserve battery power. 1. Access the setup menu. 2. Press the or (Auto Power Off). 3. Press the 4. Press setting. 5. Press the choice. 1 MINUTE SETUP Date /Time Auto Power Off Beep Sound Volume 1 Minute On button to select button to enter. or to select the desired Video System LCD 1/3 Auto Power Off Off .

1 Minute 3 Minutes button to confirm your The camera is designed to switch off automatically to save battery life after the specified period of inactivity. The camera will enter power saving mode automatically after 1 minute's inactivity and power off after 3 minutes' inactivity. The power saving function is not active. 3 MINUTES OFF NOTE: Auto power off is automatically disabled under any one of the following conditions: · · While the camera is recording a video clip. While the camera is running a slide show. 18 Polaroid i835 Digital Camera User Guide www.polaroid.com · Setting the Beep Sound On / Off The beep sound can be turned on and off in the SETUP menu. When the beep sound is turned on, the camera will beep when you press any of the buttons. SETUP 1. Access the setup menu. 2. Press the or button to select (Beep Sound). 3. Press the button to enter.

4. Press the or button to select the desired setting. 5. Press the button to confirm your choice. Date /Time Auto Power Off Beep Sound Volume Video System LCD 1/3 1 Minute On Beep Sound Off .

On · Adjusting Volume Control Volume can be adjusted for beep sounds and video clips. 1. Access the setup menu. Date /Time 2. Press the or button to select (Volume). 3. Press the button to enter. 4. Press the or button to select the desired setting. 5. Press the button to confirm your choice. Auto Power Off Beep Sound Volume Video System SETUP 1 Minute On LCD 1/3 Volume . Polaroid i835 Digital Camera User Guide www.polaroid.com 19 · Setting the Display Language Under this setting, you can select the language you prefer for the LCD screen. SETUP 1. Access the setup menu. 2. Press the (Language). 3. Press the or button to select Language Date Stamp LCD Brightness Format Sequence No. English Date Off 2/3 button to enter. English Deutsch Language 4. Press the or desired setting. 5. Press the choice. button to select the Français Español Italiano 1/4 button to confirm your Português Dutch Polish Language 2/4 0 Polaroid i835 Digital Camera User Guide www.polaroid.com · Setting the Date Stamp On / Off Use the date stamp setting to imprint the date on your pictures. Make sure the date is correct before setting the date stamp on.

1. Access the setup menu. 2. Press the or (Date Stamp). 3. Press the button to select SETUP Language Date Stamp LCD Brightness Format Sequence No. Off 2/3 English Date button to enter. button to select the 4. Press the or desired setting. 5. Press the choice. Date Stamp Date / Time Date button to confirm your Off · Adjusting the LCD Brightness 1. Access the setup menu. 2. Press the Brightness). 3. Press the or This setting enables you to adjust the brightness for the LCD screen. SETUP Language English Date to select (LCD Date Stamp LCD Brightness Format Sequence No. Off 2/3 button to enter. button to select the 4. Press the or desired setting. 5. Press the choice. LCD Brightness button to confirm your 1 Polaroid i835 Digital Camera User Guide www.polaroid.com · Turning Sequence Number On / Off The instructions below show how to select the way file numbers are assigned. 1. Access the setup menu. 2. Press the or (Sequence No. button to select the OFF On button to confirm your OFF The file numbers are reassigned to the start each time when any images are removed from the memory card or internal memory is formatted.

New images recorded on the memory card with existing files are given the next available number. A file number is assigned to a recorded image and memorized and images recorded onto a memory card start from the next number. Polaroid i835 Digital Camera User Guide www.polaroid.com · Resetting to Default Settings Default setting can be restored by the following steps (For more guidelines, please see "Camera Default Settings" on page 110). 1. Access the setup menu. Default Setting SETUP 2. Press the or (Default Settings). 3. Press the to select ICON Opening Storage Media On Auto button to enter. button to select the 3/3 4. Press the or desired setting. 5. Press the choice.

NOTE: Default Setting Return menu setting to default? Cancel OK button to confirm your Selecting CANCEL will cancel the operation and exit from the menu window. Need help with your digital camera? Call our toll-free customer service number. Look for the insert with this icon: Or visit www.polaroid.com. Polaroid i835 Digital Camera User Guide www.polaroid.com 3 · Cancelling the Startup Image A startup animation image appears on the LCD screen for a few seconds when the camera is turned on. You may cancel displaying the startup image according to the following steps: 1. Access the setup menu. 2. Press the (Opening). 3. Press the or to select Default Setting Opening Storage Media On Auto SETUP button to enter.



[You're reading an excerpt. Click here to read official POLAROID
I835 user guide
http://yourpdfguides.com/dref/1222018](http://yourpdfguides.com/dref/1222018)

button to select the Off On 3/3 4.

Press the or desired setting. 5. Press the choice. Opening button to confirm your 4 Polaroid i835 Digital Camera User Guide www.polaroid.com · Choosing the Media for Storage 1. Access the setup menu. You can choose your preferred media for images or video clips storage. SETUP Default Setting 2. Press the or (Storage Media).

3. Press the to select Opening Storage Media On Auto button to enter. button to select 3/3 4. Press the or the desired setting. 5.

Press the choice. Auto Internal Memory SD Card Storage Media Auto Internal Memory SD Card button to confirm your Images and video clips are stored on SD card if present otherwise the camera selects internal memory. The images or video clips will be stored in internal memory first. The images or video clips will be stored in SD card first. Polaroid i835 Digital Camera User Guide www.polaroid.com

polaroid.com 5 · Turning the Information Display On/Off Press the button each time switches the LCD screen to the next display mode in the following mode.

Still Image Mode Press Press LCD Screen On/Off Button Press 6 Polaroid i835 Digital Camera User Guide www.polaroid.com Video Mode Press Press Playback Mode Press Press Press Press Press Polaroid i835 Digital Camera User Guide www.polaroid.com 7 3 Taking Pictures Before you take pictures, please read this note first: NOTE: Never remove the batteries while a picture is being saved. Doing so will prevent the current picture from being saved and may corrupt other pictures already stored on the camera's internal memory or a memory card. · Taking Pictures in Normal Mode You can take pictures at approximately 1.6 feet (50cm) to infinity.

NOTE: Most settings are saved by the camera when the power is turned off, so that the same setting is automatically available when the power is turned on again. Make sure you verify your settings when turning the camera on again. 1. Press the button to set the camera to Still Image mode. 2. Frame your subject using the LCD screen. 3 Hold the camera steady and slowly press the shutter button down to take your image. Focus Frame Auto Focus LED Aperture Value Shutter Speed 8 Polaroid i835 Digital Camera User Guide www.polaroid.com NOTE: (Still Image) mode is the capture mode by default.

· The LCD screen will show you the aperture value and shutter speed at which you take the picture. · If the shutter speed is slow or that the image maybe blurred, the shake warning icon may appear on the LCD screen. To avoid this situation, the use of a tripod is recommended or turn on the flash. 4. Hold the camera steady and slowly press the shutter button down to take your image.

Polaroid i835 Digital Camera User Guide www.polaroid.com 9 · Taking Pictures in Macro Mode Use this mode to capture subjects close to the lens: Wide Angle: 0.3 ~ 1.6 ft (10 cm ~ 50 cm) Telephoto: 1.

1 ~ 2.6 ft (35 cm ~ 80 cm) 1. Set the camera to Still Image mode. 2. Press the button and the icon appears on the LCD screen. 3. Capture procedures are the same as for taking a picture in the normal capture mode. See page 28. Macro 30 Polaroid i835 Digital Camera User Guide www.polaroid.com

com · Taking Pictures in Different Scene Shooting Modes Selecting a mode to suit your shooting conditions: 1. Press the button to set the camera to Still Image mode. 2. Press button to access scene mode. button to select the 3. Press the or desired setting. Scene Mode Button Manual Manual Manual set parameters for the scene NOTE: Capture procedures are the same as for taking a picture in the normal capture mode. Polaroid i835 Digital Camera User Guide www.polaroid.com 31 Display Option Automatic Manual Digital Image Stabilization Face Tracking Smile Detection Landscape Portrait Sport Night Landscape Night Portrait Sunset Children Pet Collection Flower Food Fireworks Description Use this setting for most scenes - the camera decides the camera settings Allows your to manually setup your camera's settings Use to minimize the effect of camera shake and subject movement.

Used for finding human faces in the picture. Used for locating smiles in your pictures. Used for taking scenic pictures Used for one person picture with background out of focus Used at sporting events to capture subjects moving Used for taking long distant subjects at night Used for many subjects in picture with background out of focus Used for sunset scene Used for brightly lit scenes when children are moving Used for taking pictures of pets Used for taking pictures of paintings in Macro mode without flash Used to take close-up pictures of flowers Used to take pictures of food with increased color Used to pictures of fireworks 3 Polaroid i835 Digital Camera User Guide www.polaroid.com Party Snow & Beach Autumn Leaves Soft Flowing Water Splashing Water Text Panorama Sepia B&W Vivid Neutral Red Filtered Green Filtered Blue Filtered Used for taking indoor pictures of many people Used for taking pictures with snow or beach scenes Used for taking pictures in the autumn season Used for taking pictures of moving water in bright light Used for taking pictures of splashing water in bright light Used for taking pictures of black and white text with increased contrast Used for taking panoramic pictures from left to right.

Used for taking pictures to produce an antique (brownish) look Used for taking black-and-white pictures Used for taking pictures to produce increased contrast and color saturation Used for taking pictures for a neutral scene Used for taking pictures to produce a reddish picture Used for taking pictures to produce a greenish picture Used for taking pictures to produce a bluish picture Polaroid i835 Digital Camera User Guide www.polaroid.com 33 · Setting Face Tracking 1. Press the button to set the camera to Still Image mode. 2.

Press button to access scene mode. button to select Face Tracking 3. Press the or Face Tracking. 4. Press the selection. button to confirm your Used for tracking human faces in the pictures NOTE: · The camera uses the single AF window to automatically set the focus. When the shutter button is pressed halfway, the camera starts focusing until it "locks" onto your subject. When in focus, the focus frame will turn green. If your subject is not in focus, the focus frame will turn red. Release the shutter button and press the shutter button halfway down again until it turns green.

Press the shutter button all the way down to take you picture. · Face tracking is powered by Arcsoft. · In some photographic scenes, the face tracking function may not be available. 34 Polaroid i835 Digital Camera User Guide www.polaroid.com · Setting Smile Detection This Feature is based on "Face Tracking". When you use smile capture, you need to set the face tracking feature on first.



[You're reading an excerpt. Click here to read official POLAROID I835 user guide](http://yourpdfguides.com/dref/1222018)
<http://yourpdfguides.com/dref/1222018>

1. Press the button to set the camera to Still Image mode. 2.

Press button to access scene mode. button to select button to confirm your Smile Detection Mode Used for taking pictures automatically when subject is smiling 3. Press the or Smile Detection. 4. Press the choice.

5. Half press the shutter button to start the smile detection feature. 6. The camera auto detects faces that are close to the centre of the screen and displays the AF frames (up to 5 frames). 7.

Camera will search for smiles on faces. 8. When all detected faces smile, the camera will take the pictures without you having to fully press the shutter button.

Polaroid i835 Digital Camera User Guide www.polaroid.com 35 NOTE: · There is a 2-second time-out to detect the smiles. If no smile is detected after 2 seconds, the camera will not take photos. Should this happen, you must press the shutter button and press it again to capture smiles in your image. 36

Polaroid i835 Digital Camera User Guide www.polaroid.com

com · Setting Flash Mode Use the flash when you take pictures at night, indoors, you see the "Shake Warning" or outdoors in heavy shadows. The camera has four flash modes (default setting is Auto Flash). Flash Range: Wide: 1.9 ft ~ 7.8 ft (0.6m ~2.4 m) Tele: 1.9 ft ~ 4.9 ft (0.6m ~1.5 m)

1. Press the button to set the camera to Still Image mode. 2. Press the button to cycle through the flash settings and select the one you need. The icon (according to the flash setting you selected) will appear on the LCD screen.

Polaroid i835 Digital Camera User Guide www.polaroid.com 37 Display Option Auto Description The flash fires automatically as needed. Use this setting to take most pictures. The flash fires for every picture.

Use this setting in high-contrast situations to provide flash, you see the "Shake Warning" or use it indoors in low light. The flash fires a few times before taking your picture to reduce the red-eye phenomenon. The flash does not fire. Use this setting for outdoor pictures or where flash is prohibited or may be distracting. Use when shooting toward a reflective surface, such as a window or mirror. If you do not have enough light when using this setting, your pictures will be too dark. A Always On Red-eye Reduction Flash Off NOTE: · Flash modes are only used in still image shooting. · Never touch or block the flash with your fingers. Need help with your digital camera? Call our toll-free customer service number. Look for the insert with this icon: Or visit www.polaroid.com.

www.polaroid.com. 38 Polaroid i835 Digital Camera User Guide www.polaroid.com · Setting Self-timer Your camera is designed with a self timer function which will allow you to take pictures with a count down of 2 or 10 seconds.

1. Press the 2. Press the button to set the camera to Still Image mode. button to select self-timer. Display Off 2 Option Single shot 2-Second 10-Second Burst Record a single image Description Take a picture after a count down of 2 seconds

Take a picture after a count down of 10 seconds Press and hold the shutter button to take four pictures in succession 10 3.

Capture procedures are the same as for taking a picture in the normal capture mode. See page 28. NOTE: · This feature is only available in Still Image mode.

· Place the camera on a flat surface or use a tripod when using the self-timer function. Polaroid i835 Digital Camera User Guide www.polaroid.com

www.polaroid.com 39 · Setting the Picture Resolution and Compression Picture resolution refers to the number of pixels in a digital picture. Picture quality depends on the JPEG file compression that the camera applies when the picture is taken. Higher resolution and less compression makes better quality and occupies more memory space. Smaller size and normal quality pictures are easier to email while larger size and fine quality pictures are better for printing.

Resolution setting 1. Press the button to set the camera to Still Image mode. Resolution STILL 3264x2448 Super Fine Normal Off Off 1/2 2. Press the 3. Press the (Resolution). 4. Press the button to enter menu bar. or to select Compression Sharpness Digital Zoom AF- assist Beam button to enter. button to select

Resolution 3264X2448 3072X2304 2816X2112 2048X1536 1600X1200 1/2 5. Press the or the desired setting.

6. Press the choice. button to confirm your 40 Polaroid i835 Digital Camera User Guide www.polaroid.com Compression setting 1. Press the button to set the camera to Still Image mode. Resolution STILL 3264x2448 Super Fine Normal Off Off 1/2 2. Press the button to enter menu bar. to select ICON Compression

Sharpness 3. Press the or (Compression).

4. Press the Digital Zoom AF- assist Beam button to enter. button to select the Compression Super Fine Fine Normal 5. Press the or desired setting. 6.

Press the choice. button to confirm your Need help with your digital camera? Call our toll-free customer service number. Look for the insert with this icon:

Or visit www.polaroid.com.

Polaroid i835 Digital Camera User Guide www.polaroid.com 41 The chart below indicates the approximate numbers of pictures you can expect the camera to hold at different resolution and quality setting based on the 32MB internal memory. You can expand memory using a Polaroid SD memory card. Please refer to "Capacity of SD Card" on page 106 for further details.

Compression Resolution 3264 X 2448 3072 X 2304 2816 X 2112 2048 X 1536 1600 X 1200 640 x 480 7 8 9 18 29 152 21 24 28 52 84 304 30 34 42 76 117 504 Super Fine Fine Normal Scene complexity affects a picture's file size. For example, a picture of trees in autumn has a larger file size than pictures of blue sky at the same resolution and quality setting. Therefore, the number of picture or the

length of video clips you can store on a memory card may vary. The number of pictures on the LCD screen is for reference only. NOTE: 4 Polaroid i835 Digital Camera User Guide www.polaroid.com

Digital Camera User Guide www.polaroid.com

www.polaroid.com · Setting the Sharpness Use the sharpness setting to highlight or blend the edges of subjects in pictures. 1. Press the button to set the camera to Still Image mode. 2. Press the 3. Press the (Sharpness). 4. Press the button to enter menu bar. or to select Resolution Compression Sharpness Digital Zoom

AF- assist Beam STILL 3264x2448 Super Fine Normal Off Off 1/2 button to enter.

button to select the Sharpness Strong Normal Soft 5. Press the or desired setting. 6. Press the choice. button to confirm your STRONG Increases contrast on the edge of the picture.

Image color noise (grain) may occur in the recording image. NORMAL The edges of the image are sharp, this is suitable for printing. SOFT Softens the edge of the picture, creating a "soft focus" effect. Polaroid i835 Digital Camera User Guide www.polaroid.com

com 43 · Zoom Feature There are two types of zoom in this camera: optical zoom and digital zoom. Optical zoom alters the focal distance, and its factor range is 1X to 3X.



[You're reading an excerpt. Click here to read official POLAROID](http://yourpdfguides.com/dref/1222018)

[1835 user guide](http://yourpdfguides.com/dref/1222018)

<http://yourpdfguides.com/dref/1222018>

Digital zoom is activated after you reach the maximum optical zoom (3X). It enlarges the part of the image at the centre of the image screen. Digital zoom factor range is 1X to 4X. These zoom features let you zoom in the central area of an image and photograph only the enlarged portion of the picture. NOTE: · Using the digital zoom may cause a slight decrease in image quality. Zoom In and Out the Image 1. Press the button to set the camera to Still Image mode. 2.

Press the to zoom in the subject, or press the button to return to original zoom status. While you press the or button, a yellow square will appear on the zoom status bar as illustrated. The yellow square in the bar indicates the zoom status. "T" stands for "Tele" and "W" stands for "Wide". Keep the button pressed, and the camera will switch from optical zoom to digital zoom when it reaches the maximum optical zoom. Zoom Status Bar 44 Polaroid i835 Digital Camera User Guide www.polaroid.com 3. Now you can take pictures and review them with the zoom setting you set. The zoom setting will remain after pictures are taken.

If you want to take a normal size picture, please use the button. Digital zoom status NOTE: · You may notice a decrease in image quality when using the digital zoom. · Digital zoom feature is also available in Video and Playback modes. Polaroid i835 Digital Camera User Guide www.polaroid.com 45 · Turning Digital Zoom On and Off 1. Press the button to set the camera to Still Image mode. 2. Press the 3. Press the Zoom). 4. Press the button to enter menu bar. or to select (Digital Resolution Compression Sharpness Digital Zoom AF- assist Beam STILL 3264x2448 Super Fine Normal Off Off 1/2 button to enter. button to select the Digital Zoom Off On 5. Press the or desired setting. 6. Press the choice. button to confirm your 46 Polaroid i835 Digital Camera User Guide www.polaroid.com · Turning the Auto-focus Assist Beam On and Off Under this setting, you can turn the Auto-Focus assist beam on or off.

When it is turned on, the focus assistant lamp gives out a strong beam and helps the camera easily focus on the subject. 1. Press the button to set the camera to Still Image mode. 2. Press the 3. Press the assist Beam). 4. Press the button to enter menu bar. or to select (AFResolution Compression Sharpness Digital Zoom AF- assist Beam STILL 3264x2448 Super Fine Normal Off Off 1/2 button to enter. button to select the AF-assist Beam Off On 5.

Press the or desired setting. 6. Press the choice. button to confirm your Polaroid i835 Digital Camera User Guide www.polaroid.com 47 · Specifying the Quick Review Period A quick review of pictures (after pictures have been taken) is available with options of 2 or 5 seconds. Follow the instructions below to set the quick review period: 1. Press the button to set the camera to Still Image mode. STILL 2. Press the 3. Press the Review). 4. Press the button to enter menu bar. or to select (Quick Quick Review Focus Area Blink 2 Seconds Single AF Off button to enter. button to select the Off 2 Seconds 5 Seconds 2/2 5. Press the or desired setting. 6. Press the choice. Quick Review button to confirm your Need help with your digital camera? Call our toll-free customer service number. Look for the insert with this icon: Or visit www.

polaroid.com. 48 Polaroid i835 Digital Camera User Guide www.polaroid.com · Selecting Focus Area 1. Press the button to set the camera to Still Image mode. 2. Press the 3. Press the Area). 4. Press the button to enter menu bar. or to select (Focus 2/2 Quick Review Focus Area Blink STILL 2 Seconds Single AF Off button to enter. button to select the Focus Area Single AF 3-Point AF 5. Press the or desired setting. 6.

Press the choice. Single AF button to confirm your The camera uses the single AF window to automatically set the focus. When the shutter button is pressed halfway, the camera starts focusing until it "locks" onto your subject. When in focus, the focus frame will turn green. If your subject is not in focus, the focus frame will turn red.

Release the shutter button and press the shutter button halfway down again. Keep your subject centered on the LCD display. When the best focus position has been selected, a green graphic will be displayed on the LCD screen. The camera uses three AF windows (left, centre and right) to automatically set the focus.

When the shutter button is pressed halfway, the camera starts focusing until it "locks" onto your subject. When the best focus position has been selected, a green graphic will be displayed on the LCD screen. 49 3-Point AF Polaroid i835 Digital Camera User Guide www.polaroid.com · Setting Blink Detection NO MORE CLOSED EYES IN YOUR PICTURES. This feature allows the camera to detect when the subjects' eyes are open.

The camera still take the pictures when the subjects' eyes are not open. After you take blinked pictures, there would be a red frame on the subjects' faces. When you playback the pictures, there will exist an exclamation mark and a triangle to sign the blinked pictures. 1. Press the button to set the camera to Still Image mode. STILL 2. Press the 3. Press the (Blink). 4. Press the button to enter menu bar.

or to select Quick Review Focus Area Blink 2 Seconds Single AF Off 2/2 button to enter. button to select the Off On Blink 5. Press the or desired setting. 6. Press the choice.

button to confirm your NOTE: Blink detection is active only for Auto, Manual, Face Tracking, Portrait, Sport, Night Portrait, Children, Party Mode. 50 Polaroid i835 Digital Camera User Guide www.polaroid.com · Setting Exposure Compensation You can adjust the exposure compensation value (EV) within the range of -2EV to +2EV in order to compensate for current lighting conditions. This setting can be used to obtain better results when shooting with backlighting, indirect indoor lighting, a dark background, and so on.

1. Press the button to set the camera to Still Image mode. 2. Press the button. "Exposure". button to select the button to confirm your Exposure 3. Current option is 4. Press the or desired setting. 5. Press the choice.

NOTE: · A higher EV value is used for light-colored and backlit subjects. A lower EV value is better for dark-colored and shooting outdoors on a clear day. · When shooting under very dark or very bright conditions, you may not be able to obtain satisfactory results even if performing exposure compensation. Need help with your digital camera? Call our toll-free customer service number. Look for the insert with this icon: Or visit www.polaroid.com. Polaroid i835 Digital Camera User Guide www.polaroid.com 51 · Setting the ISO This function enables you to change the camera's sensitivity to light by selecting the different ISO values.



[You're reading an excerpt. Click here to read official POLAROID I835 user guide](http://yourpdfguides.com/dref/1222018)
<http://yourpdfguides.com/dref/1222018>

ISO is a measure of how quickly your camera reacts to light. The higher the ISO value, the less light the camera needs to make an exposure, allowing the same exposure to be achieved with higher shutter speeds or smaller apertures. In a digital camera, higher ISO value allows higher shutter speed come at the expense of mottled or grain appearing in the final picture. 1. Press the button to set the camera to Still Image mode.

(See page 31) 2. Press the "ISO". or button to select ISO 3. Press the or desired setting. 4.

Press the choice. Auto button to select the button to confirm your The camera's sensitivity is automatically changed by different lighting value or subject brightness. 80/100/200/400/800/1600 In the same lighting condition, the higher the ISO value is, the faster the shutter speed will be. NOTE: · Higher ISO speeds increase the image noise. To get better images, use as low as ISO speed as possible. · Only scene shooting is in manual mode, can ISO be operational manually. 5 Polaroid i835 Digital Camera User Guide www.polaroid.com · Setting White Balance Selecting the right type of white balance can help to make the color of a subject appear more natural under the type of lighting that is available. 1.

Press the 2. Press the button to set the camera to Still Image mode. button. button to select White Balance 3. Press the or "White Balance". 4. Press the or button to select the desired setting. 5. Press the button to confirm your choice. Option Description Auto Automatic adjustment.

Use this for most picture taking scenes. @@@@Neutral standard fluorescent Indoors, illuminated by cool white fluorescent lighting. NOTE: (Video) mode. · This setting is also available in · White balance is measured by color temperature. Color temperature is higher, the photo you take is incline to blue; the color temperature is lower, the photo you take is incline to red.

Polaroid i835 Digital Camera User Guide www.polaroid.com 53 · Setting Shutter Speed 1. Press the button to set the camera to Still Image mode. (See page 31) 2.

Press the button. button to select button to select the button to confirm your Shutter Speed 3. Press the or "Shutter Speed". 4. Press the or desired setting. 5.

Press the choice. NOTE: · You can only adjust the shutter speed by using the camera in the Manual mode. 54 Polaroid i835 Digital Camera User Guide www.polaroid.com.

com · Setting Light Metering Use the light metering setting to ensure that the proper amount of light enters into the camera lens. 1. Press the button to set the camera to Still Image mode. 2. Press the button. button to select Light Metering 3. Press the or "Light Metering". 4. Press the or desired setting. 5.

Press the choice. Option button to select the button to confirm your Description Evaluates the lighting conditions throughout the picture to give an optimum picture exposure. Ideal for general picture taking. Evaluates the lighting conditions of the subject centered on the LCD screen. Ideal for backlit subjects.

Similar to Centre, except the metering is concentrated on a smaller area of the subject centered on the LCD. Ideal when an exact exposure of a specific area in the picture is needed. Polaroid i835 Digital Camera User Guide www.polaroid.com 55 4 Recording Video Clips · Recording Video Clips 1.

Press the Use the Video mode to record video clips together with audio. button to set the camera to (Video mode). NOTE: The icon will appear on the LCD screen, indicating the Video mode is activated. 2. Frame your screen. 3. Press the recording. subject Shutter using button the to LCD start 4. Press the Shutter button again to stop recording, or recording stops when the current memory is full. 5.

Press the or or out the subject. button to zoom in NOTE: · Digital zoom feature is not available when recording video. 56 Polaroid i835 Digital Camera User Guide www.polaroid.com · Setting Video Resolution Video resolution refers to the number of pixels in a digital video clip. Video clip quality depends on the file resolution that the camera applies when the video clip is recorded. Higher resolution makes better quality while occupying more memory space. 1. Press the button to set the camera to (Video mode). 2.

Press the 3. Press the (Resolution). 4. Press the button. button to select button to enter.

button to select Resolution 640X480 320X240 VIDEO Resolution 640x480 5. Press the and the desired setting. 6. Press the button. Here are the approximate length of video clips you can expect the camera to hold at each setting based on the 32MB memory card.

You can expand the memory with a Polaroid SD memory card. Please refer to "Capacity of SD Card" on page 108 for further details. Resolution: 640 X 480 Approx. 0.35 minute (30 fps) 320 X 240 Approx. 1.2 minutes (30 fps) NOTE: is the default value, suitable for viewing on TV. is suitable for viewing on PC.

Polaroid i835 Digital Camera User Guide www.polaroid.com.

com 57 · Setting Exposure Compensation for Video Clips You can adjust the exposure compensation value (EV) within the range of 2EV to +2EV in order to compensate for current lighting conditions. This setting can be used to obtain better result when shooting with backlighting, indirect indoor lighting, a dark background, and so on. 1. Press the 2. Press the button to set the camera to button. (Exposure). button to select the Exposure (Video mode). 3. Current option is 4. Press the or desired setting.

5. Press the button. NOTE: · A higher EV is best used for light-colored subjects and backlit subjects. A lower EV is best for dark-colored subjects and for shooting outdoors on a clear day. · When shooting under very dark or very bright conditions, you may not be able to obtain satisfactory results even if performing exposure compensation.

Need help with your digital camera? Call our toll-free customer service number. Look for the insert with this icon: Or visit www.polaroid.com. 58 Polaroid i835 Digital Camera User Guide www.polaroid.com.

polaroid.com · Setting White Balance for Video Clips Selecting the right type of white balance can help to make the color of a subject in the video clip appear more natural under the type of lighting that is available. Exposure 1. Press the button to set the camera to (Video mode). 2. Press the button. button to select button to select the Auto 3. Press the and (White Balance). 4. Press the or desired setting.

5. @@Use this for most picture taking scenes. @@@@@@Press the button to set the camera to Playback mode. 2. Use the and pictures taken. @@Press the button to set the camera to Playback mode. 2. @@3. Press the 4. @@Press the button to set the camera to Playback mode.

2. Use the picture. 3. Press 4. Press the picture.

5. @@@@Press the 2. Press the 3. Press the 4. Press the 5.

@@button again to pause. @@@@Press button. or button to select 3. Press the "Protect".



[You're reading an excerpt. Click here to read official POLAROID I835 user guide](http://yourpdfguides.com/dref/1222018)

<http://yourpdfguides.com/dref/1222018>

4. Press the Copy From Card button to enter. button to select the Off On Protect 5. Press the or desired setting. 6. @@The icon will disappear from the LCD screen.

To protect the selected file. The LCD screen. @@@@1. Press the button to set the camera to Playback mode. 2. Press button. @@Press the "Slide Show". 4. Press the button to enter. button to select the 5.

Press the or desired setting. 6. @@Press the button to stop the slide show. @@1. Insert an SD card into the camera.

2. Turn on the camera. Set the camera's storage media to internal memory. 3. Press the button to set the camera to Playback mode.

4. Press button. @@Press the or "Copy To Card". 6. Press the button to enter. button to select the 7. Press the or desired setting. 8. @@@@1. Insert an SD card into the camera.

2. Turn on the camera. 3. Press the button to set the camera to Playback mode. 4. Press button. button to select Copy From Card This Image All Images PLAYBACK Protect Slide Show Copy To Card Copy From Card Off 5. Press the or "Copy From Card". 6. Press the button to enter.

button to select the 7. Press the or desired setting. 8. @@@@Copy all pictures and video clips stored in the current memory. ALL IMAGES Polaroid i835 Digital Camera User Guide www.

polaroid.com 65 · Deleting Pictures or Video Clip 1. Press the button to set the camera to Playback mode. Deleting a Single Picture or Video Clip 2. Press the or button to select the picture or video clip you want to delete.

3. Press the button. button to select the Delete Button 4. Press the or desired setting. 5. Press the button. This Image All 6. Press the or desired setting. 7. Press the choice.

button to select the button to confirm your Erase This ? Cancel OK 66 Polaroid i835 Digital Camera User Guide www.polaroid.com Deleting All Pictures and Video Clips 2. Press the 3. Press the "All". 4. Press the button. or button. button to select Erase all images & videos ? Cancel OK button to select This Image All 5. Press the or the desired setting.

6. Press the choice. button to confirm your This Image All Delete a selected unprotected option. Delete all the unprotected files in the current memory. NOTE: · Protected files cannot be deleted.

Remove protection before deleting. · All deleted pictures and video clips cannot be recovered. Need help with your digital camera? Call our toll-free customer service number. Look for the insert with this icon: Or visit www.polaroid.

com. Polaroid i835 Digital Camera User Guide www.polaroid.com 67 · Image Cropping Under this setting, the currently displayed JPEG picture can be cropped to the size or a location on the image. 1. Press the button to set the camera to Playback mode. 2. Select an image you want to crop. 3. Press the 4.

Press the "Crop". 5. Crop button. or button to select Press the button to enter. 6. Press and buttons to control the size of the crop mark. Press the , , , buttons to move the crop mark. 7. Press the button. 8.

Press the your choice. or button to confirm Zoom Move Crop this image to...? Cancel OK 9.

Press the button to return back to the main menu. 10. Press the Cancel OK 68 or button to select "Save" to save your image. It returns to the main menu without cropping. Image crops and returns back to the main menu.

Polaroid i835 Digital Camera User Guide www.polaroid.com · Dynamic Lighting This function allows you to improve your images by making changes to color enhancement, contrast and /or level. 1. Press the button to set the camera to Playback mode. 2. Select an image you want to edit. 3. Press the button. 4.

Press the or "Dynamic Lighting". 5. Press the 6. Press the your option. 7. Press the choice. button to select Dynamic Lighting button to enter. or button to adjust button to confirm your Return Option 1 8. Press the button to return back to the main menu. 9.

Press the or button to select "Save" to save your image. Option 1 Color enhancement. To find the average lightest and darkest pixels in an image and uses them to maximize contrast while minimizing clipping. Contrast enhancement. To enhance monochromatic contrast clips all channels identically.

This preserves the overall color relationship while making highlights appear lighter and shadows darker. Level enhancement. To enhance per channel contrast maximizes the tonal range in each channel to produce a more dramatic correction. 69 Option 2 Option 3 Polaroid i835 Digital Camera User Guide www.polaroid.

com · Red-eye Removal Under this setting, red-eye in your subject's eyes may be removed from the image. 1. Press the button to set the camera to Playback mode. 2. Select an image you want to edit. 3. Press the button. button to select Red Eye Remove 4. Press the or "Red Eye Remove". 5.

Press the choice. 6. Press the menu. button to confirm your button to return to the main Return 7. Press the or button to select "Save" to save your image. 70 Polaroid i835 Digital Camera User Guide www.polaroid.com · Saving Your Pictures Using "SAVE" 1. Press the button to set the camera to Playback mode. 2.

Select an image you want to edit. 3. Press the 4. Press the "Save". 5.

Press the button. or button to select Save Save the image ? Cancel OK Save button to enter. button to select 6. Press the or the desired setting. 7.

Press the choice. button to confirm your Polaroid i835 Digital Camera User Guide www.polaroid.com 71 · Saving Your Pictures Using "SAVE AS" 1. Press the button to set the camera to Playback mode. 2. Select an image you want to edit. 3. Press the 4. Press the "Save As".

5. Save As button. or button to select Save As Save the image to ... Cancel OK Press the button to enter. button to select the 6. Press the or desired setting. 7. Press the choice.

button to confirm your NOTE: · A new picture will be created and saved onto the internal memory or SD Card. 7 Polaroid i835 Digital Camera User Guide www.polaroid.com · Exiting Editing Menu After you enter editing menu to edit your images, follow the actions below will exit. Exit 1.

Press the "Exit". 2. or button to select Press the button to enter. button to select the Exit Save Save As Exit Cancel 3. Press the or desired setting.

Polaroid i835 Digital Camera User Guide www.polaroid.com 73 · Viewing Pictures and Video Clips on a TV To set the video output system: The video output signal (NTSC or PAL) can be switched to accommodate different signal systems. For example, NTSC for U.S.A., Canada, Taiwan, Japan, etc. and PAL for Europe, Asia (excluding Taiwan), etc. You can change the video output system according to the following steps: SETUP 1. Access the setup menu.

2. Press the or (Video System). 3. Press the button to select Date /Time Auto Power Off Beep Sound Volume Video System 1/3 button to enter.

[You're reading an excerpt. Click here to read official POLAROID](#)



[I835 user guide](#)

<http://yourpdfguides.com/dref/1222018>

button to select LCD 4. Press the or the desired setting. 5. Press the choice. Video System . NTSC PAL button to confirm your NOTE: · Please connect to TV before choosing NTSC and PAL for video output system.

74 Polaroid i835 Digital Camera User Guide www.polaroid.com 6 Print Settings · About PictBridge PictBridge is a new industry standard that allows you to print images directly from a PictBridge enable digital still camera to a PictBridge compatible printer without using a photo editing software or a computer.

Printing Procedures 1. Preparing the camera and the printer.

Camera Printer Be sure battery level is full before printing. Refer to the user guide that comes with your printer and make preparations (paper, ink cassette, cartridge, etc.) as required. Turn on the camera and the printer. 2.

Selecting PictBridge mode Set the camera to playback mode and select the PictBridge mode. Refer to page 78 for details. 3. Connecting the camera to the printer Refer to "Camera / Printer Connection" on page 78 for details. 4. Select print settings. Use the camera's function and navigation buttons to select the print settings. 5. Printing Press the button to start printing. Polaroid i835 Digital Camera User Guide www.

polaroid.com 75 Printing Errors Printing operation may still fail with some errors even if you press the button after selecting "CONTINUE". In that case, select "CANCEL" and press the button. NOTE: Please refer to the printer's user guide for the solutions. Printing may resume once the problem is solved.

Need help with your digital camera? Call our toll-free customer service number. Look for the insert with this icon: Or visit www.polaroid.com. 76 Polaroid i835 Digital Camera User Guide www.

polaroid.com List of Error Messages PAPER IS EMPTY PAPER IS NOT LOADED PAPER IS NOT EJECTED MEDIA ERROR PAPER IS JAMMED PAPER IS NEARLY EMPTY PAPER TYPE IS NOT SUPPORTED INK EMPTY INK LOW WASTE INK RESERVOIR FULL HARDWARE FATAL ERROR PRINTER IS BUSY PRINTER IS OCCUPIED COVER IS OPENED NO MARKING AGENT INK COVER IS OPENED NO INK CARTRIDGE SPECIFIED INFO IS TOO LARGE FILE DECODE ERROR Paper cassette runs out of paper. Paper is not loaded or incorrectly loaded. Paper is not ejected correctly. Paper is not detected, paper is skewed, or roll paper cannot be cut or torn off The paper is jammed during printing.

Paper cassette almost out of paper. Paper type or size is not supported by the printer or paper found in the printer does not match request. Ink cassette is out of ink. Ink cassette is almost empty. Waste ink reservoir is full.

A serious error occurs with the printer's hardware. The printer is busy with other print jobs from another source. The printer is performing maintenance or occupied by other external device. The printer's cover is open or not securely closed. Some print information is missing during printing, e.g. missing print head. The printer's ink cover is open or not securely closed. No ink cartridge is loaded. Image information is too large to process.

Picture format of specified image cannot be decoded. Polaroid i835 Digital Camera User Guide www.polaroid.com 77 Selecting PictBridge Mode 1. Press the button to set the camera to Playback mode. 2. Press the button and press the button to enter print setting. or button to select the 3. Press PICTBRIDGE option. Camera / Printer Connection 4.

Plug Series A of the USB cable into the marked socket on your printer. Plug USB of the USB cable into the port on your camera. Location of USB socket will vary from printer to printer. DPOF Pictbridge PRINT SETTING To Printer 78 Polaroid i835 Digital Camera User Guide www.polaroid.

com 5. System will enter Pictbridge menu automatically. Pictbridge This Image Please Connect To Device Device Is Connected All Images All Index NOTE: · " DEVICE IS CONNECTED" displays on the LCD screen, indicating a proper connection to the printer. · Do not connect the USB cable to the camera until PictBridge is enable and when prompted by the "PLEASE CONNECT TO DEVICE" screen. Or if you already have connected the cable to the camera, do not plug into printer until prompt to do so.

Not following this sequence will result in connection failure. Selecting Print Settings 1. Press or print mode. button to select the Pictbridge This Image All Images All Index 2. The following options are available. THIS IMAGE Print the selected image in the camera's internal memory or a memory card according to specified settings. Use the left or right button to designate the image you want to print before selecting the print settings. Print all images in the camera's internal memory or a memory card according to the specified settings. All images in the camera's internal memory or a memory card are given an index and printed according to the specified settings. ALL IMAGES ALL INDEX Polaroid i835 Digital Camera User Guide www.

polaroid.com 79 NOTE: · Print settings are configured for images only. Make sure there are no video clips or other file besides images in the memory before printing. · Not all printers will support all these print options. Please refer to the printer user guide for options available. 3. Press the button to select the print settings. No. of Copy 05 1 Off On A4 Number of Copies Print Layout File Name On/Off Date Stamp On/Off Paper Size Select a setting item using the up or down button and select setting contents using the left or right button. NOTE: The camera's print settings are not supported by some printers.

The LCD screen shows those settings that are available for the currently connected printer. Need help with your digital camera? Call our toll-free customer service number. Look for the insert with this icon: Or visit www.polaroid.com.

80 Polaroid i835 Digital Camera User Guide www.polaroid.com Specifying the Number of Copies Press the or button to specify the number of copies (from 1 to 99) you want to print for the selected image or all images. NOTE: "01" is the default setting. No.

of Copy 05 1 Off On A4 Selecting Print Layout 1. Press the or "N-UP LAYOUT". button to select N-up Layout 05 1 Off On A4 2. Press the or button to specify the number of printed images on a page. DEFAULT 1/2/4/6/8 BORDERLESS Print settings differ according to the printer model. Specify the number of printed images on a page. Print right to the edge of the page. Setting the File Name On/Off 1. Press the or button to select "FILE NAME". 2.

Press the or button to select "DEFAULT", "ON" or "OFF". DEFAULT ON OFF File Name 05 1 Off On A4 Print settings differ according to the printer model. Add the file name to the printed image. Print without the file name. 81 Polaroid i835 Digital Camera User Guide www.polaroid.com Setting the Date Stamp On/Off 1. Press the or button to select "DATE STAMPING".



[You're reading an excerpt. Click here to read official POLAROID I835 user guide](http://yourpdfguides.com/dref/1222018)
<http://yourpdfguides.com/dref/1222018>

2. Press the or button to select "DEFAULT", "ON" or "OFF".

DEFAULT ON OFF Date Stamping 05 1 Off On A4 Print settings differ according to the printer model. Add the date stamp to the printed image. Print without the date stamp. Selecting Paper Size 1. Press the or button to select "SIZE".

2. Press the or button to select the paper size. The following paper sizes are supported: 8" x 10", 4" x 6", A4, A6, 11" x 17", B5, postcard, full and default.

DEFAULT Size 05 1 Off On A4 Print settings differ according to the printer model. Printing 1.

Press the 2. Press the 3. Press the Press the button. or button to select "OK". button. button to return to the print setting window. 8 Polaroid i835 Digital Camera User Guide www.polaroid.com · About DPOF DPOF stands for "Digital Print Order Format", which is a format for recording on a memory card or other medium which digital camera images should be printed and how many copies of the image should be printed. You can print on a DPOF-compatible printer or at a professional print service from the memory card in accordance with the file name and number of copies settings recorded on the card.

With this camera, you should always select images by viewing them on the LCD screen. Do not specify images by file name without viewing the file contents.

NOTE: Print settings are configured for images only. Make sure there are no video clips or other file besides images in the memory before printing. 1. Insert an SD card into the camera. 2. Turn on the camera. 3. Press the button to set the camera to Playback mode.

4. Press the button and press the button to enter print setting. 5. Press or DPOF option. 6.

Press the button to select the DPOF Pictbridge PRINT SETTING DPOF Select Images All Images button to enter. 83 Polaroid i835 Digital Camera User Guide www.polaroid.com 7. Press the or desired setting.

8. Press the button. button to select the DPOF 9. Specifying the number of printing copy using the or button. 10. Press the button. Print 05 Images? 11. Remove the memory card from the camera and insert it into the printer's card slot (as illustrated). Location of the card slot may vary from printer to printer model. NOTE: Make sure you turn off the camera before inserting or removing a memory card.

12. Press the Print button on the printer to start printing. SELECT IMAGES ALL IMAGES The selected picture in the memory card will be printed up to 99 copies. All pictures in the memory card will be printed up to 99. Polaroid i835 Digital Camera User Guide www.polaroid.com 84 7 Using the SD (Secure Digital) Card · Using the SD Card Your camera comes with built-in flash memory for storing pictures and video clips. You can expand the memory by using a Polaroid SD card (sold separately) (up to 4GB). The camera senses whether a memory card is inserted, and automatically saves pictures and video clips accordingly. Note that you cannot save pictures or video clips to the built-in flash memory while a memory card is installed in the camera.

See pages 106 to 107 for storage capacities. Memory card precautions: 1. Use only a compatible SD memory card with this camera preferably a Polaroid SD card. 2. Electrostatic charge, electrical noise, and other phenomena can cause data corruption or even loss.

Always make sure that you always back up important data on other media (MO disc, computer hard drive, etc.). 3. If a memory card starts to behave abnormally, you can restore normal operation by formatting it. However, we recommend that you always take along with more than one memory card whenever using the camera far away from your home or office.

4. We recommend that you format a memory card when using it for the first time, or whenever the card you are using seems to be the cause of abnormal pictures. Remember to format a memory card if it was used in another digital camera or other devices. Need help with your digital camera? Call our toll-free customer service number. Look for the insert with this icon: Or visit www.polaroid.com. Polaroid i835 Digital Camera User Guide www.polaroid.com 85 IMPORTANT! · Make sure you turn off the camera before inserting or removing a memory card.

· Be sure to orient the card correctly when inserting it. Never try to force a memory card into the slot when you feel resistance. · SD memory cards have a write protection switch that you can use to protect files from accidental deletion. However, you must remove the write protection whenever you want to record new files onto it, format it, or delete its files. · Files contained in the SD card recorded by other cameras may conflict with the i835 camera, and valuable data in your existing SD card may be distorted or lost when the card is inserted in the i835 camera. We strongly recommend the user to use a new or formatted Polaroid (not included) SD card for the i835 camera. The manufacturer is not liable for losing or corrupting any valuable data or files in your SD card due to improper operation. Inserting a SD card 1. Turn off the camera. 2.

Open the Battery/SD card door by pushing it outwards as illustrated. 3. Insert the SD card and ensure the card is inserted the correct position as illustrated.

4. Close the Battery/SD card door by pressing it downwards and slide it back to lock.

1 3 a b b a The icon will appear on the LCD screen when a SD card is inserted into the camera. 86 Polaroid i835 Digital Camera User Guide www.polaroid.com Removing the SD card To remove the SD card, turn off your camera and open the Battery/SD card door. Gently push the SD card inwards and then release it.

The SD card will eject out of the SD card slot. 1 a b IMPORTANT! · Never insert any other object into the camera's SD card slot. Doing so results in the risk of damage to the camera and card. · Should water or any foreign objects ever get into the card slot, immediately turn off the camera, remove the battery or disconnect the AC adapter, and contact your dealer or the nearest service provider. · Never remove a card from the camera while the camera is powered on.

Doing so can cause the picture or video recording operation to fail, and even damage the memory card. Need help with your digital camera? Call our toll-free customer service number. Look for the insert with this icon: Or visit www.polaroid.com.

Polaroid i835 Digital Camera User Guide www.polaroid.com 87 · Formatting the SD card Formatting a memory card erases all data stored on it, including the protected ones. Removing the SD card during formatting may damage the card. 1. Insert an SD card into the camera. SETUP 2. Turn on the camera. 3. Access the setup menu.

4. Press the (Format). 5. Press the or button to select Language Date Stamp LCD Brightness Format Sequence No. English Date Off 2/3 Format button to enter.

button to select the Internal Memory SD Card 6. Press the or desired setting.



[You're reading an excerpt. Click here to read official POLAROID i835 user guide](http://yourpdfguides.com/dref/1222018)
<http://yourpdfguides.com/dref/1222018>