



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for RANE MP 4. You'll find the answers to all your questions on the RANE MP 4 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual RANE MP 4
User guide RANE MP 4
Operating instructions RANE MP 4
Instructions for use RANE MP 4
Instruction manual RANE MP 4

MP 4 QUICK START

WELCOME
Before installing, visit scratchlive.net to be sure you have the latest Scratch LIVE software update. Check back regularly for updates, advice and tips. If you are new to computers and installing software, read this section first.

- At scratchlive.net, click **UPDATE** your Scratch LIVE.
- See if the version online is higher than the disc you have.
 - If it is the same, proceed to the Mac or Windows installation section.
 - If it is higher, click the download link for Mac or Win software.
- Enter your email before you can download. We recommend joining the Forum to learn more about using Scratch LIVE (optional).
- Do you want to open or save this file? Click **Save**, and navigate to an easy place to find it, such as your desktop. When using Vista's Windows Explorer, click **Browse Folders** in the lower left corner and select **Desktop**.

WINDOWS XP & VISTA INSTALLATION

- Temporarily disconnect any unnecessary USB devices from your PC that may consume bandwidth.
- Connect the MP 4 to your computer with the included USB cable.
- The WDM drivers are installed as the Found New Hardware bubbles appear:
 - MP 4
 - USB Composite Device
 - MP 4 USB1 Out
 - USB Audio Device
 - MP 4 USB2 Out
 - USB Audio Device
 - MP 4 Line In
 - USB Audio Device
 - MP 4
 - USB Human Interface DeviceYour new hardware is installed and ready to use.
- You now have the option to stop installation and use the WDM drivers with a third-party application if it does not utilize ASIO. If you wish to install Scratch LIVE or use ASIO drivers with a third-party application, keep reading.

SCRATCH LIVE INSTALLATION FOR WINDOWS

- If you wish to use the MP 4 with Scratch LIVE (in Windows), connect the MP 4 with the USB cable, then run the installer.
 - Insert the Software Installation CD. If the CD doesn't start automatically, browse to the CD drive and run **setup.exe**.
 - If you downloaded the installer in Windows XP as described in the previous section, double-click **setup.exe** on your desktop.
 - If you downloaded the installer in Windows Vista, double-click **setup.exe** in the compressed (zipped) folder. If a message tells you the software you are installing has not passed Windows logo testing, choose **Allow** or **Continue Anyway**.
- Follow the on-screen instructions. Once the installation is complete, Scratch LIVE appears in the Start Menu under **All Programs > Serato > Scratch LIVE**. Note: Select **Custom Install** to change the directory you wish to install Scratch LIVE into.

MAC INSTALLATION
Insert the Software Installation CD and double-click the installer icon. Mac users need only connect the MP 4 mixer after installing the software. No extra hardware installation is required.

MP 4 QUICK START V5 RELEASE 1.1.0 1



[You're reading an excerpt. Click here to read official RANE MP 4 user guide](http://yourpdfguides.com/dref/3579477)
<http://yourpdfguides.com/dref/3579477>

Manual abstract:

Temporarily disconnect any unnecessary USB devices from your PC that may consume bandwidth. 2. Connect the MP 4 to your computer with the included USB cable. 3. The WDM drivers are installed as the Found New Hardware bubbles appear: MP 4 USB Composite Device MP 4 USB1 Out USB Audio Device MP 4 USB2 Out USB Audio Device MP 4 Line In USB Audio Device MP 4 USB Human Interface Device Your new hardware is installed and ready to use. 4. You now have the option to stop installation and use the WDM drivers with a third-party application if it does not utilize ASIO. If you wish to install Scratch LIVE or use ASIO drivers with a third-party application, keep reading. MP 4 QUICK START Before installing, visit scratchlive.net to be sure you have the latest Scratch LIVE software update.

Check back regularly for updates, advice and tips. If you are new to computers and installing software, read this section first. 1. At scratchlive.net, click UPDATE your Scratch LIVE.

2. See if the version online is higher than the disc you have. a. If it is the same, proceed to the Mac or Windows installation section. b.

If it is higher, click the download link for Mac or Win software. 3. Enter your email before you can download. We recommend joining the Forum to learn more about using Scratch LIVE (optional). 4. do you want to open or save this file? Click Save, and navigate to an easy place to find it, such as your desktop. When using Vista's Windows Explorer, click Browse Folders in the lower left corner and select desktop. SCRATCH LIVE INSTALLATION FOR WINDOWS 1. If you wish to use the MP 4 with Scratch LIVE (in Windows), connect the MP 4 with the USB cable, then run the installer. a.

Insert the Software Installation CD. @.@b. @.@c. @.@@2. Follow the on-screen instructions. Once the installation is complete, Scratch LIVE appears in the Start Menu under All Programs > Serato > Scratch LIVE. Note: Select Custom Install to change the directory you wish to install Scratch LIVE into. 5.

When the download is complete, click Open. a.

For Mac, just double click the Scratch LIVE Installer and it will install. b. For Windows XP, opening this downloaded file (double-clicking) should uncompress it. A dialog will ask where you want the files: choose desktop. Note: if nothing happens when you double-click the downloaded file, you will need to install an unzip utility to uncompress the file.

Type "unzip" into a search engine for several options. MAC INSTALLATION Insert the Software Installation CD and doubleclick the installer icon. Mac users need only connect the MP 4 mixer after installing the software. No extra hardware installation is required. MP 4 QUICK START VERSION 1.

8.2 1 DRIVER UPDATE TOOL OTHER DRIVERS You can update or reinstall your drivers later by using the Driver Update Tool. By default the Driver Updater will be located at C:\Program Files\Serato\driver_updater.exe. The process works the same on both Windows XP and Vista to ensure use of the correct drivers. 1. Connect the MP 4 mixer to your computer with the USB cable. If the Hardware Wizard shows up, click Cancel. 2. Run the driver_updater.

exe utility. If you are asked whether to install one of the drivers, choose Continue Anyway and the utility will confirm that the driver has been updated. Note: Be aware that Windows system event sounds (beeps, dings, etc.) will come through your MP 4 when it is your sound card. To prevent embarrassment, have no other applications running. Better yet, turn off your computer's sound scheme: Windows XP 1. Start > Control Panel > Sounds and Audio devices. 2. Click the Sounds tab. 3.

Under Sound scheme, change to No Sounds. 4. Click OK. Windows Vista 1. @.@2.

Click Sound. 3. Click the Sounds tab. 4. Under Sound scheme, change to No Sounds.

5. @.@When you install Scratch LIVE, an ASIO driver is also installed. @.@@.@.@You can reduce the USB Buffer Size for lower latency. 3.

@.@@.@System Preferences > Sound. 2. Make changes for both Input and Output. @.@@.@.@Start > Control Panel > Sounds and Audio devices. 2. Click the Audio tab.

3. @.@4. Click OK. Windows Vista 1. @.@2. Click Sound. 3. @.@4. @.@Unplug unnecessary devices and install Scratch LIVE again. You may need to temporarily move your mouse to the built-in USB port.

After installation, reconnect USB units as needed. @.@@.@.@Your application may not support an ASIO bitdepth of 32-bit. @.@@.@Connection requires two USB cables from your computer: one to the MP 4, and another to the USB controller. Installation and features will vary. Search for support instruction articles with your model number at www.scratchlive.net.

CONNECTIONS 1. IN 1 and IN 2 inputs on the back of the MP 4. Push the PHONO / LINE switches out for LINE.

2. Connect the USB cable from the MP 4 to your computer as described in the previous section. Note: TURNTABLE CONNECTION 1. Connect your turntables to the IN 1 and IN 2 inputs on the back of the MP 4. Push the PHONO / LINE switches in for PHONO. 2. Connect the turntable ground wires to the ground post of your mixer. 3. Connect the USB cable from the MP 4 to your computer as described in the previous section. Note: USB MIDI DJ Controller Two CD players or Two Turntables or One of Each.

COMMERCIAL AUDIO EQUIPMENT 24TJ 100-240V 50/60 Hz 7 WATTS MP 4 MADE IN U.S.A. RANE CORP. ACN 001 345 482 HOUSE AUX MIC TO USB RECORD LEVEL BALANCED OUTPUTS: TIP = (+), RING = (-), SLEEVE = SIGNAL GROUND PHONO GROUND MIC L R BALANCED INPUT R FOR CONTINUED GROUNDING PROTECTION DO NOT REMOVE SCREW USB RIGHT LEFT RIGHT LEFT RIGHT LEFT NO YES LINE PHONO IN 2 IN 1 LINE PHONO MP 4 QUICK START VERSION 1.8.2 3 KEYBOARD SHORTCUTS ACTIONS ACCESSED DIRECTLY FROM THE COMPUTER

KEYBOARD KEy ctrl - l ctrl - R ctrl - F ctrl - A ctrl - C ctrl - E ctrl - V ctrl - X ctrl - Z shift - ctrl - shift - ctrl - ACTION Locate the current track. This will highlight the track you most recently loaded. Pressing ctrl - L again will alternate between the tracks recently loaded on both decks. Reveal - the highlighted song is opened in a file browser.

Find - moves the cursor to the search box. Select all. Copy text in edit mode. Edit text. Paste text in edit mode.

Cut text in edit mode. Undo last track load. Move focus up / down through the library or crates. Note that if you have a song highlighted in the song view, and use shift - ctrl - you will move up or down through the library or crates. @.@Add tracks to the prepare window.

Start a new mic recording. Open the track in your default MP3/WAV/OGG/AIF player. Zoom the main waveform display. Alternate focus between crates or songs. @.@@.@.@ctrl - shift - / Toggle the input reverse switch esc Clear search string if searching, or exit Scratch LIVE. Note: Playback, cue and speed controls use Shift or Caps Lock. You can turn this off in the setup screen. lEFT dECK ACTION RIGHT dECK Load the highlighted song to a deck. ctrl - or shift - ctrl - or shift - Load the track currently on one deck onto the other deck as well. ctrl - shift - ctrl - shift - ctrl - / Swap the two currently playing tracks from one deck to the other.



[You're reading an excerpt. Click here to read official RANE MP 4 user guide](http://yourpdfguides.com/dref/3579477)

<http://yourpdfguides.com/dref/3579477>

*ctrl - / Unload the track from a deck. shift - alt - shift - alt - ctrl - , (comma) Place a cue point. ctrl - . (period) 1, 2, 3, 4, 5 Jump to cue points in track. 6, 7, 8, 9, 0 F5 Key lock on / off. F10 Q Play / pause reverse. A W E R T y U I ctrl - I O P [ctrl - [alt - Q alt - W alt - 1, 2, 3, 4, 5 alt - E alt - R alt - O alt - l alt - space bar Play / pause forward. Pitch down. Pitch up. Bend down.
Bend up. Censor. Jump to fader start point. Set fader start point. Set / adjust loop in-point.
Set / adjust loop out-point. Loop on / off. Jump to selected loop. Load previous track. Load next track.
Auto loop on / off. Rewind. Fast forward. Previous loop. Next loop. Activate the tempo tapper. S d F G H J K ctrl - K l ; ' ctrl - ' alt - A alt - S alt - 6, 7, 8, 9, 0 alt - d alt - F alt - P alt - ; alt - space bar (x2) SCRATCHLIVE VERSION 1.8.2 PART 17951 .*



[You're reading an excerpt. Click here to read official RANE MP 4 user guide](http://yourpdfguides.com/dref/3579477)

<http://yourpdfguides.com/dref/3579477>