




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for RICOH AFICIO MP C2500. You'll find the answers to all your questions on the RICOH AFICIO MP C2500 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual RICOH AFICIO MP C2500
User guide RICOH AFICIO MP C2500
Operating instructions RICOH AFICIO MP C2500
Instructions for use RICOH AFICIO MP C2500
Instruction manual RICOH AFICIO MP C2500



C2525/C3030
DSc525/DSc530
LD42Sc/LD430c
Aficio® MP C2500/C3000

Operating Instructions **General Settings Guide**



- 1 Connecting the Machine
- 2 System Settings
- 3 Copier / Document Server Features
- 4 Facsimile Features
- 5 Printer Features
- 6 Scanner Features
- 7 Registering Addresses and Users for Facsimile/Scanner Functions
- 8 Other User Tools
- 9 Appendix

Read this manual carefully before you use this machine and keep it handy for future reference. For safe and correct use, be sure to read the Safety Information in "About This Machine" before using the machine.



[You're reading an excerpt. Click here to read official RICOH AFICIO MP C2500 user guide](http://yourpdfguides.com/dref/3177271)

<http://yourpdfguides.com/dref/3177271>

Manual abstract:

@@In no event will the company be liable for direct, indirect, special, incidental, or consequential damages as a result of handling or operating the machine. Notes: Some illustrations in this manual might be slightly different from the machine. Certain options might not be available in some countries. For details, please contact your local dealer. Depending on which country you are in, certain units may be optional. For details, please contact your local dealer. Notes:

The model names of the machines do not appear in the following pages. Check the type of your machine before reading this manual. · · Type 1: C2525/DSc525/LD425c/Aficio MP C2500 Type 2: C3030/DSc530/LD430c/Aficio MP C3000 Certain types might not be available in some countries. For details, please contact your local dealer.

Two kinds of size notation are employed in this manual. With this machine refer to the inch version. Manuals for This Machine Refer to the manuals that are relevant to what you want to do with the machine. About This Machine Be sure to read the Safety Information in this manual before using the machine. This manual provides an introduction to the functions of the machine.

It also explains the control panel, preparation procedures for using the machine, how to enter text, and how to install the CD-ROMs provided. General Settings Guide Explains User Tools settings, and Address Book procedures such as registering fax numbers, e-mail addresses, and user codes. Also refer to this manual for explanations on how to connect the machine. Troubleshooting Provides a guide to solving common problems, and explains how to replace paper, toner, staples, and other consumables. Security Reference This manual is for administrators of the machine.

It explains security functions that the administrators can use to protect data from being tampered, or prevent the machine from unauthorized use. Also refer to this manual for the procedures for registering administrators, as well as setting user and administrator authentication. Copy/ Document Server Reference Explains Copier and Document Server functions and operations. Also refer to this manual for explanations on how to place originals. Facsimile Reference Explains Facsimile functions and operations. Printer Reference Explains Printer functions and operations. Scanner Reference Explains Scanner functions and operations. Network Guide Explains how to configure and operate the machine in a network environment, and use the software provided. This manual covers all models, and includes descriptions of functions and settings that might not be available on this machine. Images, illustrations, and information about operating systems that are supported might also differ slightly from those of this machine.

i Other manuals · PostScript3 Supplement · UNIX Supplement · Manuals for DeskTopBinder Lite · DeskTopBinder Lite Setup Guide · DeskTopBinder Introduction Guide · Auto Document Link Guide Note Manuals provided are specific to machine types. Adobe Acrobat Reader/Adobe Reader must be installed in order to view the manuals as PDF files. ii TABLE OF CONTENTS Manuals for This Machine

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....i How to Read This Manual ..

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

...I Symbols

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....
.....

.....
.....
.....
1 Display Panel.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....2 Accessing User Tools (System Settings)

.....
.....
.....

.....
.....
.....
.....

.....3 Changing Default Settings

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....3 Quitting User Tools

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

4 Menu Protect.....

.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....4 1. *Connecting the Machine Connecting to the Interfaces*

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

.....5 *Connecting to the Ethernet Interface*

.....
.....
.....
.....

.....
.....
.....
.....

.....6 *Connecting to the USB Interface.*

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

.....7 *Connecting to the IEEE 1394 Interface.*

.....
.....
.....
.....

.....
.....
.....
.....

.....8 *Connecting to the IEEE 1284 Interface.*

.....
.....
.....

.....
.....
.....
.....

.....
.....

....9 Connecting to the IEEE 802.
11b (Wireless LAN) Interface.....

.....
.....
.....

.....10 Network Settings..

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....13 Settings Required to Use the Printer/LAN-Fax

.....
.....
.....

.....
.....
.....
.....

..13 Settings Required to Use Internet Fax

.....
.....
.....

.....
.....
.....
.....

..16 Settings Required to Use E-mail Function

.....
.....
.....

.....
.....
.....
.....

.... 20 Settings Required to Use Scan to Folder Function .

.....

.....
.....
.....
.....
.....

...24 Settings Required to Use the Network Delivery Scanner.....

.....
.....
.....

.....
.....

27 Settings Required to Use Network TWAIN Scanner

.....
.....
.....
.....
.....

...30 Settings Required to Use Document Server

.....
.....
.....
.....
.....
.....
.....

... 32 Using Utilities to Make Network Settings

.....
.....
.....
.....
.....
.....

.....35 Connecting the Machine to a Telephone Line and Telephone ..

.....
.....
.....

..44 Connecting the Telephone Line

.....
.....
.....
.....
.....
.....

.....
.....
.....

.44 Selecting the Line Type.....

.....
.....
.....
.....

.....
.....
.....
.....

...45 2. System Settings General Features.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..47 Output tray settings

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

50 Tray Paper Settings

.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

...51 Timer Settings ..

.....
.....

.....
.....
.....
.....

.....
.....

.....
.....
.....
.....
.....
.....
.....
.....

..63 IEEE 802.11b

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

65 Print List

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

66 File Transfer

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

68 Administrator Tools.....

.....

.....
94 Edit

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
98 Stamp

.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
...104 Background Numbering

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
... 104 Preset Stamp

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

...105 User Stamp ..

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....108 Date Stamp

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

....109 Page Numbering

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.... 111 Input/Output

.....
.....
.....

.....
.....

.....
.....

.....
.....
.....

.....
.....

..114 Adjust Color Image ...

.....
.....
.....

.....
.....
.....

.....
.....

...117 Settings for the Document Server.

.....
.....
.....

.....
.....

..... 118 4. Facsimile Features General Features..

.....
.....

.....
.....
.....

.....
.....
.....

....119 Scan Settings

.....
.....

.....
.....
.....

.....
.....
.....

.....
.....
122 Send Settings
.....

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....123 Reception Settings

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....126 Initial Settings ..

.....
.....
.....

.....
.....
.....

.....
.....
.....

..... 132 Reception File Setting ..

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....137 Reception Report e-mail

142 Deleting Fax Information

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

...144 Forwarding ..

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

...145 Programming an End Receiver

.....
.....

.....
.....
.....
.....

.....
.....
.....

.146 Quitting the forwarding function

.....
.....
.....
.....

.....
.....
.....
.....

.....148 Forwarding Mark ..

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

... 148 Parameter Settings ..

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

149 Changing the User Parameters.....

.....
.....
.....
.....

.....
.....
.....
.....

.....155 Special Senders to Treat Differently ..

.....
.....
.....

.....
.....
.....
.....

..156 Authorized Reception...

.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

157 Reception File Print Quantity

.....
.....
.....
.....

.....
.....
.....
.....
.....
.....

.....158 Forwarding

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.....158 Print 2 Sided.....

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.....158 Memory Lock...

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.....159 Paper Tray ..

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
...es to a shared folder directly...
.....

.....
.....
.....
.....

.....205 Preventing unauthorized user access to shared folders from the machine ...

.....
.....
...205 Managing users and machine usage ..
.....

.....
.....
.....
.....

.....
.....
.....
.....
.....205 Registering Names ...

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....
.....206 Registering Names.

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....206 Changing a Registered Name....

.....
.....
.....
.....

.....
.....
.....

.....207 *Deleting a Registered Name*

.....
.....
.....
.....

.....
.....
.....
.....

.....208 *Authentication Information* ..

.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 209 *Registering a User Code*...

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....210 *Changing a User Code*.....

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....211 *Deleting a User Code*.....

.....
.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....213 *Displaying the Counter for Each User.*

.....

.....

.....

.....

.....

.....

.....

.....

.....214 *Printing the Counter for Each User ...*

.....

.....

.....

.....

.....

.....

.....

..... 215 *Printing the Counter for All User .*

.....

.....

.....

.....

.....

.....

.....

.....

.....

216 *Clearing the Number of Prints.....*

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....217 *Fax Destination*

.....

.....

.....

.....
.....
.....
.....

.....
.....
...218 Fax Destination ..

.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

.....220 IP-Fax Destination.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

...226 v E-mail Destination.....

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....231 Registering an E-mail Destination...

.....
.....
.....

.....
.....

.....
.....

.231 Changing an E-mail Destination.....

.....
.....
.....

.....
.....
.....

.....233 Deleting an E-mail Destination..

.....
.....

.....
.....
.....

.....
.....

.....234 Registering Folders ...

.....
.....
.....

.....
.....
.....

.....
.....

.....235 Using SMB to Connect..

.....
.....
.....

.....
.....
.....

.....
.....

.....235 Using FTP to Connect.

.....
.....
.....

.....
.....
.....
.....
.....
.....
.....
.....

.241 Using NCP to Connect

.....
.....
.....
.....
.....
.....
.....
.....
.....

..246 Registering Names to a Group

.....
.....
.....
.....
.....
.....
.....

252 Registering a Group

.....
.....
.....
.....
.....
.....
.....

252 Registering Names to a Group.....

.....
.....
.....
.....
.....
.....

.....253 Adding a Group to Another Group .

.....
.....
.....
.....

261 Registering a Protection Code

.....
.....
.....

.....
.....
.....

...262 Registering a Protection Code to a Single User.....

.....
.....
.....

.....
.....
.....

.....262 Registering a Protection Code to a Group User....

.....
.....
.....

.....
.....
.....

....264 Registering SMTP and LDAP Authentication.

.....
.....
.....
.....

.....265 SMTP Authentication .

.....
.....
.....

.....
.....
.....

.....
.....
.....

..265 LDAP Authentication ...

.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

.267 8. Other User Tools Maintenance ...

.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

269 Changing the Display Language

.....
.....
.....

.....
.....
.....
.....

.....

270 Inquiry

.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

...271 Counter

.....
.....
.....

.....
.....

.....
.....

.....
.....
.....
.....

.....
.....
.....

.... 273 *Displaying the Total Counter*.....

.....
.....
.....

.....
.....
.....

.....
.....

.273 9. *Appendix Specifications for the Main Unit* ...

.....

.....
.....
.....

.....
.....
.....

.....275 *Auto Document Feeder* ..

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....279 *Specifications for Options* ..

.....
.....
.....

.....
.....
.....

.....
.....

...280 *Information about Installed Software*..

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

....285 NetBSD .

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

... 286 Sablotron..

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

....288 JPEG LIBRARY

.....

.....

.....

.....

.....

.....

.....

.....
.....
.....
.....

.....
.....
.288 SASL ...
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
...289 MD4.
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
...290 MD5.
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
...290 Samba(Ver 3.

0.4)...

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....291 RSA BSAFE®

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....
291 Open SSL.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.292 Open LDAP

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

machine is connected correctly to the network.

Indicator (yellow) Lights up yellow when 100 BASE-TX is in operation. Goes off when 10 BASE-T is in operation. Note For details about installing the printer driver, see "Preparing the Machine", Printer Reference. Reference "Turning On the Power", About This Machine "Preparing the Machine", Printer Reference Connecting to the USB Interface Connect the USB2.0 interface cable to the USB2.0 port. A Connect the USB2.0 interface cable to the USB2.0 port. AMB013S B Connect the other end to the USB2.

0 port on the host computer. 7 Connecting the Machine Note This machine does not come with a USB interface cable. Make sure you purchase the appropriate cable for the machine and your computer. 1 The USB2.0 interface board is supported by Windows 98SE / Me / 2000 / XP, Windows Server 2003, Mac OS X 10.



[You're reading an excerpt. Click here to read official RICOH AFICIO MP C2500 user guide](http://yourpdfguides.com/dref/3177271)
<http://yourpdfguides.com/dref/3177271>

3.3 or higher. · For Windows 98SE / Me: Make sure to install "USB Printing Support". When used with Windows 98SE / Me, only a speed equal to that of USB1.1 is possible.

· For Mac OS: To use Macintosh, the machine must be equipped with the optional PostScript 3 unit. When used with Mac OS X 10.3.3 or higher, a transfer speed of USB2.0 is supported. For details about installing the printer driver, see "Preparing the Machine", Printer Reference. Reference "Preparing the Machine", Printer Reference Connecting to the IEEE 1394 Interface Connect the IEEE 1394 interface cable to the IEEE 1394 interface board. A Connect the IEEE 1394 interface cable to the IEEE 1394 port. AMB014S B Connect the other end of the cable into the interface connector on the host computer. Check the shape of the connector to the computer.

Connect the cable firmly. Note Use the interface cable supplied with the IEEE 1394 interface board. Two interface ports are available for connecting the IEEE 1394 interface cable. Either is suitable. For details about installing the printer driver, see "Preparing the Machine", Printer Reference. 8 Connecting to the Interfaces Reference "Turning On the Power", About This Machine "Preparing the Machine", Printer Reference Connecting to the IEEE 1284 Interface

Connect the IEEE 1284 interface cable to the IEEE 1284 interface board. 1 A Make sure the main power switch on the machine is off. If the main power switch is on, turn it off. B Turn off the main power switch of the host computer. C Connect the IEEE 1284 interface cable to the IEEE 1284 port. AMB015S Use the conversion connector (1) supplied with the IEEE 1284 interface board. D Connect the other end of the cable into the interface connector on the host computer. Check the shape of the connector to the computer. Connect the cable firmly. E Turn on the main power switch of the machine.

F Turn on the host computer. When using Windows 95/98/Me/2000/XP and Windows Server 2003, a printer driver installation screen might appear when the computer is turned on. If this happens, click [Cancel] on the screen. Note For details about installing the printer driver, see "Preparing the Machine", Printer Reference. Reference "Turning On the Power", About This Machine "Preparing the Machine", Printer Reference 9 Connecting the Machine Connecting to the IEEE 802.

11b (Wireless LAN) Interface Connect to the IEEE 802.11b (wireless LAN) interface. 1 Note Check the settings of the IPv4 address and subnet mask of this machine. For details about how to set the IPv4 address and subnet mask from the control panel of the machine, see "Interface Settings". Reference p.58 "Network" Setup Procedure Set up IEEE 802.11b (wireless LAN) according to the following procedure: AME006S 10 Connecting to the Interfaces Note Select [802.11 Ad-hoc Mode] mode when connecting Windows XP as a wireless LAN client using Windows XP standard driver or utilities, or when not using the infrastructure mode. For details about how to specify wireless LAN settings from the control panel on the machine, see "IEEE 802.11b".

For details about how to specify wireless LAN settings from other than the control panel on the machine, see "Using Utilities to Make Settings". For details about the setting items, see "IEEE 802.11b". Reference p.65 "IEEE 802.11b" 1 p.35 "Using Utilities to Make Network Settings" Checking the Connection

Check the wireless LAN connection. Make sure the LED of the IEEE 802.11b interface unit is lit. When using in infrastructure mode 1 2 ZGDH600J 1. If [LAN Type] on the [Interface Settings] / [Network] screen is not set to [IEEE 802.11b], it does not light, even if the main power is on. 2. If it is connected properly to the network, the LED is green when in infrastructure mode. If the LED is blinking, the machine is searching for devices.

11 Connecting the Machine When using in adhoc mode / 802.11 ad hoc mode 1 1 2 ZGDH600J 1. If the IEEE 802.11b interface unit is functioning, the LED lights up in orange. 2.

If it is connected properly to the network, the LED is green when in ad hoc mode or 802.11 ad hoc mode. If the LED is blinking, the machine is searching for devices. The LED will light after a few seconds. Print the configuration page to verify settings. Note For more information about printing a configuration page, see "Print List". Reference p.182 "Printing the configuration page" Checking the Signal When using in infrastructure mode, you can check the machine's radio wave status using the control panel. A Press [System Settings]. B Press [Interface Settings].

C Press [IEEE 802.11b]. D Press [Wireless LAN Signal]. The machine's radio wave status appears. E After checking radio wave status, press [Exit]. F Press the {User Tools/Counter} key to return to the User Tools / Counter / Inquiry menu. Note To check the radio wave status, press [IEEE 802.11b] under [LAN Type] in Network menu of Interface Settings. Reference p.35 "Using Utilities to Make Network Settings" 12 p.

65 "IEEE 802.11b" Network Settings Network Settings This section describes the network settings you can change with User Tools (System Settings). Make settings according to functions you want to use and the interface to be connected. Important These settings should be made by the system administrator, or with the advice the system administrator. 1 Settings Required to Use the Printer/LAN-Fax This section lists the settings required for using the printer or LAN-Fax function.

Ethernet This section lists the settings required for using the printer or LAN-Fax function with an Ethernet connection. For details about how to specify the settings, see "Interface Settings". Menu User Tool Setting Requirements Necessary As required As required As required As required As required As required As required As required Necessary Interface Settings/Network Machine IPv4 Address Interface Settings/Network IPv4 Gateway Address Interface Settings/Network Machine IPv6 Address Interface Settings/Network IPv6 Gateway Address Interface Settings/Network IPv6 Stateless Address Autoconfiguration Interface Settings/Network DNS Configuration Interface Settings/Network DDNS Configuration Interface Settings/Network Domain Name Interface Settings/Network WINS Configuration Interface Settings/Network Effective Protocol Interface Settings/Network NCP Delivery Protocol Interface Settings/Network NW Frame Type Interface Settings/Network SMB Computer Name Interface Settings/Network SMB Work Group Interface Settings/Network Ethernet Speed Interface Settings/Network LAN Type 13 Connecting the Machine Menu User Tool Setting Requirements As required As required As required As required Interface Settings/Network Permit SNMPv3 Communication Interface Settings/Network Permit SSL/TLS Communication 1 Interface Settings/Network Host Name Interface Settings/Network Machine Name Note IPv6 can be used only for the printer function.



[You're reading an excerpt. Click here to read official RICOH AFICIO MP C2500 user guide](http://yourpdfguides.com/dref/3177271)
<http://yourpdfguides.com/dref/3177271>

[Network] [Machine IPv4 Address] [Specify] [Sub-net Mask] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Can be used for specifying the setting. · telnet: Can be used for specifying the setting. [Network] [IPv4 Gateway Address] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Can be used for specifying the setting. · telnet: Can be used for specifying the setting. 35 Connecting the Machine 1 [Network] [Machine IPv6 Address] [Manual Configuration Address] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Cannot be used for specifying the setting. · telnet: Can be used for specifying the setting. [Network] [IPv6 Stateless Address Autoconfiguration] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Cannot be used for specifying the setting.

· telnet: Can be used for specifying the setting. [Network] [DNS Configuration] [Auto-Obtain (DHCP)] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Cannot be used for specifying the setting. · telnet: Can be used for specifying the setting. [Network] [DNS Configuration] [Specify] [DNS Server1-3] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Cannot be used for specifying the setting. · telnet: Can be used for specifying the setting. [Network] [DDNS Configuration] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Cannot be used for specifying the setting. · telnet: Can be used for specifying the setting. [Network] [Domain Name] [Auto-Obtain (DHCP)] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Cannot be used for specifying the setting. · telnet: Can be used for specifying the setting. [Network] [Domain Name] [Specify] [Domain Name] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Cannot be used for specifying the setting.

· telnet: Can be used for specifying the setting. [Network] [WINS Configuration] [On] [Primary WINS Server] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Cannot be used for specifying the setting. · telnet: Can be used for specifying the setting. 36 Network Settings [Network] [WINS Configuration] [On] [Secondary WINS Server] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Cannot be used for specifying the setting. · telnet: Can be used for specifying the setting. [Network] [WINS Configuration] [On] [Scope ID] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Cannot be used for specifying the setting. · telnet: Can be used for specifying the setting. [Network] [Effective Protocol] [IPv4] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: You can make the TCP/IP settings if SmartDeviceMonitor for Admin is communicating with the machine using IPX/SPX. · telnet: Can be used for specifying the setting. [Network] [Effective Protocol] [IPv6] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Can be used for specifying the setting.

· telnet: Can be used for specifying the setting. [Network] [Effective Protocol] [NetWare] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: You can make the IPX/SPX settings if SmartDeviceMonitor for Admin is communicating with the machine using TCP/IP. · telnet: Can be used for specifying the setting. [Network] [Effective Protocol] [SMB] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Can be used for specifying the setting. · telnet: Can be used for specifying the setting. [Network] [Effective Protocol] [AppleTalk] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Can be used for specifying the setting. · telnet: Can be used for specifying the setting.

[Network] [NCP Delivery Protocol] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Can be used for specifying the setting. · telnet: Cannot be used for specifying the setting. 1 37 Connecting the Machine 1 [Network] [NW Frame Type] [Auto Select] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Cannot be used for specifying the setting.

· telnet: Can be used for specifying the setting. [Network] [NW Frame Type] [Ethernet II] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Cannot be used for specifying the setting. · telnet: Can be used for specifying the setting. [Network] [NW Frame Type] [Ethernet 802.2] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Cannot be used for specifying the setting. · telnet: Can be used for specifying the setting. [Network] [NW Frame Type] [Ethernet 802.3] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Cannot be used for specifying the setting. · telnet: Can be used for specifying the setting. [Network] [NW Frame Type] [Ethernet SNAP] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Cannot be used for specifying the setting. · telnet: Can be used for specifying the setting.

[Network] [SMB Computer Name] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Cannot be used for specifying the setting. · telnet: Can be used for specifying the setting. [Network] [SMB Work Group] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Cannot be used for specifying the setting. · telnet: Can be used for specifying the setting. [Network] [Ethernet Speed] · Web Image Monitor: Cannot be used for specifying the setting. · SmartDeviceMonitor for Admin: Cannot be used for specifying the setting. · telnet: Cannot be used for specifying the setting. 38 Network Settings [Network] [LAN Type] [Ethernet] · Web Image Monitor: Can be used for specifying the setting. · SmartDeviceMonitor for Admin: Cannot be used for specifying the setting. · telnet: Can be used for specifying the setting. [Network] [LAN Type] [IEEE 802.11b] · Web Image Monitor: Can be used for specifying the setting.



You're reading an excerpt. Click here to read official RICOH AFICIO MP C2500 user guide
<http://yourpdfguides.com/dref/3177271>