




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for SAMSUNG GALAXY GRAND PRIME. You'll find the answers to all your questions on the SAMSUNG GALAXY GRAND PRIME in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual SAMSUNG GALAXY GRAND PRIME
User guide SAMSUNG GALAXY GRAND PRIME
Operating instructions SAMSUNG GALAXY GRAND PRIME
Instructions for use SAMSUNG GALAXY GRAND PRIME
Instruction manual SAMSUNG GALAXY GRAND PRIME



[You're reading an excerpt. Click here to read official SAMSUNG GALAXY GRAND PRIME user guide](http://yourpdfguides.com/dref/5793231)
<http://yourpdfguides.com/dref/5793231>

Manual abstract:

01/2015. @@@@ Apps related to the content may not work properly depending on the device's specifications and the environment that it is used in. Samsung is not liable for performance issues caused by apps supplied by providers other than Samsung. Samsung is not liable for performance issues or incompatibilities caused by edited S registry settings or modified operating system software. Attempting to customise the operating system may cause the device or apps to work improperly. @@@@ Users are entirely responsible for illegal use of media. @@ For large data transfers, it is recommended to use the Wi-Fi feature. @@ If you have questions about an app provided with the device, contact a Samsung Service Centre. For user-installed apps, contact service providers. Modifying the device's operating system or installing softwares from unofficial sources M may result in device malfunctions and data corruption or loss.

These actions are violations of your Samsung licence agreement and will void your warranty. 4 Read me first Instructional icons Warning: situations that could cause injury to yourself or others Caution: situations that could cause damage to your device or other equipment Note: notes, usage tips, or additional information 5 Getting started Package contents Check the product box for the following items: Device Dock Battery Quick start guide Q The items supplied with the device and any available accessories may vary T depending on the region or service provider. The supplied items are designed only for this device and may not be compatible T with other devices. Appearances and specifications are subject to change without prior notice. A You can purchase additional accessories from your local Samsung retailer.

Make Y sure they are compatible with the device before purchase. Use only Samsung-approved accessories. Using unapproved accessories may cause U the performance problems and malfunctions that are not covered by the warranty. Availability of all accessories is subject to change depending entirely on A manufacturing companies. For more information about available accessories, refer to the Samsung website.

6 Getting started Device layout Proximity sensor Earpiece Front camera Touch screen Power button Home button Back button Recent apps button Microphone Multipurpose jack Headset jack Flash GPS antenna Rear camera Back cover Volume button Speaker NFC antenna (on the battery) Main antenna 7 Getting started Do not cover the antenna area with your hands or other objects. This may cause D connectivity problems or drain the battery. Using a Samsung-approved screen protector is recommended. Unapproved screen U protectors may cause the sensors to malfunction. Do not allow water to contact the touch screen. The touch screen may malfunction D in humid conditions or when exposed to water. Buttons Button Power Function Press and hold to turn the device on or off. P Press to turn on or lock the screen. P Tap to open the list of recent apps. T Recent apps Tap and hold to access additional options for the current T screen.

Press to turn on the screen while the screen is locked. P Press to return to the Home screen. P Press and hold to launch Google. P Back Volume Tap to return to the previous screen. T Press to adjust the device volume. P Home 8 Getting started Using the SIM or USIM card and battery Installing the SIM or USIM card and battery Insert the SIM or USIM card provided by the mobile telephone service provider, and the included battery. Only microSIM cards work with the device. O Some LTE services may not be available depending on the service provider. For S more information about service availability, contact your service provider. 1 Remove the back cover.

Be careful not to damage your fingernails when you remove the back cover. Do not bend or twist the back cover excessively. Doing so may damage the cover.

9 Getting started 2 Insert the SIM or USIM card with the gold-coloured contacts facing downwards. Do not insert a memory card into the SIM card slot. If a memory card happens to D be lodged in the SIM card slot, take the device to a Samsung Service Centre to remove the memory card. Use caution not to lose or let others use the SIM or USIM card. Samsung is not U responsible for any damages or inconveniences caused by lost or stolen cards. 3 Insert the battery with the battery's gold-coloured contacts properly aligned with the device's contacts. 2 1 10 Getting started 4 Replace the back cover. Ensure that the back cover is closed tightly. E Use only Samsung-approved back covers and accessories with the device. U Removing the SIM or USIM card and battery 1 Remove the back cover. 2 Pull out the battery. 3 Pull out the SIM or USIM card. 11 Getting started Charging the battery Use the charger to charge the battery before using it for the first time. A computer can be also used to charge the battery by connecting them via the USB cable. Use only Samsung-approved chargers, batteries, and cables. Unapproved chargers or cables can cause the battery to explode or damage the device. When the battery power is low, the battery icon appears empty.

W If the battery is completely discharged, the device cannot be turned on I immediately when the charger is connected. Allow a depleted battery to charge for a few minutes before turning on the device. If you use multiple apps at once, network apps, or apps that need a connection I to another device, the battery will drain quickly. To avoid disconnecting from the network or losing power during a data transfer, always use these apps after fully charging the battery.

Connect the USB cable to the USB power adaptor and then plug the end of the USB cable into the multipurpose jack. Connecting the charger improperly may cause serious damage to the device. Any damage caused by misuse is not covered by the warranty. 12 Getting started The device can be used while it is charging, but it may take longer to fully charge T the battery. If the device receives an unstable power supply while charging, the touch screen I may not function. If this happens, unplug the charger from the device.

While charging, the device may heat up. This is normal and should not affect the W device's lifespan or performance. If the battery gets hotter than usual, the charger may stop charging. If the device is not charging properly, take the device and the charger to a I Samsung Service Centre. After fully charging, disconnect the device from the charger.

First unplug the charger from the device, and then unplug it from the electric socket. Do not remove the battery before removing the charger. This may damage the device. To save energy, unplug the charger when not in use. The charger does not have a power switch, so you must unplug the charger from the electric socket when not in use to avoid wasting power.



[You're reading an excerpt. Click here to read official SAMSUNG GALAXY GRAND PRIME user guide](http://yourpdfguides.com/dref/5793231)
<http://yourpdfguides.com/dref/5793231>

The charger should remain close to the electric socket and easily accessible while charging. Reducing the battery consumption Your device provides options that help you save the battery power. By customising these options and deactivating features in the background, you can use the device longer between charges: •hen you are not using the device, switch to sleep mode by pressing the Power button. W •lose unnecessary apps using the task manager. C •eactivate the Bluetooth feature. D •eactivate the Wi-Fi feature. D •eactivate auto-syncing of apps. D •ecrease the backlight time. D •ecrease the screen brightness. D 13 Getting started Using a memory card Installing a memory card Your device accepts memory cards with maximum capacities of 64 GB.

Depending on the memory card manufacturer and type, some memory cards may not be compatible with your device. •ome memory cards may not be fully compatible with the device. Using an S incompatible card may damage the device or the memory card, or corrupt the data stored in it. •se caution to insert the memory card right-side up. U •he device supports the FAT and the exFAT file systems for memory cards. When T inserting a card formatted in a different file system, the device asks to reformat the memory card. •requent writing and erasing of data shortens the lifespan of memory cards. F •hen inserting a memory card into the device, the memory card's file directory W appears in the My Files → SD card folder. 1 Remove the back cover. 2 Insert a memory card with the gold-coloured contacts facing upwards.

3 Replace the back cover. 14 Getting started Removing the memory card Before removing the memory card, first unmount it for safe removal. On the Home screen, tap Apps → Settings → Storage → Unmount SD card. 1 Remove the back cover. 2 Pull out the memory card.

3 Replace the back cover. Do not remove the memory card while the device is transferring or accessing information. Doing so can cause data to be lost or corrupted or can damage the memory card or device. Samsung is not responsible for losses that result from the misuse of damaged memory cards, including the loss of data. Formatting the memory card A memory card formatted on a computer may not be compatible with the device.

Format the memory card on the device. On the Home screen, tap Apps → Settings → Storage → Format SD card → Format SD card → Erase everything. Before formatting the memory card, remember to make backup copies of all important data stored in the device. The manufacturer's warranty does not cover loss of data resulting from user actions. 15 Getting started Turning the device on and off Press and hold the Power button for a few seconds to turn on the device. When you turn on your device for the first time or after performing a data reset, follow the onscreen instructions to set up your device. To turn off the device, press and hold the Power button, and then tap Power off. Follow all posted warnings and directions from authorised personnel in areas where the use of wireless devices is ear on the status bar. To see more information about the icons, open the notifications panel and view the details. To open the notifications panel, drag the status bar downwards.

To close the notifications panel, drag the bar from the bottom of the screen upwards. 24 Basics You can use the following functions on the notifications panel. Launch Settings. Activate or deactivate options. Tap and hold a button to view more detailed settings. Tap a notification and perform various actions. Adjust the brightness. Clear all notifications. Using the quick setting buttons You can activate or deactivate some features on the notifications panel. Tap the following options to activate or deactivate them.

You can view more detailed settings if you tap and hold a button. •i-Fi: Refer to Wi-Fi for more information. W •ocation: Refer to Location for more information. L •ound / Vibrate / Mute: Select a sound mode. S •reen rotation: Allow or prevent the interface from rotating when you rotate the device.

S Some apps do not allow screen rotation. 25 Basics •luetooth: Refer to Bluetooth for more information. B •obile data: Refer to Data usage or Mobile networks for more information. M •. power saving: Refer to Ultra power saving mode for more information.

U •obile hotspot: Refer to Tethering and Mobile hotspot for more information. M •reen Mirroring: Refer to Screen Mirroring for more information. S •FC: Refer to NFC for more information. N •ync: When you activate this feature, the device automatically syncs apps, such as S calendar or email. •light mode: Refer to Flight mode for more information. F Opening apps On the Home screen or the Apps screen, select an app icon to open it. To open the list of recently-used apps, tap and select an app icon to open. Closing an app Tap and drag an app icon to the left or right to close it. To close all running apps, tap → . Installing or uninstalling a → Screenshots folder.

After capturing a screenshot, you can edit the image and share it with others. It is not possible to capture a screenshot while using some apps. 30 Basics My Files About My Files Use this app to access various files stored in the device. Tap My Files on the Apps screen. Search for files or folders. Access additional options. View files by categories. View the download history. View files stored in the device. 31 Basics Power saving feature Ultra power saving mode Use this mode to extend the device's battery power.

In ultra power saving mode, the device performs the following: • restricts the available apps to essential and selected apps only. R •eactivates the mobile data connection when the screen turns off. D •eactivates the Wi-Fi and Bluetooth features. D On the Apps screen, tap Settings → Ultra power saving mode, and tap the Ultra power saving mode switch to activate it. To add an app to the Home screen, tap and select an app.

To change the settings for ultra power saving mode, such as network connectivity or sound, tap → Settings. To deactivate ultra power saving mode, tap → Disable ultra power saving mode. The estimated maximum standby time shows the time remaining before the battery power runs out if the device is not used.

Standby time may vary depending on your device settings and operating conditions. 32 Network connectivity Mobile data Connect the device to a mobile network to use the Internet or share media files with other devices.

Refer to Data usage for additional options. On the Apps screen, tap Settings → Data usage, and then tick Mobile data. Alternatively, open the notifications panel and tap Mobile data to activate it. Wi-Fi Connect the device to a Wi-Fi network to use the Internet or share media files with other devices. Refer to Wi-Fi for additional options.



[You're reading an excerpt. Click here to read official SAMSUNG](http://yourpdfguides.com/dref/5793231)

[GALAXY GRAND PRIME user guide](http://yourpdfguides.com/dref/5793231)

<http://yourpdfguides.com/dref/5793231>

Turn off Wi-Fi to save the battery when not in use. 1 On the Apps screen, tap Settings → Wi-Fi, and then tap the Wi-Fi switch to activate it. 2 Select a network from the Wi-Fi networks list. Networks that require a password appear with a lock icon. 3 Tap Connect.

Once the device connects to a Wi-Fi network, the device will reconnect to that network each time it is available without requiring a password. To prevent the device connecting to the network automatically, select it from the list of networks and tap Forget. 33 Network connectivity Tethering and Mobile hotspot About tethering and mobile hotspots Use this feature to share the device's mobile data connection with computers and other devices if an Internet connection is unavailable. Connections can be made via Wi-Fi, USB, or Bluetooth. You may incur additional charges when using this feature. Using the mobile hotspot Use your device as a mobile hotspot to share your device's mobile data connection with other devices. 1 On the Apps screen, tap Settings → Tethering and Mobile hotspot. 2 Tick Mobile hotspot. • appears on the status bar. Other devices can find your device in the Wi-Fi networks list.

• o set a password for the mobile hotspot, tap → Configure hotspot and select the T level of security. Then, enter a password and tap Save. 3 On the other device's screen, search for and select your device from the Wi-Fi networks list. 4 On the connected device, use the device's mobile data connection to access the Internet. 34 Network connectivity Using USB tethering Share the device's mobile data connection with other devices via a USB cable.

1 On the Apps screen, tap Settings → Tethering and Mobile hotspot. 2 Connect your device to the computer via the USB cable. 3 Tick USB tethering. appears on the status bar when the two devices are connected. 4 On the computer, use your device's mobile data connection.

Using Bluetooth tethering Share the device's mobile data connection with other devices via Bluetooth. Ensure that the computer that you connect to supports the Bluetooth feature. 1 Pair your device with the other device via Bluetooth. Refer to Pairing with other Bluetooth devices for more information. 2 On the Apps screen of your device, tap Settings → Tethering and Mobile hotspot. 3 Tick Bluetooth tethering. 4 On the connected device, open the Bluetooth settings screen, tap → Internet access. appears on the status bar when the two devices are connected. 5 On the connected device, use the device's mobile data connection to access the Internet. The connection methods may vary depending on the connected devices.

35 Personalising Managing the Home and Apps screens Managing the Home screen Adding items Tap and hold an app from the Apps screen, and then drag it to the Home screen. To add widgets, open the Home screen, tap and hold an empty area, tap Widgets, tap and hold a widget, and then drag it to the Home screen. Moving and removing an item Tap and hold an item on the Home screen, and then drag it to a new location. To move the item to another panel, drag it to the side of the screen. You can also move frequently-used apps to the shortcuts area at the bottom of the Home screen. To remove an item, tap and hold the item. Then, drag it to Remove that appears at the top of the screen. Creating a folder 1 On the Home screen, tap and hold an app, and then drag it to Create folder that appears at the top of the screen. 2 Enter a folder name. 3 Tap , select the apps to move to the folder, and then tap Done.

36 Personalising Managing panels On the Home screen, tap and hold an empty area to add, move, or remove a panel. To add a panel, scroll left to the last panel, and then tap . To move a panel, tap and hold a panel preview, and then drag it to a new location. To remove a panel, tap and hold a panel preview, and then drag it to Remove at the top of the screen. To set a panel as the main Home screen, tap .

Managing the Apps screen Changing the sorting method On the Apps screen, tap → View as and select a sorting method. Hiding apps Hide apps that you do not want to see on the Apps screen. On the Apps screen, tap → Hide apps, select apps, and then tap Done. To display hidden apps, tap → Show hidden apps, select apps, and then tap Done. Moving items On the Apps screen, tap → Edit.

Tap and hold an item and drag it to a new location. To move the item to another panel, drag it to the side of the screen. To move an item to a new panel, drag it to Create page that appears at the top of the screen. 37 Personalising Setting wallpaper and ringtones Setting wallpaper Set an image or photo stored in the device as wallpaper for the Home screen or the locked screen. 1 On the Home screen, tap and hold an empty area, and then tap Wallpapers. Alternatively, on the Apps screen, tap Settings → Display → Wallpaper. 2 Select a screen to change or apply wallpaper to. 3 Scroll left or right and select from images displayed at the bottom of the screen. To select photos taken by the device's camera or other images, tap From Gallery. 4 Tap Set as wallpaper or Done.

Changing ringtones Change ringtones for incoming calls and notifications. On the Apps screen, tap Settings → Sound. To set a ringtone for incoming calls, tap Ringtones, select a ringtone, and then tap Done. To use a song stored in the device or in your account as a ringtone, tap Add. To set a ringtone for notifications, tap Notifications, select a ringtone, and then tap Done. 38 Personalising Changing the screen lock method You can change the way that you lock the screen to prevent others from accessing your personal information. On the Apps screen, tap Settings → Lock screen → Screen lock, and then select a screen lock method. The device requires an unlock code whenever unlocking it. If the unlock code is forgotten, take the device to a Samsung Service Centre to reset it. Pattern Draw a pattern by connecting four dots or more, and then draw the pattern again to verify it.

Set a backup PIN to unlock the screen when you forget the pattern. PIN A PIN consists of numbers only. Enter at least four numbers, and then enter the password again to verify it. Password A password consists of characters and numbers. Enter at least four characters including numbers and symbols, and then enter the password again to verify it.

39 Personalising Transferring data from your previous device Using backup accounts You can transfer backup data from your previous device to your new device using your Google account. Refer to Backing up and restoring data for more information. Using Samsung Smart Switch You can transfer data of the previous device to a new device via Smart Switch. Visit www.samsung.com/smartswitch for more information. Samsung Smart Switch is not supported on some devices or computers. Using Smart Switch with computers Use this

feature to import a backup of your data (from selected manufacturer's mobile devices) from a computer to your device.



[You're reading an excerpt. Click here to read official SAMSUNG GALAXY GRAND PRIME user guide](http://yourpdfguides.com/dref/5793231)
<http://yourpdfguides.com/dref/5793231>

You can download the app from www.samsung.com/smarts witch. 1 Back up data from a previous device to the computer. For more information, contact the device's manufacturer. 2 On the computer, launch Smart Switch. 3 Connect your current device to the computer using the USB cable.

4 On the computer, click the manufacturer of the previous device and follow the on-screen instructions to transfer data to your device. 40 Personalising Using Samsung Kies Import a backup of your data from your computer via Samsung Kies to restore data on your device. You can also back up data to the computer via Samsung Kies. Refer to Connecting with Samsung Kies for more information. Setting up accounts Adding accounts Some apps used on your device require a registered account. Create accounts to have the best experience with your device. On the Apps screen, tap Settings → Accounts → Add account and select an account service. Then, follow the on-screen instructions to complete the account setup. To sync content with your accounts, select an account and tick items to sync. Removing accounts On the Apps screen, tap Settings → Accounts, select an account, and then tap → Remove account.

41 Phone Making calls Tap Phone on the Apps screen. Tap Keypad, enter a phone number, and then tap to make a voice call, or tap to make a video call. You can also make calls to phone numbers listed in Logs, Favourites, and Contacts. View call and message logs. Enter the number using the keypad.

Add the number to the contacts list. View favourite contacts. View the contacts list. Access additional options. Preview the phone number.

Delete a preceding character. Making calls from call logs or contacts list Tap Logs or Contacts, select a contact or a phone number, and then tap or . 42 Phone Making an international call Tap Keypad. Tap and hold 0 until the + sign appears. Enter the country code, area code, and phone number, and then tap . To block outgoing international calls, tap → Settings → Call → Additional settings → Call barring → a voice call or video call. Then, tick International calls, enter password, and then tap OK. Receiving calls Answering a call When a call comes in, drag outside the large circle. Rejecting a call When a call comes in, drag outside the large circle. To send a message when rejecting an incoming call, drag the reject message bar upwards.

To create various rejection messages, open the Apps screen and tap Phone → → Settings → Call → Set up call reject messages → . Missed calls If a call is missed, appears on the status bar. Open the notifications panel to view the list of missed calls. Alternatively, on the Apps screen, tap Phone → Logs to view missed calls. 43 Phone Options during calls During a voice call The following actions are available: •dd call: Dial a second call. A •eypad: Open the keypad. K •nd call: End the current call. E •peaker: Activate or deactivate the speakerphone. When using the speakerphone, speak S into the microphone at the top of the device and keep the device away from your ears. •ute: Turn off the microphone so that the other party cannot hear you.

M •lueetooth: Switch to a Bluetooth headset if it is connected to the device. B Tap to view more options. During a video call The following actions are available: •→ Hide me: Hide your image from the other party. •→ Outgoing image: Select an image to show it to the other party. •→ Capture image: Capture the other party's image.

•→ Record video: Record a video of the other party's images. •→ Memo: Create a memo. •→ Messages: Send a message. •→ Keypad: Open the keypad. •→ Speaker off / Speaker on: Activate or deactivate the speakerphone.

When using the speakerphone, speak into the microphone at the top of the device and keep the device away from your ears. •→ Switch to headset / Switch to phone: Switch sound output to a connected Bluetooth headset or back to the device's speaker. Tap the screen to use the following options: •witch: Switch between the front and rear cameras. S •ute: Turn off the microphone so that the other party cannot hear you. M •nd call: End the current call. E 44 Contacts Adding contacts Moving contacts from other devices You can move contacts from other devices to your device. Refer to Transferring data from your previous device for more information. Creating contacts manually 1 On the Apps screen, tap Contacts → Contacts. 2 Tap and enter contact information. •: Add an image.

•/: Add or delete a contact field. 3 Tap Save. To add a phone number to the contacts list from the keypad, tap Keypad, enter the number, and then tap Add to contacts. Importing and exporting contacts Import contacts from storage services to your device or export contacts from the device to storage services. On the Apps screen, tap Contacts → Contacts. Tap → Settings → Contacts → Import/export, and then select an import or export option. 45 Contacts Searching for contacts On the Apps screen, tap Contacts → Contacts. Use one of the following search methods: •croll up or down the contacts list. S •ap the search field at the top of the contacts list and enter search criteria. T Once a contact is selected, take one of the following actions: •: Add to favourite contacts.

•/ ••: Make a voice or video call. : Compose a message. : Compose an email. Adding shortcuts for contacts to the Home screen Add shortcuts to contacts that you frequently communicate with on the Home screen. 1 On the Apps screen, tap Contacts → Contacts.

2 Select a contact. 3 Tap → Add shortcut to home screen. 46 Messages & email Messages Sending messages Send text messages (SMS) or multimedia messages (MMS). You may incur additional charges for sending or receiving messages when you are roaming. 1 Tap Messages on the Apps screen.

2 Tap . 3 Add recipients and enter a message. Access additional options. Enter recipients. Select contacts from the contacts list. Enter a message. Send the message. Attach files. 4 Tap to send the message. 47 Messages & email Viewing incoming messages Incoming messages are grouped into message threads by contact.

Select a contact to view the person's messages. You may incur additional charges for sending or receiving messages when you are roaming. While viewing a message, tap to view more options. Email Setting up email accounts Tap Email on the Apps screen. Set up an email account when opening Email for the first time. Enter the email address and password. Tap Next for a private email account or tap Manual setup for a company email account. After that, follow the on-screen instructions to complete the setup. To set up another email account, tap → Settings → Manage accounts → .



[You're reading an excerpt. Click here to read official SAMSUNG GALAXY GRAND PRIME user guide](http://yourpdfguides.com/dref/5793231)
<http://yourpdfguides.com/dref/5793231>

→ If you have more than one email account, you can set one as the default account.

Tap **Manage accounts**, select an account, and then tick **Default account**. 48 **Messages & email Sending emails** Tap **Email** on the **Apps** screen. Tap at the bottom of the screen to compose a message. Save the message for later delivery. Attach images, videos and others.

Add recipients. Enter a subject. Discard the message. Send the message. Access additional options.

Add a **CC** or **BCC**. Add recipients from the contacts list. Enter a message. 49 **Messages & email Reading emails** Tap **Email** on the **Apps** screen. Tap , select an email account to use, and new messages are retrieved. To manually retrieve new messages, tap . Tap a message to read. Delete the message. Access additional options. Add this email address to the contacts list or view other options.

Open attachments. Mark the message as a reminder. Forward the message. Reply to all recipients. Reply to the message. Go to the previous or next message.

50 **Camera Basic shooting Taking photos or recording videos** 1 Tap **Camera** on the **Apps** screen. 2 Tap the image on the preview screen where the camera should focus. 3 Tap to take a photo or tap to record a video. •pread two fingers apart on the screen to zoom in, and pinch to zoom out.

S •o capture an image from the video while recording, tap **T** . Display current mode. Switch between the front and rear cameras. Start recording a video.

Take a photo.

Change camera settings. Change the shooting mode. View photos and videos you have captured. 51 **Camera** •he camera automatically shuts off when unused.

T •ake sure that the lens is clean.

Otherwise, the device may not work properly in **M** some modes that require high resolutions. •he front camera lens is suitable for taking wide-angle photos.

Minor distortion **T** may occur in wide-angle photos and does not indicate device performance problems. Launching **Camera** on the locked screen To quickly take photos of special moments, launch **Camera** on the locked screen. On the locked screen, drag outside the large circle. If is not shown, open the **Apps** screen, tap **Settings** → **Lock screen**, and then tick **Camera shortcut**. This feature may not be available depending on the region or service provider. **Camera etiquette** •o not take photos or record videos of other people without their permission. **D** •o not take photos or record videos where legally prohibited. **D** •o

not take photos or record videos in places where you may violate other people's **D** privacy.

52 **Camera Shooting modes Auto** Use this mode to allow the camera to evaluate the surroundings and determine the ideal mode for the photo. On the **Apps** screen, tap **Camera** → → **Auto**. **Selfie** Use this mode to take a self-portrait using the front camera. 1 On the **Apps** screen, tap **Camera**. 2 Tap to use the front camera. 3 Tap → **Selfie**. 4 Show your palm to the screen or tap **Wide selfie** to take a photo of yourself. Use this mode to take a wide self-portrait using the

front camera. 1 On the **Apps** screen, tap **Camera**. 2 Tap to use the front camera.

3 Tap → **Wide selfie**. 53 **Camera** 4 Show your palm to the screen or tap to take a photo of yourself. 5 Slowly rotate the device left and then right to take a panoramic photo. The device combines the photos into a single panoramic image. •ake sure to keep the blue frame inside the viewfinder window.

M •he subjects should remain still while taking wide self-portraits. **T** •he resolution of a photo may be affected by lighting conditions. **T** •he top and bottom parts of the image displayed on the preview screen may be **T** cut out of the photo depending on the shooting conditions. **Beauty face** Use this mode to take a photo with lightened faces for gentler images. On the **Apps** screen, tap **Camera** → → **Beauty face**.

Panorama Use this mode to take a photo composed of many photos strung together. The device in **Gallery**. identifies the photo with On the **Apps** screen, tap **Camera** → → **Panorama**. To get the best shot, follow these tips: •ove the camera slowly in one direction. **M** •eep the image within the frame on the camera's viewfinder. **K** •void taking photos of indistinct backgrounds, such as an empty sky or a plain **A** wall. 54 **Camera Rear-cam selfie** Use this mode to allow the camera to detect and focus your face automatically when you take a self-portrait using the rear camera. 1 On the **Apps** screen, tap **Camera** → → **Rear-cam selfie**. 2 Move the frame to the position where your face will appear and adjust the frame size. 3 Position the device so the rear camera is aimed at your face.

When the face is detected, the device beeps. Then, the device automatically takes the photo after 2 seconds. **Continuous shot** Use this mode to take a series of photos of moving subjects. On the **Apps** screen, tap **Camera** → Tap and hold → **Continuous shot**. to take several photos continuously. **HDR (Rich tone)** Use this mode to take photos with rich colours and reproduce details even in bright and dark areas. On the **Apps** screen, tap **Camera** → → **HDR (Rich tone)**.

Without effect With effect 55 **Camera Night** Use this mode to take a photo in low-light conditions, without using the flash. On the **Apps** screen, tap **Camera** → → **Night**. **Animated GIF** Use this mode to create an animated photo from a series of photos.

On the **Apps** screen, tap **Camera** → → **Animated GIF**. **Camera settings** On the **Apps** screen, tap **Camera** → . Not all of the following options are available in both still camera and video camera modes. •: Activate or deactivate the flash. •: Invert the image to create a mirror-image of the original scene, when taking photos with the front camera.

•: Use this for delayed-time shots. •: Select a filter effect to use when taking photos or recording videos. •/: Select a resolution. Use higher resolution for higher quality. But it takes up more memory.

To use more options, tap . •alm selfie: Set the device to detect your palm, so you can use it to take self-portraits. **P** •eauty face: Set the device to take a photo with lightened faces for gentler images. **B** •xposure value: Change the exposure value. This determines how much light the **E** camera's sensor receives. For low-light situations, use a higher exposure. •SO: Select an ISO value. This controls camera light sensitivity. It is measured in film camera equivalents. Low values are for stationary or brightly-lit objects.

Higher values are for fast-moving or poorly-lit objects. 56 **Camera** •hite balance: Select an appropriate white balance, so images have a true-to-life colour **W** range. The settings are designed for specific lighting situations. These settings are similar to the heat range for white-balance exposure in professional cameras. •etering modes: Select a metering method. This determines how light values are **M** calculated. Centre-weighted measures background light in the centre of the scene.

57 **Camera** •hite balance: Select an appropriate white balance, so images have a true-to-life colour **W** range. The settings are designed for specific lighting situations. These settings are similar to the heat range for white-balance exposure in professional cameras. •etering modes: Select a metering method. This determines how light values are **M** calculated. Centre-weighted measures background light in the centre of the scene.

58 **Camera** •hite balance: Select an appropriate white balance, so images have a true-to-life colour **W** range. The settings are designed for specific lighting situations. These settings are similar to the heat range for white-balance exposure in professional cameras. •etering modes: Select a metering method. This determines how light values are **M** calculated. Centre-weighted measures background light in the centre of the scene.

59 **Camera** •hite balance: Select an appropriate white balance, so images have a true-to-life colour **W** range. The settings are designed for specific lighting situations. These settings are similar to the heat range for white-balance exposure in professional cameras. •etering modes: Select a metering method. This determines how light values are **M** calculated. Centre-weighted measures background light in the centre of the scene.

60 **Camera** •hite balance: Select an appropriate white balance, so images have a true-to-life colour **W** range. The settings are designed for specific lighting situations. These settings are similar to the heat range for white-balance exposure in professional cameras. •etering modes: Select a metering method. This determines how light values are **M** calculated. Centre-weighted measures background light in the centre of the scene.

61 **Camera** •hite balance: Select an appropriate white balance, so images have a true-to-life colour **W** range. The settings are designed for specific lighting situations. These settings are similar to the heat range for white-balance exposure in professional cameras. •etering modes: Select a metering method. This determines how light values are **M** calculated. Centre-weighted measures background light in the centre of the scene.

62 **Camera** •hite balance: Select an appropriate white balance, so images have a true-to-life colour **W** range. The settings are designed for specific lighting situations. These settings are similar to the heat range for white-balance exposure in professional cameras. •etering modes: Select a metering method. This determines how light values are **M** calculated. Centre-weighted measures background light in the centre of the scene.

63 **Camera** •hite balance: Select an appropriate white balance, so images have a true-to-life colour **W** range. The settings are designed for specific lighting situations. These settings are similar to the heat range for white-balance exposure in professional cameras. •etering modes: Select a metering method. This determines how light values are **M** calculated. Centre-weighted measures background light in the centre of the scene.

64 **Camera** •hite balance: Select an appropriate white balance, so images have a true-to-life colour **W** range. The settings are designed for specific lighting situations. These settings are similar to the heat range for white-balance exposure in professional cameras. •etering modes: Select a metering method. This determines how light values are **M** calculated. Centre-weighted measures background light in the centre of the scene.

65 **Camera** •hite balance: Select an appropriate white balance, so images have a true-to-life colour **W** range. The settings are designed for specific lighting situations. These settings are similar to the heat range for white-balance exposure in professional cameras. •etering modes: Select a metering method. This determines how light values are **M** calculated. Centre-weighted measures background light in the centre of the scene.



You're reading an excerpt. Click here to read official SAMSUNG GALAXY GRAND PRIME user guide
<http://yourpdfguides.com/dref/5793231>

Spot measures the light value at a specific location. Matrix averages the entire scene. •ap to take pics: Tap the image on the preview screen to take photos. T •ideo size: Select a resolution. Use higher resolution for higher quality. But it takes up V more memory. •ecording mode: Change the recording mode. R •ocation tags: Set the device to attach the location tag to the photo.

L •o improve GPS signals, avoid shooting in locations where the signal may be T obstructed, such as between buildings or in low-lying areas, or in poor weather conditions. •hen you share a photo with the location tag attached, the location information W may be exposed to others. •torage location: Select the memory location for storage. S •rid lines: Display viewfinder guides to help composition when selecting subjects. G •oice control: Set the device to take photos with voice commands.

V •he volume key: Set the device to use the Volume button to control the shutter or zoom T function. •reset settings: Reset the camera settings. R The available options vary depending on the mode used. 57 Gallery Viewing content on the device On the Apps screen, tap Gallery and select an image or a video. Video files show the icon on the preview thumbnail. To hide or show the menu bar and the preview thumbnails, tap the screen. Send the image to others. Move to the previous screen. Modify the image. Access additional options.

Delete the image. Image and video preview thumbnails 58 Gallery Editing photos Edit images by applying various effects. Tap Gallery on the Apps screen. To use this feature, you need to download and install the required app. While viewing an image, tap •otate: Rotate the image. R •rop: Crop the image. C •olour: Adjust the saturation or brightness of the image. C •ffect: Apply effects to the image. E •ortrait: Correct red-eye, adjust and retouch faces, or make background blurry. P •ticker: Attach stickers.

S •rawing: Draw on the image. D •rame: Apply frames to the image. F When you are finished editing the image, tap . and use the following functions: 59 Useful apps and features S Planner Creating events or tasks 1 Tap S Planner on the Apps screen. 2 Tap . Alternatively, select a date with no events or tasks in it and tap the date again. If the date already has saved events or tasks in it, tap the date and tap . 3 Select either event or task and enter details. •dd event: Set a start and end date for an event. You can set an optional repeat A setting. •dd task: Add a task to do on a specific date. You can set an optional priority setting. A Select an item. Enter a title. Select a calendar to use or sync with. Set a start and end date for the event. Add more details. 4 Tap Save to save the event or task. 60 Useful apps and features Syncing events and tasks with your accounts Tap S Planner on the Apps screen. To sync events and tasks with your accounts, tap → Sync.

To add accounts to sync with, tap → Calendars → Add account. Then, select an account to sync with and sign in. When an account is added, a green circle is displayed next to the account name. To change an account's syncing option, open the Apps screen, tap Settings → Accounts, and then select an account service. Internet 1 Tap Internet on the Apps screen. 2 Tap the address field. To change the search engine, tap the search engine icon next to the web address field. 3 Enter the web address or a keyword, and then tap Go. To view the toolbars, drag your finger downwards slightly on the screen. Read an article in reading mode.

Bookmark the current webpage. Access additional options. Open the webpage window manager. Refresh the current webpage. Open the homepage. Move to the previously-visited page. View your bookmarks and recent Internet history. 61 Useful apps and features Video Playing videos Tap Video on the Apps screen. Select a video to play. Change screen ratio.

Adjust the volume. Access additional options. Move forwards or backwards by dragging the bar. Pause and resume playback. Rotate the screen's orientation. Skip to the previous video. Tap and hold to move backwards quickly. Skip to the next video. Tap and hold to move forwards quickly. Calculator Use this app for simple or complex calculations.

Tap Calculator on the Apps screen. Rotate the device to landscape orientation to display the scientific calculator. If Screen rotation is disabled, tap → Scientific calculator. 62 Useful apps and features Clock Alarm On the Apps screen, tap Clock → Alarm. Setting alarms Tap in the alarms list, set an alarm time, select the days on which the alarm will repeat, set other various alarm options, and then tap Save. @@@@•mart alarm: Set a time and tone for the smart alarm. @@@@Tap Start to time an event. Tap Lap to record lap times. Tap Stop to stop timing. @@Set the duration, and then tap Start. @@@@: Insert images. •: Make a voice recording to insert. To save the memo, tap Save. @@Before you use this app, you must connect a headset, which serves as the radio antenna. @@Tap to turn on the FM radio.

@@Access additional options. Enter radio station frequency manually. @@View the list of available stations. Search for an available radio station. @@Tap → Scan, and then select a scan option.

The FM radio scans and saves available stations automatically. @@@@Tap to start recording. Speak into the microphone. Tap recording, tap . Tap to finish recording. to pause recording. @@Tap and select a voice memo to play. : Pause or resume playback. : Skip to the previous or next voice memo. @@You may require a Google account to access some apps.

Refer to Setting up accounts for more information. @@@@Use Bluetooth to exchange data or media files with other devices. @@@@The detected devices are listed. @@@@2 Select an image. @@Or, set your device as visible to other devices. 4 Accept the Bluetooth authorisation request on the other device. 70 Connecting with other devices Receiving an image When another device sends you an image, accept the Bluetooth authorisation request. The received image is saved in the Gallery → Download folder. Unpairing Bluetooth devices 1 On the Apps screen, tap Settings → Bluetooth. The device displays the paired devices in the list.

2 Tap next to the device's name to unpair. 3 Tap Unpair. Wi-Fi Direct About Wi-Fi Direct Wi-Fi Direct connects devices directly via a Wi-Fi network without requiring an access point. Connecting to other devices 1 On the Apps screen, tap Settings → Wi-Fi, and then tap the Wi-Fi switch to activate it. 2 Tap → Wi-Fi Direct.

The detected devices are listed. 3 Select a device to connect to. To connect to multiple devices, tap → Multi-connect. To change the device name, tap → Rename device. 4 Accept the Wi-Fi Direct authorisation request on the other device to confirm.

71 Connecting with other devices Sending and receiving data You can share data, such as contacts or media files, with other devices.



[You're reading an excerpt. Click here to read official SAMSUNG GALAXY GRAND PRIME user guide](http://yourpdfguides.com/dref/5793231)
<http://yourpdfguides.com/dref/5793231>

2 Select an image. 3 Tap → Wi-Fi Direct, select a device to transfer the image to, and then tap Done. 4 Accept the Wi-Fi Direct authorisation request on the other device. Receiving an image When another device sends you an image, accept the Wi-Fi Direct authorisation request. The received image is saved in the Gallery → Download folder. Ending the device connection 1 On the Apps screen, tap Settings → Wi-Fi. 2 Tap → Wi-Fi Direct. The device displays the connected devices in the list. 3 Tap End connection → OK to disconnect the devices.

72 Connecting with other devices NFC About NFC Your device allows you to read near field communication (NFC) tags that contain information about products. You can also use this feature to make payments and buy tickets for transportation or events after downloading the required apps. The battery contains a built-in NFC antenna. Handle the battery carefully to avoid damaging the NFC antenna. Using the NFC feature Use the NFC feature to send images or contacts to other devices, and read product information from NFC tags. If you insert a SIM or USIM card that has a payment feature, you can use the device to make payments conveniently. On the Apps screen, tap Settings → NFC, and then tap the NFC switch to activate it. Place the NFC antenna area on the back of your device near an NFC tag. The information from the tag appears. Ensure that the device's screen is unlocked.

Otherwise, the device will not read NFC tags or receive data. 73 Connecting with other devices Making a purchase with the NFC feature Before you can use the NFC feature to make payments, you must register for the mobile payment service. To register or get more information about the service, contact your service provider. On the Apps screen, tap Settings → NFC, and then tap the NFC switch to activate it. Touch the NFC antenna area on the back of your device to the NFC card reader.

To set the default payment app, tap Tap and pay and select an app. The payment services list may not include all available payment apps. Sending data Use the Android Beam feature to send data, such as webpages and contacts, to NFC-enabled devices. 1 On the Apps screen, tap Settings → NFC, and then tap the NFC switch to activate it. 2 Tap Android Beam and tap the Android Beam switch to activate it.

3 Select an item and touch the other device's NFC antenna to your device's NFC antenna. 4 When Touch to beam. @@@@*o save energy, deactivate this feature when not in use. @@@@To set up the connection, refer to the device's user manual. @@@@On the Apps screen, tap Settings → Printing → Add printer, and search for a printer plug-in in Play Store. Select a printer plug-in and install it. Connecting to a printer On the Apps screen, tap Settings → Printing, select a printer plug-in, and then tap the switch at the top right of the screen to activate it. The device searches for printers that are connected to the same Wi-Fi network as your device. Select a printer to use as the default printer. To add printers manually, select a printer plug-in, tap → Add printer → and then tap OK.

, enter details, To change print settings, select a printer plug-in and tap → Printing settings. Printing content While viewing content, such as images or documents, tap → Print, and then select a printer. 77 Device & data manager Upgrading the device The device can be upgraded to the latest software. Upgrading over the air The device can be directly upgraded to the latest software by the firmware over-the-air (FOTA) service. On the Apps screen, tap Settings → About device → Software update → Update. Upgrading with Samsung Kies Download the latest version of Samsung Kies from the Samsung website. Launch Samsung Kies and connect the device to the computer. Samsung Kies automatically recognises the device and shows available updates in a dialogue box, if any. Click the Update button in the dialogue box to start upgrading. Refer to the Samsung Kies help for more information about how to upgrade.

*o not turn off the computer or disconnect the USB cable while the device is D upgrading. *hile upgrading the device, do not connect other media devices to the computer. W Doing so may interfere with the update process. 78 Device & data manager Transferring files between the device and a computer Move audio, video, image, or other types of files from the device to the computer, or vice versa. Do not disconnect the USB cable from the device when you are transferring files.

Doing so may cause data loss or device damage. *o not disconnect the device from the computer when you play files saved in the D device on the connected computer. After you finish playing the file, disconnect the device from the computer. *he devices may not connect properly if they are connected via a USB hub. Directly T connect the device to the computer's USB port.

Connecting as a media device 1 Connect the device to the computer using the USB cable. 2 Open the notifications panel, and then tap Connected as a media device → Media device (MTP). Tap Camera (PTP) if your computer does not support Media Transfer Protocol (MTP) or not have any appropriate driver installed. 3 Transfer files between your device and the computer. Connecting with Samsung Kies Samsung Kies is a computer app that manages media contents and personal information with Samsung devices. Download the latest Samsung Kies from the Samsung website. 1 Connect the device to the computer using the USB cable. Samsung Kies launches on the computer automatically. If Samsung Kies does not launch, double-click the Samsung Kies icon on the computer. 2 Transfer files between your device and the computer.

Refer to the Samsung Kies help for more information. 79 Device & data manager Backing up and restoring data Keep your personal information, app data, and settings safe on your device. You can back up your sensitive information to a backup account and access it later. 1 Tap Settings on the Apps screen. 2 Tap Backup and reset and tick Back up my data. 3 Tap Backup account and select an account as the backup account. To restore data, you must sign in to your Google account via the setup wizard. You can launch and open the setup wizard by performing a factory data reset on the device. If you do not sign in to your Google account via the setup wizard, you cannot restore the backup data. Performing a data reset Delete all settings and data on the device.

Before performing a factory data reset, ensure you back up all important data stored on the device. Refer to Backing up and restoring data for more information. On the Apps screen, tap Settings → Backup and reset → Factory data reset → Reset device → Erase everything. The device automatically restarts. 80 Settings About Settings Use this app to configure the device, set app options, and add accounts.

Tap Settings on the Apps screen.



[You're reading an excerpt. Click here to read official SAMSUNG GALAXY GRAND PRIME user guide](http://yourpdfguides.com/dref/5793231)
<http://yourpdfguides.com/dref/5793231>

CONNECTIONS Wi-Fi Activate the Wi-Fi feature to connect to a Wi-Fi network and access the Internet or other network devices. On the Settings screen, tap Wi-Fi, and then tap the Wi-Fi switch to activate it. To use options, tap . • can: Search for available networks.

Wi-Fi Direct: Activate Wi-Fi Direct and connect devices directly via Wi-Fi to share files. **Advanced:** Customise Wi-Fi settings. **PS push button:** Connect to a secured Wi-Fi network with a WPS button. **PS PIN entry:** Connect to a secured Wi-Fi network with a WPS PIN. **Setting Wi-Fi sleep policy** Tap → Advanced → Keep Wi-Fi on during sleep. When the screen is turned off, the device automatically turns off Wi-Fi connections. When this happens, the device automatically accesses mobile networks if it is set to use them. This may incur data transfer fees. To avoid additional charges, set this option to Always. **81 Settings Wi-Fi Direct** Wi-Fi Direct connects devices directly via a Wi-Fi network without requiring an access point.

Tap → Wi-Fi Direct. Bluetooth Activate the Bluetooth feature to exchange information over short distances. On the Settings screen, tap Bluetooth, and then tap the Bluetooth switch to activate it. To use more options, tap . • **visibility timeout:** Set duration that the device is visible. **Received files:** View received files via Bluetooth. **Tethering and Mobile hotspot** Use the device as a mobile hotspot to share the device's mobile data connection with other devices. Refer to Tethering and Mobile hotspot for more information. On the Settings screen, tap Tethering and Mobile hotspot. • **mobile hotspot:** Use the mobile hotspot to share the device's mobile data connection M with computers or other devices through the Wi-Fi network.

You can use this feature when the network connection is not available. • **USB tethering:** Use USB tethering to share the device's mobile data connection with U a computer via USB. When connected to a computer, the device is used as a wireless modem for the computer. • **Bluetooth tethering:** Use Bluetooth tethering to share the device's mobile data B connection with computers or other devices via Bluetooth. **82 Settings Flight mode** This disables all wireless functions on your device.

You can use only non-network services. On the Settings screen, tap Flight mode. **Data usage** Keep track of your data usage amount and customise the settings for the limitation. On the Settings screen, tap Data usage. • **mobile data:** Set the device to use data connections on any mobile network.

Mobile data limit: Set a limit for mobile data usage. **Mobile data usage cycle:** Set a monthly reset date to monitor data usage between periods. **To use more options, tap .** • **mobile roaming:** Set the device to use data connections when you are roaming. **Restrict background data:** Set the device to disable sync in the background while using R a mobile network. • **Auto sync data:** Activate or deactivate auto-syncing of apps, such as calendar or email. **You can select what information to sync for each account in Settings → Accounts.** • **How Wi-Fi usage:** Set the device to show your data usage via Wi-Fi. **Mobile hotspots:** Select mobile hotspots to prevent apps that are running in the M background from using them. **Location** Change settings for location information permissions.

On the Settings screen, tap Location, and then tap the Location switch to activate it. • **Mode:** Select a method to collect your location data. **Recent Location Requests:** View which apps request your current location R information and their battery usage. • **Location Services:** View the location services your device is using. **83 Settings NFC** Activate the NFC feature to read or write NFC tags that contain information. On the Settings screen, tap NFC, and then tap the NFC switch to activate it. • **Android Beam:** Turn on the Android Beam feature to send data, such as webpages and A contacts, to NFC-enabled devices. • **Tap and pay:** Set the default payment app for mobile payments. **The payment services list may not include all available payment apps.**

Screen Mirroring Activate the screen mirroring feature and share your display with others.

On the Settings screen, tap Screen Mirroring. **Printing** Download a printer app to print files. On the Settings screen, tap Printing. **More networks** Customise settings to control networks. On the Settings screen, tap More networks.

Default messaging app Select the default app to use for messaging. **Mobile networks** • **mobile data:** Set the device to use data connections on any mobile network. **Mobile roaming:** Set the device to use data connections when you are roaming. **Access Point Names:** Set up access point names (APNs). **Network mode:** Select a network type.

Network operators: Search for available networks and manually register a network. **84 Settings VPN** Set up and connect to virtual private networks (VPNs). **DEVICE Sound** Change settings for various sounds on the device. On the Settings screen, tap Sound. • **Volume:** Adjust the volume level for call ringtones, music and videos, system sounds, and V notifications. • **Ringtones:** Add or select a ringtone for incoming calls. **Notifications:** Select a ringtone for events, such as incoming messages and missed calls. **Vibrate when ringing:** Set the device to vibrate and play a ringtone for incoming calls. • **Keypad tone:** Set the device to sound when you tap the buttons on the keypad. **Touch sounds:** Set the device to sound when you select an app or option on the touch T screen.

• **Screen lock sound:** Set the device to sound when you lock or unlock the touch screen. **Display** Change the display settings. On the Settings screen, tap Display. • **Wallpaper:** W -- Home screen: Select a background image for the Home screen. -- Lock screen: Select a background image for the locked screen.

-- Home and lock screen: Select a background image for the Home screen and the locked screen. **85 Settings Notification panel:** N -- Application notifications: Change the notification method for each app. • **Brightness:** Set the brightness of the display. **Auto rotate screen:** Set the content to rotate automatically when the device is turned. **Screen timeout:** Set the length of time the device waits before turning off the display's S backlight.

• **Screensaver:** Set the device to launch a screensaver when the device is charging. **Font style:** Change the font type for display text. **Font size:** Change the font size. **Lock screen** Change settings for the locked screen. On the Settings screen, tap Lock screen.

• **Screen lock:** Change the screen lock method. The following options may vary depending S on the screen lock method selected. • **Dual clock:** Set the device to show the dual clock.



[You're reading an excerpt. Click here to read official SAMSUNG GALAXY GRAND PRIME user guide](http://yourpdfguides.com/dref/5793231)
<http://yourpdfguides.com/dref/5793231>

D • how date: Set the device to show the date with the clock. **S • camera shortcut:** Set the device to show the camera shortcut on the locked screen. **C This feature may not be available depending on the region or service provider. • wner information:** Enter your information that is shown with the clock. **O • nlock effect:** Select an effect that you see when you unlock the screen. **U • elp text:** Set the device to show the help text on the locked screen. **H 86 Settings Call Customise the settings for calling features.** On the Settings screen, tap **Call**. **• et up call reject messages:** Add or edit the message sent when you reject a call. **S • nswering/ending calls:** **A -- Pressing the home key:** Set the device to answer a call when you press the Home button. **-- Pressing the power key:** Set the device to end a call when pressing the Power button. **• dditional settings:** **A -- Caller ID:** Display your caller ID to other parties for outgoing calls.

-- Call forwarding: Divert incoming calls to another number. **-- Auto area code:** Set the device to automatically insert a prefix (area or country code) before a phone number. **-- Call barring:** Block incoming or outgoing calls. **-- Call waiting:** Allow incoming call alerts when a call is in progress. **-- Fixed Dialling Numbers:** Activate or deactivate FDN mode to restrict calls to numbers in the FDN list. Enter the PIN2 supplied with your SIM or USIM card. **• ingtones and keypad tones:** **R -- Ringtones:** Add or select a ringtone for incoming calls. **-- Vibrate when ringing:** Set the device to vibrate and play a ringtone for incoming calls. **-- Dialling keypad tone:** Set the device to sound when buttons on the keypad are tapped. **• ide my video:** Select an image to be shown to the other party.

H • oicemail service: Select your voicemail service provider. **V • oicemail settings:** Enter the number to access the voicemail service. Obtain this number **V** from the service provider. **Application manager** View and manage the apps on your device. On the Settings screen, tap **Application manager**.

87 Settings PERSONAL Accounts Add email or SNS accounts. On the Settings screen, tap **Accounts**. **Backup and reset** Change the settings for managing settings and data. On the Settings screen, tap **Backup and reset**. **• ack up my data:** Set the device to back up settings and app data to the Google server. **B • ackup account:** Set up or edit your Google backup account. **B • utomatic restore:** Set the device to restore settings and app data when the apps are **A** reinstalled on the device. **• actory data reset:** Reset settings to the factory default values and delete all data. **F Accessibility** Use this feature to improve accessibility to the device. On the Settings screen, tap **Accessibility**. **• irect access:** Set the device to open selected accessibility menus when you press the **D** Home button three times quickly. **• nswering/ending calls:** **A -- Pressing the home key:** Set the device to answer a call when you press the Home button. **-- Pressing the power key:** Set the device to end a call when you press the Power button. **• ingle tap mode:** Set the device to control incoming calls or notifications by tapping the **S** button instead of dragging it. **• ERVICES:** Select an accessibility app to use.

S 88 Settings • alkBack: Activate TalkBack, which provides voice feedback. To view help information to **T** learn how to use this feature, tap **Settings** → **Launch** “Explore by touch” tutorial. **• eak passwords:** Set the device to read the password aloud when you enter the **S** password while TalkBack is activated. **• ont size:** Change the font size. **F • agnification gestures:** Set the device to magnify the screen and to zoom in on a **M** specific area. **• ecessibility shortcut:** Set the device to activate TalkBack when you press and hold the **A** Power button, and then tap and hold the screen with two fingers. **• ext-to-speech options:** **T -- PREFERRED TTS ENGINE:** Select an engine for the text-to-speech feature. To change the settings for speech synthesis engines, tap **.** **-- Speech rate:** Select a speed for the text-to-speech feature. **-- Listen to an example:** Listen to the spoken text for an example.

-- Default language status: View the status of the current language set for the text-to-speech feature. **• ash notification:** Set the flash to blink when you have incoming calls, new messages, or **F** notifications. **• urn off all sounds:** Set the device to mute all device sounds, such as media sounds, and **T** the caller's voice during a call. **• oogle subtitles (CC):** Set the device to display closed captions on content supported by **G** Google and to change the closed caption settings. **• ono audio:** Set the device to switch the sound output from stereo to mono when a **M** headset is connected.

• ound balance: Set the device to adjust the sound balance when using a headset. **S • ap and hold delay:** Set the recognition time for tapping and holding the screen. **T • nteraction control:** Activate interaction control mode to restrict the device's reaction to **I** inputs while using apps. **89 Settings SYSTEM Language and input** Change the settings for text input. Some options may not be available depending on the selected language.

On the Settings screen, tap **Language and input**. **Language** Select a display language for all menus and apps. **Default** Select a default keyboard type for text input. **Samsung keyboard** To change the Samsung keyboard settings, tap **.** The available options may vary depending on the region or service provider. **• nglish(UK):** Select a default keyboard layout. **E • lect input languages:** Select languages for text input. **S • redictive text:** Activate predictive text mode to predict words based on your input and **P** show word suggestions. You can also customise the word prediction settings. **• uto replacement:** Set the device to correct misspelled and incomplete words by **A** tapping the space bar or punctuation mark.

• uto capitalisation: Set the device to automatically capitalise the first character after a **A** final punctuation mark, such as a full stop, question mark, or exclamation mark. **• uto spacing:** Set the device to automatically insert a space between words. **A • uto-punctuate:** Set the device to insert a full stop when you double-tap the space bar. **A • eyboard swipe:** **K -- None:** Set the device to deactivate the keyboard swipe feature. **-- Continuous input:** Set the device to enter text by sweeping on the keyboard. **90 Settings • ound:** Set the device to sound when a key is touched. **S • haracter preview:** Set the device to display a large image of each character tapped. **C • eset settings:** Reset Samsung keyboard settings.



[You're reading an excerpt. Click here to read official SAMSUNG GALAXY GRAND PRIME user guide](http://yourpdfguides.com/dref/5793231)
<http://yourpdfguides.com/dref/5793231>