



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for SMC 8648T. You'll find the answers to all your questions on the SMC 8648T in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual SMC 8648T**  
**User guide SMC 8648T**  
**Operating instructions SMC 8648T**  
**Instructions for use SMC 8648T**  
**Instruction manual SMC 8648T**

## TigerSwitch 10/100/1000

### Gigabit Ethernet Switch

- ◆ 24/48 auto-MDI/MDI-X 10/100/1000BASE-T ports
- ◆ 4 ports shared with 4 SFP transceiver slots
- ◆ Non-blocking switching architecture
- ◆ Support for a redundant power unit
- ◆ Spanning Tree Protocol, Rapid STP, and Multiple STP
- ◆ Up to six LACP or static 8-port trunks
- ◆ Layer 2/3/4 CoS support through eight priority queues
- ◆ Layer 3/4 traffic priority with IP Precedence and IP DSCP
- ◆ Full support for VLANs with GVRP
- ◆ IGMP multicast filtering and snooping
- ◆ Support for jumbo frames up to 9 KB
- ◆ Manageable via console, Web, SNMP/RMON

**SMC**<sup>®</sup>  
Networks

### Installation Guide

*SMC8624T*  
*SMC8648T*



[You're reading an excerpt. Click here to read official SMC 8648T user guide](#)

<http://yourpdfguides.com/dref/3457392>

**Manual abstract:**

(SMC) is believed to be accurate and reliable. @@@@ Copyright © 2004 by SMC Networks, Inc. 38 Tesla Irvine, CA 92618 All rights reserved. Printed in Taiwan Trademarks: SMC is a registered trademark; and EZ Switch, TigerStack and TigerSwitch are trademarks of SMC Networks, Inc. Other product and company names are trademarks or registered trademarks of their respective holders. LIMITED WARRANTY Limited Warranty Statement: SMC Networks, Inc. ("SMC") warrants its products to be free from defects in workmanship and materials, under normal use and service, for the applicable warranty term. All SMC products carry a standard 90-day limited warranty from the date of purchase from SMC or its Authorized Reseller. SMC may, at its own discretion, repair or replace any product not operating as warranted with a similar or functionally equivalent product, during the applicable warranty term. SMC will endeavor to repair or replace any product returned under warranty within 30 days of receipt of the product.

The standard limited warranty can be upgraded to a Limited Lifetime\* warranty by registering new products within 30 days of purchase from SMC or its Authorized Reseller. Registration can be accomplished via the enclosed product registration card or online via the SMC Web site. Failure to register will not affect the standard limited warranty. The Limited Lifetime warranty covers a product during the Life of that Product, which is defined as the period of time during which the product is an "Active" SMC product. A product is considered to be "Active" while it is listed on the current SMC price list.

As new technologies emerge, older technologies become obsolete and SMC will, at its discretion, replace an older product in its product line with one that incorporates these newer technologies. At that point, the obsolete product is discontinued and is no longer an "Active" SMC product. A list of discontinued products with their respective dates of discontinuance can be found at: [http://www.smc.com/index.cfm?action=customer\\_service\\_warranty](http://www.smc.com/index.cfm?action=customer_service_warranty).

All products that are replaced become the property of SMC. Replacement products may be either new or reconditioned. Any replaced or repaired product carries either a 30-day limited warranty or the remainder of the initial warranty, whichever is longer. SMC is not responsible for any custom software or firmware, configuration information, or memory data of Customer contained in, stored on, or integrated with any products returned to SMC pursuant to any warranty. Products returned to SMC should have any customer-installed accessory or add-on components, such as expansion modules, removed prior to returning the product for replacement. SMC is not responsible for these items if they are returned with the product. Customers must contact SMC for a Return Material Authorization number prior to returning any product to SMC. Proof of purchase may be required. Any product returned to SMC without a valid Return Material Authorization (RMA) number clearly marked on the outside of the package will be returned to customer at customer's expense.

For warranty claims within North America, please call our toll-free customer support number at (800) 762-4968. Customers are responsible for all shipping charges from their facility to SMC. SMC is responsible for return shipping charges from SMC to customer. i WARRANTIES EXCLUSIVE: IF AN SMC PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, CUSTOMER'S SOLE REMEDY SHALL BE REPAIR OR REPLACEMENT OF THE PRODUCT IN QUESTION, AT SMC'S OPTION. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SMC NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE OR USE OF ITS PRODUCTS. SMC SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THE ALLEGED DEFECT IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER'S OR ANY THIRD PERSON'S MISUSE, NEGLIGENCE, IMPROPER INSTALLATION OR TESTING, UNAUTHORIZED ATTEMPTS TO REPAIR, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, OR OTHER HAZARD. LIMITATION OF LIABILITY: IN NO EVENT, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), SHALL SMC BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE, LOSS OF BUSINESS, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF ITS PRODUCTS, EVEN IF SMC OR ITS AUTHORIZED RESELLER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES OR THE LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR CONSUMER PRODUCTS, SO THE ABOVE LIMITATIONS AND EXCLUSIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, WHICH MAY VARY FROM STATE TO STATE.

NOTHING IN THIS WARRANTY SHALL BE TAKEN TO AFFECT YOUR STATUTORY RIGHTS. \* SMC will provide warranty service for one year following discontinuance from the active SMC price list. Under the limited lifetime warranty, internal and external power supplies, fans, and cables are covered by a standard one-year warranty from date of purchase. SMC Networks, Inc. 38 Tesla Irvine, CA 92618 ii COMPLIANCES FCC - Class A This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause interference to radio communications.

It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart B of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user, at his own expense, will be required to take whatever measures may be required to correct the interference. You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment. You may use unshielded twisted-pair (UTP) cable for RJ-45 connections--Category 3 or greater for 10 Mbps connections, Category 5 for 100 Mbps connections and Category 5 or 5e for 1000 Mbps connections. Use 50/125 or 62.

5/125 micron multimode fiber optic cable, or 9/125 micron single-mode cable, for SFP transceiver connections. Warnings: 1. Wear an anti-static wrist strap or take other suitable measures to prevent electrostatic discharge when handling this equipment. 2. When connecting this switch to a power outlet, connect the field ground lead on the tri-pole power plug to a valid earth ground line to prevent electrical hazards.



[You're reading an excerpt. Click here to read official SMC 8648T user guide](http://yourpdfguides.com/dref/3457392)

<http://yourpdfguides.com/dref/3457392>

Industry Canada - Class A This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus as set out in the interference-causing equipment standard entitled "Digital Apparatus," ICES-003 of the Department of Communications. Cet appareil numérique respecte les limites de bruits radioélectriques applicables aux appareils numériques de Classe A prescrites dans la norme sur le matériel brouilleur: "Appareils Numériques," NMB-003 édictée par le ministère des Communications. Japan VCCI Class A iii COMPLIANCES CE Mark Declaration of Conformance for EMI and Safety (EEC) SMC contact for these products in Europe is: SMC Networks Europe, Edificio Conata II, Calle Fructuós Gelabert 6-8, 2o, 4a, 08970 - Sant Joan Despí, Barcelona, Spain. This information technology equipment complies with the requirements of the Council Directive 89/336/EEC on the Approximation of the laws of the Member States relating to Electromagnetic Compatibility and 73/23/EEC for electrical equipment used within certain voltage limits and the Amendment Directive 93/68/EEC. For the evaluation of the compliance with these Directives, the following standards were applied: RFI Emission: · Limit class A according to EN 55022:1998 · Limit class A for harmonic current emission according to EN 61000-3-2/1995 · Limitation of voltage fluctuation and flicker in low-voltage supply system according to EN 61000-3-3/1995 Immunity: · Product family standard according to EN 55024:1998 · Electrostatic Discharge according to EN 61000-4-2:1995 (Contact Discharge: ±4 kV, Air Discharge: ±8 kV) · Radio-frequency electromagnetic field according to EN 61000-4-3:1996 (80 - 1000 MHz with 1 kHz AM 80% Modulation: 3 V/m) · Electrical fast transient/burst according to EN 61000-4-4:1995 (AC/DC power supply: ±1 kV, Data/Signal lines: ±0.

5 kV) · Surge immunity test according to EN 61000-4-5:1995 (AC/DC Line to Line: ±1 kV, AC/DC Line to Earth: ±2 kV) · Immunity to conducted disturbances, Induced by radio-frequency fields: EN 61000-4-6:1996 (0.15 - 80 MHz with 1 kHz AM 80% Modulation: 3 V/m) · Power frequency magnetic field immunity test according to EN 61000-4-8:1993 (1 A/m at frequency 50 Hz) · Voltage dips, short interruptions and voltage variations immunity test according to EN 61000-4-11:1994 (>95% Reduction @ 10 ms, 30% Reduction @500 ms, >95% Reduction @5000 ms) LVD: · EN 60950 (A1/1992; A2/1993; A3/1993; A4/1995; A11/1997) Warning: Do not plug a phone jack connector in the RJ-45 port. This may damage this device. Les raccordeurs ne sont pas utilisés pour le système téléphonique! iv COMPLIANCES Taiwan BSMI Class A Australia AS/NZS 3548 (1995) - Class A SMC contact for products in Australia is: SMC Communications Pty. Ltd. Suite 18, 12 Tryon Road, Lindfield NSW2070, Phone: 61-2-94160437 Fax: 61-2-94160474 Safety Compliance Warning: Fiber Optic Port Safety CLASS I LASER DEVICE When using a fiber optic port, never look at the transmit laser while it is powered on. Also, never look directly at the fiber TX port and fiber cable ends when they are powered on. Avertissement: Ports pour fibres optiques - sécurité sur le plan optique DISPOSITIF LASER DE CLASSE I Ne regardez jamais le laser tant qu'il est sous tension. Ne regardez jamais directement le port TX (Transmission) à fibres optiques et les embouts de câbles à fibres optiques tant qu'ils sont sous tension. Warnhinweis: Faseroptikanschlüsse - Optische Sicherheit LASERGERÄT DER KLASSE I Niemals ein Übertragungslaser betrachten, während dieses eingeschaltet ist.

Niemals direkt auf den Faser-TX-Anschluß und auf die Faserkabelenden schauen, während diese eingeschaltet sind. v COMPLIANCES Power Cord Safety Please read the following safety information carefully before installing the switch: WARNING: Installation and removal of the unit must be carried out by qualified personnel only. · The unit must be connected to an earthed (grounded) outlet to comply with international safety standards. · Do not connect the unit to an A.C.

outlet (power supply) without an earth (ground) connection. · The appliance coupler (the connector to the unit and not the wall plug) must have a configuration for mating with an EN 60320/IEC 320 appliance inlet. · The socket outlet must be near to the unit and easily accessible; 2 mètres. - type SV ou SJ - 3 conducteurs Le cordon doit être en mesure d'acheminer un courant nominal d'au moins 10 A. La prise femelle de branchement doit être du type à mise à la terre (mise à la masse) et respecter la configuration NEMA 5-15P (15 A, 125 V) ou NEMA 6-15P (15 A, 250 V).

vii COMPLIANCES Cordon électrique - Il doit être agréé dans le pays d'utilisation Danemark: Suisse: Europe La prise mâle d'alimentation doit respecter la section 107-2 D1 de la norme DK2 1a ou DK2 5a. La prise mâle d'alimentation doit respecter la norme SEV/ASE 1011. La prise secteur doit être conforme aux normes CEE 7/7 ("SCHUKO") LE cordon secteur doit porter la mention <HAR> ou <BASEC> et doit être de type HO3VVF3GO.75 (minimum). Bitte unbedingt vor dem Einbauen des Switches die folgenden Sicherheitsanweisungen durchlesen: WARNUNG: Die Installation und der Ausbau des Geräts darf nur durch Fachpersonal erfolgen. · Das Gerät sollte nicht an eine ungeerdete Wechselstromsteckdose angeschlossen werden. · Das Gerät muß an eine geerdete Steckdose angeschlossen werden, welche die internationalen Sicherheitsnormen erfüllt. · Der Gerätestecker (der Anschluß an das Gerät, nicht der Wandsteckdosenstecker) muß einen gemäß EN 60320/IEC 320 konfigurierten Geräteeingang haben. · Die Netzsteckdose muß in der Nähe des Geräts und leicht zugänglich sein. Die Stromversorgung des Geräts kann nur durch Herausziehen des Geräteretzkabels aus der Netzsteckdose unterbrochen werden.

· Der Betrieb dieses Geräts erfolgt unter den SELV-Bedingungen (Sicherheitskleinstspannung) gemäß IEC 60950. Diese Bedingungen sind nur gegeben, wenn auch die an das Gerät angeschlossenen Geräte unter SELV-Bedingungen betrieben werden. Stromkabel. Dies muss von dem Land, in dem es benutzt wird geprüft werden: Schweiz Europe Dieser Stromstecker muß die SEV/ASE 1011 Bestimmungen einhalten. Das Netzkabel muß vom Typ HO3VVF3GO.75 (Mindestanforderung) sein und die Aufschrift <HAR> oder <BASEC> tragen. Der Netzstecker muß die Norm CEE 7/7 erfüllen ("SCHUKO").



[You're reading an excerpt. Click here to read official SMC 8648T user guide](http://yourpdfguides.com/dref/3457392)  
<http://yourpdfguides.com/dref/3457392>

viii **COMPLIANCES Warnings and Cautionary Messages** Warning: Warning: This product does not contain any serviceable user parts. When connecting this device to a power outlet, connect the field ground lead on the tri-pole power plug to a valid earth ground line to prevent electrical hazards. This switch uses lasers to transmit signals over fiber optic cable.

The lasers are compliant with the requirements of a Class 1 Laser Product and are inherently eye safe in normal operation. However, you should never look directly at a transmit port when it is powered on. Wear an anti-static wrist strap or take other suitable measures to prevent electrostatic discharge when handling this equipment. Do not plug a phone jack connector in the RJ-45 port. This may damage this device.

Les raccordeurs ne sont pas utilisés pour le système téléphonique! Use only twisted-pair cables with RJ-45 connectors that conform to FCC standards.

Warning: Caution: Caution: Caution: Environmental Statement The manufacturer of this product endeavours to sustain an environmentally-friendly policy throughout the entire production process. This is achieved through the following means: . . . . . Adherence to national legislation and regulations on environmental production standards. Conservation of operational resources. Waste reduction and safe disposal of all harmful un-recyclable by-products.

Recycling of all reusable waste content. Design of products to maximize recyclables at the end of the product's life span. Continual monitoring of safety standards. End of Product Life Span This product is manufactured in such a way as to allow for the recovery and disposal of all included electrical components once the product has reached the end of its life. Manufacturing Materials There are no hazardous nor ozone-depleting materials in this product.

Documentation All printed documentation for this product uses biodegradable paper that originates from sustained and managed forests. The inks used in the printing process are non-toxic. Purpose This guide details the hardware features of the switch, including Its physical and performance-related characteristics, and how to install the switch. ix **COMPLIANCES Related Publications** The following publication gives specific information on how to operate and use the management functions of the switch: The SMC8624T, SMC8648T Management Guide Also, as part of the switch's firmware, there is an online web-based help that describes all management related features. x **CONTENTS** 1 About the TigerSwitch 10/100/1000 .

. . . . .  
. . . . .1-1 Overview .  
. . . . .  
. . . . .

. . . . .1-1 Switch Architecture . . . . .  
. . . . .  
. . . . .

. . . . .1-2 Management Options .  
. . . . .  
. . . . .

. . . . .1-2 Description of Hardware . .  
. . . . .  
. . . . .

1-3 10/100/1000BASE-T Ports . . . . .  
. . . . .  
. . . . .

. . . . .1-3 SFP Slots .  
. . . . .  
. . . . .

. . . . .1-3 Status LEDs . . . . .  
. . . . .  
. . . . .

. . . . .1-4 Optional Redundant Power Unit .  
. . . . .

.....	
..... 1-7 Power Supply Receptacles .	
.....	
.....	
..... 1-7 Features and Benefits .	
.....	
.....	
.....	
..... 1-8 Connectivity .	
.....	
.....	
.....	
1-8 Expandability . . . . .	
.....	
.....	
.....	
1-8 Performance . . . . .	
.....	
.....	
.....	
. 1-8 Management . . . . .	
.....	
.....	
.....	
.....	
.. 1-9 2 Network Planning . . . . .	
.....	
.....	
..... 2-1 Introduction to Switching .	
.....	
.....	
.....	
..... Application Examples . . . . .	
.....	
.....	
.....	
..... Collapsed Backbone .	
.....	
.....	
.....	
..... Network Aggregation Plan .	
.....	

.....  
.....  
... *Remote Connections with Fiber Cable* .  
.....

..... *Making VLAN Connections* .  
.....  
.....

..... *Application Notes* ...  
.....  
.....

.....  
.....  
... 2-1 2-2 2-2 2-3 2-4 2-5 2-6 3 *Installing the Switch* .  
.....

.....  
.....  
3-1 *Selecting a Site* .....  
.....

.....  
.....  
.....

*Ethernet Cabling* .....  
.....  
.....

.....  
... *Equipment Checklist* ..  
.....  
.....

.....  
.....  
... *Package Contents* .....  
.....

.....  
.....  
.....

*Optional Rack-Mounting Equipment* .....  
.....  
.....  
. *Mounting* .....  
.....

.....  
.....  
.....

.....  
*Rack Mounting* .....  
.....  
.....

.....  
.....

... Desktop or Shelf Mounting .	.....
... Installing an Optional SFP Transceiver into the Switch ..	.....
..... 3-1 3-2 3-3 3-3 3-3 3-4 3-4 3-6 3-7 xi CONTENTS Connecting to a Power Source .....	
... 3-8 Connecting to the Console Port ...	.....
... 3-9 4 Making Network Connections ..	.....
.. 4-1 Connecting Network Devices ...	.....
4-1 Twisted-Pair Devices .....	.....
4-1 Cabling Guidelines .....	.....
..... 4-1 Connecting to PCs, Servers, Hubs and Switches .....	.....
... 4-2 Network Wiring Connections ...	.....
4-3 Fiber Optic SFP Devices .....	.....
.. 4-4 Connectivity Rules .....	.....
... 4-6 1000BASE-T Cable Requirements .....	.....
..... 4-6 1000 Mbps Gigabit Ethernet Collision Domain ...	.....
4-6 100 Mbps Fast Ethernet Collision Domain .....	.....
.. 4-7 10 Mbps Ethernet Collision Domain ...	.....

.....	4-7 Cable Labeling and Connection Records ..
	.....
	.....
	.....
..	4-8 A Troubleshooting .....
	.....
	.....
	.....
..	A-1 Diagnosing Switch Indicators .....
	.....
	.....
	.....
.....	A-1 Power and Cooling Problems .....
	.....
	.....
	.....
.....	A-2 Installation ..
	.....
	.....
	.....
	.....
	.....
.....	A-2 In-Band Access .....
	.....
	.....
	.....
	.....
	.....
	.....
	.....
	.....
	.....
	.....
..	B-1 Twisted-Pair Cable and Pin Assignments ..
	.....
	.....
..	B-1 10BASE-T/100BASE-TX Pin Assignments .....
	.....
.....	B-2 Straight-Through Wiring ..
	.....
	.....
	.....
.....	B-3 Crossover Wiring ..
	.....
	.....
	.....
	.....
.....	B-4 1000BASE-T Pin Assignments .....
	.....
	.....
	.....
..	B-4 1000BASE-T Cable Requirements .....



.....  
.....  
.....  
.....  
.....  
*..... B-5 Fiber Standards .....*

.....  
.....  
.....  
.....  
.....  
*B-6 C Specifications .....*

.....  
*.. C-1 Physical Characteristics ...*  
.....  
.....

.....  
.....  
.....  
*C-1 Switch Features .....*  
.....  
.....  
.....  
.....

.....  
*..... C-3 Standards .....*  
.....  
.....  
.....  
.....  
.....  
.....

*... C-3 Compliances .....*  
.....  
.....  
.....  
.....

.....  
*C-4 xii CONTENTS APPENDICES: Warranty .....*  
.....  
.....

*C-4 D Ordering Information .....*

.....  
*..... D-1 Glossary Index xiii TABLES Table 1-1. Table 1-2. Table 3-1. Table 4-1. Table 4-2.  
Table 4-3. Table 4-4. Table 4-5. Table 4-6. Table A-1. Table B-1. Table B-2. Port Status LEDs ...*

.....  
.....  
[You're reading an excerpt. Click here to read official SMC 8648T user](#)



[guide](#)

<http://yourpdfguides.com/dref/3457392>



.....	.....
.....	..... 2-5 RJ-45 Connections . . .
.....	.....
.....	.....
.....	..... 3-2 Attaching the Brackets . . .
.....	.....
.....	.....
.....	..... 3-5 Installing the Switch in a Rack . . . . .
.....	.....
.....	.....
.....	..... 3-5 Attaching the Adhesive Feet . . . . .
.....	.....
.....	..... 3-6 Inserting an SFP Transceiver into a Slot .
.....	.....
.....	.....
.....	..... 3-7 Power Receptacle . . . . .
.....	.....
.....	.....
.....	..... 3-8 Serial Port (DB-9 DTE) Pin-Out . . . . .
.....	.....
.....	.....
.....	..... 3-9 Making Twisted-Pair Connections . . . . .
.....	.....
.....	.....
.....	..... 4-2 Wiring Closet Connections . . . . .
.....	.....
.....	.....
.....	..... 4-3 Making LC Port Connections . . . . .
.....	.....
.....	.....
.....	..... 4-5 RJ-45 Connector Pin Numbers . . . . .
.....	.....
.....	.....
.....	..... B-1 Straight-through Wiring . . . . .
.....	.....
.....	.....
.....	.....
.....	..... B-3 Crossover Wiring . . . . .
.....	.....
.....	.....
.....	.....

... B-4 xvii FIGURES xviii CHAPTER 1 ABOUT THE TIGERSWITCH 10/100/1000 Overview SMC's TigerSwitch 10/100/1000 SMC8624T and SMC8648T are intelligent switches with 24 or 48 10/100/1000BASE-T ports, four of which are combination ports that are shared with four SFP transceiver slots. There is also an SNMP-based management agent embedded on the main board. This agent supports both in-band and out-of-band access for managing the switch. These switches provide a broad range of powerful features for Layer 2 switching, delivering reliability and consistent performance for your network traffic. They bring order to poorly performing networks by segregating them into separate broadcast domains with IEEE 802.1Q compliant VLANs, and empower

multimedia applications with multicast switching and CoS services.

Port Status Indicators 10/100/1000 Mbps RJ-45 Ports System Indicators Console Port RPU TigerSwitch 10/100/1000 8648T Power Socket Redundant Power Socket SFP Slots Figure 1-1. SMC8648T Front and Rear Panels 1-1 ABOUT THE TIGERSWITCH 10/100/1000 10/100/1000 Mbps RJ-45 Ports SFP Slots 1 3 5 7 9 11 13 15 17 19 21 23 System Indicators TigerSwitch 10/100/1000 8624T Link /Act 21 22 23 24 FDX Link /Act FDX RPU 2 4 6 8 10 12 14 16 18 20 22 24 1000=Green 10/100=Yellow FDX=Green HDX=Off Redundant Power Socket Port Status Indicators Power Socket Console Port 100-240V~, 50-60Hz 2A RPU DC IN 12V 8.5A Figure 1-2. SMC8624T Front and Rear Panels Switch Architecture The TigerSwitch 10/100/1000 employs a wire-speed, non-blocking switching fabric. This permits simultaneous wire-speed transport of multiple packets at low latency on all ports.

This switch also features full-duplex capability on all ports, which effectively doubles the bandwidth of each connection. The switch uses store-and-forward switching to ensure maximum data integrity. With store-and-forward switching, the entire packet must be received into a buffer and checked for validity

before being forwarded. This prevents errors from being propagated throughout the network. Management Options This switch contains a comprehensive array of LEDs for "at-a-glance" monitoring of network and port status.

It also includes a management agent that allows you to configure or monitor the switch using its embedded management software, or via SNMP applications.

To manage the switch, you can make a direct connection to the RS-232 console port (out-of-band), or you can manage the switch through a network connection (in-band) using Telnet, the on-board Web agent, or Windows-based network management software. For a detailed description of the switch's advanced features, refer to the Management Guide. 1-2 DESCRIPTION OF HARDWARE Description of Hardware 10/100/1000BASE-T Ports These ports are RJ-45 ports that operate at 10 Mbps or 100 Mbps, half or full duplex, or at 1000 Mbps, full duplex. Because all ports on this switch support automatic MDI/MDI-X operation, you can use straight-through cables for all network connections to PCs or servers, or to other switches or hubs. (See "1000BASE-T Pin Assignments" on page B-4.) Each of these ports support auto-negotiation, so the optimum transmission mode (half or full duplex), and data rate (10, 100, or 1000 Mbps) can be selected automatically. If a device connected to one of these ports does not support auto-negotiation, the communication mode of that port can be configured manually. Each port also supports auto-negotiation of flow control, so the switch can automatically prevent port buffers from becoming saturated. SFP Slots The Small Form Factor Pluggable (SFP) transceiver slots are shared with four of the RJ-45 ports (ports 21~24 for the SMC8624T and ports 45~48 for the SMC8648T).

In its default configuration, if an SFP transceiver (purchased separately) is installed in a slot and has a valid link on its port, the associated RJ-45 port is disabled and cannot be used. The switch can also be configured to force the use of an RJ-45 port or SFP slot, as required. 1-3 ABOUT THE TIGERSWITCH 10/100/1000 Status LEDs The LEDs, which are located on the front panel for easy viewing, are shown below and described in the following tables. Port Status LEDs Figure 1-3. SMC8648T Port Status LEDs Link/Activity TigerSwitch 10/100/1000 8624T Link /Act 24 FDX Link /Act FDX RPU 1000=Green 10/100=Yellow FDX=Green HDX=Off Duplex Figure 1-4. SMC8624T Port Status LEDs 1-4 DESCRIPTION OF HARDWARE Table 1-1. Port Status LEDs LED RJ-45 Ports Link/Activity On Amber On Green Flashing Amber Port has established a valid 10 or 100 Mbps network connection. Port has established a valid 1000 Mbps network connection.



[You're reading an excerpt. Click here to read official SMC 8648T user guide](http://yourpdfguides.com/dref/3457392)

<http://yourpdfguides.com/dref/3457392>

Port has established a valid 10 or 100 Mbps network connection and traffic is passing through the port. Port has established a valid 1000 Mbps network connection and traffic is passing through the port.

There is no valid link on the port. The port is operating in full-duplex mode. The port is operating in half-duplex mode. Condition Status Flashing Green Off Duplex (SMC8624T only) On Green Off SFP Transceiver Slots (Ports 21-45, 45-48) On Green An SFP transceiver port has established a valid 1000 Mbps network connection. The associated RJ-45 port is disabled.

An SFP transceiver port has no valid link, or the link has failed. The associated RJ-45 Port is enabled. Off 1-5 ABOUT THE TIGERSWITCH 10/100/1000 Power Indicator Redundant Power Indicator RPU TigerSwitch 10/100/1000 8648T Diagnostic Indicator Figure 1-5. SMC8648T System Status LEDs Power Indicator Diagnostic Indicator TigerSwitch 10/100/1000 8624T Link /Act 24 FDX Link /Act FDX RPU 1000=Green 10/100=Yellow FDX=Green HDX=Off Redundant Power Indicator Figure 1-6. SMC8624T System Status LEDs Table 1-2.

System Status LEDs LED Power Condition On Green On Amber Off RPU On Green Flashing Green On Amber Off Status The unit's internal power supply is operating normally. There is a fault with the internal power supply. The unit has no power connected. The redundant power unit is operating normally. The switch is operating using the redundant power unit. There is a fault with the redundant power unit The redundant power unit is not functioning. 1-6 DESCRIPTION OF HARDWARE Table 1-2. System Status LEDs LED Diag. (Diagnostic) Condition Flashing Green On Green On Amber Status The system diagnostic test is in progress. The system diagnostic test has completed successfully.

The system diagnostic test has detected a fault. Optional Redundant Power Unit SMC provides an optional Redundant Power Unit (RPU), SMC8648T, that can supply power to the switch in the event of failure of the internal power supply. Power Supply Receptacles There are two power receptacles on the rear panel of the switch. The standard power receptacle is for the AC power cord. The receptacle labeled "RPU" is for the optional Redundant Power Unit.

Redundant Power Socket Power Socket 100-240V~, 50-60Hz 2A RPU DC IN 12V 8.5A Figure 1-7. SMC8624T Power Supply Receptacles Power Socket Redundant Power Socket Figure 1-8. SMC8648T Power Supply Receptacles 1-7 ABOUT THE TIGERSWITCH 10/100/1000 Features and Benefits Connectivity 24/48 dual-speed ports for easy Gigabit Ethernet integration and for protection of your investment in a legacy LAN equipment. Auto-negotiation enables each RJ-45 port to automatically select the optimum communication mode (half or full duplex) if this feature is supported by the attached device; otherwise the port can be configured manually.

Independent RJ-45 10/100/1000BASE-T ports with auto MDI/MDI-X pinout selection. Unshielded (UTP) cable supported on all RJ-45 ports: Category 3 or better for 10 Mbps connections, Category 5 or better for 100 Mbps connections, and Category 5 or better for 1000 Mbps connections. IEEE 802.3 Ethernet, 802.3u Fast Ethernet, 802.

3z and 802.3ab Gigabit Ethernet compliance ensures compatibility with standards-based hubs, network cards and switches from any vendor. Expandability Supports 1000BASE-SX, 1000BASE-LX, 1000BASE-ZX, and 1000BASE-T SFP transceivers. Performance Transparent bridging Switching table with a total of 16K MAC address entries Provides store-and-forward switching Supports wire-speed switching Supports flow control, using back pressure for half duplex and IEEE 802.3x for full duplex 1-8 FEATURES AND BENEFITS Broadcast storm control Desktop or rack-mountable Limited lifetime warranty Management "At-a-glance" LEDs for easy troubleshooting Network management agent: · Manages the switch in-band or out-of-band Supports Telnet, SNMP/RMON and Web-based interface 1-9 ABOUT THE TIGERSWITCH 10/100/1000 1-10 CHAPTER 2 NETWORK PLANNING Introduction to Switching A network switch allows simultaneous transmission of multiple packets via non-crossbar switching.

This means that it can partition a network more efficiently than bridges or routers. The switch has, therefore, been recognized as one of the most important building blocks for today's networking technology. When performance bottlenecks are caused by congestion at the network access point (such as the network card for a high-volume file server), the device experiencing congestion (server, power user or hub) can be attached directly to a switched port. And, by using full-duplex mode, the bandwidth of the dedicated segment can be doubled to maximize throughput. When networks are based on repeater (hub) technology, the maximum distance between end stations is limited. For Ethernet, there may be up to four hubs between any pair of stations; for Fast Ethernet, the maximum is two. This is known as the hop count. However, a switch turns the hop count back to zero. So subdividing the network into smaller and more manageable segments, and linking them to the larger network by means of a switch, removes this limitation. A switch can be easily configured in any Ethernet, Fast Ethernet, or Gigabit Ethernet network to significantly boost bandwidth while using conventional cabling and network cards.

2-1 NETWORK PLANNING Application Examples The TigerSwitch 10/100/1000 is not only designed to segment your network, but also to provide a wide range of options in setting up network connections and linking VLANs. Some typical applications are described below. Collapsed Backbone The TigerSwitch 10/100/1000 is an excellent choice for mixed Ethernet, Fast Ethernet, and Gigabit Ethernet installations where significant growth is expected in the near future. You can easily build on this basic configuration, adding direct full-duplex connections to workstations or servers. When the time comes for further expansion, just connect to another hub or switch using one of the Gigabit Ethernet ports built into the front panel or a Gigabit Ethernet port on a plug-in SFP transceiver. In the figure below, this switch is operating as a collapsed backbone for a small LAN. It is providing dedicated 100 Mbps full-duplex connections to workstations and 1 Gbps full-duplex connections to power users and servers. RPU TigerSwitch 10/100/1000 8648T ...

Servers 1 Gbps Full Duplex ... Workstations 1 Gbps Full Duplex ..

· Workstations 100 Mbps Full Duplex Figure 2-1. Collapsed Backbone 2-2 APPLICATION EXAMPLES Network Aggregation Plan With 24/48 parallel bridging ports (i.e., 24/48 distinct collision domains), the Gigabit Ethernet Switch can collapse a complex network down into a single efficient bridged node, increasing overall bandwidth and throughput.

In the figure below, the 10/100/1000BASE-T ports on the Gigabit Ethernet Switch are providing 1 Gbps connectivity for up to 24/48 segments through stackable switches.



[You're reading an excerpt. Click here to read official SMC 8648T user guide](http://yourpdfguides.com/dref/3457392)  
<http://yourpdfguides.com/dref/3457392>

In addition, the switch is also connecting several servers at 1 Gbps. RPU TigerSwitch 10/100/1000 8648T Server Farm . . . 1 ES3526F . . . 1 ES3526F 1 ES3526F 1 ES3526F 10/100/1000 Mbps Segments ..

. . . Figure 2-2. Network Aggregation Plan 2-3 NETWORK PLANNING Remote Connections with Fiber Cable Fiber optic technology allows for longer cabling than any other media type. A 1000BASE-SX (MMF) link can connect to a site up to 550 meters away, and a 1000BASE-LX (SMF) link can run up to 5 km. This allows the Gigabit Ethernet Switch to serve as a collapsed backbone, providing direct connectivity for a widespread LAN. A 1000BASE-SX SFP can be used for a high-speed connection between floors in the same building, and a 1000BASE-LX SFP can be used to connect to other buildings in a campus setting. The figure below illustrates this switch connecting multiple segments with fiber cable.

Headquarters RPU TigerSwitch 10/100/1000 8648T Server Farm Remote Switch 25 26 1 2 3 4 5 6 13 14 15 16 17 18 Link Act Console Power 7 8 9 Self Test 10 11 12 Fan Status 19 20 21 22 23 24 Link Act 1000BASE-SX MMF (500 meters) 1000BASE-LX SMF (5 kilometers) Remote Switch 1 2 3 4 5 6 13 14 15 16 17 18 26 25 26 1 2 3 4 5 6 13 14 15 16 17 18 Link Act 25 1 25 26 2 3 4 5 6 13 14 15 16 17 18 Fault Reset Clear 7 8 9 10 11 12 19 20 21 22 23 24 Power Console 7 8 9 Self Test 10 11 12 Fan Status 19 20 21 22 23 24 Link Act Fault Reset Clear 7 8 9 10 11 12 19 20 21 22 23 24 10/100/1000 Mbps Segments ... ..

. Figure 2-3. Remote Connection with Fiber Cable 2-4 APPLICATION EXAMPLES Making VLAN Connections This switch supports VLANs which can be used to organize any group of network nodes into separate broadcast domains. VLANs confine broadcast traffic to the originating group, and can eliminate broadcast storms in large networks. This provides a more secure and cleaner network environment.

VLANs can be based on untagged port groups, or traffic can be explicitly tagged to identify the VLAN group to which it belongs. Untagged VLANs can be used for small networks attached to a single switch. However, tagged VLANs should be used for larger networks, and all the VLANs assigned to the inter-switch links. The switch also supports multiple spanning trees which allow VLANs groups to maintain a more stable path between all VLAN members. This can reduce the overall amount of protocol traffic crossing the network, and provide a shorter reconfiguration time when any link in the spanning tree fails.

R&D VLAN 1 Tagged Ports Untagged Ports VLAN unaware switch R&D RPU TigerSwitch 10/100/1000 8648T Tagged Port VLAN aware switch Finance VLAN 2 Testing Marketing Finance Testing VLAN 3 VLAN 4 VLAN 3 VLAN 1 VLAN 2 Figure 2-4. @@@@2. @@@@3. @@@@Be sure to follow the guidelines below when choosing a location. @@@@Grounding: Rack-mounted equipment should be properly grounded.

@@@Attaching the Brackets 2. @@Installing the Switch in a Rack 3-5 INSTALLING THE SWITCH 3. If installing a single switch only, turn to "Connecting to a Power Source" at the end of this chapter. 4. If installing multiple switches, mount them in the rack, one below the other, in any order. 5. If also installing RPUs, mount them in the rack below the other devices. Desktop or Shelf Mounting 1. Attach the four adhesive feet to the bottom of the first switch. 2.

Set the device on a flat surface near an AC power source, making sure there are at least two inches of space on all sides for proper air flow. 3. If installing a single switch only, go to "Connecting to a Power Source" at the end of this chapter. 4. If installing multiple switches, attach four adhesive feet to each one. Place each device squarely on top of the one below, in any order. 5. If also installing RPUs, place them close to the stack. 3-6 RPU Tig erS wi tch 10/10 0/1 86 000 48 T Figure 3-4. Attaching the Adhesive Feet MOUNTING Installing an Optional SFP Transceiver into the Switch RPU Tig erS wit ch 10/1 00/1 0 864 00 8T Figure 3-5.

Inserting an SFP Transceiver into a Slot To install an SFP transceiver, do the following: 1. Consider network and cabling requirements to select an appropriate SFP transceiver type. 2. Insert the transceiver with the optical connector facing outward and the slot connector facing down. Note that SFP transceivers are keyed so they can only be installed in one orientation. 3. Slide the SFP transceiver into the slot until it clicks into place. Note: SFP transceivers are hot-swappable. The switch does not need to be powered off before installing or removing a transceiver. However, always first disconnect the network cable before removing a transceiver.

3-7 INSTALLING THE SWITCH Connecting to a Power Source To connect a device to a power source: 1. Insert the power cable plug directly into the receptacle located at the back of the device. Figure 3-6. Power Receptacle 2. Plug the other end of the cable into a grounded, 3-pin socket. Note: For international use, you may need to change the AC line cord. You must use a line cord set that has been approved for the receptacle type in your country. 3. Check the front-panel LEDs as the device is powered on to be sure the Power LED is on. If not, check that the power cable is correctly plugged in.

4. If you have purchased a Redundant Power Unit, connect it to the device and to an AC power source now, following the instructions included with the package. 3-8 CONNECTING TO THE CONSOLE PORT Connecting to the Console Port The DB-9 serial port on the switch's front panel is used to connect to the switch for out-of-band console configuration. The on-board configuration program can be accessed from a terminal or a PC running a terminal emulation program. The pin assignments used to connect to the serial port are provided in the following tables.

1 5 6 9 Figure 3-7. Serial Port (DB-9 DTE) Pin-Out Table 3-1. Wiring Map for Serial Cable Switch's 9-Pin Serial Port 2 RXD (receive data) 3 TXD (transmit data) No other pins are used. Null Modem <-----> PC's 9-Pin DTE Port 3 TXD (transmit data) 2 RXD (receive data) 5 SGND (signal ground) 5 SGND (signal ground) ----- The serial port's configuration requirements are as follows: Default Baud rate--9,600 bps Character Size--8 Characters Parity--None Stop bit--One Data bits--8 Flow control--none 3-9 INSTALLING THE SWITCH 3-10 CHAPTER 4 MAKING NETWORK CONNECTIONS Connecting Network Devices The TigerSwitch 10/100/1000 is designed to interconnect multiple segments (or collision domains). It can be connected to network cards in PCs and servers, as well as to hubs, switches or routers.

It may also be connected to devices using optional SFP transceivers.



[You're reading an excerpt. Click here to read official SMC 8648T user guide](http://yourpdfguides.com/dref/3457392)

<http://yourpdfguides.com/dref/3457392>



*Twisted-Pair Devices* Each device requires an unshielded twisted-pair (UTP) cable with RJ-45 connectors at both ends. Use Category 5, 5e or 6 cable for 1000BASE-T connections, Category 5 or better for 100BASE-TX connections, and Category 3 or better for 10BASE-T connections. Cabling Guidelines The RJ-45 ports on the switch support automatic MDI/MDI-X pinout configuration, so you can use standard straight-through twisted-pair cables to connect to any other network device (PCs, servers, switches, routers, or hubs). See Appendix B for further information on cabling. Caution: Do not plug a phone jack connector into an RJ-45 port. This will damage the switch. Use only twisted-pair cables with RJ-45 connectors that conform to FCC standards. 4-1 MAKING NETWORK CONNECTIONS Connecting to PCs, Servers, Hubs and Switches 1. Attach one end of a twisted-pair cable segment to the device's RJ-45 connector.

Figure 4-1. Making Twisted-Pair Connections 2. If the device is a PC card and the switch is in the wiring closet, attach the other end of the cable segment to a modular wall outlet that is connected to the wiring closet. (See "Wiring Closet Connections" on the next page.) Otherwise, attach the other end to an available port on the switch. 3. Make sure each twisted pair cable does not exceed 100 meters (328 ft) in length. 4. As each connection is made, the Link LED (on the switch) corresponding to each port will light to indicate that the connection is valid. Note: @ @ Otherwise back pressure jamming signals may degrade overall performance for the segment.

4-2 TWISTED-PAIR DEVICES Network Wiring Connections Today, the punch-down block is an integral part of many of the newer equipment racks. It is actually part of the patch panel. Instructions for making connections in the wiring closet with this type of equipment follows. 1. Attach one end of a patch cable to an available port on the switch, and the other end to the patch panel.

2. If not already in place, attach one end of a cable segment to the back of the patch panel where the punch-down block is located, and the other end to a modular wall outlet. 3. Label the cables to simplify future troubleshooting. 4.

Equipment Rack (side view) RPU w it ch 10 /1 0 0 6724L 3 TigerSwitch 10/100/1000 ES4524C 8648T Punch-Down Block Patch Panel Wall Figure 4-2.

Wiring Closet Connections 4-3 MAKING NETWORK CONNECTIONS Fiber Optic SFP Devices An optional Gigabit SFP transceiver (1000BASE-SX, 1000BASE-LX or 1000BASE-LH) can be used for a backbone connection between switches, or for connecting to a high-speed server. Each multimode fiber optic port requires 50/125 or 62.5/125 micron multimode fiber optic cabling with an LC connector at both ends. Each single-mode fiber port requires 9/125 micron single-mode fiber optic cable with an LC connector at both ends. Caution: This switch uses lasers to transmit signals over fiber optic cable. The lasers are compliant with the requirements of a Class 1 Laser Product and are inherently eye safe in normal operation. However, you should never look directly at a transmit port when it is powered on. 1. Remove and keep the LC port's rubber cover.

When not connected to a fiber cable, the rubber cover should be replaced to protect the optics. 2. Check that the fiber terminators are clean. You can clean the cable plugs by wiping them gently with a clean tissue or cotton ball moistened with a little ethanol. Dirty fiber terminators on fiber cables will impair the quality of the light transmitted through the cable and lead to degraded performance on the port. 4-4 FIBER OPTIC SFP DEVICES 3. Connect one end of the cable to the LC port on the switch and the other end to the LC port on the other device. Since LC connectors are keyed, the cable can be attached in only one orientation. RPU Tig erS wit ch 10/1 00/1 0 864 0 0 8T Figure 4-3. Making LC Port Connections 4.

As a connection is made, check the green Link LED on the switch corresponding to the port to be sure that the connection is valid. The 1000BASE-SX, 1000BASE-LX and 1000BASE-LH fiber optic ports operate at 1 Gbps full duplex, with auto-negotiation of flow control. The maximum length for fiber optic cable operating at Gigabit speed will depend on the fiber type as listed under "1000 Mbps Gigabit Ethernet Collision Domain" on page 4-6. 4-5 MAKING NETWORK CONNECTIONS Connectivity Rules When adding hubs (repeaters) to your network, please follow the connectivity rules listed in the manuals for these products. However, note that because switches break up the path for connected devices into separate collision domains, you should not include the switch or connected cabling in your calculations for cascade length involving other devices.

1000BASE-T Cable Requirements All Category 5 UTP cables that are used for 100BASE-TX connections should also work for 1000BASE-T, providing that all four wire pairs are connected. However, it is recommended that for all critical connections, or any new cable installations, Category 5e (enhanced Category 5) or Category 6 cable should be used. The Category 5e specification includes test parameters that are only recommendations for Category 5. Therefore, the first step in preparing existing Category 5 cabling for running 1000BASE-T is a simple test of the cable installation to be sure that it complies with the IEEE 802.3ab standards.

1000 Mbps Gigabit Ethernet Collision Domain Table 4-1. Maximum 1000BASE-T Gigabit Ethernet Cable Length Cable Type Category 5, 5e, 6 100-ohm UTP or STP Maximum Cable Length 100 m (328 ft) Connector RJ-45 Table 4-2. Maximum 1000BASE-SX Fiber Optic Cable Distance Fiber Diameter 62.5/125 micron multimode fiber (MMF) 50/125 micron multimode fiber (MMF) Fiber Bandwidth 160 MHz/km 200 MHz/km 400 MHz/km 500 MHz/km Cable Length Range 2-220 m (7-722 ft) 2-275 m (7-902 ft) 2-500 m (7-1641 ft) 2-550 m (7-1805 ft) Connector LC LC LC LC 4-6 CONNECTIVITY RULES Table 4-3. Maximum 1000BASE-LX Fiber Optic Cable Distance Fiber Diameter 9/125 micron single-mode fiber Fiber Bandwidth N/A Cable Length Range 2 m - 5 km (7 ft - 3.2 miles) Connector LC Table 4-4. Maximum 1000BASE-ZX Fiber Optic Cable Distance Fiber Diameter 9/125 micron single-mode fiber Fiber Bandwidth N/A Cable Length Range 70\* - 100 km (43.5 - 62.1 miles) Connector LC \* For link spans exceeding 70 km, you may need to use premium single mode fiber or dispersion shifted single mode fiber 100 Mbps Fast Ethernet Collision Domain Table 4-5. Maximum Fast Ethernet Cable Distance Type 100BASE-TX Cable Type Category 5 or better 100-ohm UTP or STP Maximum Cable Length 100 m (328 ft) Connector RJ-45 10 Mbps Ethernet Collision Domain Table 4-6.

Maximum Ethernet Cable Distance Cable Type Twisted Pair, Categories 3, 4, 5 or better 100-ohm UTP Maximum Length 100 m (328 ft) Connector RJ-45 4-7 MAKING NETWORK CONNECTIONS Cable Labeling and Connection Records When planning a network installation, it is essential to label the opposing ends of cables and to record where each cable is connected.



You're reading an excerpt. Click here to read official SMC 8648T user guide  
<http://yourpdfguides.com/dref/3457392>



Doing so will enable you to easily locate inter-connected devices, isolate faults and change your topology without need for unnecessary time consumption. To best manage the physical implementations of your network, follow these guidelines: Clearly label the opposing ends of each cable. Using your building's floor plans, draw a map of the location of all network-connected equipment. For each piece of equipment, identify the devices to which it is connected. Note the length of each cable and the maximum cable length supported by the switch ports. For ease of understanding, use a location-based key when assigning prefixes to your cable labeling. Use sequential numbers for cables that originate from the same equipment. Differentiate between racks by naming accordingly. Label each separate piece of equipment.

Display a copy of your equipment map, including keys to all abbreviations at each equipment rack. 4-8 APPENDIX A TROUBLESHOOTING Diagnosing Switch Indicators Table A-1. Troubleshooting Chart Symptom Power LED is Off Action · · · Diag LED is On Amber Link LED is Off · · · · · Check connections between the switch, the power cord, and the wall outlet. Contact your dealer for assistance. Contact SMC Technical Support.

Try power cycling the switch to clear the condition. Contact your dealer for assistance. Verify that the switch and attached device are powered on. Be sure the cable is plugged into both the switch and corresponding device. Verify that the proper cable type is used and its length does not exceed specified limits.

Check the adapter on the attached device and cable connections for possible defects. Replace the defective adapter or cable if necessary. A-1 TROUBLESHOOTING Power and Cooling Problems If the power indicator does not turn on when the power cord is plugged in, you may have a problem with the power outlet, power cord, or internal power supply. However, if the unit powers off after running for a while, check for loose power connections, power losses or surges at the power outlet, and verify that the fans on the unit are unobstructed and running prior to shutdown. If you still cannot isolate the problem, then the internal power supply may be defective. Installation Verify that all system components have been properly installed. If one or more components appear to be malfunctioning (such as the power cord or network cabling), test them in an alternate environment where you are sure that all the other components are functioning properly. In-Band Access You can access the management agent in the switch from anywhere within the attached network using Telnet, a Web browser, or other network management software tools. However, you must first configure the switch with a valid IP address, subnet mask, and default gateway. If you have trouble establishing a link to the management agent, check to see if you have a valid network connection.

Then verify that you entered the correct IP address. Also, be sure the port through which you are connecting to the switch has not been disabled. If it has not been disabled, then check the network cabling that runs between your remote location and the switch. Caution: The management agent can accept up to four simultaneous Telnet sessions. If the maximum number of sessions already exists, an additional Telnet connection will not be able to log into the system. A-2 APPENDIX B CABLES Twisted-Pair Cable and Pin Assignments Caution: DO NOT plug a phone jack connector into any RJ-45 port. Use only twisted-pair cables with RJ-45 connectors that conform with FCC standards. For 10BASE-T/100BASE-TX connections, a twisted-pair cable must have two pairs of wires.

Each wire pair is identified by two different colors. For example, one wire might be green and the other, green with white stripes.

Also, an RJ-45 connector must be attached to both ends of the cable. Caution: Each wire pair must be attached to the RJ-45 connectors in a specific orientation. (See "Cabling Guidelines" on page 4-1 for an explanation.) Figure B-1 illustrates how the pins on the RJ-45 connector are numbered. Be sure to hold the connectors in the same orientation when attaching the wires to the pins.

Figure B-1. RJ-45 Connector Pin Numbers B-1 CABLES 10BASE-T/100BASE-TX Pin Assignments Use unshielded twisted-pair (UTP) or shielded twisted-pair (STP) cable for RJ-45 connections: 100-ohm Category 3 or better cable for 10 Mbps connections, or 100-ohm Category 5 or better cable for 100 Mbps or 1000 Mbps connections. Also be sure that the length of any twisted-pair connection does not exceed 100 meters (328 feet). The RJ-45 ports on the switch base unit support automatic MDI/MDI-X operation, so you can use straight-through cables for all network connections to PCs or servers, or to other switches or hubs. In straight-through cable, pins 1, 2, 3, and 6, at one end of the cable, are connected straight through to pins 1, 2, 3, and 6 at the other end of the cable.

Table B-1. 10/100BASE-TX MDI and MDI-X Port Pinouts Pin MDI-X Assignment MDI Assignment 1 Input Receive Data + Output Transmit Data + 2 Input Receive Data Output Transmit Data 3 Output Transmit Data + Input Receive Data + 6 Output Transmit Data Input Receive Data 4,5,7,8 Not used Not used Note: The "+" and "-" signs represent the polarity of the wires that make up each wire pair. B-2 TWISTED-PAIR CABLE AND PIN ASSIGNMENTS Straight-

Through Wiring If the twisted-pair cable is to join two ports and only one of the ports has an internal crossover (MDI-X), the two pairs of wires must be straight-through. (When auto-negotiation is enabled for any RJ-45 port on this switch, you can use either straight-through or crossover cable to connect to any device type.) EIA/TIA 568B RJ-45 Wiring Standard 10/100BASE-TX Straight-through Cable White/Orange Stripe Orange End A 1 2 3 4 5 6 7 8 White/Green Stripe Blue White/Blue Stripe Green White/Brown Stripe 1 2 3 4 5 6 7 8 End B Brown Stripe Figure B-2. Straight-through Wiring B-3 CABLES Crossover Wiring If the twisted-pair cable is to join two ports and either both ports are labeled with an "X" (MDI-X) or neither port is labeled with an "X" (MDI), a crossover must be implemented in the wiring. (When auto-negotiation is enabled for any RJ-45 port on this switch, you can use either straight-through or crossover cable to connect to any device type.) EIA/TIA 568B RJ-45 Wiring Standard 10/100BASE-TX Crossover Cable White/Orange Stripe Orange End A 1 2 3 4 5 6 7 8 White/Green Stripe Blue White/Blue Stripe Green White/Brown Stripe 1 2 3 4 5 6 7 8 End B Brown Stripe Figure B-3.

Crossover Wiring 1000BASE-T Pin Assignments All 1000BASE-T ports support automatic MDI/MDI-X operation, so you can use straight-through cables for all network connections to PCs or servers, or to other switches or hubs. The table below shows the 1000BASE-T MDI and MDI-X port pinouts.



[You're reading an excerpt. Click here to read official SMC 8648T user guide](http://yourpdfguides.com/dref/3457392)

<http://yourpdfguides.com/dref/3457392>

These ports require that all four pairs of wires be connected. Note that for 1000BASE-T operation, all four pairs of wires are used for both transmit and receive. Use 100-ohm Category 5, 5e or 6 unshielded twisted-pair (UTP) or shielded twisted-pair (STP) cable for 1000BASE-T connections. Also be sure that the length of any twisted-pair connection does not exceed 100 meters (328 feet). B-4 TWISTED-PAIR CABLE AND PIN ASSIGNMENTS Table B-2. 1000BASE-T MDI-X and MDI Port Pinouts Pin 1 2 3 4 5 6 7 8 MDI-X Signal Name Bi-directional Data Two Plus (BI\_D2+) Bi-directional Data Two Minus (BI\_D2-) Bi-directional Data One Plus (BI\_D1+) Bi-directional Data Four Plus (BI\_D4+) Bi-directional Data Four Minus (BI\_D4-) Bi-directional Data One Minus (BI\_D1-) Bi-directional Data One Plus (BI\_D3+) Bi-directional Data Three Minus (BI\_D3-) MDI Signal Name Bi-directional Data One Plus (BI\_D1+) Bi-directional Data One Minus (BI\_D1-) Bi-directional Data Two Plus (BI\_D2+) Bi-directional Data Three Plus (BI\_D3+) Bi-directional Data Three Minus (BI\_D3-) Bi-directional Data Two Minus (BI\_D2-) Bi-directional Data One Plus (BI\_D4+) Bi-directional Data Four Minus (BI\_D4-) 1000BASE-T Cable Requirements All Category 5 UTP cables that are used for 100BASE-TX connections should also work for 1000BASE-T, providing that all four wire pairs are connected. However, it is recommended that for all critical connections, or any new cable installations, Category 5e (enhanced Category 5) or 6 cable should be used. The Category 5e and 6 specifications include test parameters that are only recommendations for Category 5. Therefore, the first step in preparing existing Category 5 cabling for running 1000BASE-T is a simple test of the cable installation to be sure that it complies with the IEEE 802.3ab standards.

Cable Testing for Existing Category 5 Cable Installed Category 5 cabling must pass tests for Attenuation, Near-End Crosstalk (NEXT), and Far-End Crosstalk (FEXT). This cable testing information is specified in the ANSI/TIA/EIA-TSB-67 standard. Additionally, cables must also pass test parameters for Return Loss and Equal-Level Far-End Crosstalk (ELFEXT). These tests are specified in the ANSI/TIA/EIA-TSB-95 Bulletin, "The Additional Transmission Performance Guidelines for 100 Ohm 4-Pair Category 5 Cabling." Note that when testing your cable installation, be sure to include all patch cables between switches and end devices.

B-5 CABLES Adjusting Existing Category 5 Cabling to Run 1000BASE-T If your existing Category 5 installation does not meet one of the test parameters for 1000BASE-T, there are basically three measures that can be applied to try and correct the problem: 1. Replace any Category 5 patch cables with high-performance Category 5e or Category 6 cables. 2. Reduce the number of connectors used in the link. 3.

Reconnect some of the connectors in the link. Fiber Standards The current TIA (Telecommunications Industry Association) 568-A specification on optical fiber cabling consists of one recognized cable type for horizontal subsystems and two cable types for backbone subsystems. Horizontal 62.5/125 micron multimode (two fibers per outlet). Backbone 62.5/125 micron multimode or single mode. TIA 568-B will allow the use of 50/125 micron multimode optical fiber in both the horizontal and backbone in addition to the types listed above. All optical fiber components and installation practices must meet applicable building and safety codes. B-6 APPENDIX C SPECIFICATIONS Physical Characteristics Port Configuration SMC8624T 10/100/100BASE-T Ports 1-24 1000BASE-T: 10/100 Mbps, half/full duplex 1000 Mbps, full duplex SFP Ports 21-24 1000BASE-X: 1000 Mbps, full duplex SMC8648T 10/100/100BASE-T Ports 1-48 1000BASE-T: 10/100 Mbps, half/full duplex 1000 Mbps, full duplex SFP Ports 45-48 1000BASE-X: 1000 Mbps, full duplex Network Interface Ports 1-24/48: RJ-45 connector, auto MDI/X 10BASE-T: RJ-45 (100-ohm, UTP cable; Categories 3 or better) Maximum Cable Length - 100 m (328 ft) 100BASE-TX: RJ-45 (100-ohm, UTP cable; Category 5 or better) Maximum Cable Length - 100 m (328 ft) 1000BASE-T: RJ-45 (100-ohm, UTP or STP cable; Category 5, 5e, or 6) Maximum Cable Length - 100 m (328 ft) System Memory 8 Mbytes flash 32 Mbytes SDRAM C-1 SPECIFICATIONS Data Packet Buffer 2 Mbytes Aggregate Bandwidth SMC8624T: 48 Gbps SMC8648T: 96 Gbps Switching Database 16K MAC address entries LEDs System: Power (Power Supply), Diag (Diagnostics), RPU (Redundant Power Unit) Port: Link/Activity Weight 4.3 kg (9.

46 lbs) Size 44.0 x 41.5 x 4.4 cm (17.4 x 16.3 x 1.7 in.) Temperature Operating: 0 to 50 °C (32 to 122 °F) Storage: -40 to 70 °C (-40 to 158 °F) Humidity Operating: 5% to 95% (non-condensing) AC Input 100 to 240 V, 50/60 Hz Power Supply Internal, auto-ranging transformer: 90 to 240 VAC, 47 to 63 Hz External, supports connection for redundant power supply Power Consumption SMC8624T: 70 Watts maximum SMC8648T: 110 Watts maximum Heat Dissipation SMC8624T: 239 BTU/hr maximum SMC8648T: 376 BTU/hr maximum C-2 SWITCH FEATURES Maximum Current SMC8624T: 1.2 A @ 110 VAC, 0.6 A @ 240 VAC SMC8648T: 1.

3 A @ 110 VAC, 0.6 A @ 240 VAC Switch Features Forwarding Mode Store-and-forward Throughput Wire speed Flow Control Full Duplex: IEEE 802.3x Half Duplex: Back pressure Standards IEEE 802.3 Ethernet IEEE 802.3u Fast Ethernet IEEE 802.

3z and 802.3ab Gigabit Ethernet IEEE 802.1p priority tags IEEE 802.3ac VLAN tagging IEEE 802.1D Bridging IEEE 802.

3x full-duplex flow control ISO/IEC 8802-3 Carrier sense multiple access with collision detection (CSMA/CD) C-3 SPECIFICATIONS Compliances CE Mark Emissions FCC Class A Industry Canada Class A EN55022 (CISPR 22) Class A EN 61000-3-2/3 VCCI Class A C-Tick - AS/NZS 3548 (1995) Class A Immunity EN 61000-4-2/3/4/5/6/8/11 Safety CSA/NRTL (CSA 22.2.950 & UL 1950) EN60950 (TUV/GS) Warranty Limited Lifetime C-4 APPENDIX D ORDERING INFORMATION TigerSwitch 10/100/1000 Products and Accessories Product Number SMC8648T Description 48 10/100/1000BASE-T ports switch with four Gigabit combination ports with RJ-45 connectors and associated SFP transceiver slots 24 10/100/1000BASE-T ports switch with four Gigabit combination ports with RJ-45 connectors and associated SFP transceiver slots 1-port 1000BASE-SX Small Form Pluggable (SFP) mini-GBIC transceiver 1-port 1000BASE-LX Small Form Pluggable (SFP) mini-GBIC transceiver 1-port 1000BASE-ZX Small Form Pluggable (SFP) mini-GBIC transceiver Redundant power unit with cables, supports one device SMC8624T SMCBGLCX1 SMCBGLLCX1 SMCBGLZCX1 SMC RPU600W\* \* Also available in models for Continental Europe and the UK. D-1 ORDERING INFORMATION D-2 GLOSSARY 10BASE-T IEEE 802.3 specification for 10 Mbps Ethernet over two pairs of Category 3 or better UTP cable. 100BASE-TX IEEE 802.3u specification for 100 Mbps Fast Ethernet over two pairs of Category 5 or better UTP cable. 1000BASE-SX IEEE 802.3z specification for Gigabit Ethernet over two strands of 50/125 or 62.



[You're reading an excerpt. Click here to read official SMC 8648T user guide](http://yourpdfguides.com/dref/3457392)

<http://yourpdfguides.com/dref/3457392>