



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for SONY ERICSSON C510. You'll find the answers to all your questions on the SONY ERICSSON C510 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual SONY ERICSSON C510**  
**User guide SONY ERICSSON C510**  
**Operating instructions SONY ERICSSON C510**  
**Instructions for use SONY ERICSSON C510**  
**Instruction manual SONY ERICSSON C510**

Thank you for purchasing a Sony Ericsson C510 Cyber-shot™. A stylish Cyber-shot™ phone with fantastic camera functions for amazing pictures.

For additional phone content, go to [www.sonyericsson.com/fun](http://www.sonyericsson.com/fun). Register now to get a suite of tools, free online storage, special offers, news and competitions at [www.sonyericsson.com/myphone](http://www.sonyericsson.com/myphone).

For product support, go to [www.sonyericsson.com/support](http://www.sonyericsson.com/support).



[You're reading an excerpt. Click here to read official SONY ERICSSON C510 user guide](http://yourpdfguides.com/dref/2712647)  
<http://yourpdfguides.com/dref/2712647>

*Manual abstract:*

*@@For additional phone content, go to www.sonyericsson.com/fun. @@@@© Print only for private use. Radio.....*

*.....  
.....  
.....*

*.....  
.....  
.....  
.....  
.....48 MusicDJTM.....*

*.....  
.....  
.....  
.....*

*.....48 Record sound.....  
.....  
.....*

*.....48 Internet...  
.....  
.....*

*.....49 Bookmarks.  
.....  
.....*

*.....  
.....  
.....49 History pages..  
.....*

*.....  
.....  
.....*

*...50 More browser features.....*

*.....  
.....50 Internet security and certificates.  
.....  
51 Web feeds.....*

*.....  
.....  
.....*

*51 Ringtones.....  
.....  
.....*

*.....  
.....59 Screen orientation....  
.....  
.....*

*.....59 Games.  
.....  
.....*

.....  
.....  
.....  
.....60 Applications.....

.....  
.....  
.....  
.....  
.....  
.....60 Locks.....

.....  
.....  
.....  
.....  
.....  
.....  
61 Troubleshooting.....

.....63 Common questions..  
.....  
.....  
.....

....63 Error messages.....  
.....  
.....  
.....

.....66 Synchronising....  
.....  
.....  
.....53 Synchronising using a computer...

..53 Synchronising using an Internet service.....  
.....  
.....  
.....

.....  
.....  
.....  
.....53 Important information..  
.....67 Index...

.....  
.....  
.....  
.....  
.....  
.....79 More features.....

.....  
.....  
.....54 Flight mode.....

.....  
.....  
.....  
.....

...54 Update Service.....  
.....  
.....  
.....

.....54 Location services....  
.....

.....  
.....  
.....55 Alarms.....

.....  
.....  
.....  
.....  
.....  
.....  
.....56 Calendar.....

.....  
.....  
.....  
.....  
.....57 Notes.....

.....  
.....  
.....  
.....  
.....57 Tasks.....

.....  
.....  
.....  
.....  
.....58 Profiles.....

.....  
.....  
.....  
.....  
.....58 Time and date.....

.....  
.....  
.....  
.....58 Theme.

.....  
.....  
.....  
.....  
.....  
.....  
.....59 Main menu layout.....

.....  
.....  
.....59 2 This is an Internet version of this publication.

© Print only for private use. Sony Ericsson C510 Cyber-shot™ UMTS/HSPA band 1 GSM/GPRS/EDGE 900/1800/1900 This User guide is published by Sony Ericsson Mobile Communications AB or its local affiliated company, without any warranty. Improvements and changes to this User guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Ericsson Mobile Communications AB at any time and without notice. Such changes will, however, be incorporated into new editions of this User guide. All rights reserved. @@This also applies to the GSM International Emergency Number 112. @@@@@ringtones. The use of such content may be restricted or prohibited by rights of third parties, including but not limited to restriction under applicable copyright laws. You, and not Sony Ericsson, are entirely responsible for additional content that you download to or forward from your mobile phone. Prior to your use of any additional content, please verify that your intended use

is properly licensed or is otherwise authorized. Sony Ericsson does not guarantee the accuracy, integrity or quality of any additional content or any other third party content. Under no circumstances will Sony Ericsson be liable in any way for your improper use of additional content or other third party content. Smart-Fit Rendering is a trademark or a registered trademark of ACCESS Co., Ltd. Bluetooth is a trademark or a registered trademark of Bluetooth SIG Inc.

and any use of such mark by Sony Ericsson is under license. The Liquid Identity logo, BestPic, PlayNow, MusicDJ, PhotoDJ, TrackID and VideoDJ are trademarks or registered trademarks of Sony Ericsson Mobile Communications AB. TrackID™ is powered by Gracenote Mobile MusicID™. Gracenote and Gracenote Mobile MusicID are trademarks or registered trademarks of Gracenote, Inc. Cyber-shot is a trademark or registered trademark of Sony Corporation. Sony, Memory Stick Micro™ and M2™ are trademarks or registered trademarks of Sony Corporation. Google™ and Google Maps™ are trademarks or registered trademarks of Google, Inc. SyncML is a trademark or registered trademark of Open Mobile Alliance LTD. Ericsson is a trademark or registered trademark of Telefonaktiebolaget LM Ericsson. Adobe Photoshop Album Starter Edition is a trademark or registered trademark of Adobe Systems Incorporated in the United States and/or other countries.

Microsoft, ActiveSync, Windows, Outlook, Windows Media and Vista are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. T9™ Text Input is a trademark or a registered trademark of Tegic Communications. T9™ Text Input is licensed under one or more of the following: U.S. Pat.

Nos. 5,818,437, 5,953,541, 5,187,480, 5,945,928, and 6,011,554; Canadian Pat. No. 1,331,057, United Kingdom Pat. No. 2238414B; 3 This is an Internet version of this publication. © Print only for private use. Hong Kong Standard Pat. No. HK0940329; Republic of Singapore Pat. No. 51383; Euro.Pat. No. 0 842 463(96927260).

8) DE/DK, FI, FR, IT, NL, PT, ES, SE, GB; and additional patents are pending worldwide. This product is protected by certain intellectual property rights of Microsoft. Use or distribution of such technology outside of this product is prohibited without a license from Microsoft. Content owners use Windows Media digital rights management technology (WMDRM) to protect their intellectual property, including copyrights. This device uses WMDRM software to access WMDRMprotected content. If the WMDRM software fails to protect the content, content owners may ask Microsoft to revoke the software's ability to use WMDRM to play or copy protected content. Revocation does not affect unprotected content. When you download licenses for protected content, you agree that Microsoft may include a revocation list with the licenses. Content owners may require you to upgrade WMDRM to access their content. If you decline an upgrade, you will not be able to access content that requires the upgrade.

This product is licensed under the MPEG-4 visual and AVC patent portfolio licenses for the personal and non-commercial use of a consumer for (i) encoding video in compliance with the MPEG-4 visual standard ("MPEG-4 video") or the AVC standard ("AVC video") and/or (ii) decoding MPEG4 or AVC video that was encoded by a consumer engaged in a personal and non-commercial activity and/or was obtained from a video provider licensed by MPEG LA to provide MPEG-4 and/or AVC video. No license is granted or shall be implied for any other use. Additional information including that relating to promotional, internal and commercial uses and licensing may be obtained from MPEG LA, L.L.C.

See <http://www.mpegla.com>. MPEG Layer-3 audio decoding technology licensed from Fraunhofer IIS and Thomson. Java, JavaScript and Java-based trademarks and logos are trademarks or registered trademarks of Sun Microsystems, Inc.

in the U.S. and other countries. End-user license agreement for Sun Java Platform, Micro Edition. 1. Restrictions: Software is confidential copyrighted information of Sun and title to all copies is retained by Sun and/or its licensors. Customer shall not modify, decompile, disassemble, decrypt, extract, or otherwise reverse engineer Software. Software may not be leased, assigned, or sublicensed, in whole or in part. 2. Export Regulations: Software including technical data, is subject to U.

S. export control laws, including the U.S. Export Administration Act and its associated regulations, and may be subject to export or import regulations in other countries. Customer agrees to comply strictly with all such regulations and acknowledges that it has the responsibility to obtain licenses to export, re-export, or import Software. Software may not be downloaded, or otherwise exported or re-exported (i) into, or to a national or resident of, Cuba, Iraq, Iran, North Korea, Libya, Sudan, Syria (as such listing may be revised from time to time) or any country to which the U.S. has embargoed goods; or (ii) to anyone on the U.S. Treasury Department's list of Specially Designated Nations or the U.

S. Commerce Department's Table of Denial Orders. 3. Restricted rights: Use, duplication or disclosure by the United States government is subject to the restrictions as set forth in the Rights in Technical Data and Computer Software Clauses in DFARS 252.



[You're reading an excerpt. Click here to read official SONY ERICSSON C510 user guide](http://yourpdfguides.com/dref/2712647)  
<http://yourpdfguides.com/dref/2712647>

227-19(c) (2) as applicable. Restricted Rights: Use, duplication or disclosure by the United States government is subject to the restrictions as set forth in the Rights in Technical Data and Computer Software Clauses in DFARS 4 This is an Internet version of this publication. © Print only for private use.

227-19(c) (2) as applicable. Other product and company names mentioned herein may be the trademarks of their respective owners. Any rights not expressly granted herein are reserved. All illustrations are for illustration only and may not accurately depict the actual phone. Instruction symbols These symbols may appear in the User guide. Note Tip Warning A service or function is network- or subscription-dependent. Contact your network operator for details. > Use a selection or navigation key to scroll and select. See Navigation on page 14. 5 This is an Internet version of this publication.

© Print only for private use. Getting started Assembly Before you start using your phone, you need to insert a SIM card and the battery. To insert to overview PlayNow™ Cyber-shot™ Alarms Calls\*\* All Answered Dialed Missed Applications Video call Calendar Tasks Notes Synchronisation Timer Stopwatch Calculator Code memo Radio Settings\*\* General Profiles Time & date Language Update service Voice control New events Shortcuts Flight mode Security Setup wizard Accessibility\* Phone status Master reset Sounds & alerts Ring volume Ringtone Silent mode Increasing ring Vibrating alert Message alert Key sound Display Wallpaper Main menu layout Theme Startup screen Screen saver Entertainment Online services\* TrackID™ Location services Games VideoDJ™ PhotoDJ™ MusicDJ™ Remote control Record sound Demo tour Internet Messaging Write new Inbox/Conversations\* Messages Email IM\* Call voicemail Media Photo Music Video Games Web feeds Settings Contacts Myself New contact Organiser File manager \*\* 12 Getting started This is an Internet version of this publication. © Print only for private use. Clock size Brightness Edit line names\* Calls Speed dial Smart search Divert calls Switch to line 2\* Manage calls Time & cost\* Show/hide my no. Handsfree Connectivity Bluetooth USB Phone name Synchronisation Device management Mobile networks Data communication\* Internet settings Streaming settings Message settings\* SIP settings Accessories \* Some menus are operator-, network- and subscription-dependent. \*\* You can use the navigation key to scroll between tabs in submenus. For more information, see Navigation on page 14. Getting started This is an Internet version of this publication. © Print only for private use.

13 Navigation To navigate the phone menus To return to standby · Press . To navigate your media 1 From standby select Menu > Media. 2 Scroll to a menu item and press the navigation key right. 3 To go back, press the navigation key left. To delete items · Press to delete items such as numbers, letters, pictures and sounds.

13 Tabs Tabs may be available. For example, Settings have tabs. 1 From standby select Menu. 2 Use the navigation key to move through the menus. To select actions on the screen · Press the left, centre or right selection key.

To view options for an item · Select Options to, for example, edit. To end a function · Press . To scroll between tabs · Press the navigation key left or right. Shortcuts You can use keypad shortcuts to go directly to functions. To use navigation key shortcuts · From standby press , , or go directly to a function. to 14 Getting started This is an Internet version of this publication. © Print only for private use. To edit a navigation key shortcut 1 From standby select Menu > Settings > the General tab > Shortcuts. 2 Scroll to an option and select Edit. 3 Scroll to a menu option and select Shortc.

. Main menu shortcuts Menu numbering starts from the top left icon and moves across and ttable lens cover. To take a photo 1 Activate the camera and press the navigation key to scroll to . 2 Press halfway down to use auto focus. 3 When the dot and focus frame are green, press fully down to take a 18 Cyber-shot™ This is an Internet version of this publication. © Print only for private use. photo. The photo is automatically saved. To record a video clip 1 Activate the camera and press the navigation key to scroll to . 2 Press fully down to start recording.

3 To stop recording, press fully down. The video clip is automatically saved. To use zoom · Press the volume key. To adjust brightness · Press the navigation key. The amount .

of brightness is shown beside the To view photos 1 Activate the camera and press the navigation key to scroll to . 2 Scroll through the photos. To view video clips 1 Activate the camera and press the navigation key to scroll to . 2 Scroll to a video clip and press the centre selection key. More camera features To change settings · Activate the camera and select .

To view information about settings · Scroll to a setting and select . To improve a photo with Photo fix 1 Activate the camera and press the navigation key to scroll to . 2 Make sure Review is set to On. Select > Settings and scroll to Review > On. 3 Take a photo. 4 During review, select Options > Photo fix. Face detection You can use face detection to bring an off-centre face into focus. The camera automatically detects up to three faces, indicated by white frames. A green frame shows which face has been selected when auto-focus is used. Focus is set to the face closest to the camera.

To set face detection 1 Activate the camera and press the navigation key to scroll to . 2 Select > Focus > Face detection. Cyber-shot™ 19 This is an Internet version of this publication. © Print only for private use. Smile Shutter™ Smile Shutter allows you to capture the smiles of family and friends. The camera detects up to three faces and selects one face for smile detection and auto focus. A yellow frame shows which face is selected. When the selected face smiles, the camera automatically takes a photo. To set Smile Shutter™ 1 Activate the camera and press the navigation key to scroll to . 2 Select > Shoot mode > Smile Shutter™.

3 When appears, the camera is in Smile Shutter mode. 1 2 3 4 To use Smile Shutter™ Activate the camera and press the navigation key to scroll to . When you see the yellow frame, press the camera key fully down. When appears, smile detection is activated. The camera automatically takes the photo when the subject smiles.

To take a photo although no smile is detected, press the camera key fully down again. Viewing and tagging photos To view photos in a slide show 1 From standby select Menu > Media > Photo > Camera album. 2 Select a month. 3 Scroll to a photo and select View. 4 Select Options > Slide show. 5 Select a mood. Viewing photos on a map When appears on the screen, your geographical position is saved with the photos you take.



[You're reading an excerpt. Click here to read official SONY ERICSSON C510 user guide](http://yourpdfguides.com/dref/2712647)  
<http://yourpdfguides.com/dref/2712647>

This is called geo tagging, and it shows the approximate location of where a photo was taken. To view photos on a map 1 From standby select Menu > Media > Photo > Camera album. 2 Select a month. 3 Scroll to a photo and select View. 4 Select Options > View on map. To change the geo tagging setting 1 Activate the camera and press the navigation key to scroll to . 2 Select > Settings > Add position. 3 Select an option.

20 Cyber-shot™ This is an Internet version of this publication. © Print only for private use. Photo tags You can tag photos to categorise them in Photo tags. For example, you can create a tag called vacation and add it to all your vacation photos. To create a new photo tag 1 From standby select Menu > Media > Photo > Camera album. 2 Select a month. 3 Scroll to a photo and select View. 4 Press and select Options > New tag. 5 Enter a name and select OK. 6 Select an icon.

7 To tag the photo, select Options > Tag this photo. To tag photos 1 From standby select Menu > Media > Photo > Camera album. 2 Select a month. 3 Scroll to a photo and select View. 4 Press and scroll to a tag.

5 Select Options > Tag this photo. 6 For each photo you want to tag, scroll to the photo and select Options > Tag this photo. Using photos You can add a photo to a contact, use it during phone startup, as a wallpaper in standby or as a screen saver. To use photos 1 From standby select Menu > Media > Photo > Camera album. 2 Select a month.

3 Scroll to a photo and select View. 4 Select Options > Use as. 5 Select an option. To set a Java™ application as a wallpaper 1 From standby select Menu > Settings > the Display tab. 2 Select Wallpaper > Application. 3 Select a Java application. You can only see the Java applications that have support for wallpaper. Working with photos You can view, enhance and organise your photos and video clips on your computer by installing the Adobe™ Photoshop™ Album Starter Edition. It is included on the CD that comes with your phone and available for download at [www.sonyericsson.com/support](http://www.sonyericsson.com/support).

@ For more information, see Transferring content to and from a computer on page 25. Cyber-shot™ This is an Internet version of this publication. © Print only for private use. 21 PhotoDJ™ and VideoDJ™ You can edit photos and video clips. 1 2 3 4 5 To edit and save a photo From standby select Menu > Media > Photo > Camera album. Select a month. Scroll to a photo and select View. Select Options > Edit in PhotoDJ™. Edit the photo.

Blogging A blog is a personal Web page. If your subscription supports this service, you can send photos or video clips to a blog. If you cannot use blogging, see I cannot use Internet-based services on page 63. Web services may require a separate license agreement between you and the service provider. Additional regulations and charges may apply.

Contact your service provider. To edit and save a video clip 1 From standby select Menu > Organiser > File manager > Videos. 2 Scroll to a video clip and select Options > Edit in VideoDJ™. 3 Edit the video clip. 4 Select Options > Save.

To trim a video clip 1 From standby select Menu > Organiser > File manager > Videos. 2 Scroll to a video clip and select Options > Edit in VideoDJ™ > Edit > Trim. 3 Select OK > Set > Start to set the starting point. 4 Select Set > End to set the ending point. 5 Select Trim > Options > Save. To send photos to an existing blog 1 From standby select Menu > Media > Photo > Camera album. 2 Select a month. 3 Scroll to a photo and select View. 4 Select Options > Send > To Web site > New Web site > Add. 5 Enter the blog address and select OK.

6 Enter the address and title. 7 Select Save and select the blog. 8 Enter the text. 9 Select Continue > Send. To send photos to Blogger 1 From standby select Menu > Media > Photo > Camera album. 2 Select a month. 3 Scroll to a photo and select View. 4 Select Options > Send > To Web site. 22 Cyber-shot™ This is an Internet version of this publication. © Print only for private use.

5 Select Blogger. 6 Enter a title and text and select OK > Publish. To send photos or videos you have just taken to a blog When you have taken a photo, select Send > To Web site. Select New Web site > Add. Enter the email address account used for sending to your blog.

Enter the Web address and title. Select Save and select the blog. Enter the text. Select Continue > Send. 3 Select Options > Send > To Web site. 4 Select Blogger. 5 Enter a title and text and select OK > Publish. To go to a blog address from contacts 1 From standby select Menu > Contacts. 2 Scroll to a contact and select Open. 3 Scroll to a Web address and select Go to. 1 2 3 4 5 6 7 Printing photos You can print photos using the USB cable connected to a compatible printer. You can also print using a Bluetooth compatible printer that supports the Object Push Profile. To send video clips to an existing blog 1 From standby select Menu > Media > Video > Videos. 2 Select Options > Send > To Web site. 3 Select New Web site > Add.

4 Enter the email address account used for sending to your blog. 5 Enter the Web address and title. 6 Select Save and select the blog. 7 Enter the text. 8 Select Continue > Send. 9 Enter the text. To send video clips to Blogger 1 From standby select Menu > Media > Video > Videos. 2 Scroll to a video clip. To print photos using a USB cable 1 Connect a USB cable to the phone. 2 Connect the USB cable to the printer.

3 Wait for feedback in the phone and select OK. 4 Enter printer settings (if required) and select Print. 5 From standby select Menu > Media > Photo > Camera album. 6 Select a month. Cyber-shot™ This is an Internet version of this publication.

© Print only for private use. 23 7 Scroll to a photo and select Options > Print. You should disconnect and re-connect the USB cable if there is a printer error. Transferring and handling content You can transfer and handle content such as pictures and music. You are not allowed to exchange some copyright-protected material.

identifies a protected item. Handling content in the phone You can use File manager to handle content saved in the phone memory or on a memory card. Tabs and icons in File manager show where the content is saved. If the memory is full, delete some content to create space. To view memory status 1 From standby select Menu > Organiser > File manager. 2 Select Options > Memory status. 3 Select Memory card or Phone. To select more than one item in a folder From standby select Menu > Organiser > File manager. Scroll to a folder and select Open. Select Options > Mark > Mark several.

For each item you want to mark, scroll to the item and select Mark. 1 2 3 4 24 Transferring and handling content This is an Internet version of this publication. © Print only for private use. 1 2 3 4 5 To move items between the phone memory and the memory card From standby select Menu > Organiser > File manager.



[You're reading an excerpt. Click here to read official SONY ERICSSON C510 user guide](http://yourpdfguides.com/dref/2712647)  
<http://yourpdfguides.com/dref/2712647>



Find an item and select Options > Manage file > Move. Select Memory card or Phone. Scroll to a folder and select Open. Select Paste. Transferring content to and from a computer You can use Sony Ericsson Media Manager to transfer content between your phone and a computer. Sony Ericsson Media Manager software is included on the CD that comes with your phone and available for download at [www.sonyericsson.com/support](http://www.sonyericsson.com/support). To view information about content 1 From standby select Menu > Organiser > File manager. 2 Find an item and select Options >

Information. When you move or copy content from a computer to your phone unrecognised content is saved in the Other folder in File manager. Required operating systems You need one of these operating systems to use the software included on the CD: · Microsoft® Windows Vista™ (32 bit and 64 bit versions of: Ultimate, Enterprise, Business, Home Premium, Home Basic) · Microsoft® Windows XP (Pro or Home), Service Pack 2 or higher To install Sony Ericsson Media Manager 1 Turn on your computer and insert the CD. The CD starts automatically and the installation window opens. 2 Select a language and click OK. Transferring and handling content 25 Sending content to another phone You can send content, for example, in messages or using Bluetooth™ wireless technology. To send content 1 Scroll to an item and select Options > Send.

2 Select a transfer method. Make sure the receiving device supports the transfer method you select. This is an Internet version of this publication. © Print only for private use. 3 Click Install Sony Ericsson Media Manager and follow the instructions. To transfer content using Sony Ericsson Media Manager Connect the phone to a computer with a USB cable supported by your phone. Computer: Start/Programs/Sony Ericsson/Sony Ericsson Media Manager. Phone: Select Media transfer. Computer: Select Portable device and click OK. Wait until the phone appears in Sony Ericsson Media Manager.

Move files between your phone and the computer in Sony Ericsson Media Manager. Do not remove the USB cable from your phone or computer during transfer, as this may corrupt the memory card or the phone memory. For details on transferring music, click in the top right corner of the Sony Ericsson Media Manager window. [www.sonyericsson.com/support](http://www.sonyericsson.com/support) to read Feature guides. 1 2 3 4 5 6 Before using the USB cable See Required operating systems on page 25. Only use a USB cable supported by your phone. Do not remove the USB cable from your phone or computer during transfer as this may corrupt the memory card or the phone memory. Using the USB cable You can connect your phone to a computer with the USB cable to synchronise, transfer and back up phone content and use your phone as a modem.

For more information, go to 26 Transferring and handling content To disconnect the USB cable safely 1 Computer: Close any software that you are using with your phone. 2 Disconnect the USB cable. This is an Internet version of this publication. © Print only for private use. Drag and drop content You can drag and drop content between your phone, a memory card and a computer in Microsoft Windows Explorer. To drag and drop content 1 Connect your phone to a computer using the USB cable. 2 Phone: Select Media transfer. The phone will remain activated during file transfer. 3 Computer: Wait until the phone memory and memory card appear as external disks in Windows Explorer. 4 Drag and drop selected files between the phone and the computer.

Using Bluetooth™ wireless technology The Bluetooth function makes wireless connection to other Bluetooth devices possible. You can, for example: · Connect to handsfree devices. · Connect to several devices at the same time. · Connect to computers and access the Internet. · Exchange items. · Play multiplayer games. A range within 10 metres (33 feet), with no solid objects in between, is recommended for Bluetooth communication. Phone name You can enter a name for your phone that is shown to other devices when using, for example, Bluetooth™ wireless technology. To enter a phone name 1 From standby select Menu > Settings > the Connectivity tab > Phone name. 2 Enter the phone name and select OK.

Before using Bluetooth wireless technology You must turn on the Bluetooth function to communicate with other devices. You may also have to pair your phone with other Bluetooth devices. To turn on the Bluetooth function · From standby select Menu > Settings > the Connectivity tab > Bluetooth > Turn on. Make sure that the device you want to pair your phone with has the Bluetooth Transferring and handling content This is an Internet version of this publication. © Print only for private use. 27 function activated and Bluetooth visibility turned on. To pair the phone with a device 1 From standby select Menu > Settings > the Connectivity tab > Bluetooth > My devices. 2 Scroll to New device and select Add to search for available devices. 3 Select a device. 4 Enter a passcode, if required.

1 2 3 4 To allow connection to the phone From standby select Menu > Settings > the Connectivity tab > Bluetooth > My devices. Select a device from the list. Select Options > Allow connection. Select Always ask or Always allow. This is only possible with devices that require access to a secure service. mode you can only connect with a single Bluetooth device. If you want to connect with more than one Bluetooth device at the same time you must turn this function off. To turn on powersave · From standby select Menu > Settings > the Connectivity tab > Bluetooth > Power save > On. Transferring sound to and from a Bluetooth handsfree You can transfer the sound to and from a Bluetooth handsfree using a phone key or the handsfree key. To transfer sound 1 From standby select Menu > Settings > the Connectivity tab > Bluetooth > Handsfree > Incoming call.

2 Select an option. In phone transfers sound to the phone. In handsfree transfers sound to the handsfree. To transfer sound during a call 1 During a call, select Sound. 2 Select from the list. To pair the phone with a Bluetooth handsfree for the first time 1 From standby select Menu > Settings > the Connectivity tab > Bluetooth > Handsfree. 2 Scroll to a device and select Yes. 3 Enter a passcode, if required. Power saving You can save battery power with the Power save function. In Power save 28 Transferring and handling content Backing up and restoring You can backup and restore contacts, the calendar, tasks, notes and bookmarks using the Sony Ericsson PC This is an Internet version of this publication.

© Print only for private use. Suite. You can backup and restore content such as music, pictures and video clips using the Sony Ericsson Media Manager Before backing up and restoring, you need to install the Sony Ericsson PC Suite and the Sony Ericsson Media Manager.



[You're reading an excerpt. Click here to read official SONY](http://yourpdfguides.com/dref/2712647)

[ERICSSON C510 user guide](http://yourpdfguides.com/dref/2712647)

<http://yourpdfguides.com/dref/2712647>



You can backup and restore contacts within your phone using a Memory Stick Micro™ (M2™) memory card. You can move content between the memory card and the phone memory. See *Handling content in the phone* on page 24. Back up your phone content regularly to make sure you do not lose it. To restore phone content using the Sony Ericsson PC Suite The Sony Ericsson PC Suite will overwrite all the phone content during the restore process. You may damage your phone if you interrupt the process. 1 Computer: Start the Sony Ericsson PC Suite from Start/Programs/ Sony Ericsson/Sony Ericsson PC Suite. 2 Follow the instructions in the Sony Ericsson PC Suite for how to connect. 3 Phone: Select Phone mode. 4 Computer: Go to the backup and restore section in the Sony Ericsson PC Suite and restore your phone. To make a backup using the Sony Ericsson Media Manager Connect your phone to the computer using a USB cable. Phone: Select Media transfer mode.

Computer: Start Sony Ericsson Media Manager from Start/Programs/ Sony Ericsson/Sony Ericsson Media Manager. Go to the backup section in the Sony Ericsson Media Manager. 1 2 3 4 To make a backup using the Sony Ericsson PC Suite Computer: Start the Sony Ericsson PC Suite from Start/Programs/ Sony Ericsson/Sony Ericsson PC Suite. Follow the instructions in the Sony Ericsson PC Suite for how to connect. Phone: Select Phone mode. Computer: Go to the backup and restore section in the Sony Ericsson PC Suite and make a backup. 1 2 3 4 Transferring and handling content This is an Internet version of this publication. © Print only for private use. 29 5 Select the files you want to back up and make a backup. You can also connect your phone to a computer using Bluetooth. Calling Making and receiving calls You need to turn on your phone and be within range of a network. To make a call 1 From standby enter a phone number (with international country code and area code, if applicable). 2 Press . You can call numbers from your contacts and call list. See *Contacts* on page 32, and *Call list* on page 32.

You can also use your voice to make calls. See *Voice control* on page 36. To restore phone content using the Sony Ericsson Media Manager The Sony Ericsson Media Manager will compare your phone content with your computer backup and then restore files missing in your phone. You may damage your phone if you interrupt the process. 1 Connect your phone to the computer. 2 Phone: Select Media transfer mode. 3 Computer: Start Sony Ericsson Media Manager from Start/Programs/ Sony Ericsson/Sony Ericsson Media Manager. 4 Go to the backup section in the Sony Ericsson Media Manager. 5 Select the files you want to restore and restore them. For more information on backing up and restoring in Sony Ericsson Media Manager see the Sony Ericsson Media Manager Feature guide at [www.sonyericsson.com/support](http://www.sonyericsson.com/support). To end a call · Press . To make international calls 1 From standby press and hold down until a "+" sign appears. 2 Enter the country code, area code (without the first zero) and phone number.

3 Press . 30 Calling This is an Internet version of this publication. © Print only for private use. To re-dial a number · When Retry? appears select Yes. Do not hold your phone to your ear when waiting.

When the call connects, your phone gives a loud signal. To answer a call · Press . To reject a call · Press . To change the ear speaker volume during a call · Press the volume key up or down. To mute the microphone during a call 1 Press and hold down . 2 Press and hold down again to resume. To turn on the loudspeaker during a call · Press SpkrOn. Do not hold your phone to your ear when using the loudspeaker. This could damage your hearing. Networks Your phone switches automatically between GSM and 3G (UMTS) networks depending on availability.

Some network operators allow you to switch networks manually. To switch networks manually 1 From standby select Menu > Settings > the Connectivity tab > Mobile networks > GSM/3G networks. 2 Select an option. Emergency calls Your phone supports international emergency numbers, for example, 112 or 911. You can normally use these numbers to make emergency calls in any country, with or without the SIM card inserted, if you are within range of a network. In some countries, other emergency numbers may also be promoted. Your network operator may therefore have saved additional local emergency numbers on the SIM card. To view missed calls from standby · Press to open the call list. To make an emergency call · From standby enter 112 (the international emergency number) and press . Calling This is an Internet version of this publication.

© Print only for private use. 31 To view your local emergency numbers 1 From standby select Menu > Contacts. 2 Scroll to New contact and select Options > Special numbers > Emergency nos.. Video call You can share experiences with friends and family as they happen or save them to share later.

You see the person you are talking to on your screen. The other person sees you or what is on your camera. Before making video calls 3G (UMTS) service is available when appears. To make a video call, both parties on the call must have a 3G (UMTS) phone subscription that supports 3G (UMTS) service and 3G (UMTS) coverage. To make a video call 1 From standby enter a phone number (with international country code and area code, if applicable).

2 Select Options > Make video call. To use the zoom with an outgoing video call · Press or . 32 Calling To view video call options · During the call, select Options. Call list You can view information about recent calls. To call a number from the call list 1 From standby press and scroll to a tab. 2 Scroll to a name or a number and press . Contacts You can save names, phone numbers and personal information in Contacts. Information can be saved in the phone memory or on the SIM card. You can synchronise your contacts using the Sony Ericsson PC Suite. Default contacts You can choose which contact information is shown as default.

If Phone contacts is selected as default, your contacts show all the information saved in Contacts. If you select SIM contacts as default, your contacts show names and numbers saved on the SIM card. This is an Internet version of this publication. © Print only for private use. To select default contacts 1 From standby select Menu > Contacts. 2 Scroll to New contact and select Options > Advanced > Default contacts. 3 Select an option. Phone contacts Phone contacts can contain names, phone numbers and personal information. They are saved in the phone memory. To add a phone contact From standby select Menu > Contacts.

Scroll to New contact and select Add. Enter the name and select OK. Scroll to New number: and select Add. Enter the number and select OK. Select a number option.

Scroll between the tabs and add information to the fields. 8 Select Save. 1 2 3 4 5 6 7 Calling contacts To call a contact 1 From standby select Menu > Contacts.



[You're reading an excerpt. Click here to read official SONY](http://yourpdfguides.com/dref/2712647)

[ERICSSON C510 user guide](http://yourpdfguides.com/dref/2712647)

<http://yourpdfguides.com/dref/2712647>

2 Scroll to a contact and press . To go directly to the contacts list · From standby press and hold down .

To call with Smart search 1 From standby press to enter a sequence of (at least two) digits. All entries which match the sequence of digits or corresponding letters are shown in a list. 2 Scroll to a contact or a phone number and press . To turn on or off Smart search 1 From standby select Menu > Settings > the Calls tab > Smart search. 2 Select an option. Editing contacts To add information to a phone contact From standby select Menu > Contacts. Scroll to a contact and select Options > Edit contact. Scroll between the tabs and select Add or Edit. Select an option and an item to add or edit. Select Save.

If your subscription supports Calling Line Identification (CLI) service, you can assign personal ringtones and pictures to contacts. 1 2 3 4 5 Calling This is an Internet version of this publication. © Print only for private use. 33 To copy names and numbers to phone contacts 1 From standby select Menu > Contacts. 2 Scroll to New contact and select Options > Advanced > Copy from SIM. 3 Select an option. To copy names and numbers to the SIM card 1 From standby select Menu > Contacts. 2 Scroll to New contact and select Options > Advanced > Copy to SIM. 3 Select an option. When you copy all contacts from your phone to the SIM card, all existing SIM card information is replaced.

SIM contacts SIM contacts can contain names and numbers only. They are saved on the SIM card. To add a SIM contact From standby select Menu > Contacts. Scroll to New contact and select Add. Enter the name and select OK.

Enter the number and select OK. Select a number option and add more information, if available. 6 Select Save. 1 2 3 4 5 Deleting contacts To delete all contacts 1 From standby select Menu > Contacts. 2 Scroll to New contact and select Options > Advanced > Delete all contacts.

3 Select an option. Contact memory status The number of contacts you can save in your phone or on the SIM card depends on available memory. To view contact memory status 1 From standby select Menu > Contacts. 2 Scroll to New contact and select Options > Advanced > Memory status. To automatically save names and phone numbers on the SIM card 1 From standby select Menu > Contacts. 2 Scroll to New contact and select Options > Advanced > Auto save on SIM. 3 Select an option. To save contacts on a memory card 1 From standby select Menu > Contacts. 2 Scroll to New contact and select Options > Advanced > Back up to m. card.

34 Calling This is an Internet version of this publication. © Print only for private use. Myself You can enter information about yourself and, for example, send your business card. To enter Myself information 1 From standby select Menu > Contacts. 2 Scroll to Myself and select Open. 3 Scroll to an option and edit the information. 4 Select Save. 1 2 3 4 5 To add your own business card From standby select Menu > Contacts. Scroll to Myself and select Open. Scroll to My contact info and select Add > Create new.

Scroll between the tabs and add information to the fields. Enter the information and select Save. Groups You can create a group of phone numbers and email addresses from Phone contacts to send messages to. See Messaging on page 40. You can also use groups (with phone numbers) when you create accepted callers lists.

See Accept calls on page 38. To create a group of numbers and email addresses 1 From standby select Menu > Contacts. 2 Scroll to New contact and select Options > Groups. 3 Scroll to New group and select Add. 4 Enter a name for the group and select Continue.

5 Scroll to New and select Add. 6 For each contact phone number or email address you want to mark, scroll to it and select Mark. 7 Select Continue > Done.

Speed dial Speed dialling lets you select nine contacts that you can dial quickly. The contacts can be saved in positions 1-9. To add contacts to speed dial numbers From standby select Menu > Contacts. Scroll to New contact and select Options > Speed dial. Scroll to a position number and select Add. Select a contact. 1 2 3 4 To speed dial · From standby enter the position number and press .

Calling This is an Internet version of this publication. © Print only for private use. 35 More calling features Voicemail If your subscription includes an answering service, callers can leave a voicemail message when you cannot answer a call. To enter your voicemail number 1 From standby select Menu > Messaging > Messages > Settings > the Message settings tab > Voicemail number. 2 Enter the number and select OK. To call your voicemail service · From standby press and hold down . Voice control By creating voice commands you can: · Voice dial call someone by saying their name · Answer and reject calls when you use a handsfree To record a voice command using voice dialling 1 From standby select Menu > Settings > the General tab > Voice control > Voice dialling > Activate. 2 Select Yes > New voice command and select a contact. If the contact has more than one number, select the number to add the voice command to. 3 Record a voice command such as "John mobile."

" 4 Follow the instructions that appear. Wait for the tone and say the command to record. The voice command is played back to you. 5 If the recording sounds OK, select Yes. If not, select No and repeat steps 3 and 4.

Voice commands are saved in the phone memory only. They cannot be used in another phone. To voice dial 1 From standby press and hold down a volume key. 2 Wait for the tone and say a recorded name, for example "John mobile." The phone plays the name back to you and connects the call.

Diverting calls You can divert calls, for example, to an answering service. When Restrict calls is used, some divert call options are not available. See Restricted dialling on page 38. 36 Calling This is an Internet version of this publication. © Print only for private use. To divert calls 1 From standby select Menu > Settings > the Calls tab > Divert calls. 2 Select a call type and a divert option. 3 Select Activate. 4 Enter the number to divert calls to and select OK.

More than one call You can handle more than one call at a time.

For example, you can put an ongoing call on hold, while you make or answer a second call. You can also switch between the two calls. You cannot answer a third call without ending one of the first two calls. Call waiting You will hear a beep if you receive a second call while call waiting is active. To activate call waiting · From standby select Menu > Settings > the Calls tab > Manage calls > Call waiting > Activate. To make a second call 1 During the call, press . This puts the ongoing call on hold. 2 Select Options > Add call. 3 Enter the number to call and press . To answer a second call · During the call, press .



[You're reading an excerpt. Click here to read official SONY ERICSSON C510 user guide](http://yourpdfguides.com/dref/2712647)  
<http://yourpdfguides.com/dref/2712647>

*This puts the ongoing call on hold. To reject a second call · During the call, press and continue with the ongoing call. To end an ongoing call and answer a second call · During the call, select Replace active call. Handling two voice calls You can have calls ongoing and on hold at the same time. To switch between two calls · During the call, press .*

*To join two calls · During the call, select Options > Join calls. To connect two calls · During the call, select Options > Transfer call. You are disconnected from both calls. To end an ongoing call and return to the call on hold · First press and then . Calling This is an Internet version of this publication.*

*© Print only for private use. 37 Conference calls With a conference call, you can have a joint conversation with up to five people. To add a new participant 1 During the call, press . This puts the joined calls on hold. 2 Select Options > Add call. 3 Enter the number to call and press . 4 Select Options > Join calls to add the new participant. 5 Repeat this task to add more participants. To release a participant 1 Select Options > Release party. 2 Select the participant to release.*

*To have a private conversation 1 During the call, select Options > Talk to and select the participant to talk to. 2 To resume the conference call, select Options > Join calls. My numbers You can view, add and edit your own phone numbers. To check your phone numbers 1 From standby select Menu > Contacts. 38 Calling 2 Scroll to New contact and select Options > Special numbers > My numbers. 3 Select an option. Accept calls You can choose to receive calls from certain phone numbers only. To add numbers to the accepted callers list 1 From standby select Menu > Settings > the Calls tab > Manage calls > Accept calls > Only from list. 2 Scroll to New and select Add. 3 Select a contact or Groups.*

*See Groups on page 35. To accept all calls · From standby select Menu > Settings > the Calls tab > Manage calls > Accept calls > All callers. Restricted dialling You can restrict outgoing and incoming calls. A password from your service provider is required. If you divert incoming calls, you cannot use some restrict calls options.*

*Restrict calls options Standard options are: This is an Internet version of this publication. © Print only for private use. · All outgoing all outgoing calls · Outgoing intl all outgoing international calls · Outgoing intl roam. all outgoing international calls except to your home country · All incoming all incoming calls · Inc. when roaming all incoming calls when you are abroad To restrict calls 1 From standby select Menu > Settings > the Calls tab > Manage calls > Restrict calls.*

*2 Select an option. 3 Select Activate. 4 Enter your password and select OK. Call time and cost During a call, the phone shows how long you have been talking. You can also check on the duration of your last call, your outgoing calls and the total time of all your calls. To check the call time · From standby select Menu > Settings > the Calls tab > Time & cost > Call timers. Showing or hiding your phone number You can decide to show or hide your phone number when you make a call. To hide your phone number 1 From standby select Menu > Settings > the Calls tab > Show/hide my no.. 2 Select Hide number.*

*Calling This is an Internet version of this publication. © Print only for private use. 39 Messaging Text and picture messages Messages can contain text, pictures, sound effects, animations, and melodies. You can also create and use templates for your messages. When sending messages, the phone automatically selects the most suitable method (as a text or picture message) for sending the message. If you cannot use picture messages, see 1 cannot use Internet-based services on page 63. Sending messages You can send messages from your phone. To create and send a message 1 From standby select Menu > Messaging > Write new > Message. 2 Enter text. To add items to the message, press , scroll and select an item.*

*3 Select Continue > Contacts look-up. 4 Select a recipient and select Send. If you send a message to a group, you will be charged for each member. See Groups on page 35. To copy and paste text in a message 1 When you write the message, select Options > Copy & paste.*

*2 Select Copy all or Mark & copy. Scroll to and mark text in the message. 3 Select Options > Copy & paste > Paste. Receiving and saving messages You are notified when you receive a message. Messages are automatically saved in the phone memory.*

*When the phone memory is full, you can delete messages or save them on a memory card or on the SIM card. To save an incoming message on a memory card · From standby select Menu > Messaging > Messages > Settings > Save to > Memory card. To save a message on the SIM card 1 From standby select Menu > Messaging > Messages and select a folder. 2 Scroll to a message and select Options > Save message. To view a message from the inbox 1 From standby select Menu > Messaging > Inbox. 2 Scroll to the message and select View. 40 Messaging This is an Internet version of this publication. © Print only for private use. To call a number in a message · When you view the message, scroll to . the phone number and press Templates If you often use the same phrases and pictures in a message, you can save the message as a template.*

*To add a message template 1 From standby select Menu > Messaging > Messages > Templates > New template > Add. 2 Enter text. To add items to the message, press , scroll and select an item. 3 Select Save. 4 Enter a title and select OK. To save a message as a template 1 From standby select Menu > Messaging > Inbox. 2 Scroll to the message and select View > Options > Save as template. Message options You can set some options, such as the Message alert and default storage location, to apply to all messages. You can set other options, such as the Delivery priority and Delivery time, for each message you send. To set options for all messages 1 From standby select Menu > Messaging > Messages > Settings.*

*2 Scroll to an option and choose Select. To set options for a specific message 1 When the message is ready and a recipient is selected, select Options > Advanced. 2 Scroll to an option and select Edit. Voice messages You can send and receive a sound recording as a voice message. The sender and recipient must have a subscription supporting picture messaging.*

*To record and send a voice message 1 From standby select Menu > Messaging > Write new > Voice message. 2 Record the message and select Stop > Send > Contacts look-up. 3 Select a recipient and select Send. Messaging This is an Internet version of this publication. @@You can also receive settings at www.*



[You're reading an excerpt. Click here to read official SONY](http://yourpdfguides.com/dref/2712647)

[ERICSSON C510 user guide](http://yourpdfguides.com/dref/2712647)

<http://yourpdfguides.com/dref/2712647>

sonyericsson.com/support. @@@@Enter the email address and select OK. When you are ready, select Done. 5 Select Edit and enter a subject. Select OK. 6 Select Edit and enter the text. Select OK. 7 Select Add and choose a file to attach. 8 Select Continue > Send.

@@2 Scroll to the message and select View. @@@@2 Scroll to the message and select Options > Reply. 3 Write the reply and select OK. @@2 Select Add > Enter email address. Enter the email address and select OK. 3 To add more recipients, scroll to To: and select Edit. 42 Messaging This is an Internet version of this publication. @@@@2 Select an account. @@@@2 Scroll to a setting and select Add. @@@@2 Scroll to a contact and select Chat.

3 Write the message and select Send. @@@@To view my status 1 From standby select Menu > Messaging > IM. 2 You are the first contact listed. @@2 Scroll to your name and select Change. 3 Edit the information and select Save.

@@@2 Select Options > Add chat group > New chat group. 3 Select who to invite from your contacts list and select Continue. 4 Enter a short invitation text and select Continue > Send. @@@@2 Enter a conversation. @@@@2 Browse by category using the navigation key.

3 Scroll to a title and select Play. To stop playing music · Press the centre selection key. To fast forward and rewind · Press and hold down or · To move between tracks · Press or · To change the volume · Press the volume key up or down. To minimise the player · Select Options > Minimise. To return to the player · From standby select Menu > Media. Playlists You can create playlists to organise your music. You can add tracks to more than one playlist.

@@Music stops when you receive a call and resumes when the call has ended.

Music This is an Internet version of this publication. © Print only for private use. 45 the memory, just the reference to the track in that list. It may take a few minutes for the phone to create a playlist. To create a playlist 1 From standby select Menu > Media > Music > Playlists. 2 Scroll to New playlist and select Add. 3 Enter a name and select OK. 4 For each track you want to add, scroll to the track and select Mark. 5 Select Add to add the marked tracks to the playlist. Audio books You can listen to audio books you have transferred to your phone from a computer using Sony Ericsson Media Manager.

It may take a few minutes before a transferred audio book appears in the list of available audio books. Buy Now If you subscribe to a music service allowing limited, non-permanent use with your phone, you can mark a track you are interested in buying later. The next time you synchronise your music with Windows Media® Player on a computer with enabled Internet access, you should be asked if you want to buy the track you marked earlier. If you accept, the track is downloaded to your computer and your selected music service account is charged. This service requires a subscription and account with a downloadable music service, a computer with Microsoft® Windows Media® Player 11 or subsequent compatible version of Windows Media® Player, and a USB computer connection.

You cannot see that a track is marked. You cannot unmark tracks you have already marked. To access audio books · From standby select Menu > Media > Music > Audio books. You can find audio books in formats other than M4B and those that do not have ID3v2 chapter tags in the Tracks folder. To mark a track · When the track you want to mark is playing, press and hold down .

PlayNow™ You can connect to PlayNow™ to download ringtones, games, music, 46 Music This is an Internet version of this publication. © Print only for private use. themes and wallpapers. You can preview or listen to content before you purchase and download it to your phone. If you cannot use PlayNow™, see I cannot use Internet-based services on page 63. This service is not available in all countries. For best results, use TrackID™ in a quiet area. Online music and video clips You can view video clips and listen to music by streaming them to your phone from the Internet. If you cannot use the Internet, see I cannot use Internetbased services on page 63. To select a data account for streaming 1 From standby select Menu > Settings > the Connectivity tab > Streaming settings > Connect using:.

2 Select the data account to use. 3 Select Save. To stream music and video clips 1 From standby select Menu > Internet. 2 Select Options > Go to > Bookmarks. 3 Select a link to stream from. To use PlayNow™ 1 From standby select Menu > PlayNow™. 2 Scroll the PlayNow™ Web site and follow the instructions to preview and purchase content. TrackID™ TrackID™ is a music recognition service. You can search for title, artist and album name for a track you hear playing through a loudspeaker or on the radio. If you cannot use TrackID™, see I cannot use Internet-based services on page 63.

To search for track information · When you hear a track through a loudspeaker, from standby select Menu > Entertainment > TrackID™ > Start. · When the radio is playing select Options > TrackID™. Video player To play videos 1 From standby select Menu > Media > Video > Videos. 2 Scroll to a title and select Play. To stop playing videos · Press the centre selection key.

Music 47 This is an Internet version of this publication. © Print only for private use. Radio Do not use your phone as a radio in places where this is prohibited. 2 Select a radio channel. To switch between saved channels · Press or .

To turn on the radio 1 Connect a handsfree to the phone. 2 From standby select Menu > Radio. To search for channels automatically · Select Search. To search for channels manually · Press or . To change the volume · Press the volume key up or down. To minimise the radio · Select Options > Minimise. To return to the radio · From standby select Menu > Radio. Saving channels You can save up to 20 preset channels. To save channels 1 When you have found a radio channel, select Options > Save. 2 Scroll to a position and select Insert.

To select saved channels 1 Select Options > Channels. @@Prearranged sounds with different characteristics are available. @@2 Select to Insert, Copy or Paste sounds. 3 Use , , or to scroll between the sounds. @@@@2 Select Save to save the recording. @@2 Scroll to Music and select Open. @@To start browsing 1 From standby select Search. 2 Enter a Web address, a search phrase or the name of a bookmark. 3 Scroll to an item in the list and select Go to or Search. @@@@2 Enter a title and an address.

Select Save. To select a bookmark 1 From standby select Menu > Internet. 2 Select Options > Go to > Bookmarks. 3 Scroll to a bookmark and select Go to. Internet This is an Internet version of this publication.

@@@@To find text on a Web page 1 When you browse the Internet, select Options > Tools > Find on page.



[You're reading an excerpt. Click here to read official SONY](http://yourpdfguides.com/dref/2712647)

[ERICSSON C510 user guide](http://yourpdfguides.com/dref/2712647)

<http://yourpdfguides.com/dref/2712647>



2 Enter text and press Find. To send a link 1 When you browse the Internet, select Options > Tools > Send link. 2 Select a transfer method. Make sure the receiving device supports the transfer method you select.

More browser features To use pan and zoom on a Web page 1 When you browse the Internet, press . 2 Use the navigation key to move the frame. 3 Press Zoom. 4 To switch back to pan, press . To use pan and zoom, Smart-Fit must be turned off. Internet keypad shortcuts You can use the keypad to go directly to an Internet browser function. Key Shortcut Bookmarks Enter text to Enter address, Search Internet or search in Bookmarks Zoom Pan & zoom (when SmartFit is off) To turn on or off Smart-Fit Rendering™ 1 From standby select Menu > Internet > Options > Advanced > Smart-Fit. 2 Select an option. To make a call when you browse · Press . To save a picture from a Web page 1 When you browse the Internet, select Options > Tools > Save picture.

50 Internet This is an Internet version of this publication. © Print only for private use. To select Internet keypad shortcuts 1 From standby select Menu > Internet. 2 Select Options > Advanced > Keypad mode > Shortcuts. Internet security and certificates Your phone supports secure browsing. Certain Internet services, such as banking, require certificates in your phone. Your phone may already contain certificates when you buy it or you can download new certificates. To view certificates in the phone · From standby select Menu > Settings > the General tab > Security > Certificates. To search for Web feeds 1 From standby select Menu > Media > Web feeds. 2 Select New feed and enter a Web address.

To download content via Web feeds 1 From standby select Menu > Media > Web feeds. 2 Scroll to an updated feed and select . View or 3 Select a heading to expand. 4 Select an icon depending on content, to open a Web page, to download an audio podcast, to download a video podcast or to download a photo. You can also subscribe to and download content to a computer via feeds using Sony Ericsson Media Manager.

You can then transfer the content to your phone. Web feeds You can subscribe to and download frequently updated content, such as news, podcasts or photos, using Web feeds. To add new feeds for a Web page 1 When you browse a page on the Internet that has Web feeds, indicated by , select Options > Web feeds. 2 For each feed you want to add, scroll to the feed and select Mark. 3 Select Continue.

Updating Web feeds You can manually update your feeds, or schedule updates. When there are updates, appears on the screen. To schedule Web feed updates 1 From standby select Menu > Media > Web feeds. 2 Scroll to a feed and select Options > Schedule update. Internet 51 This is an Internet version of this publication. © Print only for private use. 3 Select an option. Frequent updates may be costly. To access video podcasts · From standby select Menu > Media > Video > Podcasts. Photo feeds You can subscribe to Photo feeds and download photos.

To start using Photo feeds, see Web feeds on page 51. To access photo feeds · From standby select Menu > Media > Photo > Photo feeds. Web feeds in standby You can show news updates on the standby screen. To show Web feeds in standby 1 From standby select Menu > Media > Web feeds. 2 Scroll to a feed and select Options > Settings > Standby ticker > Show in standby. To access Web feeds from standby 1 From standby select Ticker. 2 To read more about a feed, press or to scroll to a headline and select Go to. Podcasts Podcasts are files, for example, radio programmes or video content, that you can download and play. You subscribe to and download podcasts using Web feeds. To access audio podcasts · From standby select Menu > Media > Music > Podcasts.

52 Internet This is an Internet version of this publication. © Print only for private use. Synchronising You can synchronise in two different ways. You can synchronise your phone using a computer program or you can synchronise using an Internet service. Use only one of the synchronisation methods at a time with your phone.

To install the Sony Ericsson PC Suite 1 Turn on your computer and insert the CD. The CD starts automatically and the installation window opens. 2 Select a language and click OK. 3 Click Install Sony Ericsson PC suite and follow the instructions on the screen. To synchronise using the Sony Ericsson PC Suite Computer: Start Sony Ericsson PC Suite from Start/Programs/ Sony Ericsson/Sony Ericsson PC Suite.

Follow the instructions in the Sony Ericsson PC Suite for how to connect. Phone: Select Phone mode. Computer: When you are notified that the Sony Ericsson PC Suite has found your phone, you can start synchronising. For usage details, see the Sony Ericsson PC Suite Help section once the software has been installed on your computer. For more information, go to [www.sonyericsson.com/support](http://www.sonyericsson.com/support) to read the Synchronisation Feature guide. 1 Synchronising using a computer You can use the USB cable or Bluetooth wireless technology to synchronise phone contacts, appointments, bookmarks, tasks and notes with a computer program such as Microsoft Outlook®. Before synchronising, you need to install the Sony Ericsson PC Suite. Sony Ericsson PC Suite software is included on the CD with your phone and available for download at [www.sonyericsson.com/support](http://www.sonyericsson.com/support).

2 3 4 Synchronising using an Internet service You can synchronise with an Internet service using SyncML™ or a Microsoft® Exchange Server using Synchronising 53 See Required operating systems on page 25. This is an Internet version of this publication. © Print only for private use. Microsoft Exchange ActiveSync. For more information, go to [www.sonyericsson.com/support](http://www.sonyericsson.com/support) to read the Synchronisation Feature guide. More features Flight mode In Flight mode the network and radio transceivers are turned off to prevent disturbance to sensitive equipment.

When the flight mode menu is activated you are asked to select a mode the next time you turn on your phone: · Normal mode full functionality · Flight mode limited functionality To activate the flight mode menu · From standby select Menu > Settings > the General tab > Flight mode > Continue > Show at startup.

To select flight mode 1 When the flight mode menu is activated, turn off your phone. 2 Turn on your phone and select Flight mode. Update Service You can update your phone with the latest software using your phone or a PC. This service is not available in all countries/regions.

54 More features This is an Internet version of this publication. © Print only for private use. To view the current software in the phone 1 From standby select Menu > Settings > the General tab > Update service. 2 Select Software version. Update Service using the phone You can update your phone over the air using your phone.



[You're reading an excerpt. Click here to read official SONY ERICSSON C510 user guide](http://yourpdfguides.com/dref/2712647)  
<http://yourpdfguides.com/dref/2712647>