



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for THOMSON T1000S. You'll find the answers to all your questions on the THOMSON T1000S in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual THOMSON T1000S User guide THOMSON T1000S Operating instructions THOMSON T1000S Instructions for use THOMSON T1000S Instruction manual THOMSON T1000S

HOW TO USE YOUR TELSTRA T1000S TELEPHONE FEATURES

To turn on Call Waiting

Wait for the tone, press **Star**, **Call**, **Answer**.

This feature enables you to answer a second call while you are on the phone. When you are on a call and you hear two beeps:

1. Press **Star** to swap between callers.
2. Press **Star** to hang up one caller and return to the caller on hold.
3. Press **Star** to talk to both callers at the same time*.

To turn off Call Waiting

Wait for the tone, press **Star**, **Call**, **Answer**.

To make an enquiry call while you are on a call

This feature enables you to call someone while you are on a call.

During a call press **Star**, **Star**, **Star**, **Star**, **Star**.

To return to the first caller after the second person hangs up, press **Star** otherwise press **Star** to end the second call.

To have a 3-Way Chat²

This feature enables you to establish a 3-way conversation.

Wait for the tone, press **Star**, **Star**, **Star**, **Star**, **Star**, **Star**.

To end 3-Way Chat simply press **Star**.

To turn on Call Forward

This feature enables you to forward your calls to your mobile or another selected number.

Wait for the tone, press **Star**, **Star**, **Star**, **Star**, **Star**, **Star**.

To forward calls to a number stored in Memory

Wait for the tone, press **Star**, **Star**, **Star**, **Star**, **Star**, **Star**.

To turn off Call Forward

Wait for the tone, press **Star**, **Star**, **Star**, **Star**, **Star**, **Star**.

To use Call Return³

This enables you to check the number of your last unanswered call (*10#)

Wait for the tone, press **Star**, **Star**, **Star**, **Star**, **Star**, **Star**.

2. Applicable call costs and usage charges apply. Available most areas.

3. Applicable call costs apply for forwarded calls. Calls can be forwarded to most numbers in Australia.

4. Not available for blocked calls. Available most areas.

HOW TO USE YOUR TELSTRA T1000S TELEPHONE FEATURES

To use Call Back when a number is busy⁴

This feature enables you to arrange an automatic call back to a busy number.

When you hear busy tone, press **Star**, **Star**, **Star**, **Star**, **Star**.

To cancel Call Back

Wait for the tone, press **Star**, **Star**, **Star**, **Star**, **Star**.

Using Telstra Voice Assistant⁵

Wait for the tone, press **Star**, **Star**, **Star**, **Star**, **Star**.

Telstra Voice Assistant can help you activate and de-activate Telstra Phone Features, e.g. Call Waiting and Call Forward.

IMPORTANT SAFETY INSTRUCTIONS

For Your Safety

Do not use the telephone during an electrical storm as it is possible to get a shock. Refer to the Telstra White Pages⁶ directory for further information.

RENTAL TERMS AND CONDITIONS

Your rental telephone is subject to the terms and conditions set out in Part A - General of the Basic Telephone Service Section of Our Customer Terms, which is available for inspection at most Telstra shops or at www.telstra.com.au/customerterms/index.htm.

RENTAL TELEPHONE FAULTS

For any service difficulties and faults call **13 2203** for Residential or **13 2255** for Small Business customers or check the Telstra White Pages⁶ directory for further contact numbers.

CARE OF THE TELEPHONE

- Avoid hard knocks and do not drop the telephone.
- Keep the telephone away from heaters.
- Clean the telephone surface with a damp cloth. Do not use detergents or immerse the telephone in water.
- The performance of the telephone may be affected by electro-magnetic interference if placed near radio transmitters, diathermy machines, welding machines, etc.

5. Applicable call costs and usage charges apply. Available most areas.

6. Available to most customers who are directly billed by Telstra for access and local calls.

© COPYRIGHT Telstra Corporation Limited. This work is copyright. All rights reserved.

This document is subject to conditions prescribed under the Copyright Act.

⁶ Registered trade mark of Telstra Corporation Limited

⁷ Trade mark of Telstra Corporation Limited ABN 33 051 775 556.

0008 8-05



Telstra T1000S

Standard Rental Telephone

User Guide

To fully benefit from this Australian designed and manufactured telephone, please read the User Guide and keep handy for future reference.



[You're reading an excerpt. Click here to read official THOMSON T1000S user guide](http://yourpdfguides.com/dref/3820531)
<http://yourpdfguides.com/dref/3820531>

Manual abstract:

Press Wait to swap between callers. 2. Press to hang up one caller and return to the caller on hold. 3. Press 3-Way to talk to both callers at the same time. 2. @@ When you hear busy tone, press Call Back To cancel Call Back press Call Back Call Back Telstra T1000S Standard Rental Telephone Using Telstra Voice Assistant 6 press Telstra Voice Assistant can help you activate and de-activate Telstra Phone Features, e.g. Call Waiting and Call Forward. To turn off Call Waiting press Call Wait User Guide To fully benefit from this Australian designed and manufactured telephone, please read the User Guide and keep handy for future reference. To make an enquiry call while you are on a call This feature enables you to call someone while you are on a call. During a call press To return to the first caller after the second person hangs up, press otherwise press to end the second call. **IMPORTANT SAFETY INSTRUCTIONS For Your Safety** Do not use the telephone during an electrical storm as it is possible to get a shock. Refer to the Telstra White Pages® directory for further information. To have a 3-Way Chat 2 This feature enables you to establish a 3-way conversation. press 3-Way press 3-Way Chat Chat To end 3-Way Chat simply RENTAL TERMS AND CONDITIONS Your rental telephone is subject to the terms and conditions set out in Part A - General of the Basic Telephone Service Section of Our Customer Terms, which is available for inspection at most Telstra shops or at www.telstra.com.au/customerterms/index.htm. To turn on Call Forward 3 This feature enables you to forward your calls to your mobile or another selected number. Call Call press Fwd press Fwd RENTAL TELEPHONE FAULTS For any service difficulties and faults call 13 2203 for Residential or 13 2255 for Small Business customers or check the Telstra White Pages® directory for further contact numbers. To forward calls to a number stored in Memory press Call Fwd CARE OF THE TELEPHONE · Avoid hard knocks and do not drop the telephone. · Keep the telephone away from heaters. · Clean the telephone surface with a damp cloth. Do not use detergents or immerse the telephone in water. @@Applicable call costs and usage charges apply. Available most areas. 3. Applicable call costs apply for forwarded calls. Calls can be forwarded to most numbers in Australia.

4. Not available for blocked calls. Available most areas. 5. Applicable call costs and usage charges apply. Available most areas. 6. @@@@ COPYRIGHT Telstra Corporation Limited. This work is copyright. All rights reserved.

@@@@@ This ensures the telephone is powered up and will ring correctly. @@@@ Handset hook is set in position by rotating the dial. @@@@ Ringer and earpiece volume level. 2. Redial button used to easily redial the last number dialled.

3. Store button used to store numbers in one touch memories. This button is also used to adjust ringer volume. 4. @@5. 10 One Touch Memory buttons. 6. Double sided memory card, lift clear window. 7. One Touch phone feature buttons. 8. One Touch MessageBank button. 9. Recall button used to make an enquiry call. 10. Cancel button used to turn off phone features, e.g. Call Wait. Wall Mounting A wall-mounting bracket can be purchased separately from Telstra. The ringer has two levels, high and low. press then or Setting will be saved. Confirmation tone will stop at minimum or maximum setting. press Mesg and follow the MessageBank prompts. Bank You can store your PIN under the MessageBank Button press press press Mesg Bank Note: A PIN is not required for Telstra Home Messages 101. Adjusting the Ringer Volume when the telephone is ringing Press or while the phone is ringing. To retrieve a message from your message service when you have stored your PIN press Mesg Bank Wait for the password prompt, press Mesg and then follow the message service prompts. Bank Adjusting the Headset Earpiece Volume Setting press or Adjusts the handset earpiece volume to one of four levels. Confirmation tone will stop after min or max setting. Note: The earpiece volume will reset to normal when the handset is replaced. @@@@ Monthly charges may apply.



[You're reading an excerpt. Click here to read official THOMSON T1000S user guide](http://yourpdfguides.com/dref/3820531)
<http://yourpdfguides.com/dref/3820531>