



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for THOMSON V1600 SMS. You'll find the answers to all your questions on the THOMSON V1600 SMS in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual THOMSON V1600 SMS**  
**User guide THOMSON V1600 SMS**  
**Operating instructions THOMSON V1600 SMS**  
**Instructions for use THOMSON V1600 SMS**  
**Instruction manual THOMSON V1600 SMS**

Telstra V1600 SMS Colour Screen  
Digital DECT Cordless Telephone



User  
Guide



**IMPORTANT**

3G SIM cards are not compatible with this product. Do not attempt to download the phonebook from 3G SIM cards to your Telstra V1600. (See page 20 for further details or check with your mobile service provider if you are unsure). If you have any problems with your phone, firstly refer to the Help section of this User Guide or call Information line on 1300 302 699.



[You're reading an excerpt. Click here to read official THOMSON V1600 SMS user guide](http://yourpdfguides.com/dref/3820547)  
<http://yourpdfguides.com/dref/3820547>

### Manual abstract:

Monthly charges apply. @@Alternative arrangements should be made for access to emergency services. This User Guide provides you with all the information you need to get the most from your phone. Before you make your first call you will need to set up your phone. Follow the simple instructions in 'Getting Started', on the next few pages. Need help? If you have any problems setting up or using your Telstra V1600 please contact Product Information on 1300 302 699. Alternatively you may find the answer to 'Help' at the back of this guide. 3 In this guide 5 5 5 7 Dial a number from the phonebook Edit an entry View details Delete an entry Select ring tone Copy SIM card 17 18 18 18 19 20 Getting started Location Setting up Setting the day and time Getting to know your Telstra V1600 Handset buttons 8 Handset display icons 9 Navigating the menus 10 Menu map 11 Base 12 Using the phone Switch handset on/off Make a call Preparatory dialling End a call Receiving calls Earpiece volume Make a handsfree call Adjust handsfree volume Answer a call handsfree Redial a number from the Dialled Call list Secrecy (Mute) Keypad lock Paging Phonebook Add a new phonebook entry 13 13 13 13 13 13 14 14 14 15 15 15 16 17 17 Telstra phone features 21 Text Messaging Service 21 Service Centres 21 Terminal Number 22 SMS Alert 22 User Settings 23 Writing/sending messages 23 View received messages 24 Saving message 24 Edit saved message 25 Calling Line Identification and text messaging 25 Deleting a message 26 Deleting all messages 26 Calling Number Display 27 Call list 27 Opening the Call lists 28 Dial a number from the Call lists 28 Copy a number to the phonebook 29 Delete individual entries 29 Delete all entries in a Call list 30 In this guide Delete all entries in all Call list Flashing Message Indicator Telstra Call Waiting Telstra Home Message 101 Telstra Calling Features Handset settings Ringtone Ringer volume Handset name Handset language Menu colour Auto-talk Base settings Base ring tone Ringer volume Handset priority Recall mode Security PIN Set date and time Set alarm Change the alarm tone Additional handsets and bases Register a Telstra V1600 handset to a base Select base 30 31 32 32 33 35 35 35 36 36 37 37 38 38 38 39 39 40 40 41 41 42 42 43 De-register a handset

Make an internal call to another Handset Transfer call Three-way calling Help Information Replacing the handset batteries General information Safety Cleaning Environmental Telstra accessories & replacement Items Technical information How many telephones can you have? Connecting to a PABX Recall PIN number SIM card compatibility Product warranty & Customer service 4 44 45 45 46 47 47 49 50 50 50 51 51 52 52 52 53 53 53 54 5 5 Getting started Location You need to place your Telstra V1600 within 2 metres of mains power and telephone sockets so that the cables will reach. Make sure it is at least 1 metre away from other electrical appliances to avoid interference. Your Telstra V1600 works by sending radio signals between the handset and base. The strength of the signals depends on where you site the base. Putting it as high as possible can help provide the best signal. WARNING Do not place your Telstra V1600 in the bathroom or other humid areas Handset range The handset reception range from the base is up to 300m outdoors and up to 50m indoors. Thick walls can severely affect the range. Range indicator The symbol on your handset display indicates when you are in range of the base. If the symbol flashes and you hear a warning beep, you are out of range and will need to move closer to the base. IMPORTANT Do not connect the telephone line until the handset(s) is fully charged. The base must be plugged into the mains power at all times. Which socket? Power socket Telephone line socket 1. Plug the mains power cable into the base.

Then plug the power adaptor into the mains wall socket and switch the power on. The power indicator on the base lights up. Setting up Getting started 2. Remove the battery compartment cover and insert the 2 x AAA NiMH batteries supplied into the handset. Slide the battery compartment cover back into place. 6 3. Charge the handset for at least 16 hours by placing it on the base. The red Charging indicator on the base comes on. The screen will show the standby display and a scrolling battery icon to show that the handset is charging. The backlit screen will turn off after approximately 30 sec.

Press any key to turn on the screen again. Battery low warning When the battery charge is low the handset battery icon will be empty and flashing. Place the handset back on the base to recharge. 4. After 16 hours, plug the telephone line cord into your Telstra V1600 base unit and the other end into the wall socket. Talk/Standby time Under ideal conditions, fully charged handset batteries should give up to 10 hours talk time or 100 hours standby on a single charge. See 'battery performance' on the following page. 7 Getting started Setting the day and time If you have subscribed to Telstra's Calling Number Display\* service, the time and date will be set automatically when you receive your first call. You can also set the time manually. 1.

On the handset, press Menu. Press to scroll down to Time settings then press OK. Scroll to Set Date & Time then press OK. 2. Enter the date, e.g. 02 05 for 2nd May. Press OK. 3. Enter the time, e.g. 10 45 for 10:45am. Press OK. This overwrites the current setting. If you make a mistake press Clear to delete. Press OK. 4. Press and hold Back to return to standby. Your Telstra V1600 is now ready to use. \*Excludes blocked calls.

Monthly charges apply. Available in most areas. Battery performance To keep your batteries in the best conditions, leave the handset off the base for a few hours at a time (after the initial 16 hour charge). Please note however, that new NiMH batteries do not reach full capacity until they have been in normal use for several days. Running the batteries right down at least once a week will help them last as long as possible. The charge capacity of rechargeable batteries will reduce with time as they wear out, so reducing the talk/standby time of the handset. Eventually, they will need to be replaced. New batteries can be obtained from your nearest electrical retailer. Helpline If you have any difficulties setting up your Telstra V1600, please call Product Information on 1300 302 699. Getting to know your Telstra V1600 Handset buttons On-screen option button Open the main menu.

Select the options shown on the screen, page 10. Left toggle button Used with the Talk button to dial Telstra Home Messages 101 Talk Press to make calls, page 13 Handsfree Dial numbers and hold conversations via the handset loudspeaker, page 14. Scroll/Dialled Calls list/ Volume Scroll through options. Press up to open Dialled Calls list, page 15 & 28. During a call, press to increase volume R (Recall) For use with a switchboard and Telstra Calling Features, page

53.



[You're reading an excerpt. Click here to read official THOMSON](http://yourpdfguides.com/dref/3820547)

[V1600 SMS user guide](http://yourpdfguides.com/dref/3820547)

<http://yourpdfguides.com/dref/3820547>

8 On-screen option button Open the phonebook. Select the options shown on the screen, page 10 Right toggle button Used during a call to answer Telstra Call Waiting End End a call, page 13 Power Press and hold to switch handset on and off, page 13. SMS Press to access SMS main menu, page 21 Scroll/Missed Calls list/Volume Scroll through options. Press down to open Missed Calls list, page 27. During a call, press to decrease volume.

Int Lets you make calls between handset registered to the base, page 45 9 Getting to know your Telstra V1600 Handset display icons Current time, Alarm set, page 40 page 41 Battery status Range indicator Flashes when out of range Handset ringer off, page 35 Keypad locked, page 15 New Missed Calls\* You have new (unread) entries in the Missed Calls list, page 28. Handset identity The number of the handset is displayed at all times. You can change the name on the handsets, e.g. Michael, Kitchen, Office etc., page 36. Menu option Press the key below to open the main menu, page 10. Names option Press the key below to open the phonebook, page 17. \* You need to subscribe to Telstra Calling Number Display in order to receive the number of your callers. Excludes blocked calls.

Monthly charges apply. Available in most areas. Getting to know your Telstra V1600 Navigating the menus Your Telstra V1600 has a menu system, which is easy to use. Each menu leads to a list of options. You'll find a menu map on the following page. When the handset is switched on and in standby, press Option button under Menu to open the main menu. and buttons to scroll to the menu Use the option you want. Then press OK to select further options or to confirm the setting displayed. For example, to change the handset ringer volume: Press Menu then scroll to Handset then press OK. Scroll down to Ring Volume then press OK.

and to select the required volume Use level, or choose Ringer Off to switch the ringer off. Press OK to confirm. Exit or go back one level in the menu To go to the previous level in the menu, press Back. To cancel an operation and/or return to standby at anytime, press and hold Back. 10 Select the option displayed by pressing the button underneath it.

For example, press to select Names and open the phonebook. Display power save If no button is pressed for 30 seconds, the handset display automatically switches off to 'power save' mode. Press any button to turn the display back on. 11 Getting to know your Telstra V1600 Menu map These are the options under each menu heading. SMS Write Message Inbox Outbox Delete Messages Settings Settings Calls list Received calls Missed calls Dialed calls Delete calls List Handset Ringtone Ring Volume Handset Name Language Menu Colour Auto Talk Base settings Base Ringtone Base Volume Handset Priority Recall Mode System PIN Registration Register Handset Select Base De-register Calling Features Voice Mail Telstra Voice Assistant Call forward on busy Call forward immediately Call forward im.

off Call forward no answer Call forward no ans. off Call return Cancel call back Call waiting on Call waiting off Message Bank PIN Edit Number Time Settings Alarm Set Time & Date Names menu (page 17) Names Options Add Entry Show Details Delete Entry Edit Entry Ring tone Copy from SIM Getting to know your Telstra V1600 Base Battery charging light Lights up when the handset is charging on the base. Missed Calls indicator\* Lights up when you have new entries in the Missed Calls list, page 22. New SMS messages Lights up when you have new or unread SMS messages 12 Page button Press to page the handset(s), page 16. Also used when registering additional handsets, page 42. Power in use / FMI indicator Lights up when the power is on. - Flashes when making or receiving a call (approx. once every second) - Flashes when a message has been left on MessageBank@^ or Telstra Home Messages 101@# (approx. twice every second) page 25. SIM card reader Insert your SIM card into the tray to copy entries from your SIM card to the phonebook, page 20.

IMPORTANT 3G SIM cards are not compatible with this product. \* You need to subscribe to Telstra Calling Number Display in order to receive the number of your callers. Excludes blocked calls. Monthly charges apply. Available in most areas. For more iPress and hold Back to return to standby. Dial a number from the phonebook. 1. Press Names 2. Scroll or to the name you want or use the keypad to enter the first letter of the name.

3. Press to dial. If you subscribed to Telstra's Calling Number Display service and want names in your phonebook displayed instead of the phone numbers, you must store the full telephone number including the area code. Entering names Use the keypad letters to enter names. For example press 8 for the letter t, or 6 for the letter o.

Keep pressing the same button to scroll through the characters shown on the screen. Press for letters in upper case. This Shift Lock icon will be displayed If the next character you want to enter is on the same button as the last, wait a moment for the cursor to move right. Press 1 to insert a space. Press 1, \* or # for special characters.

If you make a mistake, press Clear to delete the last character. Phonebook Edit an entry 1. Press Names. Scroll or to the entry you want then press Options. 2. Scroll to Edit Entry then press OK. The name is displayed. 3. Press Clear to delete characters then enter the new name then press OK. The number is displayed.

4. Press Clear to delete digits then enter the new number then press OK to save. 5. Press and hold Back to return to standby. View Details 18 1. Press Names. Scroll or to the entry you want then press Options. 2. Scroll to Show Details then press OK. The number is displayed.

You can edit the entry or press and hold Back to return to standby. Delete an entry 1. Press Names. Scroll or to the entry you want then press Options. 2. Scroll to Delete Entry then press OK. 3. Press Yes to confirm or No to cancel. 4. Press and hold Back to return to standby.

Names are stored alphabetically. 19 Phonebook Select ringtone You can choose a different ringer melody to play when you receive a call from a particular number in the phonebook. For example, you may wish to assign a different ring tone to friends and family phone numbers. 1. Press Names. Scroll or to the entry you want then press Options. 2. Scroll to Ringtone then press OK. or to the melody you want 3. Scroll then press OK.

4. Press and hold Back to return to standby. Phonebook Copy SIM card You can copy phonebook information stored on a mobile phone SIM card to your Telstra V1600 phonebook. (Note: CDMA mobile handsets do not have a SIM card, and so are not compatible with this feature.) If there is enough space, you can copy the contents of more than one SIM card (see 'Handset memory full' below) 20 NOTE When you copy the contents of your mobile phone SIM card you will need to enter the SIM card PIN code. DO NOT ATTEMPT TO DOWNLOAD THE PHONEBOOK FROM 3G SIM CARDS.



[You're reading an excerpt. Click here to read official THOMSON V1600 SMS user guide](http://yourpdfguides.com/dref/3820547)  
<http://yourpdfguides.com/dref/3820547>

The SIM card reader in the Telstra V1600 base is not compatible with 1.8V SIM cards (only available with 3G phones, at the time of writing). **WARNING** Keep SIM cards away from small children, as they are a possible choking hazard. Handset memory full If the handset memory becomes full during copying, not all the entries will be transferred.

The maximum number of entries is 150. If your handset phonebook already contains 140 entries, only the first 10 entries on the SIM card will be copied. 1. Slide the SIM card reader out of the base, insert 2. Press Names then Options to scroll the SIM card into the reader and slide it back in. to Copy from SIM. Press OK. 3. The phonebook entries stored on your SIM card will be copied in the order of their location. Your Telstra V1600 handset will then store the entries in alphabetical order. 4. Press and hold Back to return to standby. 21 Telstra phone features Text Messaging Service \*Telstra customers can use this phone to send and receive text messages. The phone will also display the telephone number of the person who sent you the message, as well as the time and date of the message. \*For most Telstra and Telstra reseller customers for messages between compatible services. Charges apply. Text messaging Telstra V1600 can store up to 50 messages in the Inbox and Outbox, dynamically allocated. Each message can have up to the 160 characters. Shortcut to SMS menu You can also press on the key to access the SMS menu directly. Service centres Telstra's text messaging service centre numbers are already setup in your Telstra V1600.

If you change or delete the Telstra text messaging service centre numbers your Telstra text messaging service will not work. Telstra's service centre number for SEND and RECEIVE is 01983391. You can change the service centre numbers as follows: 1. Press Menu and OK to open the SMS menu. 2. Scroll to select Settings then press OK. 3. Service Centres is highlighted then press OK. 4. Receive Centres is highlighted then press OK.

Enter the telephone number of the SMS receiving centre and then press OK. 5. Scroll to select the Sending Centres then press OK. Enter the telephone number of the SMS sending centre and then press OK. Telstra phone features Terminal Number If you have more than one text messaging capable phone on the same line you may not be able to receive text messages.

To prevent this you can change the terminal number of one or more of the phones to prevent interference. You can also use this feature to create personal text message mailboxes. Your Telstra V1600 is set-up with Terminal number '0' by default. To change the terminal number: 22 1. Press to open the SMS menu. 2. Scroll to select Settings then press OK. 3. Scroll to select Terminal then press OK. 4. Enter the terminal number (0-9) and then press OK. SMS Alert This is to enable your Telstra V1600 to alert you when there is a text message being received by the phone. 1. Press 2. Scroll 3.

Scroll 4. Scroll to open the SMS menu. to select Settings then press OK. to select SMS Alert then press OK. or to select On or Off for incoming messages alert. Press OK to confirm. 5. On SMS Alert menu, select Set Alert then press OK to select the alert tone. There are 3 tones selection: Recipient Terminal When sending a message to a personal mailbox, be sure that you enter the personal terminal ID number at the end of the recipient's telephone number, e.g. xx-xxxx-xxxx1, xx-xxxx-xxxx = the telephone numbers, and 1 = recipient personal terminal ID. If no terminal ID is entered, your message will be sent to the default terminal ID '0', which is the public mailbox. - Morse - Discreet - Polyphonic Select your choice then press OK to confirm. 23 Telstra phone features Users setting This is to enable you and other users to setup your personal mailboxes. Mailboxes There are 4 personal mailboxes with password protection available.

A Terminal Number will be automatically assigned to your mailbox. You can check and change your Terminal Number (see Terminal Number, page22) while you are in your personal mailbox. Insert symbol While typing or editing your message, you can insert symbols by pressing Options, and then select the Insert Symbol. Writing/sending messages 1. Press to open the SMS menu.

2. Scroll to select Settings then press OK. 3. Scroll to select Users then press OK. 4. Add User is highlighted then press OK. 5. Enter the new user name then press OK. 6. Enter your password then press OK.

7. Re-type your password then press OK to confirm. 1. Press to open the SMS menu. 2. Write Message is highlighted then press OK. 3. Type your message using the keypad. If you make a mistake press Clear to delete character on the left side of the cursor. 4.

When complete, press Options then Send to then press OK to send message. 5. Enter the phone number of the recipient. Then press Send to deliver the message. 6.

Press and hold Back to return to standby. Telstra phone features View received messages When there is a new message received, the handset display will show to indicate that there is a new / unread message in the Inbox, and the SMS message indicator on the base will light up. 24 1. Press to open the SMS menu. 2.

Scroll or to select Inbox then press OK. 3. The phone will list all the received messages. The new / unread messages will be denoted with icon on the side of the message. 4. Select the new / unread message then press Read to read message. 5. To Reply, Forward or Delete message, press Options to perform your selection. 6. Press and hold Back to return to standby.

Saving message You can write a message and save the unsent / draft message into Outbox to be sent later. 1. Press to open the SMS menu. 2. Write Message is highlighted then press OK. 3. When complete, press Options to select Save 4. Press and hold Back to return to standby. then press OK to save message. 25 Telstra phone features Edit saved message 1.

Press 2. Scroll 3. Scroll to open the SMS menu. or to select Outbox then press OK. or to select the message to be edited then press READ.

4. Press Option and Edit is highlighted. Press OK to go into editing mode. 5. When completed, press Options and Save is highlighted.

Press OK to save the edited message. 6. Scroll or to select if you want to Edit, Send to or Delete the messages. You can also select User Name to go into personal mailbox selection to send the message using your personal mailbox terminal. 7. Press and hold Back to return to standby. Calling Line Identification and Text Messaging In accordance with worldwide standards for text messaging, all messages including reply messages will display the telephone number of the sender. If you have a silent line or have blocked Calling line Identification (CLI) and attempt to send a message your message will be rejected. You can call into the Telstra Fixed Phone SMS service on 0198339999 and use the prompts to turn off silent line or CLI blocking for text messaging ONLY. Telstra phone features Deleting a message You can delete a message in both the Inbox and Outbox.



[You're reading an excerpt. Click here to read official THOMSON](http://yourpdfguides.com/dref/3820547)

[V1600 SMS user guide](http://yourpdfguides.com/dref/3820547)

<http://yourpdfguides.com/dref/3820547>

To delete messages in a personal mailbox, you will need to go into your personal mailbox to perform the delete. 26 1. Press 2. Scroll to open the SMS menu. or to select Inbox or Outbox then press OK. 3. Scroll or to select the message to be deleted then press Read. 4. Press Option and scroll to select Delete then press OK. 5.

Press OK to confirm the delete. 6. Press and hold Back to return to standby. Deleting all messages You can delete all messages in both the Inbox and Outbox.

To delete all messages in a personal mailbox, you will need to go into your personal mailbox to perform the delete.

1. Press 2. Scroll to open the SMS menu. or to select Delete Messages then press OK. 3.

Scroll or to select Inbox, Outbox or All Messages to be deleted then press OK. 4. Press OK again to confirm the delete. 5. Press and hold Back to return to standby. 27 Telstra phone features Calling Number Display \* If you subscribed to Telstra's Calling Number Display service your handset displays the telephone number of the person who is calling you, as well as the time and date of their call. If the caller's number matches an entry stored in the phonebook, the name will also be displayed. Please store the full telephone number, including the area code, otherwise the name will not match the number stored in the phonebook. Calls lists Your Telstra V1600 stores details of all calls you make and receive in 3 different calls lists: · Received calls Calls you have answered. · Missing calls Calls that were not answered, or 'missed'.

· Dialed calls The last 20 numbers dialed, see page 15. @@@@ Excludes blocked calls. Monthly charges apply. Available in most areas.

@@@@ Also, the indicator on the base will light up. Press Read to view the missed calls. All new missed calls in the list will have a next to them.

Opening the Calls lists 1. Press Menu and scroll to select Calls list menu then press OK. 2.

Scroll and to select the list you want to view, then press OK. 3. @@@4. Press and hold Back to return to standby. @@@The Missed Calls list by pressing .

1. @@@@3. Scroll or to the entry you want then press . 2. Scroll 29 Telstra phone features 1.

@@@@@3. Scroll or to the entry you want then press Options. 4. Scroll or to Add Entry then press OK. 5. Enter a name then press OK. The number is displayed. 6. Press OK. 7.

Press and hold Back to return to standby. Copy a number to the phonebook 2. Scroll 1. @@@@3. Scroll or to the entry you want then press Options. Delete is highlighted. Press OK to confirm or Back to cancel. 4. @@@@2. Scroll or to Delete Calls List then press OK.

3. Scroll to the list you want then press OK. 4. Press Yes to confirm and No to cancel. 5.

Press and hold Back to return to standby. 30 1. @@@or to Delete Calls List then press OK. 3. Scroll to All Calls then press OK.

4. Press Yes to confirm and No to cancel. 5. @@@@\*Available to most Telstra home phone access customers. ^Message retrieval is free from most Telstra fixed phones. @@2 flashes per second, and Handset a tape icon and text bubble reading "You have a new message" will be displayed on the handset. After you have listened to your message(s), the orange In Use light will return to a steady light and TAPE icon & text bubble will disappear. Telstra phone features

Call Waiting\* Call Waiting lets you know if someone is trying to call you while you are already on the phone. You can answer that call and place the first caller on hold by dialling Recall 2 \* Available on most fixed phones. or: To Use Call Waiting While on a phone call, Press the RIGHT toggle button.

The telephone will dial Recall 2. MessageBank®^ and Telstra Home Messages 101®# MessageBank takes the message for you when you're on the phone or can't answer it, so you can call back when it suits you. Message retrieval is free from most Telstra fixed phones. Telstra Home Messages 101 is free to turn on and use. ^Monthly charge and call charges apply. # 32 Available to most Telstra home phone access customers. or: To call MessageBank® or Telstra Home Message 101® From the standby screen, press the LEFT toggle button. The telephone will dial 125101. 33 Telstra phone features Telstra Calling Features Your Telstra V1600 is pre-programmed with the following Telstra network features which can be easily accessed or activated via the Calling Features Menu Calling Features From the standby screen, Press Menu and scroll to select Calling Features menu then press or OK. Scroll to select desired option: Voice Mail Telstra Voice Assist^ Call fwd busy · Call fwd busy off Call fwd immediate · Call fwd im.

off · Call fwd no answer ^Available to most Telstra home phone customers. Telstra phone features · Call fwd no ans. Off Call Return · Cancel Call back Call waiting on · Call waiting off · MessageBank Pin · Edit Number Allows you to edit the following Calling Features numbers: Voice Mail Telstra Voice Assist Call fwd on busy off Call fwd im. off Call fwd no ans. off Call Return Cancel Call back Call Waiting on Call waiting off MessageBank Pin 34 35 Handset settings Using the Handset menu you can change the settings of your handset.

Ringtone You can choose from 5 melodies. You can set different melodies for internal and external calls. 1. Press Menu, scroll to Handset then press OK. or 2.

Ringtone is highlighted. Press OK. Press to switch between External or Internal then press OK. 3. Scroll or to the melody you want. A sample is played. Press OK to confirm. 4. Press and hold Back to return to standby. Ringer volume There are five handset ringer volume levels and 'Off'.

If you select 'Off', only the base will ring (unless you have set the base ringer to 'Off' as well, see page 38). 1. Press Menu, scroll to Handset then press OK. to Ring Volume then press OK. 2. Scroll or to select the volume level or 3. Use Ringer Off then press OK to confirm. 4. Press and hold Back to return to standby.

If you have more than one handset, you can have different settings for each one.

The default ringtone for external calls is Melody 5. The default ringtone for internal calls is Melody 1. The default ringer volume is 3. If the ringer is switched off, the icon is displayed to remind you. Handset settings Handset name You can change the name displayed on your handset's screen, e.

g. Peter, Office, Kitchen etc. The handset number is not altered. 1. Press Menu, scroll to Handset then press OK.

2. Scroll to Handset, Name then press OK. 3. Press Clear to delete the current name. Enter the name you want then press OK to confirm. 4. Press and hold Back to return to standby. Handset language You can set your handset to English, French, German, Italian, Spanish, Dutch, or Portuguese. 1. Press Menu, scroll to Handset then press OK.

2. Scroll to Language then press OK. 3. Press or to select the language you want then press OK to confirm. 4. Press and hold Back to return to standby. 36 The handset name can be a maximum of 8 characters.



[You're reading an excerpt. Click here to read official THOMSON V1600 SMS user guide](http://yourpdfguides.com/dref/3820547)  
<http://yourpdfguides.com/dref/3820547>

Press for letters in uppercase. The default language is English. 37 Handset settings Menu colour Choose from 3 different menu background colours blue, green and pink.

1. Press Menu, scroll to Handset then press OK. to Menu Colour then press OK. 2. Scroll or to select the colour you want 3. Press blue, green or pink. 4. Press Save to confirm. 5. Press and hold Back to return to standby.

Auto-talk When the handset is on the base and the phone rings, you can answer a call just by picking the handset up from the base, without having to press the button. You can also end a call by placing the handset back on the base. By switching Auto-talk off you will need to press to answer a call and to hang up. 1. Press Menu, scroll to Handset then press OK. 2. Scroll to Auto Talk then press OK. 3. Press or to select On or Off. 4.

Press OK to confirm. 5. Press and hold Back to return to standby. The default menu colour is blue. By default, Auto-talk is set to On. Base settings Base ringtone You can choose from 5 melodies. 1. Press Menu, scroll to Base Settings then press OK. 2. Base Ringtone is highlighted. Press OK. or to the melody you want. A 3. Scroll sample is played. Press OK to confirm.

4. Press and hold Back to return to standby. Ringer volume There are five ringer volume levels and 'Off'. 1. Press Menu, scroll to Base Settings then press OK.

to Base Volume then press OK. 2. Scroll or to select the volume level or 3. Press Ringer Off then press OK to confirm. 4. Press and hold Back to return to standby. 38 The default base ringtone is Melody 5. The default base ringer volume is 3. 39 Base settings Handset priority Normally, if you have more than one handset registered to your base, they all ring at the same time. However, you can set one of them to ring before the others, so that calls can be answered at one handset first.

1. Press Menu, scroll to Base Settings then press OK. 2. Press to highlight Handset Priority then press OK. 3. Scroll or to All Handset for all to ring at the same time or Select Handset to choose one handset to ring first. 4. Press OK. 5. If choosing one handset to ring first, scroll or to select the handset then press OK to confirm.

6. Scroll or to select the Numbers of Ring then press OK to confirm. 7. Press and hold Back to return to standby. Recall 1 is 100ms (standard for the Telstra network and most PABX) Recall mode See 'Connecting to a PABX' for dialling mode and recall settings, page 53.

In the menu, Recall 1 and Recall 2 are available for PABX settings. Base settings Security PIN The security PIN is used for registering and deregistering handsets. The default security PIN is 0000. You can set your own security PIN preference. 1.

Press Menu, scroll to Base Settings then press OK. to highlight System PIN then press OK. 2. Press 3. Enter the old PIN (default setting 0000) then press OK. 4. Enter the new PIN, press OK and enter it again. 5. Press OK to confirm. 6.

Press and hold Back to return to standby. 40 KEEP TRACK OF YOUR PIN If you change the System PIN, keep a record of the new number by writing in the space provided on page 53. You need your System PIN for registering handsets and for some other options Time settings Set date and time If you have subscribed to Telstra's Calling Number Display, the date and time will be set automatically when you receive your first call. You can also set the date and time manually. 1. Press Menu, scroll to Time Settings then press OK. 2. Scroll to Set Date & Time, then press OK. 3. Enter the date, e.g. 2708 = 27th August, then press OK. 4. Enter the time, e.g.

1430 = 2:30pm. Then press OK. 5. Press and hold Back to return to standby. If you make a mistake when entering the date or time, press Clear.

41 Base settings Set alarm When an alarm is set, the display shows the When the alarm sounds, press Stop to silence it. 1. Press Menu, scroll to Time Settings then press OK. 2. Alarm is highlighted, press OK. Press OK again to select On/Off. 3. Scroll or to highlight the option you want, then press OK. On Once alarm sounds just once On Daily alarm sounds at the same time each day. Off alarm off 4.

Enter the time you want to set the alarm for, e.g. 0730 for 7:30am, then press OK. 5. Press and hold Back to return to standby. Change the alarm tone 1. Press Menu, scroll to Time Settings then press OK. 2. Press OK again to select Alarm. 3.

Scroll to Set Alarm Tone then press OK. 4. Scroll or to select the melody you want and press OK to confirm. 5. Press and hold Back to return to standby. Additional handsets and bases You can use up to five handsets with your Telstra V1600. To do this you need to register each additional handset with the base following the simple steps given below. Each handset can be registered on up to 4 bases. Register a Telstra V1600 handset to a base. 42 1.

On the base, press and hold until you hear two beeps. You have 90 second to complete the following steps. 2. On the handset, press Menu, scroll to Registration, then press OK. Registration Handset is highlighted. Press OK. 3. The display shows the available base stations. A against one of them indicates the handset is already registered with that base. 4.

Scroll to the base you want to register to then press OK. 5. Enter the four-digit Security PIN (default setting 0000) then press OK. The handset registration is confirmed and the handset is given a handset number (1-5) which is displayed. 6. Press and hold Back to return to standby. IMPORTANT Before registration, make sure the handset batteries are fully charged and that you are close to the base. 43 Additional handsets and bases Select base If your handset is registered to more than one base, for example, one at work and one at home, you can quickly select which base it takes its signal from. 1. When in range of the base you want to connect to, press Menu, scroll Registration, then press OK.

2. Scroll to Select Base then press OK. The display shows Select Base and the available base stations. A against one of them indicates the handset is registered with that base. 3.

Scroll or to the base you want or choose Automatic to automatically select the base with the strongest signal. If you use a handset with two or more bases you can select Automatic from the Selected Base menu so that your handset will automatically link to the base with the strongest signal. 4. Press and hold Back to return to standby. If you use a handset with two or more bases you can select automatic from the Select Base menu so that your handset will automatically link to the base with the strongest signal.

Additional handsets and bases De-register a handset Use one handset to de-register another handset from the same base. 1. Press Menu, scroll to Registration, then press OK. 2. Scroll to De-register then press OK. 3. Enter the system PIN (default setting 0000) then press OK. The screen lists all handsets registered to the base. 4. Scroll or to select the handset you want to de-registered then press OK.

5. Press Yes to confirm or No to return to the previous screen listing the handsets 6.



[You're reading an excerpt. Click here to read official THOMSON V1600 SMS user guide](#)



Press and hold Back to return to standby. 44 45 Additional handsets and bases Using additional handsets Make an internal call to another handset If you have two or more handsets registered to your base, you can make internal calls between handsets. Two handsets can be holding an internal call while a third is on an external call. 1. Press then the handset number (1-5). The receiving handset displays your number. 2. Press to hang up.

Transfer calls You can transfer an external caller to another handset. 1. During an external call, press . Your caller is put on hold. 2.

Dial the number of the handset you want (1-5). 3. When the other handset answers you can tell them they have a call, then press . The external caller is transferred. If the other handset does not answer or you decide not to transfer the call, press to talk to your caller again.

Additional handsets and bases Three-way call You can hold a three-way call between two internal handsets and an external caller. 1. During an external call, press then the handset number you want (1-5). Your external caller is put on hold. 2. When the other handset answers, press to start the conference call. 3. If the other handset does not answer, press again to speak to your external caller. 46 During a conference call Your handset displays Conference, the number of the handset called and either the external caller's number or External Call. Note When on a three-way call, the call can only be cleared by the handset which set it up.

4. Press to hang up. 47 Help · The batteries may be dead. Recharge or · No display replace the batteries, see 'Replacing the handset batteries', page 49. Is the handset switched off? To switch the handset on, see page 13. Product Information 1300 302 699 Call the V1600 Helpline: · If you are having difficulties using your Telstra V1600 If you need a replacement main power lead No dial tone · Check that the telephone line cord is plugged into the phone socket. · Check that the base is connect to the mains power and switched on. You cannot link up with the base · Check that the base is connected to the mains power and switched on. · Are you out of range? Move the handset closer to the base. · Are the batteries low or flat? If so, charge the batteries or replace them if necessary.

· If using more than one base, check that you are connected to the correct base, see page 43. Lines open: 8:00am 5:00pm EST (or ESST), Monday to Friday Help No ring on the handset · Check that the ringer volume is switched on, see page 38. · Check that the base is plugged into the phone socket and that it is also connected to the mains power and switched on. Buzzing noise on my radio, TV, computer or hearing aid · Sometimes, your Telstra V1600 and other cordless telephones can interfere with other electrical equipment if placed too close. Try moving it as least one metre away from such appliances.

The charging light does not appear to be working · Check that the base is plugged into the mains socket and switched on. · Check that the handset has slotted correctly into the base. · Check that the handset batteries have been correctly fitted. 48 Please note Telstra accepts no responsibility for damage caused to your Telstra V1600 handset by using any other type of batteries. 49 Help Replacing the handset batteries After a time, you may find that the handset batteries are running out of charge more quickly.

This is a standard sign of wear and the batteries will need replacing. For spare AAA rechargeable NiMH batteries, please contact your nearest electrical retailers. Slide off the battery compartment cover and remove existing batteries. Insert new batteries and replace the compartment cover. General information IMPORTANT This equipment is not designed for making emergency telephone calls when the power fails. Alternative arrangements should be made for access to emergency services. 50 · It is recommended that advice from a qualified expert be sought before using this product in the vicinity of medical equipment. Your product may interfere with other electrical equipment, e.g. TV and radio sets, clock/alarms and computers if placed too close.

It is recommended that you place your product at least one metre away from such appliances to minimised any risk of interference. Never dispose of batteries in a fire. There is a serious risk of explosion and/or the release of highly toxic chemicals. · Safety General · Only use the power supply included with the product. Using an unauthorised power supply will invalidate your guarantee and may damage the telephone. · Use only the approved rechargeable batteries supplied. Spare rechargeable batteries are available from your nearest electrical retailer. · Do not open the handset (except to replace the handset batteries) or the base. This could expose you to high voltages or other risks. · Contact Product Information on 1300 302 699 for all repairs.

· Radio signal transmitted between the handset and base may cause interference to hearing aids. · Cleaning Simply clean the handset and base with a damp (not wet) cloth, or an anti-static wipe. Never use household polish as this will damage the product. Never use a dry cloth as this may cause a static shock. 51 General information Telstra Accessories and replacement items For a full range of accessories and replacement items for the Telstra V1600, please call Product Information on 1300 302 699.

Environmental Do not expose to direct sunlight. The produce may heat up when the batteries are being recharged or during prolonged periods of use. This is normal, however, we recommend that to avoid damage you do not place the product on antique/veneered wood. Do not stand your product on carpets or other surfaces, which generate fibres, or place it in locations preventing the free flow or air over its surface. Do not submerge any part of your product in water and do not use it in damp or humid conditions, such as bathrooms.

Do not expose your product to fire, explosive or other hazardous conditions. There is a slight chance that your phone could be damaged by an electrical storm. We recommended that you unplug the power and telephone line cord from the base for the duration of the storm. Technical information How many telephones can you have? All items of telephone equipment have a Ringer Equivalence Number (REN), which is used to calculate the number of items, which may be connected to any other telephone line. Your Telstra V1600 has a REN of 0.1. A total REN of 4 is allowed. If the total REN of 4 is exceeded, the telephone may not ring. @@ Only use the approved power adaptor and charger. Only use the approved AAA NiMH rechargeable batteries.

@@@ to get an outside line. To allow the PABX time to pick up an outside line before the rest of the number is dialled, you may need to add a pause in the dialling sequence.



[You're reading an excerpt. Click here to read official THOMSON](#)

[V1600 SMS user guide](#)

<http://yourpdfguides.com/dref/3820547>

9 PABX code for an outside line P Pause inserted in dialling sequence. 9Pxxx xxx Rest of the phone number When storing a number in the phonebook, at the point you want to insert a pause, press and hold down until P is displayed. 53 Technical information Recall The button is used when connected to certain PABX's and with some Telstra phone features. PIN number If you change the System PIN, keep a record of the new number by writing in the space provided on this page. SIM card compatibility 3G SIM card are not compatible with this product. Do not attempt to download information from 3G SIM cards to your Telstra V1600. Please check with your network provider first if you are unsure. 3G SIM cards are 1.

8V. CDMA mobile phones do not have a SIM card, and so are not compatible with this product. PIN NUMBER Product warranty & Customer service Product Warranty Telstra Guarantees your product for 12 months from the date of purchase against any defect in materials or workmanship under conditions of normal use and service and subject to proof of the date of the purchase being provided and subject to the conditions specified below. The benefits conferred by this warranty are in addition to all other rights and remedies in respect of the product that the consumer has under the Trade Practices Act and similar State and Territory laws. Warranty Service Conditions Subject to your statutory right referred to the above, Telstra expressly limits its liability with respect to its products to the person who purchases the product from the Telstra authorised retailer.

Subject to your statutory right referred to the above, Telstra expressly limits its liability with respect to its products to whichever is the lowest amount out of:  
A. The cost of having the goods repaired B. The cost of replacing the goods, or C. The cost of obtaining equivalent goods. Subject to your statutory right referred to the above, in the event of the goods requiring service under warranty, the owner is responsible for the cost of transportation to the authorised service organization.

Whilst in transit the goods are at the owner's risk. Subject to your statutory right referred to the above, should the goods be found to be in sound working order by the authorised service organization the owner may be charged a service fee. Subject to your statutory right referred to the above, the goods will not be eligible for service under this warranty if: A. Proof of date of purchase cannot be provided; B. The goods are not branded Telstra; C. The goods have been rented to another person; D. The defect was caused by an accident, misuse, abuse, improper installation or operation, lack of 54 reasonable care, unauthorised modification, loss of parts, tempering or attempted repair by a person not authorised by Telstra; E. The product has been damaged by lightning or a mains power surge. Do you really need service? Before calling for service under this warranty have you: Check that all cables are securely connected as detailed in the User Guide. Refer to the User Guide to ensure that the features are being used correctly.

If you are trying to access a network service such as Call Waiting, confirmed with your network provider that you have access to this feature. If You Require Warranty Service To obtain service during the terms of this warranty: Call Product Information on 1300 302 699 for advice and assistance on the repair of your product. After consulting our operators, should it be deemed necessary to have the product serviced, the operator will inform you of your nearest authorised service organization and provide a Return Authority Number. Please ensure that: A. You provide proof of the date of purchase. B. That your product is suitably packaged (Preferably in original packaging). C. That you have included all components from the original purchase. D. That you provide details of the Return Authority Number. IMPORTANT Please retain this booklet with your sales receipt as proof of the date of purchase. [www.telstra.com](http://www.telstra.com).



[You're reading an excerpt. Click here to read official THOMSON V1600 SMS user guide](http://yourpdfguides.com/dref/3820547)  
<http://yourpdfguides.com/dref/3820547>