



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for TRENDNET TPL-306E. You'll find the answers to all your questions on the TRENDNET TPL-306E in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual TRENDNET TPL-306E**  
**User guide TRENDNET TPL-306E**  
**Operating instructions TRENDNET TPL-306E**  
**Instructions for use TRENDNET TPL-306E**  
**Instruction manual TRENDNET TPL-306E**



[You're reading an excerpt. Click here to read official TRENDNET TPL-306E user guide](http://yourpdfguides.com/dref/4129144)  
<http://yourpdfguides.com/dref/4129144>

**Manual abstract:**

.....  
.....  
.....

*.....5 Before you Install .*

.....  
.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*..... 5 Connect a Powerline adapter to your router ....*

.....  
.....  
.....

.....  
.....  
.....

*5 Add adapters to your network .....*

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*..... 6 Securing your Powerline Network ....*

.....  
.....  
.....

.....  
.....  
.....

*.....7 Using the Sync button...*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... 7 Change your default encryption key using the Sync button ...

.....  
.....  
.....

.....

... 7 Add adapters using the Sync button .

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

..... 8 Using the Powerline Utility ...

.....  
.....  
.....  
.....

.....  
.....  
.....

.....9 Powerline Utility System Requirements .

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....

. 9 Software Installation....

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....





dishwasher, etc.) The quality of your household electrical wiring may also cause additional noise on your electrical system. Distance Long lengths of electrical wiring through your electrical system between connected Powerline adapters. © Copyright 2012 TRENDnet. All Rights Reserved.

3 TRENDnet User's Guide Power Saving: The device will automatically reduce power usage when the connected devices via Ethernet are powered off, unplugged or inactive for more than 3 minutes.



[You're reading an excerpt. Click here to read official TRENDNET](#)

[TPL-306E user guide](#)

<http://yourpdfguides.com/dref/4129144>

*TPL-306E / TPL-306E2K Application Diagram Erp (EuP) Operation: Standby Mode Disconnect the Ethernet cables from the device Ethernet ports, and after 3 minutes, the device will enter standby mode. The Power (PWR) LED will flash every 15 seconds to indicate that the device is currently in standby mode. To return to active mode, reconnect the Ethernet cables to the device Ethernet ports, and the device will re-enter active mode. A router is already installed in the room where the xDSL/Cable modem (typically supplied by your ISP "Internet Service Provider") is located in order to physically connect an Ethernet cable (also called network cable) from the router WAN port to the modem network port which connects to the Internet. A second Powerline adapter is plugged into a wall power outlet in another room in order to extend the network connectivity to the network devices in that room. The Ethernet port of the second Powerline adapter is then connected to a network enabled TV or other network enabled media device in order to extend connectivity to these devices allowing access to your network and to the Internet through the electrical system. © Copyright 2012 TRENDnet. All Rights Reserved. 4 TRENDnet User's Guide TPL-306E / TPL-306E2K Connect a Powerline adapter to your router 1.*

*Plug the Powerline adapter into an available wall power outlet near your router. Note: This will allow devices connected to your Powerline network to access the Internet and other devices connected to your network. 2. Connect the included Ethernet cable (also called network cable) from the Ethernet port (also called network port) of your Powerline adapter to an available Ethernet port (also called LAN port) on your router. 3.*

*Once the Powerline adapter is installed and connected to your router, verify that the Power (PWR) LED is on or blinking and the Ethernet Connection (ETH) LED is on or blinking. Installing your Powerline Adapters Before you Install 1. Before you proceed with the installation, verify the following: You already have an existing Ethernet network along with a router already installed. You already have Internet access through your existing network. An Ethernet port (also called LAN port) is available on your router.*

*Verify that you have at least two Powerline adapters. You will need at least two Powerline adapters to create a Powerline network. Note: The TPL-306E package only includes a single Powerline adapter. Please ensure that your other Powerline adapter is HomePlug® AV or IEEE 1901 compliant (e.g. TRENDnet models TPL-303E, TPL-304E, TPL-305E, TPL-307E, TPL310AP, TPL-401E, TPL-402E, TPL-405E, or another TPL-306E.) The TPL-306E2K package already includes two Powerline adapters. 2. Plan the location of where you will install your Powerline adapters. Avoid plugging the adapters into power strips, extension cords, or surge protectors as this may prevent the adapter from functioning correctly such as degrading performance.*

*Avoid plugging the adapters into wall power outlets that are controlled by a switch to prevent the Powerline adapter from being turned off accidentally. Avoid plugging the adapters into wall power outlets that are located near appliances that consume a lot of power (e.g. refrigerators, washers, dryers) as this may degrade performance. Make sure there is an available wall power outlet in the room where the router is installed and also near the router. Make sure there is an available wall power outlet in the room where you want to extend your network connectivity. © Copyright 2012 TRENDnet. All Rights Reserved. 5 TRENDnet User's Guide Add adapsysical Sync button on your Powerline adapter to generate a random encryption key. See "Using the Sync Button" on page 7.*

*OR Create a customized encryption key for your Powerline network using the included Powerline Utility. See "Using the Powerline Utility" on page 9. © Copyright 2012 TRENDnet. All Rights Reserved. 7 TRENDnet User's Guide To change the default encryption key between two Powerline adapters: 1.*

*Verify that all Powerline adapters are already installed and connected using the default encryption key, see "Installing your Powerline Adapters" on page 5. 2. On one of your connected Powerline adapters, push and hold the Sync button for 10 seconds and release it. All LEDs will turn off and turn back on. This will erase the current encryption key assigned to the first Powerline adapter.*

*Note: Once you complete this step, the other Powerline adapter will not be able to communicate to this Powerline adapter. 3. Push and hold the Sync button on the other Powerline adapter for 10 seconds and release it. All LEDs will turn off and turn back on. This will erase the current encryption key assigned to the second Powerline adapter. 4. Within 2 minutes, push and hold the Sync button on the first Powerline adapter for 2 seconds and release it. The Power (PWR) LED will start blinking. This will generate a random encryption key on the first Powerline adapter. 5.*

*Push and hold the Sync button on the second Powerline adapter for 2 seconds and release it. The Power (PWR) LED will start blinking. This will create a connection between both Powerline adapters using the new encryption key. All LEDs will turn off and turn back on and the Powerline (PL) LED will turn on the when adapters are connected. Add adapters using the Sync button TPL-306E / TPL-306E2K If you have changed the default encryption key assigned to your Powerline adapters, additional adapters will not automatically connect to your Powerline network after they are plugged into a wall power outlet. For any additional adapters, you will need to reconfigure any additional Powerline adapters that you add to use the encryption key of your existing Powerline network. © Copyright 2012 TRENDnet. All Rights Reserved. 8 TRENDnet User's Guide To reconfigure an additional Powerline adapter to connect and use the encryption key of your existing Powerline network: 1. Verify that all existing Powerline adapters are already installed and connected.*

*2. Push and hold the Sync button on the additional Powerline adapter for 10 seconds and release it. All LEDs will turn off and turn back on. This will erase the current encryption key assigned to the additional Powerline adapter. 3.*

*Push and hold the Sync button on one of the existing Powerline adapters connected to your Powerline network for 2 seconds and release it. The Power (PWR) LED will start blinking. 4. Within 2 minutes, push and hold the Sync button on the additional Powerline adapter for 2 seconds and release it. The Power (PWR) LED will start blinking.*

*This will reconfigure your additional Powerline adapter to connect and use the encryption key of your existing Powerline network. All LEDs will turn off and turn back on and the Powerline (PL) LED will turn on the adapters are connected. To reconfigure the encryption key and connect additional Powerline adapters to your existing Powerline network, repeat the steps above for each adapter.*



[You're reading an excerpt. Click here to read official TRENDNET](http://yourpdfguides.com/dref/4129144)

[TPL-306E user guide](http://yourpdfguides.com/dref/4129144)

<http://yourpdfguides.com/dref/4129144>

*TPL-306E / TPL-306E2K Using the Powerline Utility The Powerline Utility allows you to do the following: Create a customized encryption key for your Powerline network and apply it to multiple Powerline adapters at the same time. Allows you to view the Powerline adapters connected to your network (using the MAC address) and the approximate connection quality and speed of each Powerline adapter View and upgrade your Powerline adapter firmware version. Note: Link speed displayed in the utility of your Powerline adapters to another through your electrical system is estimated. Actual link speed may vary. Before installing and using the utility, please ensure the following: Write down the Device Password (DPW) (16-digit characters A-Z only) and MAC Address (12-digit characters a-f, A-F, 0-9) of each Powerline adapter as this will be required to change the encryption key for multiple Powerline adapters. See "Product Hardware Features" on page 2. Make sure your computer in which you are installing the utility is connected to your network and your Powerline adapters are also connected to your network.*

*If you have changed your encryption key using the Sync button and you are creating a customized encryption key, it is required to reset all Powerline devices to defaults using the physical Reset button on your Powerline adapter first before using the utility. See "Product Hardware Features" on page 2. Please ensure that your Powerline adapters are already installed and connected and the Ethernet port on each adapter is connected to a device powered on. Powerline Utility System Requirements Supported Operating Systems Windows 7 (32/64-bit) Windows Vista (32/64-bit) Windows XP (32/64-bit) CPU 1GHz or above 800MHz or above 300MHz or above Memory 1GB RAM or above 512MB RAM or above 256MB RAM or above © Copyright 2012 TRENDnet. All Rights Reserved. 9 TRENDnet User's Guide Software Installation 1. Insert the included CD-ROM into your computer's CD-ROM drive. 2. At the CD Autorun Prompt window, click Run Autorun.exe Note: If the Autorun prompt does not appear automatically, open the CD contents and double-click Autorun.exe. 3. At the CD-ROM main menu, click Install Utility. 5. At the WinPcap installer window, click Next.*

*TPL-306E / TPL-306E2K 6. In the Setup Wizard window, click Next. 4. Click OK. Note: The Powerline Configuration Utility requires the use of the WinPcap application.*

*If this prompt does not appear, you may already have the WinPcap application installed. If so, please skip over to Step 11. © Copyright 2012 TRENDnet. All Rights Reserved. 10 TRENDnet User's Guide 7. In the License Agreement window, click I Agree. 9. Wait for the WinPcap installation to complete. TPL-306E / TPL-306E2K 8. In the Install Options window, leave the option Automatically start the WinPcap driver at boot time checked and click Install.*

*10. After the process is completed, click Finish. © Copyright 2012 TRENDnet. All Rights Reserved. 11 TRENDnet User's Guide 11. At the Powerline Configuration Utility installation window, click Next. TPL-306E / TPL-306E2K 13. In the Select Installation Folder window, click Next. 12. In the License Agreement window, check the radio button I Agree, and click Next.*

*14. In the Confirm Installation window, click Next. © Copyright 2012 TRENDnet. All Rights Reserved. 12 TRENDnet User's Guide 15.*

*Wait for the Powerline Utility installation to complete. TPL-306E / TPL-306E2K Using the Utility Before using the utility, please ensure the following: Write down the Device Password (DPW) (16-digit characters A-Z only) and MAC Address (12-digit characters a-f, A-F, 0-9) of each Powerline adapter as this will be required to change the encryption key for multiple Powerline adapters. See "Product Hardware Features" on page 2. Make sure your computer in which you are installing the utility is connected to your network and your Powerline adapters are also connected to your network. If you have changed your encryption key using the Sync button and you are creating a customized encryption key, it is required to reset all Powerline devices to defaults using the physical Reset button on your Powerline adapter first before using the utility.*

*See "Product Hardware Features" on page 2. Please ensure that your Powerline adapters are already installed and connected and the Ethernet port on each adapter is connected to a device powered on. 16. At the Installation Complete window, click Close. Upon completing the software installation, a desktop shortcut is automatically created. Double-click the icon to start the utility or open the utility if it is already running. Closing the utility will exit the application. You can also launch the utility from the Start Menu programs. Start > Programs (or All Programs) > TRENDnet > TRENDnet Powerline Utility 17. Reboot your computer to complete the installation.*

*© Copyright 2012 TRENDnet. All Rights Reserved. 13 TRENDnet User's Guide Powerline Utility Overview Main Window TPL-306E / TPL-306E2K Connect Local Device The Powerline adapter connected to your router. Note: If your computer is connected directly to your Powerline adapter, the Local Device listed will be the Powerline adapter your computer is directly connected. Device Name Remote Devices Powerline adapters in remote locations that are connected to the selected Powerline adapter (Local Device) across the electrical system. @@If not, you will need to add them manually. @@@@All Rights Reserved. @@Note: The default encryption key is HomePlugAV. @@@@© Copyright 2012 TRENDnet. @@@@All Rights Reserved. @@@@Note: It is recommended to keep this option checked (Enabled). @@@@All Rights Reserved. @@@@This is required when using the Powerline utility to change the encryption key for multiple Powerline adapters. To add automatically detected Powerline adapters to the Powerline Utility 1. Launch the Powerline Utility.*

*3. Select one of the Powerline adapters listed under Remote Device. 4. Click Enter Password. © Copyright 2012 TRENDnet.*

*All Rights Reserved. 18 TRENDnet User's Guide 5. Enter the Device Password (DPW) and click OK. Note: Match the Device Password (DPW) to the corresponding MAC address. To create a customized encryption key TPL-306E / TPL-306E2K 1. In the Powerline Utility Privacy window, under Private Network Name, enter the new encryption key for your Powerline network. 2. After you have entered your new Powerline encryption key, click Set All Devices. 6. If successful, you will receive a message indicating that the password is correct.*

*Click OK. 3. Click OK. If successful, you will receive a message indicating that all Powerline adapters were added to your network verifying that the encryption key was changed for all Powerline adapters. Click OK. Repeat steps 2-6 for each additional Powerline adapter listed in Remote Device until you have added all of your remaining Powerline adapters before continuing to the next step "To create a customized encryption key".*



[You're reading an excerpt. Click here to read official TRENDNET TPL-306E user guide](http://yourpdfguides.com/dref/4129144)  
<http://yourpdfguides.com/dref/4129144>



© Copyright 2012 TRENDnet. All Rights Reserved. 19 TRENDnet User's Guide To rename the Powerline adapters Note: Renaming the Powerline adapters (Remote devices) to describe the location of the device will help you to easily identify which Powerline adapter you are monitoring in the utility. 1. In the Powerline Utility Main window, select one of the Powerline adapters listed under Remote Device. Upgrade Firmware TPL-306E / TPL-306E2K Note: The firmware can only be upgraded when your computer is directly connected to the Powerline adapter Ethernet port (also called network port) using an Ethernet cable (also called network cable). The Device Password (DPW) is not required when upgrading the firmware. 1. To check if firmware updates are available for your Powerline adapter, check your Powerline model.

<http://www.trendnet.com/downloads/> 2. Save the zipped firmware file (.zip) and extract the file to your computer.

3. Make sure you connect your computer with the utility installed is directly connected to the Powerline adapter using an Ethernet cable (also called network cable) when upgrading the device firmware. 2. Click Rename. 3. The device name field will be available to edit. 4. Enter the new device name and press Enter on your keyboard. © Copyright 2012 TRENDnet. All Rights Reserved.

20 TRENDnet User's Guide 4. Launch the Powerline Utility by double-clicking the icon. TPL-306E / TPL-306E2K 6. Click Browse next to the PIB field and navigate to the unzipped folder with the firmware files. Select the PIB file. (Ex. TPL-401E-PIB-v50100.pib) 5. The device should appear in the Main window of the utility under Local Device. Click Upgrade Firmware.

7. Click Browse next to the NVM field and navigate to the unzipped folder with the firmware files. Select the NVM file. (Ex. TPL-401E-NVM-v5.0.1-0-0-X-FINAL.nvm) 8. Click OK. Wait until the firmware upload completed and the device reboot Important! Do not turn off the device or press the reset button while this procedure is in progress.

© Copyright 2012 TRENDnet. All Rights Reserved. 21 TRENDnet User's Guide TPL-306E / TPL-306E2K Ethernet (ETH) Connection Buttons Dimension (L x W X H) Solid Blinking Off Technical Specifications Hardware Standards Interface IEEE 802.3, IEEE 802.3x, IEEE 802.3u, HomePlug® AV, IEEE 1901 1 x 10/100Mbps Auto-MDIX RJ-45 Port Power prong: Frequency Band Modulation Protocols Speed Utility OS Compatibility Nodes Overlapping Powerline Networks Supported Coverage Security LED A: North America Type B (NEMA 515) EU: Euro Type C (CEE 7/16) UK : United Kingdom Type G (BS 1363) Weight Sync, Reset A: 55 x 87 x 51 mm (2.2 x 3.4 x 2 in.) per unit EU: 55 x 87 x 65 mm (2.2 x 3.

4 x 2.6 in.) per unit UK: 55 x 87 x 58 mm (2.2 x 3.4 x 2.3 in.) per unit A: Total Weight: 148 g (5.2 oz) / Per Unit Weight: 74 g (2.6 oz) EU: Total Weight: 158.8 g (5.

6 oz) / Per Unit Weight: 79.4 g (2.8 oz) UK: Total Weight: 170g (6 oz) / Per Unit Weight: 85 (3 oz) 2 ~ 28 MHz OFDM Symbol modulation on link synchronization, 1024/256/64/8 - QAM, QPSK, BPSK, ROBO carrier TDMA and CSMA/CA Powerline: Up to 200Mbps\*\* Ethernet: Up to 200Mbps (Full Duplex mode) Windows 7 (32/64-bit), Vista (32/64-bit), XP(32/64-bit) Up to 6 (max.) Up to 4 (per electrical system) Up to 300 m (984 ft.) 128-Bit AES (Advanced Encryption Standard) Power (PWR) Powerline (PL) Connection Best (Green) Better (Amber) Good (Red) No connection (Off) Humidity Certifications Temperature Power Source Consumption 100~240V AC, 50~60Hz Active mode: 3. I Watts (max.) Standby mode: 0.5 Watts (max.) Operating: 0° ~ 40°C (32° ~ 104°F) Storage: -20° ~ 70°C (-4° ~ 158°F) Max. 90% (non-condensing) CE, FCC, HomePlug® AV \* Maximum of 6 adapters (nodes) for streaming video across your network.

\*\* 200Mbps is the maximum theoretical Powerline data rate. Actual throughput will vary depending on environment. \*\*\* Networked Powerline devices need to be plugged into power outlets that are on the same electrical system. \*\*\*\* GFCI outlets and AFCI circuit breakers may degrade Powerline network signals. © Copyright 2012 TRENDnet. All Rights Reserved. 22 TRENDnet User's Guide TPL-306E / TPL-306E2K If your building has more than one circuit breaker box, the Powerline adapter may not be able to establish connectivity between different circuit breaker boxes. In this Troubleshooting Please reference the items below if you continue to experience difficulty with installing and using your Powerline adapters. Try power cycling the unit by unplugging it from the wall power outlet for 15 seconds and plugging it back in. If the Powerline (PL) LED is red indicating good quality only, try plugging the Powerline adapter into another available wall power outlet to check if you can obtain better connection quality.

If you are having issues connecting the Powerline adapters after changing the encryption key using the Sync button or Powerline utility, reset the Powerline adapters to defaults using the physical Reset button. Use a pin or paperclip and push and hold the Reset button for 1 second on each Powerline adapter. All LEDs will turn off and turn back on. This will reset the Powerline adapters to their default settings, default encryption key assignment HomePlugAV. The Powerline adapters can provide better connectivity and performance when plugged directly into a wall power outlet instead of a power strip or surge protector. Connecting the Powerline adapters to a power strip or surge protector may degrade Powerline performance. Using the Powerline adapters on GFI protected outlets and electrical systems with AFCI circuit breakers as these items may degrade Powerline performance. The Powerline adapters should not be used in areas with excessive heat. Certain florescent or incandescent lights are noise sources on the electrical system and can degrade Powerline performance. case, connect a Powerline adapter into a wall power outlet located on each of the circuit breaker boxes, and then connect an Ethernet cable between the Powerline adapters to bridge the two circuits together.

This will allow the Powerline adapters from different circuit breaker boxes connect to each other. In addition to this User's Guide, you can find help below: <http://www.trendnet.com/support> (documentation, downloads, FAQs, how to contact technical support) Autorun CD (Quick Installation Guide) © Copyright 2012 TRENDnet. All Rights Reserved.

23 TRENDnet User's Guide TPL-306E / TPL-306E2K Move Powerline adapters between different overlapping Powerline networks Note: Assuming all powerline adapters are TRENDnet Powerline adapters and for reference in the diagram and this procedure, the adapters will be labeled Adapter A, B, C, D, and E. Adapters A, B, and C are currently connect together to form one powerline network and Adapters D and E form another powerline network. Adapter B will be disconnected from Adapters A and C and connected to Adapters D and E.



[You're reading an excerpt. Click here to read official TRENDNET TPL-306E user guide](http://yourpdfguides.com/dref/4129144)  
<http://yourpdfguides.com/dref/4129144>

*Appendix Overlapping Powerline networks It is possible to create multiple Powerline networks on the same electrical system separated and grouped by different network encryption keys. The Powerline networks will work and communicate independently of each other which can provide security between different groups of Powerline adapters.*

*For example, if you have five powerline adapters (Adapter A, Adapter B, Adapter C, Adapter D, Adapter E), you can group Adapters A,B, and C together on one powerline network and group Adapters D and E on a different Powerline network. Each group will use a different encryption key. Note: It is recommended that only a maximum of up to 4 Powerline networks can be created per electrical system. Any additional Powerline networks above the recommended may result in significant degradation in Powerline performance. 1. Push and hold the Sync button on Adapter B for 10 seconds and release it. All LEDs will turn off and turn back on. This will erase the current encryption key assigned to Adapter B and disconnect from Adapter A and Adapter C. 2. Push and hold the Sync button on Adapter D for 2 seconds and release it.*

*The Power (PWR) LED will start blinking. 3. Within 2 minutes, push and hold the Sync button on Adapter B for 2 seconds and release it. The Power (PWR) LED will start blinking. This will establish connectivity between Adapter B, Adapter D, and Adapter E by reconfiguring the encryption key of Adapter B to match the encryption key of Adapter D and Adapter E. All LEDs will turn off and turn back on and the Powerline (PL) LED will turn on when adapters are connected. © Copyright 2012 TRENDnet. All Rights Reserved. 24 TRENDnet User's Guide Federal Communication Commission Interference Statement This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.*

*This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.*

*Consult the dealer or an experienced radio/TV technician for help. TPL-306E / TPL-306E2K The availability of some specific channels and/or operational frequency bands are country dependent and are firmware programmed at the factory to match the intended destination. The firmware setting is not accessible by the end user. RoHS This product is RoHS compliant. FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.*

*This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Europe EU Declaration of Conformity*

*This device complies with the essential requirements of the Directive 2004/108/EC. The following test methods have been applied in order to prove presumption of conformity with the essential requirements of the Directive 2004/108/EC: EN 55022 : 2006 + A1 : 2007 EN 61000-3-3 : 2008 EN 50412-2-1 : 2005 EN 60950-1 : 2006 + A11 : 2009 IMPORTANT NOTE: FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. © Copyright 2012 TRENDnet. All Rights Reserved. 25 TRENDnet User's Guide noteikumiem. Cesky [Czech] Dansk [Danish] Deutsch [German] TRENDnet tínto prohlasuje, ze tento TPL-306E je ve shod se základními požadavky a dalšími příslušnými ustanoveními smrnice 2004/108/ES.*

*Undertegnede TRENDnet erklærer herved, at følgende udstyr TPL306E overholder de væsentlige krav og øvrige relevante krav i direktiv 2004/108/EF. Hiermit erklärt TRENDnet, dass sich das Gerät TPL-306E in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 2004/108/EG befindet. Käesolevaga kinnitab TRENDnet seadme TPL-306E vastavast direktiivi 2004/108/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele. Hereby, TRENDnet, declares that this TPL-306E is in compliance with the essential requirements and other relevant provisions of Directive 2004/108/EC. Por medio de la presente TRENDnet declara que el TPL-306E cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 2004/108/CE. TRENDnet TPL-306E 2004/108/. Par la présente TRENDnet déclare que l'appareil TPL-306E est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 2004/108/CE. Con la presente TRENDnet dichiara che questo TPL-306E è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 2004/108/CE. Ar so TRENDnet deklār, ka TPL-306E atbilst Direktīvas 2004/108/EK būtiskajām prasībām un citiem ar to saistītajiem Lietuvi [Lithuanian] Nederlands [Dutch] Malti [Maltese] Magyar [Hungarian] Polski [Polish] Português [Portuguese] Slovensko [Slovenian] Slovensky [Slovak] Suomi [Finnish] Svenska [Swedish] TPL-306E / TPL-306E2K Siuo TRENDnet deklaruoja, kad šis TPL-306E atitinka esminius reikalavimus ir kitas 2004/108/EB Direktyvos nuostatas. Hierbij verklaart TRENDnet dat het toestel TPL-306E in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 2004/108/EG.*

*Hawnhekk, TRENDnet, jiddikjara li dan TPL-306E jikkonforma maltiġġiet essenzjali u ma provvedimenti orajni relevanti li hemm fid-Dirrettiva 2004/108/EC.*

*Alulírott, TRENDnet nyilatkozom, hogy a TPL-306E megfelel a vonatkozó alapvető követelményeknek és az 2004/108/EC irányelv egyéb előírásainak. Niniejszym TRENDnet owiadcza, e TPL-306E jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 2004/108/EC.*



**[You're reading an excerpt. Click here to read official TRENDNET TPL-306E user guide](http://yourpdfguides.com/dref/4129144)**  
<http://yourpdfguides.com/dref/4129144>

TRENDnet declara que este TPL-306E está conforme com os requisitos essenciais e outras disposições da Directiva 2004/108/CE. TRENDnet izjavlja, da je ta TPL-306E v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 2004/108/ES.

TRENDnet týmto vyhlasuje, že TPL-306E spa základné požiadavky a všetky príslušné ustanovenia Smernice 2004/108/ES. TRENDnet vakuuttaa täten että TPL-306E tyyppinen laite on direktiivin 2004/108/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen. Härmed intyggar TRENDnet att denna TPL-306E står i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 2004/108/EG. Eesti [Estonian] English Español [Spanish] [Greek] Français [French] Italiano [Italian] Latviski [Latvian] © Copyright 2012 TRENDnet. All Rights Reserved.

26 TRENDnet User's Guide Limited Warranty TRENDnet warrants its products against defects in material and workmanship, under normal use and service, for the following lengths of time from the date of purchase. TPL-306E / TPL-306E2K 3 Years Warranty AC/DC Power Adapter, Cooling Fan, and Power Supply carry 1 year warranty. @@@@All products that are replaced become the property of TRENDnet. Replacement products may be new or reconditioned. TRENDnet does not issue refunds or credit. Please contact the point-of-purchase for their return policies. @@There are no user serviceable parts inside the product. @@This warranty is voided if (i) the product has been modified or repaired by any unauthorized service center, (ii) the product was subject to accident, abuse, or improper use (iii) the product was subject to conditions more severe than those specified in the manual. Warranty service may be obtained by contacting TRENDnet within the applicable warranty period and providing a copy of the dated proof of the purchase. Upon proper submission of required documentation a Return Material Authorization (RMA) number will be issued.

An RMA number is required in order to initiate warranty service support for all TRENDnet products. Products that are sent to TRENDnet for RMA service must have the RMA number marked on the outside of return packages and sent to TRENDnet prepaid, insured and packaged appropriately for safe shipment.

Customers shipping from outside of the USA and Canada are responsible for return shipping fees. Customers shipping from outside of the USA are responsible for custom charges, including but not limited to, duty, tax, and other fees. **WARRANTIES EXCLUSIVE: IF THE TRENDNET PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, THE CUSTOMER'S SOLE REMEDY SHALL BE, AT TRENDNET'S OPTION, REPAIR OR REPLACE. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING © Copyright 2012 TRENDnet. All Rights Reserved. Limited Warranty WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. TRENDNET NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION MAINTENANCE OR USE OF TRENDNET'S PRODUCTS. TRENDNET SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THAT THE ALLEGED DEFECT IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER'S OR ANY THIRD PERSON'S MISUSE, NEGLIGENCE, IMPROPER INSTALLATION OR TESTING, UNAUTHORIZED ATTEMPTS TO REPAIR OR MODIFY, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, OR OTHER HAZARD.**

**LIMITATION OF LIABILITY: TO THE FULL EXTENT ALLOWED BY LAW TRENDNET ALSO EXCLUDES FOR ITSELF AND ITS SUPPLIERS ANY LIABILITY, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATE, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF THE POSSIBILITY OF SUCH DAMAGES, AND LIMITS ITS LIABILITY TO REPAIR, REPLACEMENT, OR REFUND OF THE PURCHASE PRICE PAID, AT TRENDNET'S OPTION. THIS DISCLAIMER OF LIABILITY FOR DAMAGES WILL NOT BE AFFECTED IF ANY REMEDY PROVIDED HEREIN SHALL FAIL OF ITS ESSENTIAL PURPOSE.** Governing Law: This Limited Warranty shall be governed by the laws of the state of California. Some TRENDnet products include software code written by third party developers. These codes are subject to the GNU General Public License ("GPL") or GNU Lesser General Public License ("LGPL").

Go to <http://www.trendnet.com/gpl> or <http://www.trendnet.com> Download section and look for the desired TRENDnet product to access to the GPL Code or LGPL Code.

These codes are distributed WITHOUT WARRANTY and are subject to the copyrights of the developers. TRENDnet does not provide technical support for these codes. Please go to <http://www.gnu.org/licenses/gpl.txt> or <http://www.gnu.org/licenses/lgpl.txt> for specific terms of each license. PWP05202009v2 2011/10/18 27.



[You're reading an excerpt. Click here to read official TRENDNET](#)

[TPL-306E user guide](#)

<http://yourpdfguides.com/dref/4129144>