



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for VTECH CS5111. You'll find the answers to all your questions on the VTECH CS5111 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual VTECH CS5111**  
**User guide VTECH CS5111**  
**Operating instructions VTECH CS5111**  
**Instructions for use VTECH CS5111**  
**Instruction manual VTECH CS5111**

Before using this telephone, please read the **important safety instructions** on page 22 of this manual.

For support, shopping, and everything new at VTech, visit our website at [www.vtechphones.com](http://www.vtechphones.com). In Canada, please visit [www.vtechcanada.com](http://www.vtechcanada.com).



The ENERGY STAR<sup>®</sup> program ([www.energystar.gov](http://www.energystar.gov)) recognizes and encourages the use of products that save energy and help protect our environment. We are proud to mark this product with the ENERGY STAR<sup>®</sup> label indicating it meets the latest energy efficiency guidelines.



Telephones identified with this logo have reduced noise and interference when used with most T-coil equipped hearing aids and cochlear implants. The TIA-1083 Compliant Logo is a trademark of the Telecommunications Industry Association. Used under license.



[You're reading an excerpt. Click here to read official VTECH CS5111 user guide](http://yourpdfguides.com/dref/1305011)  
<http://yourpdfguides.com/dref/1305011>

**Manual abstract:**

*T TIA-1083 Table of contents Getting started . . . . .*

*. 1 Parts checklist . . . . .*

*. . . 1 Telephone base installation . . . . .*

*2 Battery installation and charging . . . 3 Wall bracket installation . .*

*. . . 3 Wall bracket installation . . . . .*

*. 3 Desktop/tabletop bracket installation . . . . .*

*. . . 4 Handset layout . .*

*. . . . . 5 Telephone base layout . . . . .*

*. 6 Telephone settings . . . . .*

*. . . . . 7 Date and time . .*

*. 7 Ringer . . . . .*

*7 Ringer volume . . . . .*

*. . . . . 7 Dial mode . . . . .*

*. . . 8 Home area code . .*

*. . . . 8 Language . . . . .*

*. . . . . 9 Clear voicemail . . . . .*

*. . 9 Telephone operation . . .*

*. . 10 Make calls . . . . .*

*. 10 Answer calls . . . . .*

*. . . . . 10 End calls . .*

*. . . . 10 Volume . . . . .*

*. 10 Channel . . . . .*

*. . 10 Call waiting . . . . .*

*. 10 Temporary tone dialing . . . . .*

. 10 Redial . . . . .	.....
. . . . .	.....
. . . . .	.....
. . . . . 11 Find handset. . . . .	.....
. . . . .	.....
. . . . . 11 Directory. . . . .	.....
. . . . .	.....
. . . . .	.....
. . . . . 11 Store a directory entry . . . . .	.....
. . . . . 11 Character chart . . . . .	.....
. . . . .	.....
. . . . . 12 Review the directory. . . . .	.....
. . . . .	.....
. . . . . 12 Edit a directory entry . . . . .	.....
. . . . .	.....
. . . . . 12 Delete a directory entry . . . . .	.....
13 Copy a directory entry into speed dial . . . . .	.....
. . . . .	.....
. . . . . 14 Dial a number from the directory . . . . .	.....
14 Speed dial . . . . .	.....
. . . . . 14 Store a speed dial entry . . . . .	.....
. . . . .	.....
. . . . . 14 Edit a speed dial entry . . . . .	.....
. . . . . 15 Delete a speed dial entry . . . . .	.....
. . . . . 16 ii Dial a speed dial number . . . . .	.....
. . . . . 16 Reassign speed dial locations . . . . .	.....
. . . . . 16 About caller ID . . . . .	.....
. . . . .	.....
. . . . . 16 Call log . . . . .	.....
. . . . .	.....
. . . . .	.....
. . . . . 17 Review the call log . . . . .	.....
. . . . .	.....
. . . . . 17 Make call log entries ready to dial . . . . .	.....
. . . . .	.....
. . . . . 18 Dial a call log number. . . . .	.....
. . . . .	.....
. . . . . 18 Save a call log entry to the directory . . . . .	.....
. . . . .	.....
. . . . .	.....
18 Delete from the call log . . . . . 19 Delete an entry . . . . .	.....
. . . . .	.....
. . . . . 19 Delete all entries . . . . .	.....
. . . . .	.....
. . . . . 19 Call log display screen messages . . . . .	.....
. . . . .	.....
. . . . .	.....
. . . . . 19 Appendix . . . . .	.....
. . . . .	.....
. . . . .	.....
. . . . . 20 Handset display screen messages . . . . .	.....
. . . . .	.....
. . . . .	.....
. . . . . 20 Battery . . . . .	.....
. . . . .	.....
. . . . .	.....
. . . . . 21 Important safety instructions . . . . .	.....

... 22 Troubleshooting .

.....

... 23 Operating range .....

.....

... 28 Maintenance.

.....

..... 28 About cordless telephones. . .

... 28 Warranty.

.....

.....

..... 29 FCC, ACTA and IC regulations . . . 31 The RBRC ® seal. .

.....

.....

... 32 Technical specifications .....

.. 33 Index.....

.....

.....

..... 34 Getting started Parts checklist Your telephone contains the following items. Save your sales receipt and original packaging in the event warranty service is necessary. CHARGE A BC D EF JKL MNO PQRS TUV W XYZ TONE OPER 1. Handset 2.

Telephone line cord 3. Telephone base power adapter 4. Battery compartment cover 5. Battery 6. Telephone base with wall bracket 7. User's manual · To purchase replacement batteries or power adapters, visit our website at [www.vtechphones.com](http://www.vtechphones.com) or call 1 (800) 595-9511. In Canada, go to [www.vtechcanada.com](http://www.vtechcanada.com) or call 1 (800) 267-7377. 1 Getting started Telephone base installation If you subscribe to high-speed Internet service (Digital Subscriber Line - DSL) through your telephone lines, you must install a DSL filter between the telephone base and the telephone wall jack to prevent noise and caller ID problems caused by DSL interference. Please contact your DSL service provider for more information about DSL filters. Telephone wall jack DSL filter (not included) required if you have DSL high-speed Internet service Telephone base power adapter Electrical outlet (not controlled by a wall switch) Telephone line cord Telephone base · Use only the power adapters supplied with this product. To order a replacement, visit our website at [www.vtechphones.com](http://www.vtechphones.com) or call 1 (800) 595-9511. In Canada, go to [www.vtechcanada.com](http://www.vtechcanada.com) or call 1 (800) 267-7377.

· The power adapters are intended to be correctly oriented in a vertical or floor mount position. 2 Getting started Battery installation and charging Install the battery as shown below. The battery may have enough charge for short calls and then completely charge and drain the battery two or three times every three months afterwards. For best performance, charge the battery for at least 16 hours before first use. When the battery power is low, LOW BATTERY is displayed and flashes on the handset screen. 1. Insert the plug of the battery as indicated. Make sure it is plugged securely and matches the color-coded label inside the battery compartment. 2. Place the battery with the label THIS SIDE UP facing up, and the wires inside the battery compartment.

3. Align the battery compartment cover flat against the battery compartment, then slide it upwards until it clicks into place. 4. Charge the handset by placing it in the telephone base. The handset charge light is on when charging. 1 2 3 4 CHARGE A BC D EF JKL MNO PQRS TUV W XYZ TONE OPER · If the handset will not be used for a long period of time, remove the battery to prevent possible leakage. · To purchase replacement batteries, visit our website at [www.vtechphones.com](http://www.vtechphones.com) or call 1 (800) 595-9511. In Canada, go to [www.vtechcanada.com](http://www.vtechcanada.com) or call 1 (800) 267-7377.

Wall bracket installation Your telephone base comes with the wall bracket installed, ready for desktop use. You may also mount your telephone onto a standard telephone wall plate. Wall bracket installation: To prepare the telephone base for wall mounting, you need to remove the bracket if it is currently attached for desktop use.

Press the tabs located on the legs of the bracket to loosen, then lift the bracket up and away from the telephone base. 3 Getting started Wall bracket installation (continued) Wall bracket installation: 1. First, insert the lower portion tabs of the wall bracket into the lower grooves in the telephone base, then snap the upper portion tabs of the wall bracket into place. 2. Mount the telephone base on the wall by positioning it so the mounting studs fit into the holes on the telephone base and wall bracket.

Slide the telephone base down on the mounting studs until it locks into place. 3. To remove the bracket, press both upper portion tabs firmly and pull the bracket downward until it releases from the grooves. upper portion tabs Wall bracket AC 7.5V lower portion tabs lower groove Wall bracket in wall mount orientation upper grooves Desktop/tabletop bracket installation: Your telephone comes ready for table use. If you have repositioned the bracket for wall mounting and now want to return to table use, follow these steps: 1. Insert the lower portion tabs of the wall bracket into the upper grooves of the telephone base. 2. Snap the upper portion tabs of the wall bracket into place. 3.

To remove the wall bracket, press both upper portion tabs firmly inward and pull the wall bracket upward until it is released from the grooves. AC 7.5V 4 Getting started Handset layout CHARGE light · On when the handset is charging in the telephone base.



[You're reading an excerpt. Click here to read official VTECH CS5111 user guide](#)

<http://yourpdfguides.com/dref/1305011>

*/VOL-/CID* · When the telephone is not in use, press to review the call log. · Press and hold to adjust the ringer volume when the telephone is not in use. · During a call, press to lower the listening volume. A double beep sounds at the lowest setting. · Press to scroll down while in programming mode or reviewing the redial list. */VOL+/* · Press to display the directory when the telephone is not in use. · Press and hold to adjust the ringer volume when the telephone is not in use.

· During a call, press to increase the listening volume. A double beep will sound when the highest setting is reached. · Press to scroll up while in programming mode or reviewing the redial list. *SELECT* · Press to store a programming option or a directory entry. *OFF* · During a call, press to hang up. · While the handset is ringing, press to silence the ringer. · Press and hold for two seconds when the telephone is not in use to erase the *MISSED CALLS* display. · During programming, press to exit without making changes. · Press to make or answer a call. · During a call, press to receive an incoming call when you receive a call waiting alert.

*TONE* · Press to switch to tone dialing temporarily when using the pulse service (page 10). *CHAN/REMOVE* · Switch to a clearer channel while on a call. · Press and hold to delete all records in the call log when the phone is not in use. · When reviewing the call log or redial list, press to delete the desired record. *PROG* · Press to enter programming mode while the telephone is not in use. *CHARGE \*A BC D EF JKL MNO PQRS TUV W XYZ TONE OPER #* · Press repeatedly to display other dialing options when reviewing the call log (page 18). · Press to use the *CLR VOICEMAIL* feature from the main menu. *REDIAL/PAUSE* · Press repeatedly to review the redial list. · While dialing or entering numbers into the directory, press to insert a dialing pause. 5 Getting started Telephone base layout *IN USE* light · Flashes when there is an incoming call.

· On when the handset is in use. *VOICEMAIL* light · Flashes when you have new voicemail from your telephone company. *FIND HANDSET* · Press to page the handset. 6 Telephone settings Date and time If you subscribe to caller ID service, the date and time is set automatically with the next incoming call. If you do not have caller ID service, you can set the date and time manually. 1. Press *PROG* when the handset is not in use. 2. Press or until *DATE/TIME* is displayed. Press *SELECT*. until the screen displays the correct until the screen displays the correct until the screen displays the correct until the screen displays the 3. When the month is flashing, press or correct month and then press *SELECT*. 4. When the date is flashing, press date and then press *SELECT*. 5. When the hour is flashing, press hour and then press *SELECT*. or or 6. When the minute is flashing, press or correct minute and then press *SELECT*. 7. When *AM* or *PM* is flashing, press or to choose between *AM* or *PM* and then press *SELECT*. You will hear a confirmation tone. · When there is a power failure, the time may need to be reset. Ringer You can select from different ringers. 1. Press *PROG* when the handset is not in use. 2. Press or until the screen displays *RINGER:* and the current setting. 3. Press *SELECT*. The current setting flashes, and you will hear a sample of the ringer.

4. Press or to select *RINGER:* 1, 2, 3, or 4. You will hear a sample of each ring tone. 5. Press *SELECT* to confirm your selection. You will hear a confirmation tone. Ringer volume You can change the ringer volume to a comfortable level or turn the ringer off. 1. Press *PROG* when the handset is not in use. Press or until the screen displays *RINGER VOL:* and the current setting. 2. Press *SELECT*. The current setting flashes, and you will hear a 3. Press sample of the ringer volume. or to select ringer volume froall waiting If you subscribe to call waiting service and you are on a call when a new call comes in, you will hear a beep. The caller ID information is displayed if you subscribe to combined caller ID with call waiting service from your local telephone company. · Press on the handset to put the current call on hold and answer the incoming call. · Press at anytime to alternate between calls. Temporary tone dialing If you have pulse (rotary) service, you can change from pulse to touch tone dialing during a call by pressing *TONE\**. This is useful if you need to send touch tone signals to access telephone banking or long distance services. Once you have initiated your call by dialing the phone number in pulse (rotary), press *TONE\**. Now, all subsequent key presses are sent as touch tone signals. After you hang up, the phone returns to pulse (rotary) dialing for the next call. 10 Telephone operation Redial · The telephone stores the five most recently dialed telephone numbers in the redial list. When the list is full, the oldest entry is deleted to make room for the new entry. · Press *REDIAL/PAUSE*, then press , or *REDIAL/PAUSE* repeatedly to review the redial list. Press *CHAN/REMOVE* to delete the displayed number. · Press , then press *REDIAL/PAUSE* to dial the last telephone number dialed. -ORPress *REDIAL/PAUSE*, then press , or *REDIAL/PAUSE* repeatedly until the desired entry displays, then press to dial the number. Find handset · Press *FIND HANDSET* on the telephone base to locate the handset when the telephone is not in use and the handset is not placed in the telephone base.

The handset rings and **\*\*PAGING\*\*** will be displayed on its screen. · Press *FIND HANDSET* again or put the handset back on the telephone base to stop the paging tone. -ORPress *OFF* on the handset. Directory The directory can store up to 20 entries (including nine speed dial entries). Each entry may consist of a number up to 24 digits and a name up to 14 characters. Store a directory entry 1. Press *PROG* when the handset is not in use. The screen displays *DIRECTORY*. 2. Press *SELECT*. The screen displays *ENTER NAME*. 3. Use the dial pad keys to enter the name. See the Character chart on page 12. · Press to move the cursor to the left or to the right. · Press *CHAN/REMOVE* to erase a character. 4. When finished, press *SELECT* or *PROG*. The screen displays *ENTER NUMBER*. 5. Use the dial pad keys to enter the telephone number. · Press to move the cursor to the left or to the right. · Press *CHAN/REMOVE* to erase a digit. · Press *REDIAL/PAUSE* to insert a dialing pause (*P* is displayed). 6. Press *SELECT* or *PROG*. The screen displays *DISTINCT RING?* and the current setting. 7. Press or to choose *Y* (yes) if you wish to customize this entry or choose *N* (no) for a normal ringer. If you choose *Y*, a is displayed with the directory entry. 8. Press *SELECT* or *PROG* to confirm and you hear a confirmation tone. 11 Telephone operation Character chart Use the dial pad keys and the chart below to enter a name (up to 14 characters).



[You're reading an excerpt. Click here to read official VTECH CS5111 user guide](http://yourpdfguides.com/dref/1305011)  
<http://yourpdfguides.com/dref/1305011>

An error tone sounds if you try to enter more than 14 characters. Each press of a particular key causes the characters to be displayed in the following order: Dial key 1 2 3 4 5 6 7 8 9 0 \* # Characters by number of key presses 1 1 A D G J M P T W 0 \* & , , . # B E H K N Q U X C F I L O R V Y 2 3 4 5 6 S 8 Z 9 7 2 3 4 5 6 Review the directory 1. Press /VOL+/- when the handset is not in use. The screen displays DIRECTORY. 2. Press or to scroll through the entries stored in the directory alphabetically.

-ORPress the dial pad key for the first letter of the name you want to search. If necessary, scroll or to find the desired entry. · When you reach the end of the list in the directory, END OF LIST is shown on the screen and there is an error tone. · If you press a dial pad key for alphabetical search while in the directory and there are no entries starting with the letters of that key, NO DATA is displayed on the screen. Edit a directory entry 1.

Press /VOL+/- when the handset is not in use. The screen displays DIRECTORY. 2. Press or to scroll through the entries stored in the directory alphabetically. -ORPress the dial pad key for the first letter of the entry you want to edit.

If necessary, scroll or to find the desired entry. 12 Telephone operation Edit a directory entry (continued) 3. When the screen displays the desired entry, press SPEED EDIT DEL SELECT and EDIT flashes. 8005959511 4. Press SELECT. The screen displays the name and number. The cursor appears at the beginning of the name. · Use the dial pad keys to edit the name. · Press to move the cursor to the left or to the right. · Press CHAN/REMOVE to erase a character.

5. Press SELECT to move on to the phone number. · Use the dial pad keys to edit the number. · Press to move the cursor to the left or to the right. · Press CHAN/REMOVE to erase a digit. · Press REDIAL/PAUSE to insert a dialing pause (P will be displayed). 6. Press SELECT. The screen displays DISTINCT RING? and the current setting. 7.

Press or to choose Y (yes) to customize this entry, or choose N (no) for a normal ringer. If you choose Y, a will be displayed with the directory entry. 8. Press SELECT to confirm and you will hear a confirmation tone. Delete a directory entry 1.

Press /VOL+/- when the handset is not in use. The screen displays DIRECTORY. 2. Press or to scroll through the entries stored in the directory alphabetically. -ORPress the dial pad key for the first letter of the entry to delete.

If necessary, scroll or to find the desired entry. 3. When the screen displays the desired entry, press SPEED EDIT DEL SELECT. Then press or until DEL (delete) 8005959511 flashes. 4. Press SELECT. The screen displays ERASE NO YES and the number. The current choice flashes. 5. Press until YES flashes.

6. Press SELECT. You will hear a confirmation beep. 13 Telephone operation Copy a directory entry into speed dial 1. Press /VOL+/- when the handset is not in use. The screen displays DIRECTORY. 2. Press or to scroll through the entries stored in the directory alphabetically. -ORPress the dial pad key for the first letter of the entry to copy. If necessary, scroll or to find the desired entry.

3. When the screen displays the desired entry, press SPEED EDIT DEL SELECT. Then press or until SPEED flashes. 8005959511 4. Press SELECT. The screen displays ENTER 1-9. 5. Press a key (1-9) to copy this entry from the directory to the speed dial memory and assign the memory location. You will hear a confirmation beep. A memory location number (01 through 09) will be displayed with this entry.

Dial a number from the directory 1. Press /VOL+/- when the handset is not in use. The screen displays DIRECTORY. 2. Press or to scroll through the entries stored in the directory alphabetically. -ORPress the dial pad key for the first letter of the desired entry. If necessary, scroll or to find the desired entry. 3.

When the screen displays the desired entry, press . Speed dial Your telephone can store up to nine telephone numbers with names (up to 14 characters and 24 digits in each location) in the speed dial memory locations you assign in the handset.

Store a speed dial entry 1. Press PROG when the handset is not in use and then press screen displays SPEED DIAL. 2. Press SELECT. The screen displays ENTER 1-9. 3. Press a key (1 through 9) to assign the speed dial location to store this number. The screen displays ENTER NAME. 4. Use the dial pad keys to enter the name (see the Character chart on page 12) and then press SELECT or PROG.

· Press to move the cursor to the left or to the right. · Press CHAN/REMOVE to erase a character. 14 or until the Telephone operation Store a speed dial entry (continued) 5. The screen displays ENTER NUMBER. 6.

Use the dial pad keys to enter the telephone number, and then press SELECT or PROG. · Press to move the cursor to the left or to the right. · Press CHAN/REMOVE to erase a digit. · Press REDIAL/PAUSE to insert a dialing pause (P will be displayed). 7.

The screen displays DISTINCT RING? and the current setting. 8. Press or to choose Y (yes) to customize this entry, or choose N (no) for a normal ringer. If you choose Y, a will be displayed with the entry. 9. Press SELECT or PROG to confirm. You will hear a confirmation tone. · The entries stored in the speed dial memory will be numbered 01 through 09 and share the memory in the directory. · Press OFF at any time to exit speed dial mode. · If the location is not empty, the new entry will replace the old entry and the old entry will be moved to a directory location.

Edit a speed dial entry 1. Press and hold the speed dial location key (1-9) of the desired entry when the handset is not in use. 2. When the screen displays the entry to edit, press SPEED EDIT DEL SELECT and EDIT flashes. 8005959511 3. Press SELECT. The screen displays the name and 01 number. The cursor appears at the beginning of the name. Use the dial pad keys to edit the name. · Press to move the cursor to the left or to the right.

· Press CHAN/REMOVE to erase a character. 4. Press SELECT to move on to the phone number. Use the dial pad keys to edit the number. · Press to move the cursor to the left or to the right.

· Press CHAN/REMOVE to erase a digit. · Press REDIAL/PAUSE to insert a dialing pause (P will be displayed). 5. Press SELECT. The screen displays DISTINCT RING? and the current setting.

6. Press or to choose Y (yes) to customize this entry, or choose N (no) for a normal ringer. If you choose Y, a will be displayed with the directory entry. 7. Press SELECT to confirm. You will hear a confirmation tone. 15 Telephone operation Delete a speed dial entry 1. Press and hold the speed dial location key (1-9) of the desired entry when the handset is not in use. 2. When the screen displays the desired entry, press SELECT.

Then press or until DEL (delete) flashes. SPEED EDIT DEL 8005959511 01 3. Press SELECT. The screen displays ERASE NO YES and the number. The current choice flashes.



[You're reading an excerpt. Click here to read official VTECH CS5111 user guide](http://yourpdfguides.com/dref/1305011)  
<http://yourpdfguides.com/dref/1305011>



4. Press until YES flashes. 5. Press SELECT. You will hear a confirmation beep.

Dial a speed dial number 1. Press and hold a speed dial location key (1-9) of the desired entry when the handset is not in use. 2. Press to dial the displayed number. Reassign speed dial locations 1.

Press and hold the speed dial location key (1-9) of the desired entry when the handset is not in use. 2. When the screen displays the desired entry, press SPEED EDIT DEL SELECT. Press or until SPEED flashes. 8005959511 3.

Press SELECT. The screen displays ENTER 1-9. 01 4. Press a key (1-9) to reassign this entry into another memory location. You will hear a confirmation beep. About caller ID The caller ID with call waiting feature in this telephone lets you see the name and telephone number of the caller before answering the call, even when already on a call. These features require services provided by your local telephone company. Contact your telephone company if: · you have both caller ID and call waiting, but as separate services (you may need combined service), · you have only caller ID service, or only call waiting service, or · you do not subscribe to any caller ID or call waiting services but wish to try these services. You can use this telephone with regular caller ID service, and you can use its other features without subscribing to either caller ID or combined caller ID with call waiting service. There may be fees for these services, and these services may not be available in all areas.

The caller ID features will work only if both you and the caller are in areas offering caller ID service, and if both telephone companies use compatible equipment. 16 Telephone operation Call log Caller's name Caller's telephone number VTECH 800-595-9511 NEW05 6:10AM 08/17 New call log indicator and location in the call log Time of call Date of call If you subscribe to caller ID service, information about each caller will be displayed after the first or second ring. · The call log can store up to 45 entries. · When the call log is full, the earliest entry will be deleted to make room for new incoming call information. · CID EMPTY will be displayed if there is no record in the call log. · If you answer a call before the information appears on the screen, it will not be stored in the call log. · The time on the handset screen is automatically set and updated with incoming caller ID information if you subscribe to this service. · Due to regional service differences, the caller ID information may not be available for every incoming call. In addition, the callers may intentionally block their names and/or telephone numbers. Review the call log 1.

Press /VOL-/CID to view the call log. 2. Press or to scroll through the entries. There will be an error tone at the end of the call log list and the screen will display END OF LIST. · If you have programmed a home area code (page 8), only the last seven digits of the incoming phone numbers from that area code will be displayed while reviewing the call log.

Press # repeatedly to display all possible dialing options. 17 Telephone operation Make call log entries ready to dial Although the call log entries received have 10 digits (the area code plus the seven-digit number), in some areas, you may dial only the seven digits, or a 1 plus the seven digits, or a 1 plus the area code plus the seven digits. You can change the number of digits that you dial from or store in the call log. While reviewing the call log, press # repeatedly to display different dialing options for local and long distance numbers before dialing or saving the telephone number in the directory. See the example on the right.

You may also press 1 repeatedly to add or remove a 1 in front of the telephone number before dialing or saving it in the directory. See the examples on the right. When the number displayed is in the correct format for dialing, press to call the number. 800-595-9511 1-800-595-9511 595-9511 1-595-9511 800-595-9511 1-800-595-9511 595-9511 1-595-9511 · If you have programmed a home area code (page 8), only the last seven digits of the incoming phone numbers from that area code will be displayed while reviewing the call log. Press # repeatedly to display all possible dialing options. Dial a call log number 1. Press /VOL-/CID to enter the call log when the telephone is not in use. 2. Press or to select the desired entry, then press . -ORI.

Press /VOL-/CID to enter the call log when the telephone is not in use. 2. Press or to select the desired entry. 3. Press SELECT, then DIAL flashes. 4. Press or SELECT. Save a call log entry to the directory 1. Press /VOL-/CID to enter the call log when the telephone is not in use. 2.

Press or to select the desired entry. If you wish to change how the number is saved, press # 800-595-9511 repeatedly until the desired option displays. See NEW28 the Make call log entries ready to dial section on 5:40PM 12/30 page 18. 3. Press SELECT, then press or until PROGRAM DIAL PROGRAM 800-595-9511 flashes.

NEW28 4. Press SELECT again. 5:40PM 12/30 18 Telephone operation Save a call log entry to the directory (continued) 5. Enter or edit the name if necessary. See the Character chart on page 12.

· Press to move the cursor to the left or to the right. · Press CHAN/REMOVE to erase a character. Press SELECT to move on to the phone number. 6. Edit the number if necessary. · Press to move the cursor to the left or to the right. · Press CHAN/REMOVE to erase a digit. · Press REDIAL/PAUSE to insert a dialing pause (P will be displayed). Press SELECT to continue. 7.

Press or to choose Y (yes) to customize this DISTINCT RING? N entry, or choose N (no) for a normal ringer. If you 8005959511 choose Y, a will be displayed with the directory entry. 8. Press SELECT to confirm. You will hear a confirmation tone. Delete from the call log Delete an entry: 1. Press /VOL-/CID to enter the call log when the telephone is not in use. 2. Press or to select the entry to be deleted. 3.

Press CHAN/REMOVE. You will hear a confirmation beep. Delete all entries: 1. Press and hold CHAN/REMOVE when the telephone is not in use. The screen displays ERASE ALL? N Y.

The current choice flashes. 2. Press until Y (yes) flashes. 3. Press SELECT.

You will hear a confirmation beep. Call log display screen messages Displays: PRIVATE NAME PRIVATE NUMBER PRIVATE CALLER UNKNOWN NAME UNKNOWN NUMBER UNKNOWN CALLER When: The caller is blocking the name information. The caller is blocking the telephone number information.

The caller is blocking the name and number information. This caller's name is unavailable. This caller's number is unavailable. No call information is available about this caller. 19 Appendix Handset display screen messages Displays: LOW BATTERY CID EMPTY CONNECTING...

DIRECTORY EMPTY MEMORY FULL XX MISSED CALLS NEW VOICEMAIL \*\*PAGING\*\* PHONE \*\*RINGING\*\* RINGER OFF SCANNING... When: The battery needs to be recharged.



[You're reading an excerpt. Click here to read official VTECH CS5111 user guide](http://yourpdfguides.com/dref/1305011)  
<http://yourpdfguides.com/dref/1305011>

There are no call log entries. The cordless handset is searching for the telephone base. There are no directory entries. The directory is full. There are unreviewed calls in the call log. There are new voicemail message(s) from the local telephone company.

The cordless handset locator has been activated. The handset is in use. There is an incoming call. The handset ringer is turned off. The telephone base is searching for another available channel.

20 Appendix Battery After the battery is fully charged for 16 hours, you can expect the following performance: Operation While in use (talking) While not in use (standby\*) \*Handset is off the telephone base but not in use. Operating time Five hours Six days The battery needs charging when: · A new battery is installed in the handset. · The handset beeps when taken off the telephone base. · LOW BATTERY is displayed and the battery icon on the handset screen is flashing. CAUTION: · Use only the battery(ies) provided or equivalent.

To order a replacement, visit our website at [www.vtechphones.com](http://www.vtechphones.com) or call 1 (800) 595-9511. In Canada, go to [www.vtechcanada.com](http://www.vtechcanada.com) or call 1 (800) 267-7377. · Do not dispose of the battery(ies) in a fire. Check with local waste management codes for special disposal instructions. · Do not open or mutilate the battery(ies). · Exercise care in handling batteries in order not to create a short circuit with conductive materials such as rings, bracelets, and keys.

The battery and/or conductor may overheat and cause burns. · Charge the battery(ies) provided with or identified for use with this product only in accordance with the instructions and limitations specified in this manual. WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO WATER OR ANY TYPE OF MOISTURE. 21 Appendix Important safety instructions When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury, including the following: 1. Read, understand, and follow all warnings and instructions marked on the product and in this manual. 2. Unplug this product from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning. 3.

Do not use this product near water (for example, near a bathtub, kitchen sink, or swimming pool). Never spill liquid of any kind on the product. 4. Do not place this product on an unstable table, shelf, stand or other unstable surfaces. 5.

Slots and openings in the back or bottom of the telephone base and handset are provided for ventilation. To protect them from overheating, these openings must not be blocked by placing the product on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a radiator or heat register. This product should not be placed in any area where proper ventilation is not provided. 6.

This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply in your home, consult your dealer or local power company. 7. Do not allow anything to rest on the power cord. Do not install this product where the cord may be walked on. 8. Never push objects of any kind into this product through the slots in the telephone base or handset as they may touch dangerous voltage points or create a short circuit that could result in a risk of fire or electric shock. 9. To reduce the risk of electric shock, do not disassemble this product, but take it to an authorized service facility. Opening or removing parts of the telephone base or handset other than specified access doors may expose you to dangerous voltages or other risks.

Incorrect reassembling can cause electric shock when the product is subsequently used, or if the product exhibits a distinct change in performance. 10. Do not overload wall outlets and extension cords as this can result in the risk of fire or electric shock. 11. Unplug this product from the wall outlet and refer servicing to an authorized service facility under the following conditions: A. When the power supply cord or plug is damaged or frayed. B. @@@C. @@@@D. @@@13.

@@@There is a remote risk of electric shock from lightning. 14. @@15. @@16. @@@@My telephone does not work at all .

@@@@@ · Unplug the unit's electrical power. Wait for approximately 15 seconds, then plug it back in. @@ · Charge the battery in the handset for at least 16 hours. · Remove and re-insert the battery. @@@@If this telephone does not work, call the local telephone company.

LOW BATTERY is displayed on screen . · Place the handset in the telephone base for recharging. @@@@ · Remove the battery from the handset and then re-install it in the handset. Put the handset back to the telephone base and charge for 16 hours. · If the handset is in the telephone base but the handset CHARGE light is not on, see The CHARGE light is off in this section. · It may be necessary to purchase a new battery. Please see the Battery section of this user's manual (page 21). · The telephone might be malfunctioning. Please see the Warranty section of this user's manual (page 29) for further instruction. The CHARGE light is off .

· Clean the charging contacts on the handset(s) and telephone base each month using a pencil eraser or a dry non-abrasive fabric. · Make sure the power adapter and telephone line cords are plugged in correctly and securely. · Unplug the power adapter. Wait for 15 seconds before plugging it back in. Allow up to one minute for the handset and telephone base to reset. · The telephone might be malfunctioning. Please see the Warranty section of this user's manual (page 29) for further instruction. 23 Appendix Troubleshooting The talk time and standby time of my handset is noticeably shorter than before . · Completely charge and drain the battery two or three times consecutively every three months instead of returning the handset to the telephone base or charger after each use. If the performance does not improve, please buy a new battery.

There is no dial tone . · First, try all the above suggestions. · Move the handset closer to the telephone base. It might be out of range. · The telephone line cord might be malfunctioning.

Try installing a new telephone line cord. · Disconnect the telephone base from the telephone jack and connect a different telephone. If there is no dial tone on the other telephone either, contact your local telephone company. My handset displays CONNECTING . .

· Move the handset closer to the telephone base. You might have moved out of range. The telephone does not ring when there is an incoming call . · Make sure the ringer is on (page 7). · Make sure the telephone line cord and power adapter are plugged in properly (page 2). · The handset may be too far from the telephone base. Move it closer to the telephone base. · There may be too many extension telephones on the telephone line to allow all of them to ring simultaneously.



[You're reading an excerpt. Click here to read official VTECH CS5111 user guide](#)

<http://yourpdfguides.com/dref/1305011>



Try unplugging some of them.

· If the other telephones in your home are having the same problem, contact the local telephone company (charges may apply). · Other electronic products can cause interference to your cordless telephone. Try installing your telephone as far away as possible from the following electronic devices: wireless routers, radios, radio towers, pager towers, cellular telephones, digital telephones, intercoms, room monitors, televisions, VCRs, personal computers, kitchen appliances, and other cordless telephones. · Test a working telephone at the telephone jack. If another telephone has the same problem, contact your local telephone company (charges may apply). · The telephone line cord might be malfunctioning. Try installing a new telephone line cord. · Remove and re-insert the battery and place the handset in the telephone base. · Wait for the handset to synchronize with the telephone base. Allow up to one minute for this to take place.

24 Appendix Troubleshooting I cannot dial out . · First, try all the above suggestions. · Make sure there is a dial tone before dialing. It is normal if the handset takes a second or two to synchronize with the telephone base before producing a dial tone. Wait an extra second before dialing.

· Make sure the telephone is set to the correct dial type (pulse dial or tone dial) for the service in your area. See Dial mode on page 8 to set the dial type. · If the other telephones in your home are having the same problem, contact your local telephone company (charges may apply). · Eliminate any background noise. If you cannot eliminate the background noise, first try muting the handset before dialing, or dialing from another room in your home with less background noise.

There is noise or interference during a telephone conversation . My calls cut in and out when I am using the cordless handset . · The handset may be out of range. Move it closer to the telephone base. · Appliances or other cordless telephones plugged into the same circuit as the telephone base can cause interference. Try moving the appliance or telephone base to another outlet. · Other electronic products can cause interference to your cordless telephone. Try installing your telephone as far away as possible from the following electronic devices: wireless routers, radios, radio towers, pager towers, cellular telephones, digital telephones, intercoms, room monitors, televisions, VCRs, personal computers, kitchen appliances, and other cordless telephones. · If your telephone is plugged in with a modem or a surge protector, plug the telephone (or modem/surge protector) into a different location. If this doesn't solve the problem, re-locate your telephone or modem farther apart from each other, or use a different surge protector.

· The layout of your home or office might be limiting the operating range. Try moving the telephone base to another location, preferably a higher location for better reception. · Disconnect the telephone base from the telephone jack and plug in a corded telephone. If calls are still not clear, contact the local telephone company (charges may apply). · If the other telephones in your home are having the same problem, contact the local telephone company (charges may apply). · If you subscribe to high-speed Internet service (Digital Subscriber Line - DSL) through your telephone lines, you must install a DSL filter between the telephone base and the telephone wall jack to prevent noise and caller ID problems caused by DSL interference. Please contact your DSL service provider for more information about DSL filters. I hear other calls when using the telephone . · Disconnect the telephone base from the telephone jack. Plug in a different telephone.

If there are still other calls, call your local telephone company. · Press CHAN/REMOVE to switch to a clearer channel when on a call. 25 Appendix Troubleshooting I hear noise in the handset, and none of the keys or buttons work . · Make sure the telephone line cord is plugged in securely. · Remove and re-insert the battery.

My caller ID features are not working properly . · Caller ID is a subscription service. You must subscribe to this service from your local telephone company for this feature to work on your telephone. · The caller may not be calling from an area which supports caller ID. · Both you and the caller's telephone companies must use equipment which are compatible with caller ID service.

· If you subscribe to high-speed Internet service (Digital Subscriber Line - DSL) through your telephone lines, you must install a DSL filter between the telephone base and the telephone wall jack to prevent noise and caller ID problems caused by DSL interference. Please contact your DSL service provider for more information about DSL filters. The system does not receive caller ID, or the system does not display caller ID during call waiting . · Make sure you subscribe to caller ID with call waiting features provided by the local telephone company. · The caller may not be calling from an area which supports caller ID. · Both you and the caller's telephone companies must use equipment compatible with caller ID service. · If you subscribe to high-speed Internet service (Digital Subscriber Line - DSL) through your telephone lines, you must install a DSL filter between the telephone base and the telephone wall jack to prevent noise and caller ID problems caused by DSL interference. Please contact your DSL service provider for more information about DSL filters. Caller ID entries do not match the numbers I need to dial . · Although the call log entries you receive have 10 digits, (the area code plus the seven-digit number,) in some areas, you may need to dial only seven digits, or a 1 plus the seven digits, or a 1 plus the area code plus the seven digits.

You can change the number of digits that you dial or store from the call log. · While reviewing the call log, press # repeatedly to display these dialing options for local and long distance numbers before dialing or saving the telephone number. 26 Appendix Troubleshooting My cordless handset beeps and is not performing normally . · Make sure the power cord is securely plugged into the telephone base. Plug the unit into a different working electrical outlet not controlled by a wall switch. · Move the handset closer to the telephone base. It may be out of range. · Reset the telephone base by unplugging the unit's electrical power. Wait for 15 seconds and plug it back in again. Allow up to one minute for the handset and the telephone base to synchronize.

· Other electronic products can cause interference to your cordless telephone. Try installing your telephone as far away from these electronic devices as possible: wireless routers, radios, radio towers, pager towers, cellular telephones, intercoms, room monitors, televisions, personal computers, kitchen appliances and other cordless telephones.



[You're reading an excerpt. Click here to read official VTECH CS5111 user guide](http://yourpdfguides.com/dref/1305011)

<http://yourpdfguides.com/dref/1305011>

*Common cure for electronic equipment · If the unit is not responding normally, try putting the handset in the telephone base. If it does not respond, try the following (in the order listed): · Disconnect the power to the telephone base. · Disconnect the battery on the handset.*

*· Wait a few minutes before connecting the power to the telephone base. · Re-install the battery and place the handset in the telephone base. · Wait for the handset to synchronize with the telephone base. Allow up to one minute for this to take place. 27 Appendix Operating range This cordless telephone operates with the maximum power allowed by the Federal Communications Commission (FCC).*

*Even so, this handset and telephone base can communicate over only a certain distance, which can vary with the locations of the telephone base and handset, the weather, and the layout of your home or office. When the handset is out of range, the handset will display CONNECTING... If there is a call while the handset is out of range, it might not ring, or if it does ring, the call might not connect well when you press . Move closer to the telephone base, then press to answer the call. If the handset moves out of range during a telephone conversation, there might be interference. To improve reception, move closer to the telephone base. Maintenance Your cordless telephone contains sophisticated electronic parts and must be treated with care. Place the handset down gently.*

*Save the original packing materials to protect your telephone if you ever need to ship it. Your telephone can be damaged if it gets wet. Do not use the handset outdoors in the rain, or handle it with wet hands. Do not install the telephone base near a sink, bathtub or shower. Electrical storms can sometimes cause power surges harmful to electronic equipment. For your own safety, take caution when using electrical appliances during storms. Your telephone has a durable plastic casing that should retain its luster for many years. Clean it only with a soft cloth slightly dampened with water or a mild soap. Do not use excess water or cleaning solvents of any kind. Remember that electrical appliances can cause serious injury if used when you are wet or standing in the water.*

*If the telephone base should fall into the water, DO NOT RETRIEVE IT UNTIL YOU UNPLUG THE POWER CORD AND TELEPHONE LINE CORD FROM THE WALL. Then pull the unit out by the unplugged cords. About cordless telephones · Privacy: There is a possibility that the cordless telephone conversations could be intercepted by radio receiving equipment within range of the cordless handset. You should not think of cordless telephone conversations as being as private as those on corded telephones. Electrical Power: The telephone base of this cordless telephone must be connected to a working electrical outlet not be controlled by a wall switch.*

*Potential TV interference: To minimize or prevent interference from cordless telephones, do not place the telephone base of the cordless telephone near or on top of a TV or VCR. Moving the cordless telephone farther away from the TV or VCR will often reduce or eliminate the interference. Rechargeable batteries: This product contains either nickel-cadmium or nickel-metal hydride rechargeable batteries. Exercise care in handling batteries in order not to create a short circuit with conducting material such as rings, bracelets, and keys. The battery or conductor may overheat and cause harm.*

*Observe proper polarity between the battery and the battery charger. Nickel-cadmium rechargeable batteries: Dispose of these batteries in a safe manner. Do not burn or puncture the battery. . . . 28 Appendix Warranty What does this limited warranty cover? The manufacturer of this VTech Product warrants to the holder of a valid proof of purchase ("Consumer" or "you") that the Product and all accessories provided in the sales package ("Product") are free from defects in material and workmanship, pursuant to the following terms and conditions, when installed and used normally and in accordance with the Product operating instructions. This limited warranty extends only to the Consumer for Products purchased and used in the United States of America and Canada.*

*What will VTech do if the Product is not free from defects in materials and workmanship during the limited warranty period ("Materially Defective Product")? During the limited warranty period, VTech's authorized service representative will repair or replace at VTech's option, without charge, a Materially Defective Product. If we repair the Product, we may use new or refurbished replacement parts. If we choose to replace the Product, we may replace it with a new or refurbished Product of the same or similar design. We will retain defective parts, modules, or equipment. Repair or replacement of the Product, at VTech's option, is your exclusive remedy.*

*VTech will return the repaired or replacement Products to you in working condition. You should expect the repair or replacement to take approximately 30 days. How long is the limited warranty period? The limited warranty period for the Product extends for ONE (1) YEAR from the date of purchase. If VTech repairs or replaces a Materially Defective Product under the terms of this limited warranty, this limited warranty also applies to the repaired or replacement Product for a period of either (a) 90 days from the date the repaired or replacement Product is shipped to you or (b) the time remaining on the original one-year warranty; whichever is longer. What is not covered by this limited warranty? This limited warranty does not cover: 1. Product that has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water or other liquid intrusion; or Product that has been damaged due to repair, alteration or modification by anyone other than an authorized service representative of VTech; or 3. Product to the extent that the problem experienced is caused by signal conditions, network reliability, or cable or antenna systems; or 4. Product to the extent that the problem is caused by use with non-VTech accessories; or 5. Product whose warranty/quality stickers, product serial number plates or electronic serial numbers have been removed, altered or rendered illegible; or 6. Product purchased, used, serviced, or shipped for repair from outside the United States of America or Canada, or used for commercial or institutional purposes (including but not limited to Products used for rental purposes); or 7.*

*Product returned without a valid proof of purchase (see item 2 below); or 8. Charges for installation or set up, adjustment of customer controls, and installation or repair of systems outside the unit. How do you get warranty service? To obtain warranty service in the United States of America, please call 1 (800) 595-9511.*



[You're reading an excerpt. Click here to read official VTECH CS5111 user guide](http://yourpdfguides.com/dref/1305011)  
<http://yourpdfguides.com/dref/1305011>

*In Canada, please call 1 (800) 267-7377. NOTE: Before calling for service, please review the user's manual - a check of the Product's controls and features may save you a service call.*

*Except as provided by applicable law, you assume the risk of loss or damage during transit and transportation and are responsible for delivery or handling charges incurred in the transport of the Product(s) to the service location. VTech will return repaired or replaced Product under this limited warranty to you, transportation, delivery or handling charges prepaid. VTech assumes no risk for damage or loss of the Product in transit. If the Product failure is not covered by this limited warranty, or proof of purchase does not meet the terms of this limited warranty, VTech will notify you and will request that you authorize the cost of repair prior to any further repair activity. You must pay for the cost of repair and return shipping costs for the repair of Products that are not covered by this limited warranty.*

*What must you return with the Product to get warranty service? 1. Return the entire original package and contents including the Product to the VTech service location along with a description of the malfunction or difficulty; and 2. Include "valid proof of purchase" (sales receipt) identifying the Product purchased (Product model) and the date of purchase or receipt; and 3. Provide your name, complete and correct mailing address, and telephone number. 29 Appendix*  
*Warranty Other Limitations This warranty is the complete and exclusive agreement between you and VTech. It supersedes all other written or oral communications related to this Product. VTech provides no other warranties for this Product. The warranty exclusively describes all of VTech's responsibilities regarding the Product. There are no other express warranties. No one is authorized to make modifications to this limited warranty and you should not rely on any such modification.*

*State/Provincial Law Rights: This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state or province to province. Limitations: Implied warranties, including those of fitness for a particular purpose and merchantability (an unwritten warranty that the Product is fit for ordinary use) are limited to one year from the date of purchase. Some states/provinces do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. In no event shall VTech be liable for any indirect, special, incidental, consequential, or similar damages (including, but not limited to lost profits or revenue, inability to use the Product or other associated equipment, the cost of substitute equipment, and claims by third parties) resulting from the use of this Product. Some states/provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Please retain your original sales receipt as proof of purchase . 30 Appendix FCC, ACTA and IC regulations FCC Part 15 This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: · Reorient or relocate the receiving antenna. · Increase the separation between the equipment and receiver. · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. · Consult the dealer or an experienced radio/TV technician for help. Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.*

*This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Privacy of communications may not be ensured when using this telephone. To ensure safety of users, the FCC has established criteria for the amount of radio frequency energy that can be safely absorbed by a user or bystander according to the intended usage of the product. This product has been tested and found to comply with the FCC criteria. The handset may be safely held against the ear of the user. The telephone base shall be installed and used such that parts of the user's body other than the hands are maintained at a distance of approximately 20 cm (8 inches) or more. If you choose to use a clipping device, please make sure to only use the supplied VTech belt clip. This Class B digital apparatus complies with Canadian ICES-003. FCC Part 68 and ACTA This equipment complies with Part 68 of the FCC rules and with technical requirements adopted by the Administrative Council for Terminal Attachments (ACTA). The label on the back or bottom of this equipment contains, among other things, a product identifier in the format US:AAAEQ##TXXXX. This identifier must be provided to your local telephone company upon request. The plug and jack used to connect this equipment to premises wiring and the telephone network must comply with applicable Part 68 rules and technical requirements adopted by ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant.*

*An RJ11 jack should normally be used for connecting to a single line and an RJ14 jack for two lines. See Installation Instructions in the user's manual. The Ringer Equivalence Number (REN) is used to determine how many devices you may connect to your telephone line and still have them ring when you are called. The REN for this product is encoded as the 6th and 7th characters following the US: in the product identifier (e.g., if ## is 03, the REN is 0.3). In most, but not all areas, the sum of all RENs should be five (5.0) or less. For more information, please contact your local telephone company.*

*This equipment may not be used with Party Lines. If you have specially wired alarm dialing equipment connected to your telephone line, ensure the connection of this equipment does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.*



**[You're reading an excerpt. Click here to read official VTECH CS5111 user guide](http://yourpdfguides.com/dref/1305011)**  
**<http://yourpdfguides.com/dref/1305011>**

If this equipment is malfunctioning, it must be unplugged from the modular jack until the problem has been corrected. Repairs to this telephone equipment can only be made by the manufacturer or its authorized agents.

For repair procedures, follow the instructions outlined under the Limited Warranty. If this equipment is causing harm to the telephone network, the telephone company may temporarily discontinue your telephone service. @@@@The telephone company is required to notify you if such changes are planned.

If this product is equipped with a corded or cordless handset, it is hearing aid compatible. If this product has memory dialing locations, you may choose to store emergency telephone numbers (e.

g., police, fire, medical) in these locations. If you do store or test emergency numbers, please: Remain on the line and briefly explain the reason for the call before hanging up. Perform such activities in off-peak hours, such as early morning or late evening. 31 Appendix FCC, ACTA and IC regulations Industry

Canada Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference, including interference that may cause undesired operation. The term 'IC: ' before the certification/registration number only signifies that the Industry Canada technical specifications were met. The Ringer Equivalence Number (REN) for this terminal equipment is 0.1. The REN is an indication of the maximum number of devices allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the RENs of all the devices does not exceed five.

This product meets the applicable Industry Canada technical specifications. The RBRC ® seal The RBRC ® seal on the nickel-cadmium battery indicates that VTech Communications, Inc. is voluntarily participating in an industry program to collect and recycle these batteries at the end of their useful lives, when taken out of service within the United States and Canada. The RBRC ® program provides a convenient alternative to placing used nickel-cadmium batteries into the trash or municipal waste, which may be illegal in your area. VTech's participation in RBRC ® makes it easy for you to drop off the spent battery at local retailers participating in the RBRC ® program or at authorized VTech product service centers. Please call 1-800-8-BATTERY TM for information on Ni-Cd battery recycling and disposal bans/restrictions in your area. VTech's involvement in this program is part of its commitment to protecting our environment and conserving natural resources. RBRC ® is a registered trademark of Rechargeable Battery Recycling Corporation . 32 Appendix Technical specifications

Frequency control Transmit frequency Channels Nominal effective range Crystal controlled PLL synthesizer Handset: 5857.20-5865.

90 MHz Telephone base: 912.75-917.10MHz 30 Maximum power allowed by FCC and IC. Actual operating range may vary according to environmental conditions at the time of use. Handset: 7.

32in X 2.01in X 1.57in (186.0mm X 51.0mm X 40.

0mm) Telephone base: 4.33in X 5.34in X 3.78in (110.0mm X 135.6mm X 96.0mm) Weight Power requirements Memory Handset: 5.14oz (145.6g) (including battery) Telephone base: 5.26oz (149g) Handset: 3.

6V 400mAh Ni-Cd battery Telephone base: 7.5V AC @ 200mA Handset directory: 20 memory locations (9 speed dial inclusive); up to 24 digits and 14 characters Handset call log: 45 memory locations; up to 11 digits and 15 characters Size 33 Appendix Index A About caller ID 16 About cordless telephones Answer calls 10 Appendix 20 28 H Handset display screen messages Handset layout 5 Home area code 8 20 B Battery 21 Battery installation and charging 3 I Important safety instructions Index 34 22 C Call log 17 Call log display screen messages 19 Call waiting 10 Channel 10 Character chart 12 Charging 3

Clear voicemail 9 Copy a directory entry into speed dial 14 L Language 9 M Maintenance 28 Make call log entries ready to dial Make calls 10 18 O Operating range 28 D Date and time 7 Delete a directory entry 13 Delete a speed dial entry 16 Delete from the call log 19 Dial a call log number 18 Dial a number from the directory Dial a speed dial number 16 Dial mode 8 Directory 11 DSL filter 2 P Parts checklist 1 R 14 Reassign speed dial locations Redial 11 Review the call log 17 Review the directory 12 Ringer 7 Ringer volume 7 16 E Edit a directory entry 12 Edit a speed dial entry 15 End calls 10 S Save a call log entry to the directory Speed dial 14 Store a directory entry 11 Store a speed dial entry 14 31 18 F FCC, ACTA and IC regulations Find handset 11 G Getting started 1 34 Appendix Index T Technical specifications 33 Telephone base installation 2 Telephone base layout 6 Telephone operation 10 Telephone settings 7 Temporary tone dialing 10 The RBRC ® seal 32 Troubleshooting 23 V Volume 10 W Wall bracket installation Warranty 29 3 35 VTECH

TELECOMMUNICATIONS LTD. A member of THE VTECH GROUP OF COMPANIES. Distributed in the U.S.A. by VTech Communications, Inc. Beaverton, Oregon Distributed in Canada by VTech Technologies Canada, Ltd., Richmond, B.C.

Copyright ©2008 for VTECH TELECOMMUNICATIONS LTD. Printed in China. 91-001433-070-100 User's manual w w w.v t e c h p h o n e s . c o m

Models: CS5111/CS5113 .



[You're reading an excerpt. Click here to read official VTECH CS5111 user guide](http://yourpdfguides.com/dref/1305011)

<http://yourpdfguides.com/dref/1305011>