



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for VTECH CS5121. You'll find the answers to all your questions on the VTECH CS5121 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual VTECH CS5121
User guide VTECH CS5121
Operating instructions VTECH CS5121
Instructions for use VTECH CS5121
Instruction manual VTECH CS5121

Congratulations

on purchasing your new VTech product.
Before using this telephone, please read the
Important safety instructions
on page 46 of this manual.

This manual has all the feature operations and troubleshooting necessary to install and operate your new VTech telephone. Please review this manual thoroughly to ensure proper installation and operation of this innovative and feature rich VTech product. For support, shopping, and everything new at VTech, visit our website at www.vtechphones.com.
In Canada, please visit www.vtechcanada.com.



The ENERGY STAR® program (www.energystar.gov) recognizes and encourages the use of products that save energy and help protect our environment. We are proud to mark this product with the ENERGY STAR® label indicating it meets the latest energy efficiency guidelines.



Telephones identified with this logo have reduced noise and interference when used with most T-coil equipped hearing aids and cochlear implants. The TIA-1083 Compliant Logo is a trademark of the Telecommunications Industry Association. Used under license.

i



[You're reading an excerpt. Click here to read official VTECH CS5121 user guide](http://yourpdfguides.com/dref/1305012)
<http://yourpdfguides.com/dref/1305012>

Manual abstract:

@@@In Canada, please visit www.vtechcanada.com. @@ We are proud to mark this product with the ENERGY STAR® label indicating it meets the latest energy efficiency guidelines. Compatible with Hearing Aid T-Coil. Congratulations T TIA-1083 Telephones identified with this logo have reduced noise and interference when used with most T-coil equipped hearing aids and cochlear implants. The TIA-1083 Compliant Logo is a trademark of the Telecommunications Industry Association. Used under license. Table of contents Getting started . . .

.
 Parts checklist
 Telephone base installation Battery installation and charging

 Mounting bracket installation Handset layout
 Telephone base layout
 Telephone settings
 Date and time

 Ringtone

 Ring volume (handset) Dial mode

 Home area code
 Language

 Telephone operation Make calls

 Answer calls

 End calls
 Volume

 Channel

 Call waiting

 Temporary tone dialing

 Redial

 Find handset
 Directory

 Store a directory entry

.....
.....

.....
.....
.....
.....

.....
.....
...1.1.

2.3.4.6.7.8.8.9.9.10.

10.11.12.12.12.12.12.12.13.13.
14.14.15.15 Character chart..

.....
..... Review the drectory

..... Edt a drectory entry

..... Delete a drectory entry..

.....
..... Copy a drectory entry nto speed dal Dal a number from the drectory ... Speed dal

..... Store a speed dal entry ..

.....
..... Edt a speed dal entry

..... Delete a speed dal entry

Dal a speed dal number

..... Reassgn speed dal locatons ...
..... About caller ID

.....
..... Call log

..... Review the call log .

.....
..... Make call log entres ready to dal .

..... Dal a call log number

Save a call log entry to the drectory . Delete from the call log

..... Call log dsplay screen messages .
..... Answering system

.....
..... Message capacity

Activate the answerng system ... Set the clock

.....
..... Answerng system setup ...

..... Set number of rngs

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

. Warranty

.

. . . FCC, ACTA and IC regulatons . The RBRC ® seal

. . Technical specifications Index

.

.

.

.

.

.

.

.

.

.

. 57 . 57 . 58 . 58 . 60 .

61 . 62 . 63 www.vtechphones.com Getting started Getting started Parts checklist Your telephone contains the following items. Save your sales receipt and original packaging in case your telephone needs warranty service. To purchase a replacement battery or power adapter, visit our website at www.vtechphones.com or call 1 (800) 595-9511. In Canada, go to www.vtechcanada.com or call 1 (800) 267-7377. CHARGE Basic operation A B C D E F J K L M N O 1. Quick start guide P Q R S T U V W X Y Z TONE OPER 2. Handset

3.

Telephone base with mounting bracket 4. Telephone base power adapter 5. Battery compartment cover 6. Battery 7. Telephone line cord 8.

User's manual www.vtechphones.com 1 Getting started Telephone base installation Use only the power adapter supplied with this product. To order a replacement, visit our website at www.vtechphones.com or call 1 (800) 595-9511. In Canada, go to www.vtechcanada.com or call 1 (800) 267-7377. The power adapter is intended to be correctly oriented in a vertical or floor mount position.

The prongs are not designed to hold the plug in place if it is plugged into a ceiling or an under-the-table/cabinet outlet. Install the telephone base as shown below. Make sure that the electrical outlet is not controlled by a wall switch. If you subscribe to high-speed Internet service (Digital Subscriber Line - DSL) through your telephone lines, you must install a DSL filter between the telephone base and the telephone wall jack. The filter will prevent noise and caller ID problems caused by DSL interference. Please contact your DSL service provider for more information about DSL filters. Telephone wall jack Telephone base power adapter Telephone line cord DSL filter (not included) required if you have DSL high-speed Internet service Electrical outlet (not controlled by a wall switch) DC

7.5V Telephone base 2 www.vtechphones.com Getting started Getting started Battery installation and charging Install the battery as shown below. The battery may have enough charge for short calls. For best performance, charge the battery for at least 16 hours before use. When the battery power is low, LOW BATTERY will be displayed and will flash on the handset screen. When fully charged, the handset battery provides approximately five hours of talk time or six days of standby time. 1.

Insert the plug of the battery as indicated. Make sure it is plugged securely and matches the color-coded label inside the battery compartment. 2. Place the battery with the label THIS SIDE UP facing up and the wires inside the battery compartment. 3.

Align the battery compartment cover flat against the battery compartment, then slide it upwards until it clicks into place. 4. Charge the handset by placing it in the telephone base. The handset charge light will be on when charging. If the handset will not be used for a long period of time, remove the battery to prevent possible leakage. To purchase a replacement battery, visit our website at www.vtechphones.com or call 1 (800) 595-9511. In Canada, go to www.vtechcanada.com

or call 1 (800) 267-7377. Basic operation 1 2 3 4 CHARGE A B C D E F J K L M N O W X Y Z P Q R S T U V TONE OPER www.vtechphones.com 3 Getting started Mounting bracket installation Your telephone base comes with the mounting bracket installed, ready for desktop use. You may also mount your telephone onto a standard telephone wall plate.



[You're reading an excerpt. Click here to read official VTECH CS5121 user guide](http://yourpdfguides.com/dref/1305012)

<http://yourpdfguides.com/dref/1305012>

Wall mounting bracket installation: To prepare the telephone base for wall mounting, you will need to remove the bracket feet currently attached for desktop use. Press on the tabs located on the legs of the bracket to loosen, then lift the bracket up and away from the telephone base. 1. First, insert the lower portion tabs of the mounting bracket into the lower grooves on the telephone base, then snap the upper portion tabs of the mounting bracket into place. 2.

Mount the telephone base on the wall by positioning it so the mounting studs will fit into the holes on the telephone base and mounting bracket. Slide the telephone base down on the mounting studs until it locks into place. 3. To remove the bracket, press both upper portion tabs firmly inward and pull the bracket downward until it releases from the grooves. Mounting bracket lower portion tabs lower groove upper grooves upper portion tabs middle grooves 4 Mounting bracket on wall mount orientation www.vtechphones.com

Getting started Getting started Mounting bracket installation (continued) Desktop/tabletop bracket installation: Your phone comes ready for table or desktop use. If you have repositioned the bracket for wall mounting and now want to return to desktop use, follow these steps: 1. Insert the lower portion tabs of the mounting bracket into the upper grooves of the telephone base. 2.

Snap the upper portion tabs of the bracket into place. 3. To remove the bracket, press both upper portion tabs firmly inward and pull the bracket upward until it is released from the grooves. Basic operation www.vtechphones.com 5 Getting started CHARGE light · On when the handset is charging on the telephone base. /VOL-/CID · When the telephone is not in use, press to review the call log. · Press and hold while the telephone is not in use to adjust ring volume. · During a call, press to decrease the listening volume. A double beep will sound at the lowest setting.

· Press to scroll down while in programming mode or reviewing the redial list. /FLASH · Press to make or answer a call. · During a call, press to receive an incoming call when you receive a call waiting alert. TONE · Press to switch to tone dialing temporarily when using the pulse service (page 13). CHAN/REMOVE · Switch to a clearer channel while on a call. · Press and hold to delete all records on the call log when telephone is not in use. · When reviewing the call log or redial list, press to delete the desired record. PROG · Press to enter programming mode while the telephone is not in use. Handset layout /VOL+/ · Press to display the directory when the telephone is not in use. · Press and hold adjust the ring volume when the telephone is not in use.

· During a call, press to increase the listening volume. A double beep will sound when the highest setting is reached. · Press to scroll up while in programming mode or reviewing the redial list. SELECT · Press to store a programming option or a directory entry. OFF · During a call, press to hang up.

· While the handset is ringing, press to silence the ringer. · Press and hold while the telephone is not in use to erase the MISSED CALLS display. · During programming, press to exit without making changes. * CHARGE A B C D E F J K L M N O P Q R S T U V W X Y Z # TONE OPER · Press repeatedly to display other dialing options when reviewing the call log (page 26). REDIAL/PAUSE · Press repeatedly to review the redial list.

· While dialing or entering numbers into the directory, press to insert a dialing pause. 6 www.vtechphones.com Getting started Getting started Telephone base layout X/DELETE · Press to delete all old messages when answering system is not in use (page 39). /REPEAT · Press to repeat a message or press twice to play back previous messages (page 38). IN USE light · Flashes when in use. 2. Press or until the screen displays DIAL MODE: and the current setting. 3.

Press SELECT. The current setting flashes. 4. Press or to select TONE or PULSE. 5. Press SELECT to confirm your selection. You will hear a confirmation tone. Home area code If you dial your local calls using only seven digits (area code not required), you can program your home area code, following the steps below. By programming your home area code, when you receive a call within your local area, the telephone number will automatically be stored without the area code on the call log. 1.

Press PROG when the handset is not in use. 2. Press or until the screen displays HOME AREA CODE. 3. Press SELECT.

The stored area code is displayed with the first digit flashing. 4. Use the dial key pad to enter the desired home area code. 5. Press SELECT to confirm.

You will hear a confirmation tone. 10 www.vtechphones.com Telephone settings Language Basic operation Telephone settings 1. Press PROG when the handset is not in use. 2. Press or until LANGUAGE is displayed. 3. Press SELECT. The current setting flashes.

4. Press or until the screen displays the desired language (English, Spanish or French). 5. Press SELECT to confirm your selection. You will hear a confirmation tone. www.vtechphones.com 11 Telephone operation Make calls · The call timer will be activated during a call to show call duration. · The handset will beep feet moved out of range while on a call. · Press /FLASH and then use the dial pad keys to dial a number.

-ORI. Enter the phone number first. You can press to backspace and press CHAN/REMOVE to erase digits. 2. Press /FLASH to dial.

Answer calls End calls Volume · Press any dial pad key (except /VOL-/CID, /VOL+/ an incoming call, and OFF) to answer · Press OFF or put the handset back to the telephone base to end a call. · Press /VOL-/CID or a conversation. /VOL+/ to adjust the listening volume during Channel · Press CHAN/REMOVE to switch to a clearer channel while on a call. 12 www.vtechphones.com

Telephone operation Call waiting If you subscribe to call waiting service and you are on a call when a new call comes in, you will hear a beep. The caller ID information will be displayed if you subscribe to combined caller ID with call waiting service from your local telephone company. · Press /FLASH on the handset to put the current call on hold and answer the incoming call. · Press /FLASH at anytime to alternate between calls. Basic operation Telephone operation Temporary tone dialing If you have pulse (rotary) service, you can change from pulse to touch tone dialing during a call by pressing TONE*. This is useful if you need to send touch tone signals to access telephone banking or long distance services. Once you have initiated your call by dialing the phone number on pulse (rotary), press TONE*. Now, all subsequent key presses will be sent as touch tone signals. After you hang up, the phone will return to pulse (rotary) dialing for the next call.

www.vtechphones.com 13 Telephone operation Redial · The telephone stores five most recently dialed telephone numbers on the redial list.



[You're reading an excerpt. Click here to read official VTECH CS5121 user guide](http://yourpdfguides.com/dref/1305012)
<http://yourpdfguides.com/dref/1305012>

When the list is full, the oldest entries are deleted to make room for the new entry. · Press REDIAL/PAUSE, then press , or REDIAL/PAUSE repeatedly to review the redial list. Press CHAN/REMOVE to delete the displayed number. · Press /FLASH, then press REDIAL/PAUSE to dial the last telephone number dialed. · OR Press REDIAL/PAUSE, then press , or REDIAL/PAUSE repeatedly until the desired entry displays, then press /FLASH to dial the number. Find handset · Press FIND HANDSET on the telephone base to locate the handset when the telephone is not in use and the handset is not on the telephone base. The handset will ring and **PAGING** will be displayed on its screen. · Press FIND HANDSET again or put the handset back on the telephone base to stop the paging tone. · OR Press OFF on the handset. 14 www.vtechphones.com Telephone operation Directory The directory can store up to 20 entries (including nine speed dial entries). Each entry may consist of a number up to 24 digits and a name up to 14 characters. Store a directory entry 1. Press PROG when the handset is not in use. The screen displays DIRECTORY. 2. Press SELECT. The screen displays ENTER NAME. 3. Use the dial pad keys to enter the name. See the Character chart on page 16. · Press to move the cursor to the left or to the right. · Press CHAN/REMOVE to erase a character. 4. When finished, press SELECT or PROG. The screen displays ENTER NUMBER. 5. Use the dial pad keys to enter the telephone number. · Press to move the cursor to the left or to the right. · Press CHAN/REMOVE to erase a digit. · Press REDIAL/PAUSE to insert a dialing pause (P will be displayed). 6. Press SELECT or PROG. The screen displays DISTINCT RING? and the current setting. 7. Press or to choose Y (yes) if you wish to customize this entry or choose N (no) for a normal ring. If you choose Y, a will be displayed with the directory entry. 8. Press SELECT or PROG to confirm and you will hear a confirmation tone. Basic operation Telephone operation www.vtechphones.com 15 Telephone operation Character chart · When you reach the end of the list in the directory, END OF LIST will be shown on the screen and there will be an error tone. · If you press a dial pad key for alphabetical search while in the directory and there are no entries starting with the letters of that key, NO DATA will be displayed on the screen. Use the dial pad keys and the chart below to enter a name (up to 14 characters). An error tone will sound if you try to enter more than 14 characters. Each press of a particular key causes the characters to be displayed in the following order: Dial key 1 2 3 4 5 6 7 8 9 0 * # Characters by number of key presses 1 1 A D G J M P T W 0 * & , , . # B E H K N Q U X C F I L O R V Y 2 3 4 5 6 S 8 Z 9 7 2 3 4 5 6 Review the directory 16 1. Press /VOL+/- when the handset is not in use. The screen displays DIRECTORY. 2. Press or to scroll through the entries stored in the directory alphabetically. · OR Press the dial pad key for the first letter of the name you want to search. If necessary, scroll or to find the desired entry. www.vtechphones.com Telephone operation Edit a directory entry 1. Press /VOL+/- when the handset is not in use. The screen displays DIRECTORY. 2. Press or to scroll through the entries stored in the directory alphabetically. · OR Press the dial pad key for the first letter of the entry you want to edit. If necessary, scroll or to find the desired entry. SPEED EDIT DEL 3. When the screen displays the desired entry, press 8005959511 SELECT. Then press or until EDIT flashes. 4. Press SELECT. The screen displays the name and number. The cursor appears at the beginning of the name. · Use the dial pad keys to edit the name. · Press to move the cursor to the left or to the right. · Press CHAN/REMOVE to erase a character. 5. Press SELECT to move on to the phone number. · Use the dial pad keys to edit the number. · Press to move the cursor to the left or to the right. · Press CHAN/REMOVE to erase a digit. · Press REDIAL/PAUSE to insert a dialing pause (P will be displayed). 6. Press SELECT. The screen displays DISTINCT RING? and the current setting. Basic operation Telephone operation www.vtechphones.com 17 Telephone operation 7. Press or to choose Y (yes) if you wish to customize this entry, or choose N (no) for a normal ring. If you choose Y, a will be displayed with the directory entry. 8. Press SELECT to confirm and you will hear a confirmation tone. Delete a directory entry 1. Press /VOL+/- when the handset is not in use. The screen displays DIRECTORY. 2. Press or to scroll through the entries stored in the directory alphabetically. · OR Press the dial pad key for the first letter of the entry you want to delete. If necessary, scroll or to find the desired entry. SPEED EDIT DEL 8005959511 3. When the screen displays the desired entry, press SELECT. Then press or until DEL (delete) flashes. 4. Press SELECT. The screen displays ERASE NO YES and the number. The current choice flashes. 5. Press until YES flashes. 6. Press SELECT. You will hear a confirmation beep. 18 www.vtechphones.com Telephone operation Copy a directory entry into speed dial 1. Press /VOL+/- when the handset is not in use. The screen displays DIRECTORY. 2. Press or to scroll through the entries stored in the directory alphabetically. · OR Press the dial pad key for the first letter of the entry you want to copy. If necessary, scroll or to find the desired entry. SPEED EDIT DEL 3. When the screen displays the desired entry, press 8005959511 SELECT. Then press or until SPEED flashes. 4. Press SELECT. The screen displays ENTER 1-9. 5. Press a key (1-9) to copy this entry from the directory to the speed dial memory and assign the memory location. You'll hear a confirmation beep. A memory location number (01 through 09) will be displayed with this entry. Basic operation Telephone operation Dial a number from the directory 1. Press /VOL+/- when the handset is not in use. The screen displays DIRECTORY. 2. Press or to scroll through the entries stored in the directory alphabetically. · OR Press the dial pad key for the first letter of the desired entry. If necessary, scroll or to find the desired entry. 3. When the screen displays the desired entry, press /FLASH. www.vtechphones.com 19 Telephone operation Speed dial · The entries stored in the speed dial memory will be numbered 01 through 09 and share the memory in the directory. · Press OFF at any time to exit the Speed dial menu. · If the location is not empty, the new entry will replace the old entry and the old entry will be moved to a directory location. Your telephone can store up to nine telephone numbers with names (up to 14 characters and 24 digits in each location) in the speed dial memory locations you assign in each handset. 1. Press PROG when the handset is not in use and then press or until the screen displays SPEED DIAL. 2. Press SELECT. The screen displays ENTER 1-9. 3. Press a key (1 through 9) to assign the speed dial location where this number will be stored. The screen displays ENTER NAME. 4. Use the dial pad keys to enter the name (see the Character chart on page 16) and then press SELECT or PROG .



[You're reading an excerpt. Click here to read official VTECH CS5121 user guide](http://yourpdfguides.com/dref/1305012)

<http://yourpdfguides.com/dref/1305012>

· Press to move the cursor to the left or to the right. · Press CHAN/REMOVE to erase a character. 5. The screen displays ENTER NUMBER. 6. Use the dal pad keys to enter the telephone number, and then press SELECT or PROG. · Press to move the cursor to the left or to the right. · Press CHAN/REMOVE to erase a dgt. · Press REDIAL/PAUSE to insert a dalng pause (P will be dsplayed). 7. The screen dsplays DISTINCT RING? and the current settng. www.vtechphones.com Store a speed dial entry 20 Telephone operation 8. Press or to choose Y (yes) f you wsh to customize ths entry, or choose N (no) for a normal rnger. If you choose Y, a will be dsplayed with the entry 9. Press SELECT or PROG to confirm. You will hear a confirmation tone. Edit a speed dial entry 1. Press and hold the speed dal locaton key (1-9) of the desred entry when the handset s not n use. 2. When the screen dsplays the entry you want to edt, press SELECT. Then press or until EDIT flashes. SPEED EDIT DEL 8005959511 3. Press SELECT.

The screen dsplays the name and 01 number. The cursor appears at the begnng of the name. Use the dal pad keys to edt the name. · Press to move the cursor to the left or to the right. · Press CHAN/REMOVE to erase a character. 4. Press SELECT to move on to the phone number. Use the dal pad keys to edt the number. · Press to move the cursor to the left or to the right. · Press CHAN/REMOVE to erase a dgt. · Press REDIAL/PAUSE to insert a dalng pause (P will be dsplayed). 5. Press SELECT. The screen dsplays DISTINCT RING? and the current settng. 6. Press or to choose Y (yes) f you wsh to customize ths entry, or choose N (no) for a normal rnger. If you choose Y, a will be dsplayed with the drectory entry. 7. Press SELECT to confirm. You will hear a confirmation tone. www.vtechphones.com 21 Basic operation Telephone operation Telephone operation Delete a speed dial entry 1. Press and hold the speed dal locaton key (1-9) of the desred entry when the handset s not n use. 2. When the screen dsplays the desred entry, press SELECT. Then press or until DEL (delete) flashes. 3. Press SELECT. The screen dsplays ERASE NO YES and the number.

The current choice flashes. 4. Press until YES flashes. 5. Press SELECT. You will hear a confirmation beep. SPEED EDIT DEL Dial a speed dial number 1. Press and hold a speed dal locaton key (1-9) of the desred entry when the handset s not n use. 2. Press /FLASH to dal the dsplayed number. 8005959511 01 22 www.vtechphones.com Telephone operation Reassign speed dial locations 1. Press and hold the speed dal locaton key (1-9) of the desred entry when the handset s not n use. SPEED EDIT DEL 2.

When the screen dsplays the desred entry, press 8005959511 SELECT. Press or until SPEED flashes. 01 3. Press SELECT. The screen dsplays ENTER 1-9. 4. Press a key (1-9) to reassgn ths entry nto another memory locaton. You will hear a confirmation beep. Basic operation Telephone operation www.vtechphones.com 23 Telephone operation About caller ID The caller ID wth call watng feature n ths telephone lets you see the name and telephone number of the caller before answerng the call, even when already on a call. These features require services provided by your local telephone company. Contact your telephone company f: · you have both caller ID and call watng, but as separate services (you may need combed service), · you have only caller ID service, or only call watng service, or · you do not subscribe to any caller ID or call watng services but wsh to try these services. You can use ths telephone wth regular caller ID service, and you can use ts other features without subscribng to ether caller ID or combed caller ID wth call watng service. There may be fees for these services, and these services may not be available n all areas.

The caller ID features wll work only f both you and the caller are n areas offerng caller ID service, and f both telephone companes use compatble equipment. 24 www.vtechphones.com Telephone operation Call log Caller's name VTECH 800-595-9511 NEW05 Caller's telephone number New call log ndcator and locaton n the call log Tme of call 6:10 AM 08/17 Date of call If you subscribe to caller ID service, nformaton about each caller will be dsplayed after the first or second ring. · The call log can store up to 45 entres. · When the call log s full, the earliest entry will be deleted to make room for new ncomng call nformaton. · CID EMPTY will be dsplayed f there s no record n the call log. · If you answer a call before the nformaton appears on the screen, t wll not be stored n the call log. · The tme on the handset s automatically set and updated wth ncomng caller ID nformaton f you subscribe to ths service. · Due to regional service dfferences, the caller ID nformaton may not be available for every ncomng call.

In addton, the callers may ntenionally block ther names and/or telephone numbers. Basic operation Telephone operation www.vtechphones.com 25 Telephone operation · If you have programmed a home area code (page 10), only the last seven dgts of the ncomng phone numbers from that area code will be dsplayed while reviewng the call log. Press # repeatedly to dsplay all possible dalng optons.

1. Press /VOL-/CID to vew the call log when n dle mode. 2. Press or to scroll through the entres. There wll be an error tone when you reach the end of the call log lst and the screen wll dsplay END OF LIST.

Review the call log Make call log entries ready to dial Although the call log entres received have 10 dgts (the area code plus the seven-dgt number), n some areas, you may need to dal only the seven dgts, or a 1 plus the seven dgts, or a 1 plus the area code plus the seven dgts. You can change the number of dgts that you dal from or store n the call log. While reviewng the call log, press # repeatedly to dsplay dfferent dalng optons for local and long dstance numbers before dalng or savng the telephone number n the drectory. See the example on the right. You may also press 1 repeatedly to add or remove a 1 n front of the telephone number before dalng or savng t n the drectory. See the examples on the right. When the number dsplayed s n the correct format for /FLASH to call the number. dalng, press www.vtechphones.com 800-595-9511 1-800-595-9511 595-9511 1-595-9511 800-595-9511 1-800-595-9511 595-9511 1-595-9511 26 Telephone operation Dial a call log number 1.

Press /VOL-/CID to enter the call log when the handset s not n use. 2. Press or to select the desred entry, then press /FLASH. -ORI. Press /VOL-/CID to enter the call log when the handset s not n use. 2. Press or to select the desred entry. 3. Press SELECT, then DIAL flashes. 4.

Press /FLASH or SELECT. Basic operation Telephone operation www.vtechphones.com 27 Telephone operation Save a call log entry to the directory 1. Press /VOL-/CID to enter the call log when the handset s not n use. 2. Press or to select the desred entry.



[You're reading an excerpt. Click here to read official VTECH CS5121 user guide](http://yourpdfguides.com/dref/1305012)

If you wish to change how the numbers are saved, press # repeatedly 8005959511 until the desired option displays. See the Make call log NEW28 entries ready to dial section on page 26. 5:40PM 12/30 3.

Press SELECT, then press or until PROGRAM flashes. DIAL PROGRAM 8005959511 4. Press SELECT again. NEW28 5. Enter or edit the name if necessary. See the 5:40PM 12/30 Character chart on page 16. Press to move the cursor to the left or to the right. DISTINCT RING? N Press CHAN/REMOVE to erase a character. 8005959511 Press SELECT to move on to the phone number. 6.

Edit the number if necessary. Press to move the cursor to the left or to the right. Press CHAN/REMOVE to erase a digit. Press REDIAL/PAUSE to insert a dialing pause (P will be displayed). Press SELECT to continue. 7. Press or to choose Y (yes) if you wish to customize this entry, or choose N (no) for a normal ring. If you choose Y, a will be displayed with the directory entry. 8. Press SELECT to confirm.

You will hear a confirmation tone. 28 www.vtechphones.com Telephone operation Delete from the call log Delete an entry: 1. Press /VOL-/CID to enter the call log.

2. Press or to select the entry to be deleted. 3. Press CHAN/REMOVE. You will hear a confirmation beep.

Basic operation Telephone operation Delete all entries: 1. Press and hold CHAN/REMOVE when the telephone is not in use. The screen displays ERASE ALL? N Y. The current choice flashes. 2. Press until Y (yes) flashes. 3. Press SELECT. You will hear a confirmation beep. www.

vtechphones.com 29 Telephone operation Call log display screen messages Displays: PRIVATE NAME PRIVATE NUMBER PRIVATE CALLER UNKNOWN NAME When: The caller is blocking the name information. The caller is blocking the telephone number information. The caller is blocking the name and number information. This caller's name is unavailable. UNKNOWN NUMBER This caller's number is unavailable. UNKNOWN CALLER No call information is available about this caller. 30 www.vtechphones.com Answering system Message capacity The answering system can record up to 95 messages, depending on the length of each message.

Each individual message can be up to four minutes in length, and the total maximum recording time is approximately 12 minutes. Messages will remain available for replay until they are deleted. Press to delete message currently playing (page 38). Press twice to delete all old messages when answering system is not in use (page 39). Press to repeat a message.

Press twice to play back previous messages (page 38). Shows the status and number of messages (page 41). Press to record a memo (page 39) or an announcement on the answering system (page 37). Press to skip to the next message (page 38). Press to adjust volume during playback (page 38).

Press to play or stop messages (page 38). Press to turn the answering system on or off (page 32). Press to listen to the set up menu (pages 33-35). Basic operation Answering system Press to set the clock (page 32). Press to enter announcement mode (pages 36-37). www.vtechphones.com 31 Answering system Activate the answering system If you have caller ID service the clock will be set automatically with incoming calls, but you will need to make sure the year is correct. Press and hold /SKIP or /REPEAT while setting the minutes or year to advance or decrease by increments of ten. The answering system must be turned on to answer and record messages.

If the answering system is turned on, the ANS ON/OFF light will be on. Press ANS ON/OFF to turn the answering system off or on. Set the clock Before playing each message, the answering system announces the day and time of the message received. Before using the answering system, set the day, time and year, so that messages are dated correctly. If the clock is not set before new messages are recorded, the system will announce "Time and day not set." before each message is played to remind you to set the clock. 1. Press CLOCK. The system announces the clock setting (e.g.

day, time and year), then announces: "To set the clock, press CLOCK." 2. Press CLOCK. The system announces the current day. 3.

Press /SKIP or /REPEAT until the system announces the correct day, then press CLOCK. The system announces the current hour. 4. Press /SKIP or /REPEAT until the system announces the correct hour, then press CLOCK. The system announces the current minute.

5. Press /SKIP or /REPEAT until the system announces the correct minute, then press CLOCK. The system announces the current year. 6. Press /SKIP or /REPEAT until the system announces the correct year, then press CLOCK. The system announces the current clock setting and exits the clock menu.

www.vtechphones.com 32 Answering system Answering system setup The answering system uses voice prompts to guide you through the steps to set up the answering system. Press /PLAY/STOP anytime to save and exit the SET UP menu.

Set number of rings This feature allows you to select the number of rings before the answering system answers. You can choose from two, four or six rings or toll saver. With toll saver active, the answering system answers after two rings when there is a new message, and after four rings when there is no new message. To set the number of rings: 1. Press SET UP when in dial mode and the system announces the current number of rings setting. 2. Press /SKIP or /REPEAT until the system announces the desired setting, then press SET UP to save the setting and go to the next setting, or press /PLAY/STOP to save and return to the dial mode.

Basic operation Answering system www.vtechphones.com 33 Answering system Set telephone base ringer The handset ringer volume is set separately. See page 9 for details. This feature allows you to select the telephone base ringer volume level. 1. Press SET UP when in dial mode until the system announces the telephone base ringer setting. There are three levels: HI (high), OF (off) and LO (low).

2. Press /SKIP or /REPEAT until the system announces the desired telephone base ringer volume level, then press SET UP to save the setting and go to the next setting, or press /PLAY/STOP to save and return to the dial mode. Set remote access code A two-digit security code is required to access the answering system from any touch tone telephone. The preset code is 19. You can set the remote access code from 10 to 99.

To set the remote access code: 1. Press SET UP when in dial mode until the system announces the remote access code setting. 2. Press /SKIP or /REPEAT to change the remote access code by one, or press and hold /SKIP or /REPEAT to change it by increments of ten. Press SET UP to save the setting and go to the next setting, or press /PLAY/STOP to save and return to the dial mode. 34 www.vtechphones.com Answering system Set message alert tone This feature programs the system to beep every 10 seconds to alert you of new messages when the telephone is not in use. The tone will stop when all new messages have been reviewed. To set the message alert tone: 1.

Press SET UP when in dial mode until the system announces the message alert tone setting. 2. Press /SKIP or /REPEAT to select on or off, then press SET UP to save and go to the next setting, or press /PLAY/STOP to save and return to the dial mode.



[You're reading an excerpt. Click here to read official VTECH CS5121 user guide](http://yourpdfguides.com/dref/1305012)

<http://yourpdfguides.com/dref/1305012>

· The answering system must be turned on for the message alert tone to function. Basic operation Answering system www.vtechphones.com 35 Answering system Outgoing announcement · Your announcement can be up to 90 seconds in length. · Announcements shorter than two seconds will not be recorded. The outgoing announcements the greeting callers hear when calls are answered by the answering system. The telephone is preset with a greeting that answers calls with "Hello, please leave a message after the tone.

" You can use this preset announcement, or replace it with your own. While in the ANNC menu, press ANNC again to exit at anytime. Play your announcement 1. Press ANNC when in dial mode and the system will announce "Announcement. Press PLAY or press RECORD.

" 2. Press /PLAY/STOP to play the announcement. You can press it again to stop playback. 36 www.vtechphones.com

Answering system Record your own announcement 1. Press ANNC while in dial mode and the system will announce "Announcement. Press PLAY or press RECORD." 2. Press RECORD and the system announces, "Record after the tone. Press STOP when you are done." 3. After the tone, speak towards the microphone at the bottom front of the telephone base from about nine inches away. 4. Press /PLAY/STOP when finished.

5. The answering system will automatically playback the newly recorded announcement and there will be a confirmation tone. Press /PLAY/STOP to stop the playback at anytime. 6. You can record your announcement again by following the steps above. 1. Press ANNC while in dial mode and the system will announce "Announcement. Press PLAY or press RECORD." 2. Press X/DELETE and the system will announce "Announcement deleted.

" · When your announcements are deleted, calls will be answered with the preset announcement. Basic operation Answering system Delete your announcement www.vtechphones.com 37 Answering system New message indication · If the system has less than five minutes of recording time left, the remaining time will be announced. · If F is flashing in the message window, the memory is full.

You will have to delete some messages before new ones can be recorded. · Only old messages can be deleted. Messages can only be deleted after they are played. The message display counter will flash when there are new answering system messages. If the new message alert tone is turned on, the telephone base will beep every ten seconds when there are unreviewed messages.

Message playback 1. Press /PLAY/STOP to listen to messages. 2. Press /PLAY/STOP again to stop playback. If you have new messages waiting, you will hear only new messages (oldest first). If there are no new messages, the system will play back all messages (oldest first). When playback begins, the total number of messages is announced, followed by the day and time of the first message to be played. Options during playback · Press VOL+/ VOL- to adjust the speaker volume. · Press /SKIP to skip to the next message. · Press /REPEAT to repeat the message currently playing.

Press /REPEAT twice to listen to the previous message. · Press X/DELETE to delete the current message. The system will advance to the next message.

www.vtechphones.com 38 Answering system Press X/DELETE when the system is not in use. The system will announce " To delete all old messages, press DELETE again." Press X/DELETE again. All previously heard messages will be erased and the system will announce "All old messages deleted." Delete all messages Record and play memos Memos are your own recorded messages used as reminders for yourself or other household members using the same answering system.

They are saved, played back and deleted the same way as the answering system messages. Record a memo 1. Press RECORD when in dial mode. The system announces, "Record after the tone. Press STOP when you are done.

" 2. After the tone, speak towards the microphone at the bottom front of the telephone base from about nine inches away. 3. Press /PLAY/STOP when finished recording. Press /PLAY/STOP when in dial mode.

See Options during playback on page 38 for other options. · Memos shorter than one second will not be recorded. · "Memory is full." will be announced if you press RECORD when the memory is full. · Each memo can be up to four minutes in length. Basic operation Answering system Memo playback

www.vtechphones.com 39 Answering system Call screening If the answering system is on, you can listen at the telephone base to a caller leaving a message on the answering system. If the base volume is set to 1, you will not hear your messages as callers leave them. Call intercept When a caller is leaving a message on the answering system and you decide to answer the call, press /FLASH.

40 www.vtechphones.com Answering system Message window displays The message counter usually displays the total number of memos and incoming messages. See the list below for explanations of other displays in this counter. Window displays: 0 1-95 0-94 (flashing) When: No messages. Total number of old message(s) recorded. Basic operation Answering system Total number of new and old messages recorded. The telephone base may have lost and regained power. Time and day may need to be set. Memory is full with total number of messages recorded.

Elapsed time while recording memo or announcement (up to 90 seconds). Recording time exceeds 99 seconds. Current message number during new message playback. Current message number during old message playback. Current volume level while adjusting.

Current remote access code while setting. Current number of rings while setting. System is answering a call, or being set the time and date, or being accessed remotely. System is being programmed or initialized. 1-95 & F (alternating) 1-99 (counting) 99 (flashing) 1-95 (flashing) 1-95 1-8 10-99 2, 4, 6, tS --- (flashing) www.

www.vtechphones.com 41 Answering system · If you pause more than four seconds after each remote command completed, the system will announce the help menu options. If no remote command is entered within 15 seconds, the remote access call will be automatically disconnected. · When the answering system is turned off, the telephone will answer after 10 rings, and announce "Please enter your remote access code." A two-digit security code is required to access the system remotely from any touch tone telephone that does not share the same line with your answering system. The factory preset code is 19; see page 34 to change it. 1. Dial your telephone number from any touch tone telephone. 2. When the system answers and announces the greeting, enter the two-digit security code.

If you have new messages, the system will play them (new messages first) automatically. 3. You may also enter one of the following remote commands. Command 1 2 3 33 4 5 *5 6 *7 8 0 Play all messages. Play only new messages. Delete the current message (during playback). Delete all old messages. Repeat the current message (during playback).



[You're reading an excerpt. Click here to read official VTECH CS5121 user guide](http://yourpdfguides.com/dref/1305012)
<http://yourpdfguides.com/dref/1305012>

Stop. Hear a list of remote commands.

Skip to the next message (during playback). Record a new announcement. End the call. Turn the answering system on or off. Function Remote access 4. Hang up or press 8 to end the call. 42 www.vtechphones.com Handset display screen messages Displays: CAN'T CONNECT CID EMPTY CONNECTING.. . DIRECTORY EMPTY LINE IN USE LOW BATTERY MEMORY FULL XX MISSED CALLS **PAGING** PARALLEL SET ON PHONE **RINGING** When: There is no power connected to the telephone base or the handset is too far away from the telephone base. There are no call log entries. The cordless handset is searching for the telephone base. There are no directory entries. The answering system is in use. The battery needs to be recharged. The directory is full. There are unreviewed calls in the call log. The cordless handset locator has been activated.

Another telephone on the same line is in use. The handset is in use. There is an incoming call. Appendix www.vtechphones.com 43 Handset display screen messages Displays: RINGER OFF SCANNING... When: The handset ringer is turned off. The telephone base is searching for another available channel.

44 www.vtechphones.com Battery After the battery is fully charged for 16 hours, you can expect the following performance: Operation While in use (talking) While not in use (standby*) *Handset is off the telephone base but not in use. Operating time Five hours Six days The battery needs charging when: · A new battery is installed in the handset. · The handset beeps.

· LOW BATTERY is displayed and the battery indicator on the handset screen is flashing. CAUTION: To reduce the risk of fire or injury to persons, read and follow these instructions: · Use only the battery(es) provided or equivalent. @@In Canada, go to www.vtechcanada.com or call 1 (800) 267-7377.

· Do not dispose of the battery(ies) in a fire. @@· Do not open or mutilate the battery(es). @@The electrolyte may be toxic if swallowed. @@The battery and/or conductor may overheat and cause burns. @@@@Read and understand all instructions. 2. Follow all warnings and instructions marked on the product. 3. Unplug this product from the wall outlet before cleaning. Do not use liquid or aerosol cleaners.

Use a damp cloth for cleaning. 4. @5. @6. @@@@7. @@@@8. Do not allow anything to rest on the power cord. Do not install this product where the cord may be walked on. 9. @@Never spill liquid of any kind on the product.

10. @@@@11. Do not overload wall outlets and extension cords. 12. @@When the power supply cord or plug is damaged or frayed.

B. If liquid has been spilled onto the product. C. If the product has been exposed to rain or water. D.

@@@@@E. If the product has been dropped and the telephone base and/or handset has been damaged. F. If the product exhibits a distinct change in performance. 13. Avoid using a telephone (other than cordless) during an electrical storm. There is a remote risk of electric shock from lightning. 14. Do not use the telephone to report a gas leak in the vicinity of the leak. 15.

Only put the handset of your telephone next to your ear when it is in normal talk mode. 16. The power adapter is intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling or an under-the-table/cabinet outlet. SAVE THESE INSTRUCTIONS 46 www.vtechphones.com Troubleshooting If you have difficulty with your telephone, please try the suggestions below. For Customer Service, visit our website at www.vtechphones.com, or call 1 (800) 595-9511; in Canada, call 1 (800) 267-7377.

Problem My telephone does not work at all. Suggestion · Make sure the battery is installed and charged correctly (page 3). For optimum daily performance, return the handset to the telephone base after use. · Make sure the power adapter is securely plugged into an outlet not controlled by a wall switch. · Make sure the telephone line cord is plugged firmly into the telephone base and the wall jack.

· Unplug the unit's electrical power. Wait for approximately 15 seconds, then plug it back in. Allow up to one minute for the handset and telephone base to synchronize. · Charge the battery in the handset for at least 16 hours. · Remove and re-insert the battery.

If that still does not work, it may be necessary to purchase a new battery. · Disconnect the telephone base from the jack and plug in a working telephone. If this telephone does not work, the problem is probably in the wiring or the local service. Call the local telephone company. · Place the handset in the telephone base or charger for recharging. · Remove and re-install the battery and use it normally until fully depleted, then recharge the handset on the telephone base for 16 hours. · If the above measures do not correct the problem, the battery may need to be replaced. LOW BATTERY is displayed on screen. Appendix www.vtechphones.com

47 Troubleshooting Problem The battery does not charge in the handset or the handset battery does not accept charge. Suggestion · Make sure the handset is placed in the telephone base correctly. The handset CHARGE light should be on. · Remove the battery from the handset and then re-install it in the handset. Put the handset back to the telephone base and charge for 16 hours. · If the handset is in the telephone base but the handset CHARGE light is not on, see The CHARGE light is off in this section. · It may be necessary to purchase a new battery. Please see the Battery section of this user's manual (page 45). · The telephone might be malfunctioning. Please see the Warranty section of this user's manual (page 58) for further instruction.

· Clean the charging contacts on the handset(s) and telephone base each month using a pencil eraser or a dry non-abrasive fabric. · Make sure the power adapter and telephone line cords are plugged in correctly and securely. · Unplug the power adapter. Wait for 15 seconds before plugging it back in. Allow up to one minute for the handset and telephone base to reset.

· The telephone might be malfunctioning. Please see the Warranty section of this user's manual (page 58) for further instruction. The CHARGE light is off. 48 www.vtechphones.com

Troubleshooting Problem There is no dial tone. Suggestion · · · · First, try all the above suggestions. Move the handset closer to the telephone base. It might be out of range. The telephone line cord might be malfunctioning. Try installing a new telephone line cord. Disconnect the telephone base from the telephone jack and connect a different telephone. If there is no dial tone on the other telephone either, the problem is in your wiring or local service. Contact your local telephone company. My handset displays CONNECTING.

· · Move the handset closer to the telephone base. You might have moved out of range. Appendix www.vtechphones.com 49 Troubleshooting Problem The telephone does not ring when there is an incoming call. Suggestion · · · · Make sure the handset ringer is on (page 9) and/or the telephone base ringer is on (page 34).



[You're reading an excerpt. Click here to read official VTECH CS5121 user guide](http://yourpdfguides.com/dref/1305012)

<http://yourpdfguides.com/dref/1305012>

Make sure the telephone line cord and power adapter are plugged in properly (page 2). The handset may be too far from the telephone base. Move it closer to the telephone base. There may be too many extension telephones on the telephone line to allow all of them to ring simultaneously. Try unplugging some of them. If the other telephones in your home are having the same problem, the problem is in the wiring or local service. Contact the local telephone company (charges may apply).

Other electronic products can cause interference to your cordless telephone. Try installing your telephone as far away as possible from the following electronic devices: wireless routers, radios, radio towers, pager towers, cellular telephones, digital telephones, intercoms, room monitors, televisions, VCRs, personal computers, kitchen appliances, and other cordless telephones. Test a working telephone at the telephone jack. If another telephone has the same problem, the problem is in the telephone jack. Contact your local telephone company (charges may apply).

The telephone line cord might be malfunctioning. Try installing a new telephone line cord. Remove and re-insert the battery and place the handset in the telephone base. Wait for the handset to synchronize with the telephone base. Allow up to one minute for this to take place. . . . 50 www.vtechphones.com Troubleshooting Problem I cannot dial out. Suggestion · First, try all the above suggestions. · Make sure there is a dial tone before dialing.

It is normal if the handset takes a second or two to synchronize with the telephone base before producing a dial tone. Wait an extra second before dialing. · Make sure the telephone is set to the correct dial type (pulse dial or tone dial) for the service in your area. See Dial mode on page 10 to set the dial type. · If the other telephones in your home are having the same problem, the problem is in the wiring or local service. Contact your local telephone company (charges may apply). ·

Eliminate any background noise. Noise from a television, radio, or other appliances may cause the telephone not to dial out properly. If you cannot eliminate the background noise, first try muting the handset before dialing, or dialing from another room in your home with less background noise. Appendix www.vtechphones.com 51 Troubleshooting Problem There is noise or interference during a telephone conversation. My calls cut in and out when I am using the cordless handset. Suggestion · The handset may be out of range. Move it closer to the telephone base.

· Appliances or other cordless telephones plugged into the same circuit as the telephone base can cause interference. Try moving the appliance or telephone base to another outlet. · Other electronic products can cause interference to your cordless telephone. Try installing your telephone as far away as possible from the following electronic devices: wireless routers, radios, radio towers, pager towers, cellular telephones, digital telephones, intercoms, room monitors, televisions, VCRs, personal computers, kitchen appliances, and other cordless telephones. · If your telephone is plugged in with a modem or a surge protector, plug the telephone (or modem/surge protector) into a different location.

If this doesn't solve the problem, re-locate your telephone or modem farther apart from each other, or use a different surge protector. · The layout of your home or office might be limiting the operating range. Try moving the telephone base to another location, preferably a higher location for better reception. · Disconnect the telephone base from the telephone jack and plug in a corded telephone. If calls are still not clear, the problem is probably in the wiring or local service.

Contact the local telephone company (charges may apply). · If the other telephones in your home are having the same problem, the problem is in the wiring or local service. Contact the local telephone company (charges may apply). · If you subscribe to high-speed Internet service (Digital Subscriber Line - DSL) through your telephone lines, you must install a DSL filter between the telephone base and the telephone wall jack. The filter will prevent noise and caller ID problems caused by DSL interference.

Please contact your DSL service provider for more information about DSL filters. 52 www.vtechphones.com Troubleshooting Problem I hear other calls when using the telephone. Suggestion · Disconnect the telephone base from the telephone jack. Plug in a different telephone. If there are still other calls, the problem is probably in the wiring or local service. Call your local telephone company. · Press CHAN/REMOVE to switch to a clearer channel when on a call. · Make sure the telephone line cord is plugged in securely.

· Remove and re-insert the battery. I hear noise in the handset, and none of the keys or buttons work. My caller ID features are not working properly. · Caller ID is a subscription service. You must subscribe to this service from your local telephone company for this feature to work on your telephone.

· The caller may not be calling from an area which supports caller ID. · Both you and the caller's telephone companies must use equipment which are compatible with caller ID service. · If you subscribe to high-speed Internet service (Digital Subscriber Line - DSL) through your telephone lines, you must install a DSL filter between the telephone base and the telephone wall jack. The filter will prevent noise and caller ID problems caused by DSL interference. Please contact your DSL service provider for more information about DSL filters.

Appendix www.vtechphones.com 53 Troubleshooting Problem The system does not receive caller ID, or the system does not display caller ID during call waiting. Suggestion · Make sure you subscribe to caller ID with call waiting features provided by the local telephone company. · The caller may not be calling from an area which supports caller ID. · Both you and the caller's telephone companies must use equipment which are compatible with caller ID service. · If you subscribe to high-speed Internet service (Digital Subscriber Line - DSL) through your telephone lines, you must install a DSL filter between the telephone base and the telephone wall jack. The filter will prevent noise and caller ID problems caused by DSL interference. Please contact your DSL service provider for more information about DSL filters. · Although the call log entries you receive have 10 digits, (the area code plus the seven-digit number,) in some areas, you may need to dial only seven digits, or a 1 plus the seven digits, or a 1 plus the area code plus the seven digits.

You can change the number of digits that you dial or store from the call log. · While reviewing the call log, press # repeatedly to display these dialing options for local and long distance numbers before dialing or saving the telephone number. · Make sure the answering system is on. When the answering system is on, the red light on the ANS ON/OFF key should be lit.



[You're reading an excerpt. Click here to read official VTECH CS5121 user guide](http://yourpdfguides.com/dref/1305012)

<http://yourpdfguides.com/dref/1305012>

· If toll saver s activated, the number of rings changes to two when there are new messages waiting (see page 33). · If the memory is full or if the answering system is off, the system will answer after ten rings. · In some cases, the answering system will be affected by the ringing system used by the local telephone company. Caller ID entries do not match the numbers I need to dial. The answering system does not answer after the number of rings to which I programmed it. 54 www.vtechphones.com Troubleshooting Problem The announcement message is not clear. The answering system does not record messages. The messages on the answering system are incomplete. Suggestion · When recording the announcement, make sure you speak in a normal tone of voice about nine inches from the telephone base.

· Make sure there is no background noise (television, music, traffic, etc.) when recording. · Make sure the answering system is on. · Make sure the memory of the answering system is not full. · If a caller leaves a very long message, part of it may be lost when the system disconnects the call after four minutes. · If the caller pauses for more than five consecutive seconds, the system stops recording and disconnects the call. · If the memory on the system becomes full during a message, the system stops recording and disconnects the call. · If the caller's voice is very soft, the system may stop recording and disconnect the call. · Make sure your remote access code is correct (page 42). · Make sure you are calling from a touch-tone telephone. When dialing a number, there should be tones. If there are clicks, then it is not a touch-tone telephone and cannot activate the answering system. · The answering system may not detect the remote access code when the announcement is playing. Wait until the announcement is over before entering the code. · There may be interference on the telephone line you are using.

Press the keypad keys firmly when dialing. The answering system does not respond to remote commands. Appendix www.vtechphones.com 55 Troubleshooting Problem The messages on the system are very difficult to hear. My cordless handset beeps and is not performing normally. Suggestion · Press VOL+ on the telephone base to increase the speaker volume. · Make sure the power cord is securely plugged into the telephone base. Plug the unit into a different working electrical outlet not controlled by a wall switch. · Move the handset closer to the telephone base.

It may be out of range. · Reset the telephone base by unplugging the unit's electrical power. Wait for 15 seconds and plug it back in again. Allow up to one minute for the handset and the telephone base to synchronize. · Other electronic products can cause interference to your cordless telephone.

Try installing your telephone as far away from these electronic devices as possible: wireless routers, radios, radio towers, pager towers, cellular telephones, intercoms, room monitors, televisions, personal computers, kitchen appliances and other cordless telephones. · If the unit is not responding normally, try putting the handset in the telephone base. If it does not respond, try the following (in the order listed): · Disconnect the power to the telephone base. · Disconnect the battery on the handset. · Wait a few minutes before connecting the power to the telephone base.

· Re-install the battery and place the handset into the telephone base. · Wait for the handset to synchronize with the telephone base. Allow up to one minute for this to take place. Common cure for electronic equipment 56 www.vtechphones.com Operating range This cordless telephone operates with the maximum power allowed by the Federal Communications Commission (FCC). Even so, this handset and telephone base can communicate over only a certain distance - which can vary with the locations of the telephone base and handset, the weather, and the layout of your home or office. When the handset is out of range, the handset will display CONNECTING...

If there is a call while the handset is out of range, it might not ring; or if it does ring, the call might not connect well when you press telephone base, then press /FLASH to answer the call. If the handset moves out of range during a telephone conversation, there might be interference. To improve reception, move closer to the telephone base. /FLASH. Move closer to the Maintenance Taking care of your telephone Your cordless telephone contains sophisticated electronic parts, so it must be treated with care. Avoid rough treatment Place the handset down gently. Save the original packing materials to protect your telephone if you ever need to ship it. Avoid water Your telephone can be damaged if it gets wet. Do not use the handset outdoors in the rain, or handle it with wet hands. Do not install the telephone base near a sink, bathtub or shower.

Electrical storms Electrical storms can sometimes cause power surges harmful to electronic equipment. For your own safety, take caution when using electrical appliances during storms. Cleaning your telephone Your telephone has a durable plastic casing that should retain its luster for many years. Clean it only with a soft cloth slightly dampened with water or a mild soap. Do not use excess water or cleaning solvents of any kind.

Remember that electrical appliances can cause serious injury if used when you are wet or standing in the water. If the telephone base should fall into the water, DO NOT RETRIEVE IT UNTIL YOU UNPLUG THE POWER CORD AND TELEPHONE LINE CORD FROM THE WALL. Then pull the unit out by the unplugged cords. Appendix www.vtechphones.

com 57 About cordless telephones Privacy: The same features that make a cordless telephone convenient create some limitations. Telephone calls are transmitted between the telephone base and the cordless handset by radio waves, so there is a possibility that the cordless telephone conversations could be intercepted by radio receiving equipment within range of the cordless handset. For this reason, you should not think of cordless telephone conversations as being as private as those on corded telephones. Electrical power: The telephone base of this cordless telephone must be connected to a working electrical outlet. The electrical outlet should not be controlled by a wall switch. Calls cannot be made from the cordless handset if the telephone base is unplugged or switched off, or if the electrical power is interrupted. Potential TV interference: Some cordless telephones operate at frequencies that may cause interference to televisions and VCRs. To minimize or prevent such interference, do not place the telephone base of the cordless telephone near or on top of a TV or VCR. If interference is experienced, moving the cordless telephone farther away from the TV or VCR will often reduce or eliminate the interference. Rechargeable batteries: This product contains either Nickel-cadmium or Nickel-metal hydride rechargeable batteries.

Exercise care in handling batteries in order not to create a short circuit with conducting material such as rings, bracelets, and keys.



[You're reading an excerpt. Click here to read official VTECH CS5121 user guide](http://yourpdfguides.com/dref/1305012)

<http://yourpdfguides.com/dref/1305012>