



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for VTECH CS6229-4. You'll find the answers to all your questions on the VTECH CS6229-4 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual VTECH CS6229-4
User guide VTECH CS6229-4
Operating instructions VTECH CS6229-4
Instructions for use VTECH CS6229-4
Instruction manual VTECH CS6229-4

vtech
Innovation Beyond Technology™

User's manual
www.vtechphones.com



Models:
CS6228-3/CS6228-6/
CS6229/CS6229-2/
CS6229-3/CS6229-4/
CS6229-5

DECT 6.0



[You're reading an excerpt. Click here to read official VTECH CS6229-4 user guide](http://yourpdfguides.com/dref/1252055)
<http://yourpdfguides.com/dref/1252055>

Manual abstract:

v t e c h p h o n e s . @ @ @ @ @ @ @ @ For support, shopping, and everything new at VTech, visit our website at www.vtechphones.com. In Canada, please visit www.vtechcanada.com. The ENERGY STAR® program (www.energystar.gov) recognizes and encourages the use of products that save energy and help protect our environment.

We are proud to mark this product with the ENERGY STAR® label indicating it meets the latest energy efficiency guidelines. Compatible with Hearing Aid T-Coil Telephones identified with this logo have reduced noise and interference when used with most T-coil equipped hearing aids and cochlear implants. The TIA-1083 Compliant Logo is a trademark of the Telecommunications Industry Association. Used under license. T TIA-1083 Table of contents Getting started .

.....

.....

.....1 Parts checklist .

.....

.....

.....

.....1 Telephone base and charger installation ...

.....

.....

.....

.....2 Battery installation and charging ..

.....

.....

.....

.....3 Installation options ...

.....

.....

...4 Table top to wall mount

.....

. installation

.....

.....

.....

..4 Wall mount to table top ...

.....

. installation

.....

.....

.....

..5 Handset layout

.....

.....

.....6 Telephone base layout .

.....

....7 Telephone settings .

.....

.....

..8 Ringer volume (handset)

....8 Ringer tone .

.....

.....

.....

.....

..8 Key tone ...

.....

.....

.....
.....
...8 LCD language

.....
.....
.....
..9 Set date/time

.....
.....
.....
..9 Clear voicemail

.....
.....
....10 Home area code .
.....

.....
....10 Answering system settings .
...11 Answering system set up ..
.....11 Number of rings .

.....
.....
.....
.....11 Remote code

.....
.....
.....
....11 Message alert tone.....

.....
.....
11 Announcement

.....
..12 Play your announcement ...
.....
...12 Record your own announcement

.....
.....
..12 Delete your announcement ...
.....12 Telephone operation

.....
..13 Make a call
.....
.....

.....
...13 Make a predial call ..
.....
.....

....13 Answer a call

.....
.....
.....
....13 End a call.....
.....
.....

.....

.....

13 Speakerphone information

.....13 Volume .

.....

.....

.....

.....

.....13 Mute ..

.....

.....

.....

.....

.....

.14 Ringer mute

.....

.....

.....

...14 Call waiting ..

.....

.....

.....

.....

.14 ii Find handset....

.....

.....

.....

..14 Chain dialing..

.....

.....

.....

...15 Multiple handset use ..

.....

.....16 Intercom

.....

.....

.....

.....

...16 Answer an incoming call during an intercom call..

.....

.....16 Share an outside call.....

.....

...17 Directory ..

.....

.....

.....

.....

.....

18 Store a directory entry.....

.....

.....19 Character chart

.....

.....

.....

..20 Search the directory
.....
.....
.21 Alphabetical search
.....
.21 Dial a directory entry
.....
.....21 Edit a directory entry .
.....
.....
..22 Delete from the directory...
.....22 About caller ID .
.....
.....
.....23 Call log ...
.....
.....
.....
.....24 Missed calls indicator
.....
..25 Review the call log
.....
..25 Make a call log entry ready to dial ...
.....
.....
.....
26 Dial a call log entry
.....
26 Save a call log entry to the directory
.....
.....
.....26 Delete from the call log ..
.....
..27 Call log display screen messages.....
.....
.....
....27 Redial list
.....
.....
.....
28 Dial a redial entry
.....
.....
...28 Delete from redial
.....
.....

.28 Answering system operation ..29 Answering system and voicemail ..
.....
.....
.....
.....
.29 Message capacity
.....
...29 Turn the answering system on or off ..
.....
.....
.....
...30 Call screening ..
.....
.....
.30 Call intercept
.....
.....
.30 Telephone base ringer volume ...30 New message indication .
.....
.31 Message playback
.....
.....
..31 Delete all messages
.....
.32 Record and play memos
.....
...32 Table of contents Record a memo
.....
.....
....32 Message window displays.
.....33 Remote access .
.....
.....
.....
.....34 Appendix
.....
.....
.....
35 Handset display screen messages.....
.....
.....
..35 Handset and telephone base indicators
.....
.....
....37 Battery
.....
.....
.....

.....
....38 Expand your telephone system .

.....
.....

.....
.....

.....

.39 Add and register a handset (optional)

.....
.....

.....

....39 Replace a handset

.....
.....

40 Troubleshooting

.....

.....
..41 Important safety instructions

..47 Operating range ...

.....

.....

..48 Maintenance ...

.....

.....

.....
...48 About cordless telephones..

.....

..49 The RBRC ® seal

.....
.....

..49 Warranty ...

.....

.....

.....

....50 FCC, ACTA and IC regulations ..52 Technical specifications

.....54 Index .

.....

.....

.....

.....

.....

.....

.55 iii Getting started Parts checklist Your telephone contains the following items. Save your sales receipt and original packaging in the event warranty service is necessary. Charger and charger adapter (1 for CS6229-2, 2 for CS6228-3 and CS6229-3, 3 for CS6229-4, 4 for CS6229-5, and 5 for CS6228-6)

Handset (1 for CS6229, 2 for CS6229-2, 3 for CS6228-3 and CS6229-3, 4 for CS6229-4, 5 for CS6229-5, and 6 for CS6228-6) Wall bracket Battery

Telephone base power adapter (1 for CS6229, 2 for CS6229-2, 3 for CS6228-3 and CS6229-3, 4 for CS6229-4, 5 for CS6229-5, and 6 for CS6228-6)

Telephone line cord Battery compartment cover (1 for CS6229, 2 for CS6229-2, 3 for CS6228-3 and CS6229-3, 4 for CS6229-4, 5 for CS6229-5, and 6 for CS6228-6) User's manual Telephone base Quick start guide To purchase replacement batteries or power adapters, visit our website at www.vtechphones.com

or call 1 (800) 595-9511. In Canada, go to www.vtechcanada.com or call 1 (800) 267-7377. 1 Getting started Telephone base and charger installation Install the telephone base and charger(s) as shown below.

Make sure that the electrical outlet is not controlled by a wall switch. If you subscribe to digital subscriber line (DSL) high-speed Internet service through your telephone line, you must install a DSL filter between the telephone line cord and the telephone wall jack. The filter prevents noise and caller ID problems caused by DSL interference. Contact your DSL service provider for more information about DSL filters. Charger adapter Telephone wall jack If you have DSL high speed Internet service, a DSL filter (not included) is required. Telephone line cord Telephone base power adapter Electrical outlet not controlled by

a wall switch Charger Telephone base Use only the power adapters supplied with this product. To order a replacement, visit our website at www.vtechphones.com or call 1 (800) 5959511. In Canada, go to www.vtechcanada.com or call 1 (800) 267-7377. The power adapters are intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling or an under-the-table/cabinet outlet. 2 Getting started Battery installation and charging Install the battery as shown below.

After installing the battery, you might be able to make and receive short calls. For best performance, charge the handset for at least 16 hours before use.

When not in use, place the handset in the telephone base or charger. See page 38 for battery operating times. Battery indicators The screen is blank.

Battery status Battery has no charge and the handset cannot be used. Battery has very little charge and the handset cannot be used. Battery has enough charge to be used for a short time. Action Charge until the screen shows LOW BATTERY (at least 10 minutes). Charge until the screen shows LOW BATTERY (about four minutes). Charge until the screen shows HANDSET X (about one hour). The screen shows PLACE IN CHARGER and flashes . The screen shows LOW BATTERY, flashes, and the handset beeps. The screen shows HANDSET X. Battery is charged.

To keep the battery charged, place it in the telephone base or charger when not in use. 1. If the battery compartment cover is on the handset, press the indentation and slide the cover to remove. 2. Plug the battery securely into the plug inside the handset battery compartment, matching the color-coded label.

3. Place the battery with the label THIS SIDE UP facing up and the wires inside the battery compartment. 4. Align the cover flat against the battery compartment, then slide it towards the center of the handset until it clicks into place. 5.

Charge the handset by placing it in the telephone base or charger. The CHARGE light is on when the handset charges. 1 2 3 4 5 CHARGE light When the screen shows LOW BATTERY, the backlight is off. If the handset will not be used for a long time, disconnect and remove the battery to prevent possible leakage. To purchase replacement batteries, visit our website at www.vtechphones.com.



[You're reading an excerpt. Click here to read official VTECH](#)

[CS6229-4 user guide](#)

<http://yourpdfguides.com/dref/1252055>

vtechphones.com or call 1 (800) 595-9511. In Canada, go to www.vtechcanada.com or call 1 (800) 267-7377.

3 Getting started Installation options Your telephone base is ready for table top use. If you want to mount your telephone on a wall, use the provided wall bracket to connect with a standard dual-stud telephone wall mounting plate. If you do not have this mounting plate, you can purchase one from many hardware or consumer electronics retailers. You might need a professional to install the mounting plate. Table top to wall mount installation 1. Position the telephone base as shown below. Insert the extended tabs (marked B) of the wall bracket into the slots on the back of the telephone base (marked B). Push the telephone base down until it clicks into place. 2. If you are using a DSL filter, plug the line cord into the filter now.

Route the telephone line cord (or DSL filter) through the wall bracket hole. Route the power cord out of the bottom of the telephone. 3. Plug the telephone line cord (or DSL filter) into the wall jack. Plug the power adapter into a power outlet not controlled by a wall switch. 4. Align the holes on the bracket with the standard wall plate and slide the bracket down until it locks securely. Bundle the telephone line cord and power adapter cord neatly with a twist tie. 1 2 3 4 4

Getting started Wall mount to table top installation 1. If the telephone line cord and power adapter cord are bundled, untie them first. 2. Lift the telephone base up to detach it from the black plastic wall bracket. Unplug the telephone line cord (or DSL filter) from the wall. Unplug the power adapter from the power outlet. 3.

See Telephone base and charger installation on page 2. 5 Getting started Handset layout CHARGE light On when the handset is charging in the telephone base or charger. (Directory) Press to enter the directory when the telephone is not in use. While in a menu, press to scroll up. During a call, press to raise the listening volume.

(Speakerphone) Press to switch between speakerphone and handset. /FLASH Press to make or answer a call. During a call, press to receive an incoming call when you receive a call waiting alert. 1 While reviewing a call log entry, press repeatedly to add or remove 1 in front of the telephone number before dialing or saving it in the directory. CID (caller ID) Press to review the call log when the telephone is not in use. While in a menu, press to scroll down. During a call, press to lower the listening volume. MENU/SELECT Press to show the menu. While in a menu, press to select an item, or save an entry or setting. OFF/CLEAR During a call, press to hang up.

While the handset is ringing, press to silence the ringer temporarily. Press and hold while the telephone is not in use to erase the missed calls indicator. During programming, press to exit without making changes. INT (intercom) Press to initiate an intercom conversation or transfer a call. MUTE/REMOVE While on a call, press to mute the microphone. While reviewing the call log or directory, press to delete an individual enlephone settings Clear voicemail If you subscribe to voicemail service offered by your telephone company, NEW VOICEMAIL and appear on the handset, and the VOICEMAIL light on the telephone base flashes when you have new voicemail messages. Contact your local telephone company for more information and assistance about using your voicemail service. After you have listened to all new voicemail messages, the indicators on both the handset and telephone base turn off automatically. Use the clear voicemail feature when the telephone indicates that there is new voicemail but there is none (for example, when you have accessed your voicemail while away from home). Clearing the voicemail waiting indicator only turns off the indicators; it does not delete your voicemail messages.

As long as you have new voicemail messages, your local telephone company continues to send the signal to turn on the indicators. >CLR VOICEMAIL To manually turn off these indicators: HOME AREA CODE 1. Press MENU/SELECT to show the menu when the handset is not in use. 2. Press or to select >CLR VOICEMAIL, then press MENU/SELECT.

The screen shows TURN OFF TURN OFF INDICATOR? INDICATOR? 3. Press MENU/SELECT to confirm your selection. Your telephone service provider might alert you to new messages with a stutter (broken) dial tone. Contact your service provider for details. Home area code If you dial your local calls using only seven digits (area code not required), you can program your home area code so that when you receive a call within your local area, the telephone number is automatically stored >HOME AREA CODE without the area code in the call log.

ANS. SYSTEM 1. Press MENU/SELECT to show the menu when the handset is not in use. 2. Press or to select >HOME AREA CODE, then press MENU/SELECT. The stored home area code appears HOME AREA CODE 800 with the last digit flashing. 3. Use the dialing keys to enter the desired home area code. · Press MUTE/REMOVE to delete a digit. · Press and hold MUTE/REMOVE to delete the entire entry.

4. Press MENU/SELECT to confirm. If, in the future, your telephone company requires you to dial the area code when making a local call, delete the home area code you have already programmed by pressing MUTE/REMOVE. After you have deleted the programmed home area code, ___ appears. 10 Answering system settings Answering system set up Use a system handset to change your answering system settings. Number of rings You can choose from two, four, or six rings; or toll saver. With toll saver selected, the answering system answers after two rings when you have new messages, and after four rings when you have no new messages. This enables you to check for new messages and avoid paying unnecessary long distance charges if you are calling from out of your local area. 1. Press MENU/SELECT to show the menu when the handset is not in use.

2. Press MENU/SELECT to select >ANS. SYSTEM. 3. Press or to select >ANS SYS SETUP, then press MENU/SELECT.

4. Press or to select ># OF RINGS, then press MENU/SELECT. 5. Press or to choose from 2, 4, 6 or TOLL SAVER, then press MENU/SELECT to confirm your selection. Remote code A two-digit security code is required to access the answering system remotely from any touch tone telephone.

The preset code is 19. You can set the code from 10 to 99. 1. Press MENU/SELECT to show the menu when the handset is not in use. 2. Press MENU/SELECT to select >ANS. SYSTEM. 3. Press or to select >ANS SYS SETUP, then press MENU/SELECT. 4.

Press or to select >REMOTE CODE, then press MENU/SELECT. 5. Press or to select, then press MENU/SELECT to confirm. Message alert tone This telephone can beep every 10 seconds to alert you of new messages. The tone stops when all new messages have been reviewed. 1. Press MENU/SELECT to show the menu when the handset is not in use. 2. Press MENU/SELECT to select >ANS. SYSTEM.

3. Press or to select >ANS SYS SETUP, then press MENU/SELECT.



[You're reading an excerpt. Click here to read official VTECH](http://yourpdfguides.com/dref/1252055)

[CS6229-4 user guide](http://yourpdfguides.com/dref/1252055)

<http://yourpdfguides.com/dref/1252055>

4. Press or to select >MSG ALERT TONE, then press MENU/SELECT. 5.

Press or to select from ON or OFF, then press MENU/SELECT to confirm your selection. The answering system must be turned on for the message alert tone to function. 11 Answering system settings Announcement The telephone is preset with a greeting that answers calls with "Hello, please leave a message after the tone." You can use this preset announcement, or replace it with your own. Play your announcement 1.

2. 3. 4. 5. Press MENU/SELECT to show the menu when the handset is not in use. Press MENU/SELECT to select >ANS. SYSTEM. Press or to select >ANS SYS SETUP, then press MENU/SELECT. Press or to select >ANNOUNCEMENT, then press MENU/SELECT. The handset announces, "To play, press 2.

To record, press 7." Press 2 to play. Press MENU/SELECT to show the menu when the handset is not in use. Press MENU/SELECT to select >ANS. SYSTEM. Press or to select >ANS SYS SETUP, then press MENU/SELECT. Press or to select >ANNOUNCEMENT, then press MENU/SELECT. The handset announces, "To play, press 2. To record, press 7." Press 7 to record.

The handset announces, "Record after the tone. Press 5 when you are done." After the tone, speak towards the microphone of the handset. Press 5 when finished. The answering system automatically plays back the newly recorded announcement.

Press 5 to stop the playback at anytime; 2 to replay the recorded announcement; or 7 to record again if desired. Your announcement can be up to 90 seconds in length. Announcements shorter than two seconds are not recorded. Record your own announcement 1. 2.

3. 4. 5. 6. 7. 8. 9. Delete your announcement 1. 2. 3.

4. 5. Press MENU/SELECT to show the menu when the handset is not in use. Press MENU/SELECT to select >ANS. SYSTEM. Press or to select >ANS SYS SETUP, then press MENU/SELECT. Press or to select >ANNOUNCEMENT, then press MENU/SELECT. The handset announces, "To play, press 2. To record, press 7." Press 3 to delete your own recorded announcement.

When your announcement is deleted, calls are answered with the preset announcement. 12 Telephone operation Make a call 1. Press /FLASH or 2. Dial the number. .

You hear a dial tone. Make a predial call 1. Dial the number. 2. Press /FLASH or .

Answer a call Press /FLASH, or any of the dialing keys (0-9, #, *). The screen shows the elapsed time as you talk (in hours, minutes and seconds). When predialing (preview numbers before dialing), press MUTE/REMOVE or OFF/CLEAR to backspace and delete; press and hold REDIAL/PAUSE to insert a dialing pause (p appears). End a call Press OFF/CLEAR or put the handset in the telephone base or charger. Speakerphone information During a call, press use. to switch between speakerphone and normal handset Volume During a call, press VOL or VOL to adjust the listening volume. 13 Telephone operation Mute The mute function allows you to hear the other party but the other party cannot hear you. 1. During a call, press MUTE/REMOVE on the handset. The handset screen shows MUTED for a few seconds and MUTE appears until the mute function is turned off.

2. Press MUTE/REMOVE again to resume the conversation. The handset screen temporarily shows MICROPHONE ON. PHONE 0:00:00 MUTED MUTE Ringer mute When the telephone is ringing, press OFF/CLEAR or MUTE/REMOVE to temporarily silence the ringer without disconnecting the call. The next call rings normally. RINGER MUTE Call waiting If you subscribe to call waiting service from your telephone company, you hear an alert tone if there is an incoming call while you are on another call. · Press /FLASH to answer the new incoming call. Press /FLASH again to return to the original call. Find handset Use this feature to page all system handsets. 1.

Press FIND HANDSET on the telephone base. All idle handsets ring and the screens show ** PAGING **. 2. To end paging, press /FLASH, , any dialing keys (0-9, #, *), or press FIND HANDSET on the telephone base. 14 Telephone operation Chain dialing Use this feature while already dialing one phone number or while on a call to initiate a dialing sequence from numbers stored in the directory, stored in the call log, or from the most recent redial phone number. Chain dialing can be useful when accessing numbers other than phone numbers (such as bank account information or access codes). To access a number in the directory while on a call: 1. Press MENU/SELECT twice to select >DIRECTORY. 2. Scroll to the desired entry by pressing or .

3. Press MENU/SELECT to dial the displayed number. To access a number in the call log while on a call: 1. Press MENU/SELECT and then press to highlight >CALL LOG. 2. Press MENU/SELECT to select. 3. Scroll to the desired entry by pressing or . 4. Press MENU/SELECT to dial the displayed number.

To access the last number on the redial list while on a call: Press REDIAL/PAUSE to dial. Press REDIAL/PAUSE again within two seconds to cancel the chain dialing. 15 Telephone operation Multiple handset use You can use up to two system handsets at a time on an outside call. If a handset is already on a call and you would like to join the call, press /FLASH or on another handset to join the call. To end the call, press OFF/CLEAR or place the handset in the telephone base or charger. The call will not be terminated until all handsets hang up. You can buy additional expansion handsets (model CS6209) for this telephone base. You can register up to 12 handsets to the telephone base. The first nine handsets that you register are named HANDSETS 1-9. Use the handset number to intercom and transfer calls.

Although the names for handsets 10-12 appear in their displays as 10-12, when you intercom or transfer to one of them, you must use *0 for HANDSET 10, *1 for HANDSET 11, and *2 for HANDSET 12. Intercom You can have a conversation between two system handsets, so you can call someone in another room of your home. CALLING OTHER HANDSET 1. Press INT on your handset when not in use. · If you have a two-handset system, your handset screen shows CALLING OTHER HANDSET.

OTHER HANDSET · If you have more than two handsets, your screen IS CALLING shows INTERCOM TO:. Use the dialing keys to select the other handset. Your screen shows CALLING HANDSET X. The other handset rings and its screen shows INTERCOM either OTHER HANDSET IS CALLING or HANDSET X IS CALLING. 2.

To answer the intercom call, press /FLASH, , INT, or any dialing keys (0-9, #, *) on the other handset. Both handsets now show INTERCOM. 3. To end an intercom call, press INT, OFF/CLEAR, or place the handset back in the telephone base or charger. If the other handset does not answer the intercom call within 100 seconds, is in use, or is out of range, your originating handset screen shows UNABLE TO CALL TRY AGAIN and returns to idle mode. Answer an incoming call during an intercom call If you receive an incoming outside call during an intercom call, there is an alert tone. · To answer the call, press /FLASH.



[You're reading an excerpt. Click here to read official VTECH](http://yourpdfguides.com/dref/1252055)

[CS6229-4 user guide](http://yourpdfguides.com/dref/1252055)

<http://yourpdfguides.com/dref/1252055>

The intercom call ends automatically. · To end the intercom call without answering the incoming call, press OFF/CLEAR. 16 Telephone operation Share an outside call You can call another system handset to join an outside call.

That call continues even if you hang up. 1. During a call, press INT. The other handset rings. The outside call is put on hold. · If you have a two-handset system, your handset screen shows CALLING OTHER HANDSET. The other handset rings and its screen shows OTHER HANDSET IS CALLING. · If you have more than two handsets, your screen shows TRANSFER TO:. Use the dialing keys to select the other handset. Your screen then shows CALLING HANDSET X.

The other handset rings and its screen shows HANDSET X IS CALLING. 2. To answer the call on the other handset, press /FLASH, , INT, or any dialing keys (0-9, #, *). The outside call is still on hold and both handsets now show INTERCOM. You can now have a private conversation between the system handsets.

TRANSFER TO: CALLING HANDSET X HANDSET X IS CALLING INTERCOM If you want to cancel an intercom call and reconnect to the outside call before the other handset answers, press /FLASH, or INT on your originating handset. If the other handset does not answer the intercom call within 100 seconds, is in use, or is out of range, your originating handset screen shows UNABLE TO CALL TRY AGAIN and reconnects to the outside call automatically.

3. From this intercom call, you have the following options: · You can let the other handset join you on the outside call in a three-way conversation. Press and hold INT on your originating handset.

· You can transfer the call. Press OFF/CLEAR, or place your handset back in the telephone base or charger. Your screen shows CALL TRANSFERED. The other handset is automatically connected to the outside call. · You can alternate between the outside call (OUTSIDE CALL appears on the screen) and the intercom call (INTERCOM appears on the screen). Press INT repeatedly on your originating handset. · The other person can leave the intercom call by pressing OFF/CLEAR, or placing the other handset back in the telephone base or charger. The outside call continues with the original system handset. 17 Telephone operation Directory The directory can store up to 50 entries with up to 30 digits for each phone number and 15 characters for each name. · When there are no records in the directory, the screen shows DIRECTORY EMPTY.

· When the directory is full and you try to save an entry, the screen shows LIST FULL. · If you try to save a number already stored in the directory, the screen shows ALREADY SAVED. · If the telephone number in the directory exceeds 15 digits, <* appears in front of the telephone number. Press * to move towards the end of the telephone number or press # to move towards the beginning of the telephone number. · Only one handset can review the directory at a time. If a handset tries to enter the directory while another handset is already in it, NOT AVAILABLE AT THIS TIME appears. Directory entries are shared by all system handsets. Any additions, deletions or edits made on one handset affect the directory on all handsets. DIRECTORY EMPTY LIST FULL ALREADY SAVED ELIZABETH JONES <* 180012345678 ELIZABETH JONES <* 800123456 #> ELIZABETH JONES 123456789012 #> 18 Telephone operation Store a directory entry Use the following steps to store an entry in the directory. 1.

Press MENU/SELECT when the handset is not in use. >DIRECTORY 2. Press or to select >DIRECTORY and then press CALL LOG MENU/SELECT. 3. Press or to select >STORE, then press MENU/SELECT.

The screen shows ENTER NUMBER. >STORE 4. Use the dialing keys to enter the number. REVIEW · Press MUTE/REMOVE to backspace and erase a digit. · Press and hold MUTE/REMOVE to erase the ENTER NUMBER entire entry.

· Press to move the cursor to the left or to the right. · Press and hold REDIAL/PAUSE to insert a dialing pause (p appears). ENTER NAME _ - OR Copy a number from the redial list by pressing REDIAL/PAUSE and then , or REDIAL/PAUSE to select a number. Press MENU/SELECT to copy the number. 5. Press MENU/SELECT to move to the name. The screen shows ENTER NAME. 6. Use the dialing keys (see page 20) to enter the name using the method explained in step 4 above. Press # to insert a space.

7. Press MENU/SELECT to confirm. _ 19 Telephone operation Character chart Use the dial pad and the chart below to enter a name (up to 15 characters). Each press of a particular key causes the characters to be displayed in the following order: Number key 1 2 3 4 5 6 7 8 9 0 * # Characters by number of key presses 1 1 A D G J M P T W 0 * space ? ! / () @ 2 # B E H K N Q U X 3 , C F I L O R V Y 4 , 2 3 4 5 6 S 8 Z 5 a d g j m 7 t 9 6 . b e h k n p u w 7 & c f i l o q v x y z r s 8 9 When entering a name in the directory, the first letter of each word is automatically capitalized. 20 Telephone operation Search the directory Entries are sorted alphabetically. To search the directory: when the handset is not in use. 1. Press -OR Press MENU/SELECT when the handset is not in use.

Press or to select >DIRECTORY and then press MENU/SELECT twice.

2. Press or to browse. >REVIEW STORE Alphabetical search VTECH 800-595-9511 To start an alphabetical search: 1. Press when the handset is not in use. -OR Press MENU/SELECT when the handset is not in use.

Press or to select >DIRECTORY and then press MENU/SELECT twice. 2. Use the dialing keys to enter the letters associated with the name. For example, if you have name entries Jenny, Kristen and Linda in your directory, press 5 (JKL) once to find Jenny, twice to find Kristen, or three times to find Linda. If there is no name entry matching your search, the next closest match in alphabetical order appears.

If necessary, use or to browse. Dial a directory entry 1. Press when the handset is not in use. -OR Press MENU/SELECT when the handset is not in use. Press select >DIRECTORY and then press MENU/SELECT twice. 2. Press or , or use the alphabetical search to browse. 3. Press /FLASH or . or to 21 Telephone operation Edit a directory entry Use the following steps to edit an entry in the directory.

1. Press when the handset is not in use. -OR Press MENU/SELECT when the handset is not in use. Press or to select >DIRECTORY and then press MENU/SELECT twice. 2. Press or , or use the alphabetical search to browse (see page 21). 3. Press MENU/SELECT to select an entry. The screen EDIT NUMBER shows EDIT NUMBER. 595-9511_ 4.

Use the dialing keys to edit the number. · Press MUTE/REMOVE to backspace and erase a digit. · Press and hold MUTE/REMOVE to erase the entire entry. · Press to move the cursor to the left or to the right. · Press and hold REDIAL/PAUSE to insert a dialing pause (p appears). · Copy a number from the redial list by pressing REDIAL/PAUSE and then , or REDIAL/PAUSE to select a number.



[You're reading an excerpt. Click here to read official VTECH CS6229-4 user guide](http://yourpdfguides.com/dref/1252055)
<http://yourpdfguides.com/dref/1252055>

Press MENU/SELECT to copy the number. 5. Press MENU/SELECT to move to the name. The screen EDIT NAME shows EDIT NAME. VTECH_ 6. Use the dialing keys (see page 20) to edit the name using the method explained in step 4 above. Press # to insert a space. 7. Press MENU/SELECT to save. Delete from the directory 1. Press when the handset is not in use. -OR Press MENU/SELECT when the handset is not in use. Press select >DIRECTORY and then press MENU/SELECT twice. 2.

Press or , or use the alphabetical search to browse. 3. Press MUTE/REMOVE to remove the selected entry. or to 22 Telephone operation About caller ID You can use this telephone with regular caller ID service or combined caller ID with call waiting. You can use the telephone's other features without subscribing to caller ID services. There might be fees for caller ID services and these services might not be available in all areas. Depending on your service, you might see the caller's number or the caller's name and number. The time and date are sent by the telephone company along with the call information. This product can provide caller ID information only if both you and the caller are in areas offering caller ID service and if both telephone companies use compatible equipment. Caller ID with call waiting lets you see the name and telephone number of the caller before answering the telephone, even while on another call. It might be necessary to change your telephone service to use caller ID with call waiting features. Contact your telephone company if: · You have both caller ID and call waiting, but as separate services (you might need combined service). · You have only caller ID service, or only call waiting service. · You do not subscribe to any caller ID or call waiting services, but wish to order them. 23 Telephone operation Call log If you subscribe to caller ID service, information about each caller appears after the first or second ring.

If you answer a call before the caller information appears on the screen, it will not be saved in the call log. · The call log stores up to 50 entries. Each entry has up to 24 digits for the phone number and 15 characters for the name. If the phone number has more than 15 but fewer than 24 digits, only the last 15 digits appear. If the name has more than 15 characters, only the first 15 characters are shown and saved in the call log. · You can review, redial, and copy an entry into the directory. · Entries appear in reverse chronological order. · When the call log is full, the oldest entry is deleted to make room for new incoming call information. HANDSET X · XX MISSED CALL(S) shows when there are new call log XX MISSED CALLS entries (including missed and unreviewed calls). · CALL LOG EMPTY shows when there are no records in the call log. CALL LOG EMPTY · Only one handset can review the call log at a time. If a handset tries to enter the call log while another handset is already in it, NOT AVAILABLE AT THIS TIME appears. The caller ID information might not be available for every incoming call. The callers might intentionally block their names and/or telephone numbers. For call log entries with numbers between 16 and 23 digits, in order to view the entire number, you must save the entry to the directory (see page 26).

If the phone number has more than 24 digits, it is not saved or shown in the call log. 24 Telephone operation Missed calls indicator When there are unreviewed calls in the call log, the handset shows XX MISSED CALL(S). Each time you review a call log entry marked NEW, the number of missed calls decreases by one. When you have reviewed all the missed calls, the missed calls indicator no longer shows. If you do not want to review the missed calls one by one, press and hold OFF/CLEAR to erase the missed calls indicator. All the entries are then considered old and kept in the call log. HANDSET X XX MISSED CALLS VTECH 800-595-9511 3:45 AM 1/02 NEW Review the call log 1. Press CID when the handset is not in use. 2. Press or to browse through the call log.

-OR 1. Press MENU/SELECT when the handset is not in use. 2. Press or to select >CALL LOG, then press MENU/SELECT. 3.

Press or to select >REVIEW, then press MENU/SELECT. 4. Press or to browse through the call log. VTECH 800-595-9511 3:45 AM 1/02 >CALL LOG RINGER VOLUME · The name (if available), telephone number, date and time of all incoming calls are shown on the screen. · You hear a double beep when the list reaches the beginning or end of the call log.

25 Telephone operation Make a call log entry ready to dial Although the call log entries received have 10 digits (the area code plus the seven-digit number), in some areas, you might need to dial only the seven digits, or 1 plus the seven digits, or 1 plus the area code plus the seven digits. You can change the number of digits that you dial from the call log and store to the directory. 800-595-9511 While reviewing the call log, press # repeatedly to show 1-800-595-9511 595-9511 different dialing options for local and long distance 1-595-9511 numbers before dialing or saving the telephone number in the directory. 595-9511 Press 1 repeatedly if you need to add or remove 1 in front 1-595-9511 of the telephone number before dialing or saving it in the directory. 800-595-9511 When the number is shown in the correct format for dialing, 1-800-595-9511 press /FLASH or to call the number. Dial a call log entry 1. When in the call log, press or to browse. 2. Press /FLASH or to dial the entry. Save a call log entry to the directory 1.

When in the call log, press or to browse. EDIT NUMBER 595-9511_ 2. Press MENU/SELECT to select an entry. The screen displays EDIT NUMBER. 3. Use the dialing keys to edit the number. · Press MUTE/REMOVE to backspace and erase a digit. · Press and hold MUTE/REMOVE to erase the entire entry. ·

Press to move the cursor to the left or to the right. · Press and hold REDIAL/PAUSE to insert a dialing pause (p appears).

· Copy a number from the redial list by pressing REDIAL/PAUSE and then , or REDIAL/PAUSE to select a number. Press MENU/SELECT to copy the number. EDIT NAME 4. Press MENU/SELECT to move to the name. The screen VTECH_ displays EDIT NAME. · Use the dialing keys (see page 20) to edit the name using the same method as explained in step 3 above. Press # to insert a space. 5. Press MENU/SELECT to save. · If the entry is already saved in the directory, the handset shows ALREADY SAVED.

· If there is no caller ID information, the handset shows UNABLE TO SAVE. 26 Telephone operation Delete from the call log To delete one entry: 1. When in the call log, press or to browse. 2. Press MUTE/REMOVE to delete the selected entry. To delete all entries: 1. Press MENU/SELECT when the handset is not in use. 2. Press or to select >CALL LOG, then press MENU/SELECT. 3.

Press or to select >DEL ALL CALLS, then press MENU/SELECT. 4. The screen shows DELETE ALL CALLS? Press MENU/SELECT to confirm.



[You're reading an excerpt. Click here to read official VTECH](#)

[CS6229-4 user guide](#)

<http://yourpdfguides.com/dref/1252055>

DELETE ALL CALLS? Call log display screen messages Displays PRIVATE NAME PRIVATE NUMBER PRIVATE CALLER UNKNOWN NAME UNKNOWN NUMBER UNKNOWN CALLER LONG DISTANCE When The caller is blocking the name. The caller is blocking the telephone number. The caller is blocking the name and number. This caller's name is unavailable. This caller's number is unavailable. No information is available about this caller. It is a long distance call.

OR L (before the caller's number) 27 Telephone operation Redial list The telephone stores the five most recently dialed numbers. · When there are already five entries, the oldest entry is deleted to make room for the new entry. · Entries are shown in reverse chronological order. · Press REDIAL/PAUSE to browse the redial list. Dial a redial entry 1.

Press REDIAL/PAUSE, then , or REDIAL/PAUSE to browse. You hear a double beep when it reaches the beginning or end of the redial list. 2. Press /FLASH or to dial the number. Delete from redial 1.

Press REDIAL/PAUSE, then , or REDIAL/PAUSE to browse. 2. Press MUTE/REMOVE to delete the selected entry. 28 Answering system operation Answering system and voicemail Your telephone has both a digital answering system and voicemail indication. Most telephone companies offer voicemail service (fees may apply). Your telephone's answering system and voicemail indication are independent features, and each alerts you to new messages differently. For more information on the voicemail indicators, see page 10. To listen to your voicemail, follow the instructions provided by your voicemail service provider. To listen to messages recorded on your digital answering system, see page 31. If you subscribe to a voicemail service through your telephone service provider, you can use your telephone answering system and voicemail together.

If you are on a call, or the answering system is busy and you receive another call, the second caller can leave a voicemail message. Set your answering system to answer calls at least two rings earlier than your voicemail is set to answer. For example, set your voicemail to answer calls after six rings and set your answering system to answer after four rings. Some telephone companies program the delay before answering calls in seconds instead of rings; in this case, allow six seconds per ring when determining the appropriate setting. Message capacity The answering system can record and store up to 99 messages. Each message can be up to four minutes in length. The total storage capacity for the announcement, messages and memos is approximately 14 minutes. The actual recording time depends on individual message characteristics. Messages remain available for replay until you delete them. 29 Answering system operation Turn the answering system on or off The answering system must be turned on to answer and record messages.

When the answering system is turned on, the ANS ON/OFF light on the telephone base will be on and ANS ON will display on the handset. To turn on or off with the telephone base: · Press ANS ON/OFF to turn the answering system on or off. If the answering system is turned on, it announces, "Calls will be answered." If the answering system is turned off, it announces, "Calls will not be answered." To turn on or off with a handset: 1.

Press MENU/SELECT to show the menu when the handset is not in use. 2. Press MENU/SELECT to select >ANS. SYSTEM. 3.

Press or to select >ANS SYS SETUP, then press MENU/SELECT. 4. Press MENU/SELECT to select >ANSWER ON/OFF. 5. Press or to choose ON or OFF, then press MENU/SELECT. Call screening You can listen at the telephone base to a caller leaving a message. If you want to turn off the call screening feature, set the telephone base volume to zero. Remember to raise the volume in order to hear your messages during playback. Call intercept If you want to talk to the person whose message is being recorded, press /FLASH on the handset. Telephone base ringer volume Press VOL or VOL on the telephone base to adjust the ringer volume when the telephone is not in use.

When you set the ringer volume to zero, the base ringer is off and the system announces, "Base ringer is off." See page 8 to set the handset ringer volume. 30 Answering system operation New message indication The message window on the telephone base flashes and shows on the handset when there are new answering system messages. If the new message alert tone is turned on, the telephone base beeps every 10 seconds when there are unreviewed messages.

Message playback If you have new messages, the telephone plays only the new messages (oldest first). If there are no new messages, the telephone plays back all messages (oldest first). When playback begins, you hear the total number of messages followed by the day and time of the message. After the last message, the telephone announces, "End of messages." To play messages with the telephone base: 1. Press /PLAY/STOP to listen to messages.

Options during playback: · Press VOL to adjust the speaker volume. · Press /SKIP to skip to the next message. · Press /REPEAT to repeat the message currently playing. Press /REPEAT twice to listen to the previous message. · Press X/DELETE to delete the current message.

The system advances to the next message. · Press /PLAY/STOP to stop. To play messages with a handset: 1. Press MENU/SELECT to show the menu when the handset is not in use. 2.

Press MENU/SELECT to select >ANS. SYSTEM. 3. Press MENU/SELECT to select >PLAY MSGS. Options during playback: · Press VOL to adjust the speaker volume. · Press 6 to skip to the next message. · Press 4 to repeat the message currently playing. Press 4 twice to listen to the previous message. · Press 3 to delete the current message. The system advances to the next message.

· Press 5 to stop. If the answering system has less than five minutes of recording time left, the remaining time is announced. If F and number of messages are flashing in the message window, the memory is full. Delete some messages to make room for more. You can only delete old messages, which are messages you have played. 31 Answering system operation Delete all messages To delete all messages with the telephone base: Press X/DELETE when the phone is not in use. The telephone announces, "To delete all old messages, press DELETE again." Press X/DELETE again. All previously heard messages are erased and the telephone announces, "All old messages deleted." To delete all messages with a handset: 1.

Press MENU/SELECT to show the menu when the handset is not in use. 2. Press MENU/SELECT to select >ANS. SYSTEM. 3.

Press or to select >DEL ALL OLD, then press MENU/SELECT. 4. The handset shows DELETE ALL OLD MSGS? Press MENU/SELECT to confirm your selection. Record and play memos Memos are your own recorded messages used as reminders for yourself or others using the same answering system.



[You're reading an excerpt. Click here to read official VTECH](http://yourpdfguides.com/dref/1252055)

[CS6229-4 user guide](http://yourpdfguides.com/dref/1252055)

<http://yourpdfguides.com/dref/1252055>

You can record your own memos using a system handset.

Playback and delete them in the same way as incoming messages. Record a memo Press MENU/SELECT to show the menu when the handset is not in use. Press MENU/SELECT to select >ANS. SYSTEM. Press or to select >RECORD MEMO, then press MENU/SELECT. The handset announces, "Record after the tone. Press 5 when you are done." After the tone, speak towards the microphone of the handset. 5. Press 5 when finished recording.

The handset announces, "Recorded." 1. 2. 3. 4. "Memory is full," is announced if you record a memo when the memory is full. Each memo can be up to four minutes in length. Memos shorter than one second are not recorded. 32 Answering system operation Message window displays Window displays 0 1-99 0-99 (flashing) 1-99 & F (alternating) 1-99 (flashing) 1-99 1-8 --- (flashing) 0-6 Descriptions No messages. Total number of old messages recorded.

Total number of messages recorded. The telephone base might have lost and regained power. The clock needs to be set. Memory is full with total number of messages recorded. Current message number during new message playback.

Current message number during old message playback. Telephone base speaker volume level while adjusting. Telephone is answering a call or being accessed remotely. The answering system is being programmed. Telephone is being initialized.

Telephone base ringer level while adjusting. If the memory is full, the answering system answers incoming calls after 10 rings and announces, "Memory is full. Enter the remote access code." 33 Answering system operation Remote access A two-digit security code is required to access the answering system remotely from any touch tone telephone. The preset code is 19; see Remote code on page 11 to change it. 1. Dial your telephone number from any touch tone telephone. 2. When the system plays your announcement, enter the two-digit security code. 3.

You can also enter one of the following remote commands. Command 1 2 3 33 4 5 *5 6 *7 8 0 Play all messages. Play only new messages. Delete the current message (during playback). Delete all messages. Repeat the current message (during playback). Stop. Hear a list of remote commands. Skip to the next message (during playback). Record a new announcement.

End the call. Turn the answering system on or off. Function 4. Hang up or press 8 to end the call. If you do not press any keys after you enter the remote access code, all new messages play.

If there are no new messages, all old messages play. Once the new messages have played, the telephone announces the help menu options. If you do not press any key within 20 seconds, the remote access call automatically disconnects. When the answering system is turned off, the telephone answers after 10 rings, and announces, "Please enter your remote access code." 34 Appendix Handset display screen messages ALREADY SAVED CALL LOG EMPTY CALLING

HANDSET X (for models with three or more handsets) CALLING OTHER HANDSET (for models with two handsets) CONNECTING.

.. CHARGING DIRECTORY EMPTY ENDED HANDSET X IS CALLING (for models with three or more handsets) OTHER HANDSET IS CALLING (for models with two handsets) INCOMING CALL INT REQUIRES TWO HANDSETS INTERCOM INTERCOM ENDED LINE IN USE LIST FULL LOW BATTERY MICROPHONE ON MUTED The telephone number entered is already stored in the directory. There are no call log entries. Calling another handset. The cordless handset is searching for the telephone base. The handset with low battery is recharging. There are no directory entries. You have just ended a call. Another system handset is calling.

There is an incoming call. Two handsets are required for an intercom call. The handset is on an intercom call. You have just ended an intercom call. A system handset or another telephone on the same line is in use. The directory is full. The battery needs to be recharged. MUTE is turned off and the person on the other end can hear you. You have turned off the handset microphone. The other party cannot hear you but you can hear the other party.

There are new voicemail messages from your telephone company. NEW VOICEMAIL 35 Appendix Handset display screen messages NO LINE NO SIGNAL, CALL ENDED NOT AVAILABLE AT THIS TIME OUTSIDE CALL **PAGING** PHONE PLACE IN CHARGER There is no telephone line connected.

Communication between handset and telephone base is lost during a call. One handset is already viewing the call log or directory and another handset attempts to review it. Connected to the external call during call transfer.

The cordless handset locator is activated. The handset is on a call. The battery is very low. Place the handset in the telephone base or charger for recharging. The ringer is muted temporarily during an incoming call.

Your selection has been saved. The handset speakerphone is in use. You have attempted to make an intercom call, but the handset you are calling is in the directory, in the call log, out of range or on an outside call. You are attempting to save a caller ID entry with no name or number. There are unreviewed calls in your call log. RINGER MUTE SAVED SPEAKER UNABLE TO CALL TRY AGAIN UNABLE TO SAVE XX MISSED CALLS 36 Appendix Handset and telephone base indicators Handset lights On when the handset speakerphone is in use. CHARGE On when the handset is charging in the telephone base or charger. Telephone base lights IN USE Flashes when there is an incoming call or another telephone sharing the same line is in use. On when the handset is in use. Flashes when you have new voicemail from your telephone company.

On when the answering system is on. VOICEMAIL ANS ON/OFF Handset icons ANS ON MUTE Answering system is turned on. Microphone is muted. Handset ringer off. @@New call log entries. New voicemail received from the telephone company. Speakerphone is in use. Cycles (low, medium, and full) when the handset battery is charging. Flashes when the battery is low and needs charging. Solid when the battery is fully charged.

@@@**Handset is not charging or in use. @@The handset beeps. A battery is properly installed and the screen is blank. @@To order a replacement, visit our website at www.vtechphones.com.

com or call 1 (800) 595-9511. In Canada, go to www.vtechcanada.com or call 1 (800) 267-7377. · Do not dispose of the battery(ies) in a fire.

@@· Do not open or mutilate the battery(ies). @@The electrolyte might be toxic if swallowed. @@@@Each handset is assigned a number that shows on the handset display. @@@@When first purchased, each expansion handset shows NOT REGISTERED. @@@@To register a handset: 1. Place the unregistered handset in the telephone base or charger. @@2. @@The handset shows PLEASE WAIT...

and it takes about 10 seconds to complete the registration. @@@@Try the registration process again. @@@@To de-register all handsets: 1. Press and hold FIND HANDSET on the telephone base for about 10 seconds (until the IN USE light on the telephone base turns on and starts to flash), then release FIND HANDSET.



[You're reading an excerpt. Click here to read official VTECH](#)

[CS6229-4 user guide](#)

<http://yourpdfguides.com/dref/1252055>

2. Press and release FIND HANDSET again. You must press FIND HANDSET while the IN USE light is still flashing. The IN USE light flashes for approximately seven seconds. 3. All system handsets show CONNECTING.

.. The de-registration process takes about 10 seconds to complete. All handsets show NOT REGISTERED when the de-registration completes. If de-registration fails, you might need to reset the telephone and try again.

To reset: /FLASH. 1. Pick up the registered handset and then press 2. Press OFF/CLEAR and place the handset back in the telephone base. -OR1.

Unplug the power from the telephone base, then plug it back in. You cannot de-register a handset if any system handset is in use. 40 Appendix Troubleshooting If you have difficulty with your telephone, please try the suggestions below. For Customer Service, visit our website at www.vtechphones.com, or call 1 (800) 595-9511; in Canada, call 1 (800) 267-7377. My telephone does not work at all. · Make sure the battery is installed and charged correctly (page 3). For optimum daily performance, return the handset to the telephone base or charger after use. · Make sure the power adapter is securely plugged into an outlet not controlled by a wall switch.

· Make sure the telephone line cord is plugged firmly into the telephone base and the telephone wall jack. · Unplug the electrical power to the telephone base. Wait for approximately 15 seconds, then plug it back in. Allow up to one minute for the cordless handset and telephone base to synchronize. · Charge the battery in the handset for up to 16 hours. · If the battery is completely depleted, it can take up to 10 minutes to charge the handset before PLACE IN CHARGER or LOW BATTERY appears on the screen (page 3). · Remove and re-insert the battery. If that still does not work, it might be necessary to purchase a new battery. · Disconnect the telephone base from the telephone wall jack and plug in a working telephone. If the other telephone does not work, the problem is probably in the wiring or the local service.

Call the local telephone company. LOW BATTERY shows on screen. · Place the handset in the telephone base or charger for recharging. · Remove and re-install the battery and use it until fully depleted, then recharge the handset in the telephone base or charger for up to 16 hours. · If the above measures do not correct the problem, replace the battery.

The battery does not charge in the handset or the handset battery does not accept charge. · Make sure the handset is placed in the telephone base or charger correctly. The CHARGE light on the handset should be on. · Remove and reinstall the battery, then charge for up to 16 hours. · If the handset is in the telephone base or charger but the CHARGE light on the handset is not on, refer to The CHARGE light is off in this section.

· If the battery is completely depleted, it can take up to 10 minutes to charge the handset before PLACE IN CHARGER or LOW BATTERY appears on the screen (page 3). · Purchase a new battery. Refer to the Battery section (page 38). 41 Appendix Troubleshooting The CHARGE light is off. · Clean the charging contacts on the handset and telephone base each month with a pencil eraser or a dry non-abrasive fabric. · Make sure the power adapter and telephone line cord are plugged in correctly and securely. · Unplug the power adapter. Wait for 15 seconds before plugging it back in. Allow up to one minute for the handset and telephone base to reset. There is no dial tone.

· · · First, try all the above suggestions. Move the handset closer to the telephone base. It might be out of range. The telephone line cord might be malfunctioning. Install a new telephone line cord. Disconnect the telephone base from the telephone wall jack and connect a different telephone. If there is no dial tone on this telephone either, the problem is in your wiring or local service. Contact your local telephone company. The telephone does not ring when there is an incoming call. · Make sure the handset ringer volume is not set to the lowest level (page 8) and the telephone base ringer volume is not set to zero (page 30).

· Make sure the telephone line cord and power adapter are plugged in properly (page 2). · The handset might be too far from the telephone base. Move it closer to the telephone base. · There might be too many extension phones on the telephone line to allow all of them to ring simultaneously. Unplug some of them.

· If the other telephones in your home are having the same problem, the problem is in the wiring or local service. Contact the local telephone company (charges might apply). · Other electronic products can cause interference to your cordless telephone. Install your telephone as far away as possible from electronic devices such as: wireless routers, radios, cellular telephones, digital telephones, intercoms, room monitors, televisions, VCRs, personal computers, kitchen appliances, and other cordless telephones. · Test a working telephone at the telephone wall jack.

If another telephone has the same problem, the problem is in the telephone wall jack. Contact your local telephone company (charges might apply). · The telephone line cord might be malfunctioning. Install a new telephone line cord. · Re-install the battery and place the handset in the telephone base or charger. · Wait for the handset to synchronize with the telephone base. Allow up to one minute for this to take place. 42 Appendix Troubleshooting I cannot dial out. · First, try all the above suggestions. · Make sure there is a dial tone before dialing.

It is normal if the handset takes a second or two to synchronize with the telephone before producing a dial tone. Wait an extra second before dialing. · If the other telephones in your home are having the same problem, the problem is in the wiring or local service. Contact your local telephone company (charges might apply). · Eliminate any background noise. Mute the cordless handset before dialing, or dial from another room in your home with less background noise. My handset beeps and is not performing normally. · Make sure the power cord is securely plugged into the telephone base. Plug the telephone base into a different working electrical outlet not controlled by a wall switch. · Move the handset closer to the telephone base.

It might be out of range. · Reset the telephone base by unplugging the electrical power to the base. Wait for 15 seconds and plug it back in again. Allow up to one minute for the cordless handset and the telephone base to synchronize. · Other electronic products can cause interference to your cordless telephone.

Install your telephone as far away from these electronic devices as possible: wireless routers, radios, radio towers, pager towers, cellular telephones, intercoms, room monitors, televisions, personal computers, kitchen appliances and other cordless telephones.



[You're reading an excerpt. Click here to read official VTECH CS6229-4 user guide](http://yourpdfguides.com/dref/1252055)
<http://yourpdfguides.com/dref/1252055>

There is interference during a telephone conversation. My calls fade out when I am using the cordless handset. · The handset might be out of range. Move it closer to the telephone base.

· If you subscribe to high-speed Internet service (digital subscriber line - DSL) through your telephone lines, you must install a DSL filter between the telephone base and the telephone wall jack. The filter prevents noise and caller ID problems caused by DSL interference. Please contact your DSL service provider for more information about DSL filters. · Appliances or other cordless telephones plugged into the same circuit as the telephone base can cause interference. Try moving the appliance or telephone base to another outlet. · Other electronic products can cause interference to your cordless telephone. Install your telephone as far away as possible from the following electronic devices: wireless routers, radios, radio towers, pager towers, cellular telephones, digital telephones, intercoms, room monitors, televisions, VCRs, personal computers, kitchen appliances, and other cordless telephones. · If your telephone is plugged in with a modem or a surge protector, plug the telephone (or modem/surge protector) into a different location. If this doesn't solve the problem, relocate your telephone or modem farther apart from each other, or use a different surge protector. 43 Appendix Troubleshooting · The location of your telephone base can impact the performance of your cordless phone.

For better reception, install the telephone base in a centralized location within your home or office, away from walls or other obstructions. In many environments, elevating the telephone base improves overall performance. · Disconnect the telephone base from the telephone wall jack and plug in a corded telephone. If calls are still not clear, the problem is probably in the wiring or local service. Contact your local service company (charges might apply). · If the other telephones in your home are having the same problem, the problem is in the wiring or local service. Contact the local telephone company (charges might apply). I hear other calls when using the telephone. · Disconnect the telephone base from the telephone wall jack. Plug in a different telephone. If you still hear other calls, the problem is probably in the wiring or local service. Call your local telephone company. I hear noise on the cordless handset and the keys do not work. · Make sure the telephone line cord is plugged in securely. My caller ID features are not working properly. · Caller ID is a subscription service. You must subscribe to this service from your local telephone company for this feature to work on your telephone. · The caller might not be calling from an area which supports caller ID. · Both you and the caller's telephone companies must use equipment compatible with the caller ID service. · The caller ID information shows after the first or second ring.

· If you subscribe to high-speed Internet service (digital subscriber line - DSL) through your telephone lines, you must install a DSL filter between the telephone base and the telephone wall jack. The filter prevents noise and caller ID problems caused by DSL interference. Contact your DSL service provider for more information about DSL filters. The telephone does not receive caller ID or the telephone does not show caller ID during call waiting. · Make sure you subscribe to caller ID with call waiting features provided by the local telephone company. · The caller might not be calling from an area which supports caller ID. · Both you and the caller's telephone companies must use equipment compatible with caller ID service. · If you subscribe to high-speed Internet service (digital subscriber line - DSL) through your telephone lines, you must install a DSL filter between the telephone base and the telephone wall jack. The filter prevents noise and caller ID problems caused by DSL interference. Please contact your DSL service provider for more information about DSL filters.

44 Appendix Troubleshooting Caller ID entries do not match the numbers I need to dial. · Caller ID service delivers 10 digits (the area code plus the seven-digits number). If you need to dial something other 10 digits, see page 26 for instructions on changing the number. · If you dial seven digits for local calls you might want to use the Home area code feature (page 10). CONNECTING... shows in the handset screen. · The handset might be out of range. Move it closer to the telephone base.

· Make sure the power cord is securely plugged into the telephone base. Use a working electrical outlet not controlled by a wall switch. · Reset your telephone by unplugging the power adapter from the telephone base. Disconnect the battery from the cordless handset. Wait for 15 seconds, then plug in the power adapter and re-install the battery.

Place the handset in the telephone base and allow up to one minute for the handset and telephone base to synchronize. · Other electronic products might prevent your handset and telephone base from communicating with each other. Install your telephone base as far away from these electronic devices as possible: wireless routers, radios, cellular telephones, intercoms, room monitors, televisions, personal computers, kitchen appliances and other cordless telephones. The answering system does not answer after the number of rings that I programmed it. · Make sure the answering system is on.

When the answering system is on, the ANS ON/OFF light on the telephone base should be lit and ANS ON should show on the handset. · If toll saver is selected, the number of rings changes to two when there are new messages waiting (page 11). · If the memory is full or if the answering system is off, the answering system answers after 10 rings. · In some cases, the answering system is affected by the ringing system used by the local telephone company. The outgoing announcement is not clear. · When recording the announcement, make sure you speak in a normal tone of voice towards the microphone of the handset. · Make sure there is no background noise when recording. 45 Appendix Troubleshooting The messages on the answering system are very difficult to hear. · Press VOL on the telephone base or handset to increase the speaker volume. The answering system does not record messages.

· Make sure the answering system is on. · If the answering machine memory is full, it does not record new messages until some old messages are deleted. The messages on the answering system are incomplete. · If a caller leaves a very long message, part of it might be lost when the answering system disconnects the call after four minutes. · If the memory on the answering system becomes full during a message, the answering system stops recording and disconnects the call.



[You're reading an excerpt. Click here to read official VTECH CS6229-4 user guide](http://yourpdfguides.com/dref/1252055)
<http://yourpdfguides.com/dref/1252055>