



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for ZYXEL GS2200-24. You'll find the answers to all your questions on the ZYXEL GS2200-24 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual ZYXEL GS2200-24**  
**User guide ZYXEL GS2200-24**  
**Operating instructions ZYXEL GS2200-24**  
**Instructions for use ZYXEL GS2200-24**  
**Instruction manual ZYXEL GS2200-24**

## GS2200-24/24P Series

*Intelligent Layer 2 GbE Switch*  
*Intelligent Layer 2 GbE Switch with PoE*

### User's Guide



#### Default Login Details

IP Address	http://192.168.1.1
User Name	admin
Password	1234

Firmware Version 3.90  
Edition 1, 2/2010

[www.zyxel.com](http://www.zyxel.com)

# ZyXEL

Copyright © 2010  
ZyXEL Communications Corporation



[You're reading an excerpt. Click here to read official ZYXEL GS2200-24 user guide](http://yourpdfguides.com/dref/3685410)  
<http://yourpdfguides.com/dref/3685410>

**Manual abstract:**

This is a collection of answers to previously asked questions about ZyXEL products. · Forum This contains discussions on ZyXEL products. Learn from others who use ZyXEL products and share your experiences as well. Customer Support Should problems arise that cannot be solved by the methods listed above, you should contact your vendor. If you cannot contact your vendor, then contact a ZyXEL office for the region in which you bought the device. See [http://www.zyxel.com/web/contact\\_us.php](http://www.zyxel.com/web/contact_us.php) for contact information. Please have the following information ready when you contact an office.

· Product model and serial number. · Warranty Information. · Date that you received your device. · Brief description of the problem and the steps you took to solve it. 4 GS2200-24 User's Guide Document Conventions Document Conventions Warnings and Notes These are how warnings and notes are shown in this User's Guide.

Warnings tell you about things that could harm you or your device. Note: Notes tell you other important information (for example, other things you may need to configure or helpful tips) or recommendations. Syntax Conventions · The GS2200-24 and GS2200-24P may be referred to as the "GS2200-24", "GS2200-24P", "Switch", the "device", the "system" or the "product" in this User's Guide. Differentiation is made where needed. · Product labels, screen names, field labels and field choices are all in bold font.

· A key stroke is denoted by square brackets and uppercase text, for example, [ENTER] means the "enter" or "return" key on your keyboard. · "Enter" means for you to type one or more characters and then press the [ENTER] key. "Select" or "choose" means for you to use one of the predefined choices. · A right angle bracket ( > ) within a screen name denotes a mouse click. For example, Maintenance > Log > Log Setting means you first click Maintenance in the navigation panel, then the Log sub menu and finally the Log Setting tab to get to that screen. · Units of measurement may denote the "metric" value or the "scientific" value. For example, "k" for kilo may denote "1000" or "1024", "M" for mega may denote "1000000" or "1048576" and so on. · "e.g.," is a shorthand for "for instance", and "i.

e.," means "that is" or "in other words". GS2200-24 User's Guide 5 Document Conventions Icons Used in Figures Figures in this User's Guide may use the following generic icons. The Switch icon is not an exact representation of your device. The Switch Computer Notebook computer Server DSLAM Firewall Telephone Router 6 GS2200-24 User's Guide Safety Warnings Safety Warnings · Do NOT use this product near water, for example, in a wet basement or near a swimming pool. · Do NOT expose your device to dampness, dust or corrosive liquids. · Do NOT store things on the device. · Do NOT install, use, or service this device during a thunderstorm. There is a remote risk of electric shock from lightning. · Do not obstruct the device ventilation slots as insufficient airflow may harm your device.

· Connect ONLY suitable accessories to the device. · Do NOT open the device or unit. Opening or removing covers can expose you to dangerous high voltage points or other risks. ONLY qualified service personnel should service or disassemble this device. Please contact your vendor for further information.

· Make sure to connect the cables to the correct ports. · Place connecting cables carefully so that no one will step on them or stumble over them. · Always disconnect all cables from this device before servicing or disassembling. · Use ONLY an appropriate power adaptor or cord for your device. Connect it to the right supply voltage (for example, 110V AC in North America or 230V AC in Europe).

· Use ONLY power wires of the appropriate wire gauge (see Chapter 40 on page 333 for details) for your device. Connect it to a power supply of the correct voltage (see Chapter 40 on page 333 for details). · Do NOT allow anything to rest on the power adaptor or cord and do NOT place the product where anyone can walk on the power adaptor or cord. · Do NOT use the device if the power adaptor or cord is damaged as it might cause electrocution. · If the power adaptor or cord is damaged, remove it from the device and the power source. · Do NOT attempt to repair the power adaptor or cord. Contact your local vendor to order a new one. · Fuse Warning! Replace a fuse only with a fuse of the same type and rating. · The POE (Power over Ethernet) devices that supply or receive power and their connected Ethernet cables must all be completely indoors. Your product is marked with this symbol, which is known as the WEEE mark.

WEEE stands for Waste Electronics and Electrical Equipment. It means that used electrical and electronic products should not be mixed with general waste. Used electrical and electronic equipment should be treated separately. GS2200-24 User's Guide 7 Safety Warnings 8 GS2200-24 User's Guide Contents Overview Contents Overview Introduction and Hardware .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.. 21 Getting to Know Your Switch ...

.....

.....

.....

.....

.....

.....

.....

.....  
.....  
.....

*... 23 Hardware Installation and Connection .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*29 Hardware Panels .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....

*... 33 Basic Configuration .*

.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....

*41 The Web Configurator .....*

.....  
.....

.....  
.....  
.....



.....  
*. 67 Basic Setting ....*

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....

*. 73 Advanced ....*

.....  
.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*.... 91 VLAN .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....

*. 93 Static MAC Forward Setup ....*

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*....113 Static Multicast Forward Setup .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*.117 Filtering .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*121 Spanning Tree Protocol .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....  
..... 123 Bandwidth Control ...

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.. 145 Broadcast Storm Control .....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

..... 149 Mirroring ...

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.. 153 Link Aggregation ...

.....  
.....

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....

*157 Port Authentication .....*

.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*..... 167 Port Security .*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*... 171 Classifier ..*

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....



.....

.....

.....

.....

.....

.....

.....

.....

... 175 Policy Rule .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 181 Queuing Method .

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 187 ...

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....  
.....  
.....  
.....

*. 190 Multicast .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*191 AAA .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*.. 209 IP Source Guard ...*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....  
*221 Loop Guard .....*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

.....  
.....  
.....  
*. 247 Layer 2 Protocol Tunneling .....*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

*... 251 IP Application .....*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

*.. 255 Static Route .....*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... 257 Differentiated Services ....

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

.. 261 GS2200-24 User's Guide 9 Contents Overview DHCP .....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... 265 Management .....

.....  
.....  
.....

.....  
.....  
.....  
.....

.....



.....  
.....  
.....  
... 305 Syslog ..  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.. 307 Cluster Management .....

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.. 33 3.2 Front Panels ..

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.. 33 3.2.1 Console Port .

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.... 35 3.2.2 Gigabit Ethernet Ports ....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
. 35 3.2.3 Mini-GBIC Slots ..

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

..... 36 GS2200-24 User's Guide 11 Table of Contents 3.

2.4 Power Connector .....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....

.....  
.....  
.....  
..... 38 3.  
*3 LEDs* .....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

..... *38 Part II: Basic Configuration*.....

.....  
.....  
.....

.....  
.....  
.....

.. *41 Chapter 4 The Web Configurator* .....

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*43 4.1 Overview* .....

.....  
.....  
.....

.....  
.....  
.....



.....  
.....  
.....

.....  
.....  
.....  
..... 43 4.2 System Login ..

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....  
..... 43 .....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
44 .....

.....  
.....  
.....

.....  
.....  
.....

.....  
49 4.3 The Status Screen 4.3.1 Change Your Password 4.5 Switch Lockout 4.  
4 Saving Your Configuration .....

.....  
.....

.....  
.....

.....  
.....

.....  
.....

..... 49 .....

.....  
.....

.....  
.....

.....  
.....

.....  
..... 50 ..

.....  
.....

.....  
.....

.....  
.....

.....  
.....

.....  
.....

.....  
.....

.....  
.....

... *50 4.6 Resetting the Switch 4.6.1 Reload the Configuration File ....*

.....  
.....

.....  
.....

.....  
.....

*50 4.7 Logging Out of the Web Configurator .....*

.....  
.....



*1 Overview ....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*.. 53 5.1.1 Creating a VLAN .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*... 53 5.1.*

*2 Setting Port VID .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*..... 55 5.2 Configuring Switch Management IP Address ....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
*. 56 Chapter 6 Tutorials ....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*..... 57 6.1 Overview ..*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*.... 57 6.2 How to Use DHCP Snooping on the Switch ....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....

*.. 57 6.3 How to Use DHCP Relay on the Switch ..*

.....

.....  
.....  
.....

.....  
.....

.....  
.....

..... 61 6.3.1 DHCP Relay Tutorial Introduction ..

.....  
.....

.....  
.....  
.....

.....  
.....

..... 61 6.3.2 Creating a VLAN ..

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.. 62 6.3.3 Configuring DHCP Relay .

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....

65 6.3.4 Troubleshooting ...

.....  
.....

.....  
.....

.....  
.....

.....  
.....

.....  
.....

*.. 65 Chapter 7 System Status and Port Statistics .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*. 67 7.1 Overview .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*..... 67 7.1.*

*1 What You Can Do .....*

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*.. 67 7.2 Port Status Summary 7.2.1 Status: Port Details .....*

.....  
.....  
.....

.....  
.....  
.....

.....

.....  
.....  
.....  
..... 68 ...

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*... 70 12 GS2200-24 User's Guide Table of Contents Chapter 8 Basic Setting ..*

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....

*73 8.1 Overview ....*

.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*.. 73 8.1.1 What You Can Do .....*

.....  
.....  
.....



.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 73 8.2 System Information 8.3 General Setup ..

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 74 .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

... 76 ..

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.. 79 8.4 Introduction to VLANs .....

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....

... 78 8.5 Switch Setup Screen 8.6 IP Setup .....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

..... 80 8.6.1 Management IP Addresses ..

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

..... 81 8.7 Port Setup ...

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....

.....  
.....

.....  
.....  
.....  
.....

*83 8.7.1 PoE Setup .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*..... 87 Part III: Advanced.....*

.....  
.....  
.....  
.....

.....  
.....  
.....

.....  
.....

*... 91 Chapter 9 VLAN ..*

.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*.... 93 9.1 Overview .....*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
*. 93 9.1.1 What You Can Do ..*

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
*..... 93 9.1.2 What You Need to Know ...*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
*..... 93 9.2 VLAN Status ..*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....

.....  
.....  
..... 97 9.2.1 VLAN Details .

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
... 98 9.3 Configure a Static VLAN .

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

..... 99 ..

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.... 101 9.4 Configure VLAN Port Settings 9.5 Subnet Based VLANs ....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....

..... 102 9.

*5.1 Configuring Subnet Based VLAN ....*

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*..... 103 9.6 Protocol Based VLANs ...*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

..... 105 9.6.

*1 Configuring Protocol Based VLAN ....*

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*... 106 9.7 Port-based VLAN Setup .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

..... 108 9.

*7.1 Configure a Port-based VLAN .....*

.....  
.....  
.....

.....  
.....  
.....  
.....

.. 109 9.8 Technical Reference .....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

111 9.8.1 Create an IP-based VLAN Example ...

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

.....111 Chapter 10 Static MAC Forward Setup ....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... 113 10.1 Overview ....

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....

.....  
.....  
.....  
.....  
.....

.....113 10.  
*1.1 What You Can Do ....*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

*113 10.2 Configuring Static MAC Forwarding .....*

.....  
.....  
.....  
.....  
.....  
.....  
.....

.....113 Chapter 11 Static Multicast Forward Setup...

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

..... 117 GS2200-24 User's Guide 13 Table of Contents 11.  
*1 Overview .....*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....



.....  
.....  
.....  
.....

.....  
...117 11.1.  
*1 What You Can Do .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

.....117 11.1.2 *What You Need To Know ...*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

.....117 11.2 *Configuring Static Multicast Forwarding ...*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
..118 *Chapter 12 Filtering...*

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....

.....  
.....  
.....

.....  
.....  
..... 121 12.  
1 Overview .....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

.. 121 12.1.1 What You Can Do .....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.. 121 12.2 Configure a Filtering Rule .....

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... 121 Chapter 13 Spanning Tree Protocol...

.....  
.....  
.....

.....  
.....  
.....

.....

.....

.....

.....

.....

.....

.....

.....

*. 123 13.1 Overview .....*

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

*.... 123 13.1.1 What You Can Do ....*

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

*.... 123 13.1.2 What You Need to Know ....*

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

*.... 124 13.2 Spanning Tree Protocol Status Screen ....*

.....

.....

.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
*127 13.3 Spanning Tree Configuration .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
*. 127 13.4 Configure Rapid Spanning Tree Protocol 13.5 Rapid Spanning Tree Protocol Status .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*.. 128 .....*

.....  
.....  
.....

.....  
.....  
.....  
.....

*.... 130 .*

.....  
.....  
.....

.....  
.....  
.....  
.....

*132 .....*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....

.....  
.....  
.....

.....  
.....

... 136 ..

.....  
.....  
.....  
.....

.....  
.....  
.....

..... 139 13.10 Technical Reference ..

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
141 13.10.1 MSTP Network Example ...

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

..... 141 13.10.  
2 MST Region .....

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....  
..... 142 13.10.3 MST Instance ...

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
142 13.10.4 Common and Internal Spanning Tree (CIST) ...

.....  
.....

.....  
.....  
.....

..... 143 Chapter 14 Bandwidth Control...

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

..... 145 14.

1 Overview .....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....

.....  
.....  
.....

*. 145 14.1.1 What You Can Do .....*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*. 145 14.2 Bandwidth Control Setup ...*

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....

*.... 146 Chapter 15 Broadcast Storm Control .*

.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*149 15.1 Overview .....*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....  
.....  
.....

*.. 149 15.1.1 What You Can Do .....*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*.. 149 15.2 Broadcast Storm Control Setup ..*

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*150 Chapter 16 Mirroring .....*

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....

*... 153 14 GS2200-24 User's Guide Table of Contents 16.1 Overview .*

.....  
.....  
.....  
.....  
.....



.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*153 16.1.1 What You Can Do .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*153 16.2 Port Mirroring Setup .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....

*154 Chapter 17 Link Aggregation .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*..... 157 17.  
1 Overview .....*

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
*. 157 17.1.1 What You Can Do ..*

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*. 157 17.1.2 What You Need to Know .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*. 157 17.2 Link Aggregation Status .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

. 159 17.3 Link Aggregation Setting .....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

..... 161 ...

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

..... 163 17.4 Link Aggregation Control Protocol 17.5 Technical Reference .

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

... 164 17.5.

1 Static Trunking Example .....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.... 164 Chapter 18 Port Authentication.

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

..... 167 18.1 Overview ....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

..... 167 18.1.1 What You Can Do .

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

.. 167 18.1.2 What You Need to Know .

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

.. 167 18.2 Port Authentication Configuration ..

.....

.....

.....

.....

.....

.....

.....

.....

.. 168 18.3 Activate *IEEE 802.1x Security* .

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 169 Chapter 19 Port Security.

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

. 171 19.1 Overview ...

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....  
... 171 19.1.  
*1 What You Can Do .....*

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

... 171 19.2 Port Security Setup .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....  
172 Chapter 20 Classifier.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

... 175 20.1 Overview .

.....

.....

.....

.....

.....

.....

.....

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*. 175 20.1.1 What You Can Do .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*. 175 20.1.2 What You Need to Know .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*. 175 20.2 Configuring the Classifier .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*..... 176 20.2.1 Viewing and Editing Classifier Configuration .*

.....  
.....  
.....

.....  
.....  
.....

..... 178 20.3 Classifier Example ....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

... 180 Chapter 21 Policy Rule.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 181 21.1 Policy Rules Overview ..

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 181 21.1.  
1 What You Can Do .....

.....

.....

.....

.....

.....

.....

.....



.....  
.....  
.....

... 181 21.2 Configuring Policy Rules .

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

..... 181 GS2200-24 User's Guide 15 Table of Contents 21.2.1 Viewing and Editing Policy Configuration ..

.....  
.....  
.....  
.....  
.....  
.....  
.....

184 21.3 Policy Example .....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

... 185 Chapter 22 Queuing Method.....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

.....

.....

.....

.... 187 22.

1 Overview .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

. 187 22.1.1 What You Can Do .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

. 187 22.1.2 What You Need to Know .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

. 187 22.2 Configuring Queuing .....

.....

.....

.....

.....

.....

.....

.....

.....  
.....  
.....  
.....

.....  
.....  
*. 188 .....*  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... *190 Chapter 23 Multicast .*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
*. 191 23.1 Overview ...*  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....

.....

.....

.....

*.. 191 23.1.1 What You Can Do .*

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

*..... 191 23.1.2 What You Need to Know .*

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

*..... 191 23.2 Multicast Status ..*

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

*.... 194 23.*

*3 Multicast Setting .....*

.....

.....

.....

.....

.....

.....

.....

.....

.....  
.....  
.....  
.....

..... 195 23.  
*4 IGMP Snooping VLAN .....*

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*198 23.5 IGMP Filtering Profile .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*.. 199 23.6 The MVR Screen .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*.. 201 23.6.1 MVR Group Configuration .....*

.....  
.....  
.....

.....

.....  
.....  
.....

.....  
.....  
..... 203 23.

*6.2 MVR Configuration Example .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
..... 205 Chapter 24 AAA ..

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... 209 24.

*1 Overview .....*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*. 209 24.1.1 What You Can Do .....*

.....  
.....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

*. 209 24.1.2 What You Need to Know ..*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

*. 209 24.2 AAA Screens ...*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

*..... 210 24.3 RADIUS Server Setup 24.4 TACACS+ Server Setup .*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*. 213 24.5 AAA Setup .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*215 24.6 Technical Reference .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*..... 217 24.6.1 Vendor Specific Attribute ...*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*..... 217 24.6.2 Supported RADIUS Attributes ...*

.....



.....  
.....

.....  
.....  
.....

.....  
.....  
.....

..... 219 24.6.3 Attributes Used for Authentication .

.....  
.....  
.....

.....  
.....  
.....

... 219 Chapter 25 IP Source Guard..

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

..... 221 25.  
1 Overview .....

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.. 221 25.1.1 What You Can Do .

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.. 221 25.1.2 What You Need to Know .....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.. 222 16 GS2200-24 User's Guide Table of Contents 25.2 IP Source Guard .....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.. 222 25.3 IP Source Guard Static Binding ..

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... 223 25.  
4 DHCP Snooping .....

.....  
.....  
.....  
.....



.....  
.....  
.....  
.. 233 25.7 ARP Inspection VLAN Status ..  
.....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

.....  
.....  
... 234 25.8 ARP Inspection Log Status .  
.....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

.....  
.....  
.....  
... 235 25.9 ARP Inspection Configure .....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

.....  
.....  
.....  
.....  
..... 236 25.

9.1 ARP Inspection Port Configure .....

.....  
.....  
.....  
.....

.....  
.....  
..... 238 25.  
9.2 ARP Inspection VLAN Configure .....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... 240 25.10 Technical Reference ...

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....

..... 241 25.

10.1 DHCP Snooping Overview .....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... 241 25.

10.2 ARP Inspection Overview ....

.....  
.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

244 Chapter 26 Loop Guard.....

.....  
.....

.....  
.....  
.....  
.....

.....  
.....

.....  
.....

.....  
.....  
.....  
.....

.....  
..... 247 26.  
*1 Overview* .....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
..... 247 26.1.1 *What You Can Do* ..

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
..... 247 26.1.2 *What You Need to Know* ..

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
..... 247 26.2 *Loop Guard Setup* ...

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.... 249 Chapter 27 Layer 2 Protocol Tunneling.

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.. 251 27.1 Overview .....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.... 251 27.1.1 What You Can Do ....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.... 251 27.1.2 What You Need to Know ....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

*.... 251 27.2 Configuring Layer 2 Protocol Tunneling .....*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

*.... 253 Part IV: IP Application.*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

*... 255 Chapter 28 Static Route .....*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

*..... 257 28.1 Overview ....*

.....  
.....  
.....  
.....  
.....  
.....



.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

..... 257 28.1.  
*1 What You Can Do* .....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

... 257 28.2 *Configuring Static Routing* .

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

... 258 *Chapter 29 Differentiated Services* .....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

..... 261 *29.1 Overview* ....

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... 261 GS2200-24 User's Guide 17 Table of Contents 29.1.1 What You Can Do .

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....

.. 261 29.1.2 What You Need to Know .

.....  
.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....

.. 261 29.2 Activating DiffServ ..

.....  
.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.... 263 29.3 DSCP-to-IEEE 802.1p Priority Settings ....

.....

.....  
.....

.....  
.....  
.....

.....  
.....

..... 263 29.

*3.1 Configuring DSCP Settings .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....

*264 Chapter 30 DHCP.....*

.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*..... 265 30.1 DHCP Overview .*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....

*... 265 30.1.*

*1 What You Can Do .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

..... 265 30.1.

*2 What You Need to Know .....*

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

..... 265 30.2 *DHCP Status* .

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*... 267 30.3 Configuring DHCP Global Relay .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....

... 268 30.3.

*1 Global DHCP Relay Configuration Example .....*

.....

.....  
.....  
.....

... 269 30.4 Configuring DHCP VLAN Settings .

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

..... 269 30.

4.1 Example: DHCP Relay for Two VLANs ....

.....  
.....  
.....  
.....  
.....

.. 271 Part V: Management...

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

.... 273 Chapter 31 Maintenance .....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

..... 275 31.1 Overview ...

.....  
.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 275 31.  
1.1 What You Can Do ....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 275 31.  
2 The Maintenance Screen .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 275 31.2.1 Load Factory Default ....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 276 31.

2.2 Save Configuration .....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

..... 277 31.2.

3 Reboot System .....

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

... 277 31.3 Firmware Upgrade .....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

..... 278 ..

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

..... 278 ...

.....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

..... 279 31.4 Restore a Configuration File 31.5 Backup a Configuration File 31.6 Technical Reference .

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

... 280 31.6.1 FTP Command Line .....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

280 31.6.2 Filename Conventions .....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

.. 280 31.6.3 FTP Command Line Procedure .....

.....  
.....  
.....



.....  
.....  
.....

.....  
.....  
.....

281 31.6.4 GUI-based FTP Clients .....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.. 281 31.6.5 FTP Restrictions .....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.... 282 Chapter 32 Access Control.



[You're reading an excerpt. Click here to read official ZYXEL  
GS2200-24 user guide  
http://yourpdfguides.com/dref/3685410](http://yourpdfguides.com/dref/3685410)

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*.. 283 32.1 Overview .....*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*... 283 32.1.1 What You Can Do .....*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*... 283 18 GS2200-24 User's Guide Table of Contents 32.2 The Access Control Main Screen .*

.....  
.....

.....  
.....  
.....  
.....

.....  
.....

.....  
.....

..... 284 32.3 *Configuring SNMP* .

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.. 284 .....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....

.. 287 ..

.....  
.....  
.....

.....  
.....  
.....

.....  
.....

.. 288 ...

.....  
.....  
.....

.....  
.....  
.....

.....  
.. 289 32.4 *Configuring SNMP Trap Group* 32.5 *Setting Up Login Accounts* 32.  
6 *Service Port Access Control* 32.7 *Remote Management* ....

.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*.. 290 32.8 Technical Reference .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*..... 291 32.8.1 About SNMP .*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*.... 292 32.8.2 SSH Overview ....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....

298 32.8.3 Introduction to HTTPS ...

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

... 300 Chapter 33 Diagnostic.

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

305 33.1 Overview .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

... 305 33.2 Diagnostic .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

... 305 Chapter 34 Syslog .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 307 34.1 Overview .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 307 34.1.  
1 What You Can Do .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....  
.....  
... 307 34.2 Syslog Setup .

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

... 308 34.3 Syslog Server Setup .

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 309 Chapter 35 Cluster Management...

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

. 311 35.1 Overview ...

.....

.....

.....

.....

.....

.....

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*311 35.1.1 What You Can Do .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*312 35.2 Cluster Management Status .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*312 35.3 Clustering Management Configuration .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*314 35.4 Technical Reference ....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....



.....  
.....  
.....  
.....

*316 35.4.1 Cluster Member Switch Management .....*

.....  
.....  
.....

.....  
.....  
.....  
.....

*..... 316 Chapter 36 MAC Table.*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*319 36.1 Overview ....*

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*.. 319 36.1.1 What You Can Do .*

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

..... 319 36.1.2 What You Need to Know .

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

..... 319 36.2 Viewing the MAC Table ..

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... 320 Chapter 37 ARP Table ...

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

... 323 37.1 Overview .

.....  
.....  
.....

.....  
.....  
.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

*323 37.1.1 What You Can Do ...*

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

*..... 323 GS2200-24 User's Guide 19 Table of Contents 37.1.2 What You Need to Know ...*

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

*..... 323 37.2 Viewing the ARP Table ....*

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

*..... 324 Chapter 38 Configure Clone .....*

.....

.....

.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*. 325 38.1 Overview .....*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*.... 325 38.2 Configure Clone .....*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*..... 325 Part VI: Troubleshooting & Product Specifications.....*

.....  
.....  
.....

*. 327 Chapter 39 Troubleshooting.....*

.....  
.....  
.....  
.....

.....  
.....



.....  
.....  
.....  
.....

..... 333 *Part VII: Appendices and Index* ....

.....  
.....  
.....

.....  
.....  
.....  
.....

.... 341 *Appendix A Changing a Fuse* .....

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... 343 *Appendix B Common Services*..

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

. 345 *Appendix C Legal Information* ....

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

349 *Index*.....

.....  
.....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

353 20 GS2200-24 User's Guide PART I Introduction and Hardware Getting to Know Your Switch (23) Hardware Installation and Connection (29) Hardware Panels (33) 21 22 CHAPTER 1.1 Introduction 1 Getting to Know Your Switch This chapter introduces the main features and applications of the GS2200-24 and GS2200-24P switches. They are layer-2 standalone Ethernet switch with additional layer-2, layer-3, and layer-4 features suitable for Ethernets. They have twenty-four 10/100/1000 Mbps Ethernet ports. They have four GbE dual personality interfaces with each interface comprising one mini-GBIC slot and one 100/1000 Mbps RJ-45 port, with either port or slot active at a time. The G2200-24P comes with the Power-over-Ethernet (PoE) feature. Both switches are referred to as the Switch in this guide. With its built-in web configurator, managing and configuring the Switch is easy. In addition, the Switch can also be managed via Telnet, any terminal emulator program on the console port, or third-party SNMP management. See Chapter 40 on page 333 for a full list of software features available on the Switch.

This section shows a few examples of using the Switch in various network environments. 1.1.1 Backbone Application The Switch is an ideal solution for small networks where rapid growth can be expected in the near future. The Switch can be used standalone for a group of heavy traffic users.

You can connect computers and servers directly to the Switch's port or connect other switches to the Switch. GS2200-24/24P User's Guide 23 Chapter 1 Getting to Know Your Switch In this example, all computers can share high-speed applications on the server. To expand the network, simply add more networking devices such as switches, routers, computers, print servers etc. Figure 1 Backbone Application 1.1.

2 Bridging Example In this example, the Switch connects different company departments (RD and Sales) to the corporate backbone. It can alleviate bandwidth contention and eliminate server and network bottlenecks. All users that need high bandwidth can connect to high-speed department servers via the Switch. You can provide a super-fast uplink connection by using a Gigabit Ethernet/mini-GBIC port on the Switch. Moreover, the Switch eases supervision and maintenance by allowing network managers to centralize multiple servers at a single location. Figure 2 Bridging Application 24 GS2200-24/24P User's Guide Chapter 1 Getting to Know Your Switch 1.1.3 High Performance Switching Example The Switch is ideal for connecting two networks that need high bandwidth. In the following example, use trunking to connect these two networks. Switching to higher-speed LANs such as ATM (Asynchronous Transmission Mode) is not feasible for most people due to the expense of replacing all existing Ethernet cables and adapter cards, restructuring your network and complex maintenance.

The Switch can provide the same bandwidth as ATM at much lower cost while still being able to use existing adapters and switches. Moreover, the current LAN structure can be retained as all ports can freely communicate with each other. Figure 3 High Performance Switched Workgroup Application 1.1.4 IEEE 802.1Q VLAN Application Examples A VLAN (Virtual Local Area Network) allows a physical network to be partitioned into multiple logical networks. Stations on a logical network belong to one group. A station can belong to more than one group. With VLAN, a station cannot directly talk to or hear from stations that are not in the same group(s) unless such traffic first goes through a router. For more information on VLANs, refer to Chapter 9 on page 93.

1.1.4.1 Tag-based VLAN Example Ports in the same VLAN group share the same frame broadcast domain thus increase network performance through reduced broadcast traffic. VLAN groups can be modified at any time by adding, moving or changing ports without any recabling.

GS2200-24/24P User's Guide 25 Chapter 1 Getting to Know Your Switch Shared resources such as a server can be used by all ports in the same VLAN as the server. In the following figure only ports that need access to the server need to be part of VLAN 1. Ports can belong to other VLAN groups too. Figure 4 Shared Server Using VLAN Example 1.2 Ways to Manage the Switch Use any of the following methods to manage the Switch.

· Web Configurator. This is recommended for everyday management of the Switch using a (supported) web browser. See Chapter 4 on page 43. · Command Line Interface. Line commands offer an alternative to the web configurator and in some cases are necessary to configure advanced features. See the CLI Reference Guide. · FTP. Use FTP for firmware upgrades and configuration backup/restore. See Section 31.6.

1 on page 280. · SNMP. The Switch can be monitored by an SNMP manager. See Section 32.8.1 on page 292. · Cluster Management. Cluster Management allows you to manage multiple switches through one switch, called the cluster manager. See Chapter 35 on page 311. 1.

3 Good Habits for Managing the Switch Do the following things regularly to make the Switch more secure and to manage the Switch more effectively. · Change the password. Use a password that's not easy to guess and that consists of different types of characters, such as numbers and letters.



**[You're reading an excerpt. Click here to read official ZYXEL GS2200-24 user guide](http://yourpdfguides.com/dref/3685410)**  
**<http://yourpdfguides.com/dref/3685410>**

26 GS2200-24/24P User's Guide Chapter 1 Getting to Know Your Switch · Write down the password and put it in a safe place. · Back up the configuration (and make sure you know how to restore it).

Restoring an earlier working configuration may be useful if the device becomes unstable or even crashes. If you forget your password, you will have to reset the Switch to its factory default settings. If you backed up an earlier configuration file, you would not have to totally re-configure the Switch. You could simply restore your last configuration. GS2200-24/24P User's Guide 27 Chapter 1 Getting to Know Your Switch 28 GS2200-24/24P User's Guide CHAPTER 2.

1 Installation Scenarios This chapter shows you how to install and connect the Switch. 2 Hardware Installation and Connection The Switch can be placed on a desktop or rack-mounted on a standard EIA rack. Use the rubber feet in a desktop installation and the brackets in a rack-mounted installation. Note: For proper ventilation, allow at least 4 inches (10 cm) of clearance at the front and 3.4 inches (8 cm) at the back of the Switch. This is especially important for enclosed rack installations. 2.2 Desktop Installation Procedure 1 2 Make sure the Switch is clean and dry. Set the Switch on a smooth, level surface strong enough to support the weight of the Switch and the connected cables. Make sure there is a power outlet nearby.

Make sure there is enough clearance around the Switch to allow air circulation and the attachment of cables and the power cord. 3 2.3 Mounting the Switch on a Rack The Switch can be mounted on an EIA standard size, 19-inch rack or in a wiring closet with other equipment. Follow the steps below to mount your Switch on a standard EIA rack using a rack-mounting kit. GS2200-24/24P User's Guide 29 Chapter 2 Hardware Installation and Connection 2.3.1 Rack-mounted Installation Requirements · Two mounting brackets. · Eight M3 flat head screws and a #2 Philips screwdriver. · Four M5 flat head screws and a #2 Philips screwdriver. Failure to use the proper screws may damage the unit.

2.3.1.1 Precautions · Make sure the rack will safely support the combined weight of all the equipment it contains. · Make sure the position of the Switch does not make the rack unstable or topheavy.

Take all necessary precautions to anchor the rack securely before installing the unit. 2.3.2 Attaching the Mounting Brackets to the Switch 1 Position a mounting bracket on one side of the Switch, lining up the four screw holes on the bracket with the screw holes on the side of the Switch. Figure 5 Attaching the Mounting Brackets 2 Using a #2 Philips screwdriver, install the M3 flat head screws through the mounting bracket holes into the Switch.

Repeat steps 1 and 2 to install the second mounting bracket on the other side of the Switch. You may now mount the Switch on a rack. Proceed to the next section. 3 4 30 GS2200-24/24P User's Guide Chapter 2 Hardware Installation and Connection 2.3.3 Mounting the Switch on a Rack 1 Position a mounting bracket (that is already attached to the Switch) on one side of the rack, lining up the two screw holes on the bracket with the screw holes on the side of the rack. Figure 6 Mounting the Switch on a Rack 2 Using a #2 Philips screwdriver, install the M5 flat head screws through the mounting bracket holes into the rack. Repeat steps 1 and 2 to attach the second mounting bracket on the other side of the rack. 3 GS2200-24/24P User's Guide 31 Chapter 2 Hardware Installation and Connection 32 GS2200-24/24P User's Guide CHAPTER 3.1 Overview 3 Hardware Panels This chapter describes the front panel and rear panel and shows you how to make the hardware connections.

3.2 Front Panels The following figure shows the front panel of the Switch. Figure 7 Front Panel (GS2200-24) LEDs Console Port Ethernet Ports Dual Personality Interfaces GS2200-24/24P User's Guide 33 Chapter 3 Hardware Panels The following table describes the port labels on the front panel. Table 1 Front Panel Connections (GS2200-24) LABEL 24 10/100/ 1000 RJ-45 Ethernet Ports Four Dual Personality Interfaces DESCRIPTION Connect these ports to a computer, a hub, an Ethernet switch or router. Each interface has one 1000BASE-T RJ-45 port and one Small Form-Factor Pluggable (SFP) slot (also called a mini-GBIC slot), with one port or transceiver active at a time. Note: The ports change to fiber mode directly when inserting the fiber module. · Four 100/1000 Mbps RJ-45 Ports: Connect these ports to high-bandwidth backbone network Ethernet switches using 1000BASE-T compatible Category 5/5e/6 copper cables. Four Mini-GBIC Slots: Use mini-GBIC transceivers in these slots for connections to backbone Ethernet switches. · Console Port The console port is for local configuration of the Switch. Figure 8 Front Panel (GS2200-24P) LEDs Console Port Ethernet Ports Dual Personality Interfaces The following table describes the port labels on the front panel.

Table 2 Front Panel Connections (GS2200-24P) LABEL 24 100/1000 BASE-T PoE Ports DESCRIPTION Connect these ports to a computer, a hub, an Ethernet switch or router. 34 GS2200-24/24P User's Guide Chapter 3 Hardware Panels Table 2 Front Panel Connections (GS2200-24P) LABEL Four Dual Personality Interfaces DESCRIPTION Each interface has one 1000BASE-T RJ-45 port and one Small Form-Factor Pluggable (SFP) slot (also called a mini-GBIC slot), with one port or transceiver active at a time. Note: The ports change to fiber mode directly when inserting the fiber module. · Four GE Ethernet 100/1000 Mbps RJ-45 Ports: Connect these ports to high-bandwidth backbone network Ethernet switches using 1000BASE-T compatible Category 5/5e/6 copper cables. Four Mini-GBIC Slots: Use mini-GBIC transceivers in these slots for connections to backbone Ethernet switches. · Console Port The console port is for local configuration of the Switch. 3.2.1 Console Port For local management, you can use a computer with terminal emulation software configured to the following parameters: · VT100 · Terminal emulation · 9600 bps · No parity, 8 data bits, 1 stop bit · No flow control Connect the male 9-pin end of the console cable to the console port of the Switch. Connect the female end to a serial port (COM1, COM2 or other COM port) of your computer.

3.2.2 Gigabit Ethernet Ports The Switch has 1000Base-T auto-negotiating, auto-crossover Ethernet ports. In 10/100/1000 Mbps Gigabit, the speed can be 10 Mbps, 100 Mbps or 1000 Mbps and the duplex mode can be half duplex or full duplex. An auto-negotiating port can detect and adjust to the optimum Ethernet speed (10/100/1000 Mbps) and duplex mode (full duplex or half duplex) of the connected device.



[You're reading an excerpt. Click here to read official ZYXEL GS2200-24 user guide](http://yourpdfguides.com/dref/3685410)  
<http://yourpdfguides.com/dref/3685410>



An auto-crossover (auto-MDI/MDI-X) port automatically works with a straightthrough or crossover Ethernet cable. GS2200-24/24P User's Guide 35 Chapter 3 Hardware Panels Four 1000Base-T Ethernet ports are paired with a mini-GBIC slot to create a dual personality interface. The Switch uses up to one connection for each mini-GBIC and 1000Base-T Ethernet pair. The mini-GBIC slots have priority over the Gigabit ports. This means that if a mini-GBIC slot and the corresponding GbE port are connected at the same time, the GbE port will be disabled.

Note: The dual personality ports change to fiber mode directly when inserting the fiber module. When auto-negotiation is turned on, an Ethernet port negotiates with the peer automatically to determine the connection speed and duplex mode. If the peer Ethernet port does not support auto-negotiation or turns off this feature, the Switch determines the connection speed by detecting the signal on the cable and using half duplex mode. When the Switch's auto-negotiation is turned off, an Ethernet port uses the pre-configured speed and duplex mode when making a connection, thus requiring you to make sure that the settings of the peer Ethernet port are the same in order to connect. 3.2.2.1 Default Ethernet Negotiation Settings The factory default negotiation settings for the Gigabit ports on the Switch are: · Speed: Auto · Duplex: Auto · Flow control: Off · Link Aggregation: Disabled 3.2.2.

2 Auto-crossover All ports are auto-crossover, that is auto-MDIX ports (Media Dependent Interface Crossover), so you may use either a straight-through Ethernet cable or crossover Ethernet cable for all Gigabit port connections. Auto-crossover ports automatically sense whether they need to function as crossover or straight ports, so crossover cables can connect both computers and switches/hubs. 3.2.3 Mini-GBIC Slots These are slots for mini-GBIC (Gigabit Interface Converter) transceivers.

A transceiver is a single unit that houses a transmitter and a receiver. The Switch does not come with transceivers. You must use transceivers that comply with the Small Form-factor Pluggable (SFP) Transceiver MultiSource Agreement (MSA). See the SFF committee's INF-8074i specification Rev 1.0 for details. You can change transceivers while the Switch is operating. You can use different transceivers to connect to Ethernet switches with different types of fiber-optic or even copper cable connectors. 36 GS2200-24/24P User's Guide Chapter 3 Hardware Panels To avoid possible eye injury, do not look into an operating fiber optic module's connectors. · Type: SFP connection interface · Connection speed: 1 Gigabit per second (Gbps) 3.2.3.1 Transceiver Installation Use the following steps to install a mini-GBIC transceiver (SFP module). 1 Insert the transceiver into the slot with the exposed section of PCB board facing down. Press the transceiver firmly until it clicks into place. The Switch automatically detects the installed transceiver.

Check the LEDs to verify that it is functioning properly. Close the transceiver's latch (latch styles vary). Connect the fiber optic cables to the transceiver. 2 3 4 5 Figure 9 Transceiver Installation Example Figure 10 Connecting the Fiber Optic Cables 3.2.3.2 Transceiver Removal Use the following steps to remove a mini-GBIC transceiver (SFP module). 1 2 Remove the fiber optic cables from the transceiver. Open the transceiver's latch (latch styles vary). GS2200-24/24P User's Guide 37 Chapter 3 Hardware Panels Pull the transceiver out of the slot.

3 Figure 11 Removing the Fiber Optic Cables Figure 12 Opening the Transceiver's Latch Example Figure 13 Transceiver Removal Example 3.2.4 Power Connector Note: Make sure you are using the correct power source as shown on the panel. To connect power to the Switch, insert the female end of the power cord to the AC power receptacle on the front panel. Connect the other end of the supplied power cord to a power outlet.

Make sure that no objects obstruct the airflow of the fans (located on the side of the unit). See Chapter 40 on page 333 for information on the Switch's power supply requirements. 3.3 LEDs After you connect the power to the Switch, view the LEDs to ensure proper functioning of the Switch and as an aid in troubleshooting. Table 3 LED Descriptions LED PWR COLOR Green STATUS On Off DESCRIPTION The system is turned on.

The system is off or has failed. 38 GS2200-24/24P User's Guide Chapter 3 Hardware Panels Table 3 LED Descriptions (continued) LED SYS COLOR Green STATUS On Blinking Off DESCRIPTION The system is on and functioning properly. The system is rebooting and performing self-diagnostic tests. The power is off or the system is not ready/ malfunctioning. External power supply is turned on. External power supply is turned off or has failed. A hardware failure is detected. The system is functioning normally. The system is transmitting/receiving to/from a 10 Mbps or a 1000 Mbps Ethernet network. The link to a 10 Mbps or a 1000 Mbps Ethernet network is up.

The system is transmitting/receiving to/from a 100 Mbps Ethernet network. The link to a 100 Mbps Ethernet network is up. The link to an Ethernet network is down. Power is supplied to all ports. There is no power supply. The Gigabit port is negotiating in full-duplex mode. The Gigabit port is negotiating in half-duplex mode. PPS (GS2200-24P only) ALM Ethernet Ports LNK/ACT Green On Off Red On Off Green Blinking On Amber Blinking On Off PoE (GS2200-24P only) FDX Amber (for 1-24 copper ports) Amber (GS2200-24P: for 25-28 copper ports only) On Off On Off Mini-GBIC Slots LNK ACT Green Green On Off Blinking The link to this port is up. The link to this port is not connected. This port is receiving or transmitting data.

GS2200-24/24P User's Guide 39 Chapter 3 Hardware Panels 40 GS2200-24/24P User's Guide PART II Basic Configuration The Web Configurator (43) Initial Setup Example (53) System Status and Port Statistics (67) Basic Setting (73) 41 42 CHAPTER 4.1 Overview 4 The Web Configurator This section introduces the configuration and functions of the web configurator. The web configurator is an HTML-based management interface that allows easy Switch setup and management via Internet browser. Use Internet Explorer 6.0 and later, Netscape Navigator 7.

0 and later, Mozilla Firefox 3.0 and later versions. The recommended screen resolution is 1024 by 768 pixels. In order to use the web configurator you need to allow: · Web browser pop-up windows from your device. Web pop-up blocking is enabled by default in Windows XP SP (Service Pack) 2. · JavaScript (enabled by default). · Java permissions (enabled by default). 4.2 System Login 1 2 Start your web browser. Type "http://" and the IP address of the Switch (for example, the default management IP address is 192.



[You're reading an excerpt. Click here to read official ZYXEL GS2200-24 user guide](http://yourpdfguides.com/dref/3685410)  
<http://yourpdfguides.com/dref/3685410>

168.1.1) in the Location or Address field. Press [ENTER]. GS2200-24/24P User's Guide 43 Chapter 4 The Web Configurator The login screen appears.

The default username is admin and associated default password is 1234. The date and time display as shown if you have not configured a time server nor manually entered a time and date in the General Setup screen. 3 Figure 14 Web Configurator: Login 4 Click OK to view the first web configurator screen. 4.3

The Status Screen The Status screen is the first screen that displays when you access the web configurator. The following figure shows the navigating components of a web configurator screen. Figure 15 Web Configurator Home Screen for GS2200-24 (Status) B C D E A 44 GS2200-24/24P User's Guide Chapter 4 The Web Configurator Figure 16 Web Configurator Home Screen for GS2200-24P (Status) B C D E A A - Click the menu items to open submenu links, and then click on a submenu link to open the screen in the main window. B, C, D, E - These are quick links which allow you to perform certain tasks no matter which screen you are currently working in. B - Click this link to save your configuration into the Switch's nonvolatile memory. Nonvolatile memory is the configuration of your Switch that stays the same even if the Switch's power is turned off.

C - Click this link to go to the status page of the Switch. D - Click this link to logout of the web configurator. E - Click this link to display web help pages. The help pages provide descriptions for all of the configuration screens. GS2200-24/24P User's Guide 45 Chapter 4 The Web Configurator In the navigation panel, click a main link to reveal a list of submenu links.

Table 4 Navigation Panel Sub-links Overview (GS2200-24) BASIC SETTING GS2200-24 ADVANCED APPLICATION IP APPLICATION MANAGEMENT GS2200-24P The following table describes the links in the navigation panel. Table 5 Navigation Panel Links LINK Basic Settings System Info General Setup Switch Setup IP Setup This link takes you to a screen that displays general system information. This link takes you to a screen where you can configure general identification information about the Switch. This link takes you to a screen where you can set up global Switch parameters such as VLAN type, GARP and priority queues. This link takes you to a screen where you can configure the IP address, subnet mask (necessary for Switch management) and DNS (domain name server) and set up to 64 IP routing domains.

This link takes you to a screen where you can configure settings for individual Switch ports. DESCRIPTION Port Setup PoE Setup set priorities so that the Switch is able to reserve and allocate power to certain PDs. (For GS2200-24P only) This link takes you to a screen where you can 46 GS2200-24/24P User's Guide Chapter 4 The Web Configurator Table 5 Navigation Panel Links (continued) LINK VLAN DESCRIPTION This link takes you to screens where you can configure port-based or 802.1Q VLAN (depending on what you configured in the Switch Setup menu). You can also configure a protocol based VLAN or a subnet based VLAN in these screens. This link takes you to a screen where you can configure static MAC addresses for a port. These static MAC addresses do not age out. This link takes you to a screen where you can configure static multicast MAC addresses for port(s). These static multicast MAC addresses do not age out. This link takes you to a screen to set up filtering rules.

This link takes you to screens where you can configure the RSTP/MRSTP/ MSTP to prevent network loops. This link takes you to a screen where you can configure bandwidth limits on the Switch. This link takes you to a screen to set up broadcast filters. This link takes you to screens where you can copy traffic from one port or ports to another port in order that you can examine the traffic from the first port without interference. This link takes you to screens where you can logically aggregate physical links to form one logical, higher-bandwidth link. This link takes you to a screen where you can configure IEEE 802.1x port authentication for clients communicating via the Switch. This link takes you to screens where you can activate MAC address learning and set the maximum number of MAC addresses to learn on a port. This link takes you to a screen where you can configure the Switch to group packets based on the specified criteria. This link takes you to a screen where you can configure the Switch to perform special treatment on the grouped packets.

This link takes you to a screen where you can configure queuing with associated queue weights for each port. This link takes you to screens where you can configure various multicast features, IGMP snooping and create multicast VLANs. This link takes you to a screen where you can configure authentication, authorization services via external servers. The external servers can be either RADIUS (Remote Authentication Dial-In User Service) or TACACS+ (Terminal Access Controller Access-Control System Plus). This link takes you to screens where you can configure filtering of unauthorized DHCP and ARP packets in your network.

This link takes you to a screen where you can configure protection against network loops that occur on the edge of your network. This link takes you to a screen where you can configure L2PT (Layer 2 Protocol Tunneling) settings on the Switch. Advanced Application Static MAC Forwarding Static Multicast Forwarding Filtering Spanning Tree Protocol Bandwidth Control Broadcast Storm Control Mirroring Link Aggregation Port Authentication Port Security Classifier Policy Rule Queuing Method Multicast AAA IP Source Guard Loop Guard Layer 2 Protocol Tunneling GS2200-24/24P User's Guide 47 Chapter 4

The Web Configurator Table 5 Navigation Panel Links (continued) LINK IP Application Static Routing This link takes you to a screen where you can configure static routes. A static route defines how the Switch should forward traffic by configuring the TCP/IP parameters manually. This link takes you to screens where you can enable DiffServ, configure marking rules and set DSCP-to-IEEE802.

Ip mappings. This link takes you to screens where you can configure the DHCP settings. This link takes you to screens where you can perform firmware and configuration file maintenance as well as reboot the system. This link takes you to screens where you can change the system login password and configure SNMP and remote management. This link takes you to a screen where you can view system logs and test port(s). This link takes you to screens where you can setup system logs and a system log server. This link takes you to screens where you can configure clustering management and view its status. This link takes you to a screen where you can view the MAC addresses (and types) of devices attached to what ports and VLAN IDs. This link takes you to a screen where you can view the MAC addresses IP address resolution table.



[You're reading an excerpt. Click here to read official ZYXEL GS2200-24 user guide](http://yourpdfguides.com/dref/3685410)  
<http://yourpdfguides.com/dref/3685410>

*This link takes you to a screen where you can copy attributes of one port to other ports.*

*DESCRIPTION DiffServ DHCP Management Maintenance Access Control Diagnostic Syslog Cluster Management MAC Table ARP Table Configure Clone 48 GS2200-24/24P User's Guide Chapter 4 The Web Configurator 4.3.1 Change Your Password After you log in for the first time, it is recommended you change the default administrator password. Click Management > Access Control > Logins to display the next screen. Figure 17 Change Administrator Login Password 4.4 Saving Your Configuration When you are done modifying the settings in a screen, click Apply to save your changes back to the run-time memory. Settings in the run-time memory are lost when the Switch's power is turned off. Click the Save link in the upper right hand corner of the web configurator to save your configuration to nonvolatile memory. Nonvolatile memory refers to the Switch's storage that remains even if the Switch's power is turned off. Note: Use the Save link when you are done with a configuration session.*

*GS2200-24/24P User's Guide 49 Chapter 4 The Web Configurator 4.5 Switch Lockout You could block yourself (and all others) from managing the Switch if you do one of the following: 1 2 Delete the management VLAN (default is VLAN 1). Delete all port-based VLANs with the CPU port as a member. The "CPU port" is the management port of the Switch. Filter all traffic to the CPU port.*

*Disable all ports. Misconfigure the text configuration file. Forget the password and/or IP address. Prevent all services from accessing the Switch. Change a service port number but forget it.*

*3 4 5 6 7 8 Note: Be careful not to lock yourself and others out of the Switch. 4.6 Resetting the Switch If you lock yourself (and others) from the Switch or forget the administrator password, you will need to reload the factory-default configuration file or reset the Switch back to the factory defaults. 4.6.1 Reload the Configuration File Uploading the factory-default configuration file replaces the current configuration file with the factory-default configuration file. This means that you will lose all previous configurations and the speed of the console port will be reset to the default of 9600 bps with 8 data bits, no parity, one stop bit and flow control set to none. The password will also be reset to "1234" and the IP address to 192.168.1.*

*1. To upload the configuration file, do the following: 1 Connect to the console port using a computer with terminal emulation software. 50 GS2200-24/24P User's Guide Chapter 4 The Web Configurator Disconnect and reconnect the Switch's power to begin a session. When you reconnect the Switch's power, you will see the initial screen. When you see the message "Press any key to enter Debug Mode within 3 seconds ..." press any key to enter debug mode. Type atlc after the "Enter Debug Mode" message. Wait for the "Starting XMODEM upload" message before activating XMODEM upload on your terminal.*

*After a configuration file upload, type atgo to restart the Switch. The Switch is now reinitialized with a default configuration file including the default password of "1234". 2 3 4 5 6 4.7 Logging Out of the Web Configurator Click Logout in a screen to exit the web configurator. You have to log in with your password again after you log out.*

*This is recommended after you finish a management session for security reasons. Figure 18 Web Configurator: Logout Screen 4.8 Help The web configurator's online help has descriptions of individual screens and some supplementary information. Click the Help link from a web configurator screen to view an online help description of that screen. GS2200-24/24P User's Guide 51 Chapter 4 The Web Configurator 52 GS2200-24/24P User's Guide CHAPTER 5.*

*1 Overview This chapter shows how to set up the Switch for an example network. The following lists the configuration steps for the initial setup: · Create a VLAN · Set port VLAN ID · Configure the Switch IP management address 5 Initial Setup Example 5.1.1 Creating a VLAN VLANs confine broadcast frames to the VLAN group in which the port(s) belongs. You can do this with port-based VLAN or tagged static VLAN with fixed port members. In this example, you want to configure port 1 as a member of VLAN 2. Figure 19 Initial Setup Network Example: VLAN GS2200-24/24P User's Guide 53 Chapter 5 Initial Setup Example Click Advanced Application > VLAN in the navigation panel and click the Static VLAN link. 1 2 In the Static VLAN screen, select ACTIVE, enter a descriptive name in the Name field and enter 2 in the VLAN Group ID field for the VLAN2 network. Note: The VLAN Group ID field in this screen and the VID field in the IP Setup screen refer to the same VLAN ID. 3 Since the VLAN2 network is connected to port 1 on the Switch, select Fixed to configure port 1 to be a permanent member of the VLAN only.*

*To ensure that VLAN-unaware devices (such as computers and hubs) can receive frames properly, clear the TX Tagging check box to set the Switch to remove VLAN tags before sending. Click Add to save the settings to the run-time memory. Settings in the run-time memory are lost when the Switch's power is turned off. 4 5 54 GS2200-24/24P User's Guide Chapter 5 Initial Setup Example 5.1.2 Setting Port VID Use PVID to add a tag to incoming untagged frames received on that port so that the frames are forwarded to the VLAN group that the tag defines. In the example network, configure 2 as the port VID on port 1 so that any untagged frames received on that port get sent to VLAN 2. Figure 20 Initial Setup Network Example: Port VID 1 Click Advanced Applications > VLAN in the navigation panel. Then click the VLAN Port Setting link. Enter 2 in the PVID field for port 1 and click Apply to save your changes back to the run-time memory.*

*Settings in the run-time memory are lost when the Switch's power is turned off. 2 GS2200-24/24P User's Guide 55 Chapter 5 Initial Setup Example 5.2 Configuring Switch Management IP Address The default management IP address of the Switch is 192.168.1.*

*1. You can configure another IP address in a different subnet for management purposes. The following figure shows an example. Figure 21 Initial Setup Example: Management IP Address 1 Connect your computer to any Ethernet port on the Switch. Make sure your computer is in the same subnet as the Switch. Open your web browser and enter 192.168.1.1 (the default IP address) in the address bar to access the web configurator. See Section 4.2 on page 43 for more information. Click Basic Setting > IP Setup in the navigation panel. Configure the related fields in the IP Setup screen. For the VLAN2 network, enter 192.168.*

*2.1 as the IP address and 255.255.255.0 as the subnet mask.*



[You're reading an excerpt. Click here to read official ZYXEL GS2200-24 user guide](http://yourpdfguides.com/dref/3685410)  
<http://yourpdfguides.com/dref/3685410>

In the VID field, enter the ID of the VLAN group to which you want this management IP address to belong. This is the same as the VLAN ID you configure in the Static VLAN screen. Click Add to save your changes back to the run-time memory. Settings in the run-time memory are lost when the Switch's power is turned off. 2 3 4 5 6 7 56 GS2200-24/24P User's Guide CHAPTER 6.

1 Overview 6 Tutorials This chapter provides some examples of using the web configurator to set up and use the Switch. The tutorials include: · How to Use DHCP Snooping on the Switch · How to Use DHCP Relay on the Switch 6.2 How to Use DHCP Snooping on the Switch You only want DHCP server A connected to port 5 to assign IP addresses to all devices in VLAN network (V). Create a VLAN containing ports 5, 6 and 7. Connect a computer M to the Switch for management.

Figure 22 Tutorial: DHCP Snooping Tutorial Overview M C B A V Note: For related information about DHCP snooping, see Section 25.1 on page 221. The settings in this tutorial are as the following. Table 6 Tutorial: Settings in this Tutorial HOST DHCP Server (A) PORT VLAN CONNECTED 5 1 and 100 PVID 100 DHCP SNOOPING PORT TRUSTED Yes GS2200-24/24P User's Guide 57 Chapter 6 Tutorials Table 6 Tutorial: Settings in this Tutorial HOST DHCP Client (B) DHCP Client (C) PORT CONNECTED VLAN 6 7 1 and 100 1 and 100 PVID 100 100 DHCP SNOOPING PORT TRUSTED No No 1 Access the Switch through <http://192.168.1.1>.

1.1 by default. Log into the Switch by entering the username (default: admin) and password (default: 1234). Go to Advanced Application > VLAN > Static VLAN, and create a VLAN with ID of 100. Add ports 5, 6 and 7 in the VLAN by selecting Fixed in the Control field as shown. Deselect Tx Tagging because you don't want outgoing traffic to contain this VLAN tag. Click Add. 2 Figure 23 Tutorial: Create a VLAN and Add Ports to It 58 GS2200-24/24P User's Guide Chapter 6 Tutorials Go to Advanced Application > VLAN > VLAN Port Setting, and set the PVID of the ports 5, 6 and 7 to 100. This tags untagged incoming frames on ports 5, 6 and 7 with the tag 100. 3 Figure 24 Tutorial: Tag Untagged Frames 4 Go to Advanced Application > IP Source Guard > DHCP snooping > Configure, activate and specify VLAN 100 as the DHCP VLAN as shown.

Click Apply. Figure 25 Tutorial: Specify DHCP VLAN GS2200-24/24P User's Guide 59 Chapter 6 Tutorials Click the Port link at the top right corner. 5 6 The DHCP Snooping Port Configure screen appears. Select Trusted in the Server Trusted state field for port 5 because the DHCP server is connected to port 5. Keep ports 6 and 7 Untrusted because they are connected to DHCP clients. Click Apply. Figure 26 Tutorial: Set the DHCP Server Port to Trusted 7 Go to Advanced Application > IP Source Guard > DHCP snooping > Configure > VLAN, show VLAN 100 by entering 100 in the Start VID and End VID fields and click Apply. Then select Yes in the Enabled field of the VLAN 100 entry shown at the bottom section of the screen. If you want to add more information in the DHCP request packets such as source VLAN ID or system name, you can also select the Option82 and Information fields in the entry. See Section 25.10.1.3 on page 243. Figure 27 Tutorial: Enable DHCP Snooping on this VLAN 60 GS2200-24/24P User's Guide Chapter 6 Tutorials Click Save at the top right corner of the web configurator to save the configuration permanently. Connect your DHCP server to port 5 and a computer (as DHCP client) to either port 6 or 7.

The computer should be able to get an IP address from the DHCP server. If you put the DHCP server on port 6 or 7, the computer will not be able to get an IP address. 8 9 10 To check if DHCP snooping works, go to Advanced Application > IP Source Guard, you should see an IP assignment with the type dhcp-snooping as shown. Figure 28 Tutorial: Check the Binding If DHCP Snooping Works You can also telnet or log into the Switch's console. Use the command "show dhcp snooping binding" to see the DHCP snooping binding table as shown next.

```
sysname# show dhcp snooping binding MacAddress IpAddress -----00:02:00:00:00:1c 10.10.1.16 Total number of bindings: 1 Lease -----6d23h59m20s Type -----dhcp-snooping VLAN ---100 Port ----7
```

6.3 How to Use DHCP Relay on the Switch This tutorial describes how to configure your Switch to forward DHCP client requests to a specific DHCP server. The DHCP server can then assign a specific IP address based on the information in the DHCP requests. 6.3.1 DHCP Relay Tutorial Introduction In this example, you have configured your DHCP server (192.168.

2.3) and want to have it assign a specific IP address (say 172.16.1.18) to DHCP client A based on GS2200-24/24P User's Guide 61 Chapter 6 Tutorials the system name, VLAN ID and port number in the DHCP request. Client A connects to the Switch's port 2 in VLAN 102. Figure 29 Tutorial: DHCP Relay Scenario DHCP Server 192.168.2.3 Port 2 PVID=102 A VLAN 102 172.

16.1.18 6.3.2 Creating a VLAN Follow the steps below to configure port 2 as a member of VLAN 102.

1 2 Access the web configurator through the Switch's management port. Go to Basic Setting > Switch Setup and set the VLAN type to 802.1Q. Click Apply to save the settings to the run-time memory. Figure 30 Tutorial: Set VLAN Type to 802.

1Q 62 GS2200-24/24P User's Guide Chapter 6 Tutorials Click Advanced Application > VLAN > Static VLAN. In the Static VLAN screen, select ACTIVE, enter a descriptive name (VLAN 102 for example) in the Name field and enter 102 in the VLAN Group ID field. Select Fixed to configure port 2 to be a permanent member of this VLAN. Clear the TX Tagging check box to set the Switch to remove VLAN tags before sending. Click Add to save the settings to the run-time memory. Settings in the run-time memory are lost when the Switch's power is turned off. 3 4 5 6 7 Figure 31 Tutorial: Create a Static VLAN GS2200-24/24P User's Guide 63 Chapter 6 Tutorials Click the VLAN Status link in the Static VLAN screen and then the VLAN Port Setting link in the VLAN Status screen. 8 Figure 32 Tutorial: Click the VLAN Port Setting Link 9 Enter 102 in the PVID field for port 2 to add a tag to incoming untagged frames received on that port so that the frames are forwarded to the VLAN group that the tag defines. 10 Click Apply to save your changes back to the run-time memory. Figure 33 Tutorial: Add Tag for Frames Received on Port 2 64 GS2200-24/24P User's Guide Chapter 6 Tutorials 11 Click the Save link in the upper right corner of the web configurator to save your configuration permanently.

6.3.3 Configuring DHCP Relay Follow the steps below to enable DHCP relay on the Switch and allow the Switch to add relay agent information (such as the VLAN ID) to DHCP requests.



[You're reading an excerpt. Click here to read official ZYXEL GS2200-24 user guide](http://yourpdfguides.com/dref/3685410)  
<http://yourpdfguides.com/dref/3685410>



1 Click IP Application > DHCP and then the Global link to open the DHCP Relay screen. Select the Active check box. Enter the DHCP server's IP address (192.168.2.3 in this example) in the Remote DHCP Server 1 field. Select the Option 82 and the Information check boxes.

Click Apply to save your changes back to the run-time memory. 2 3 4 5 Figure 34 Tutorial: Set DHCP Server and Relay Information 6 Click the Save link in the upper right corner of the web configurator to save your configuration permanently. The DHCP server can then assign a specific IP address based on the DHCP request. 7 6.3.

4 Troubleshooting Check the client A's IP address. If it did not receive the IP address 172.16.1.18, make sure: GS2200-24/24P User's Guide 65 Chapter 6 Tutorials Client A is connected to the Switch's port 2 in VLAN 102.

You configured the correct VLAN ID, port number and system name for DHCP relay on both the DHCP server and the Switch. You clicked the Save link on the Switch to have your settings take effect. 1 2 3 66 GS2200-24/24P User's Guide CHAPTER 7.1 Overview 7 System Status and Port Statistics This chapter describes the screens for system status (web configurator home page), port details and PoE status. The home screen of the web configurator displays a port statistical summary with links to each port showing statistical details. 7.1.1 What You Can Do · Use the Port Status Summary screen (Section 7.2 on page 68) to view the port statistics. · Use the Port Details screen (Section 7.

2.1 on page 70) to display individual port statistics. GS2200-24/24P User's Guide 67 Chapter 7 System Status and Port Statistics 7.2 Port Status Summary To view the port statistics, click Status in all web configurator screens to display the Status screen as shown next. Figure 35 Status (GS2200-24) Figure 36 Status (GS2200-24P) 68 GS2200-24/24P User's Guide Chapter 7 System Status and Port Statistics The following table describes the labels in this screen. Table 7 Status LABEL Port Name Link DESCRIPTION This identifies the Ethernet port. Click a port number to display the Port Details screen (refer to Figure 37 on page 70). This is the name you assigned to this port in the Basic Setting > Port Setup screen. This field displays the speed (either 10M for 10Mbps, 100M for 100Mbps or 1000M for 1000Mbps) and the duplex (F for full duplex or H for half). It also shows the cable type (Copper or Fiber) for the combo ports.

If STP (Spanning Tree Protocol) is enabled, this field displays the STP state of the port (see Section 13.1 on page 123 for more information). If STP is disabled, this field displays FORWARDING if the link is up, otherwise, it displays STOP. State PD LACP TxPkts RxPkts Errors Tx KB/s Rx KB/s Up Time Clear Counter (for GS2200-24P only) This field displays whether or not a powered device (PD) is allowed to receive power from the Switch on this port. This fields displays whether LACP (Link Aggregation Control Protocol) has been enabled on the port.

This field shows the number of transmitted frames on this port. This field shows the number of received frames on this port. This field shows the number of received errors on this port. This field shows the number of kilobytes per second transmitted on this port. This field shows the number of kilobytes per second received on this port.

This field shows the total amount of time in hours, minutes and seconds the port has been up. Enter a port number and then click Clear Counter to erase the recorded statistical information for that port, or select Any to clear statistics for all ports. GS2200-24/24P User's Guide 69 Chapter 7 System Status and Port Statistics 7.2.1 Status: Port Details Click a number in the Port column in the Status screen to display individual port statistics. Use this screen to check status and detailed performance data about an individual port on the Switch. Figure 37 Status > Port Details The following table describes the labels in this screen.

Table 8 Status: Port Details LABEL Port Info Port NO. Name Link This field displays the port number you are viewing. This field displays the name of the port.

This field displays the speed (either 10M for 10Mbps, 100M for 100Mbps or 1000M for 1000Mbps) and the duplex (F for full duplex or H for half duplex). It also shows the cable type (Copper or Fiber). DESCRIPTION 70 GS2200-24/24P User's Guide Chapter 7 System Status and Port Statistics Table 8 Status: Port Details (continued) LABEL Status DESCRIPTION If STP (Spanning Tree Protocol) is enabled, this field displays the STP state of the port (see Section 13.1 on page 123 for more information). If STP is disabled, this field displays FORWARDING if the link is up, otherwise, it displays STOP. LACP TxPkts RxPkts Errors Tx KB/s Rx KB/s Up Time Tx Packet This field shows if LACP is enabled on this port or not. This field shows the number of transmitted frames on this port This field shows the number of received frames on this port This field shows the number of received errors on this port. This field shows the number kilobytes per second transmitted on this port. This field shows the number of kilobytes per second received on this port. This field shows the total amount of time the connection has been up.

The following fields display detailed information about packets transmitted. TX Packets Multicast Broadcast Pause Rx Packet The following fields display detailed information about packets received. RX Packets Multicast Broadcast Pause TX Collision The following fields display information on collisions while transmitting. Single Multiple Excessive Late Error Packet RX CRC This is a count of successfully transmitted packets for which transmission is inhibited by exactly one collision. This is a count of successfully transmitted packets for which transmission was inhibited by more than one collision.

This is a count of packets for which transmission failed due to excessive collisions. Excessive collision is defined as the number of maximum collisions before the retransmission count is reset. This is the number of times a late collision is detected, that is, after 512 bits of the packets have already been transmitted. The following fields display detailed information about packets received that were in error. This field shows the number of packets received with CRC (Cyclic Redundant Check) error(s).

This field shows the number of good packets (unicast, multicast and broadcast) received. This field shows the number of good multicast packets received. This field shows the number of good broadcast packets received. This field shows the number of 802.3x Pause packets received. This field shows the number of good packets (unicast, multicast and broadcast) transmitted. This field shows the number of good multicast packets transmitted. This field shows the number of good broadcast packets transmitted. This field shows the number of 802.



[You're reading an excerpt. Click here to read official ZYXEL](http://yourpdfguides.com/dref/3685410)

[GS2200-24 user guide](http://yourpdfguides.com/dref/3685410)

<http://yourpdfguides.com/dref/3685410>