



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for NILFISK GD 110. You'll find the answers to all your questions on the NILFISK GD 110 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual NILFISK GD 110
User guide NILFISK GD 110
Operating instructions NILFISK GD 110
Instructions for use NILFISK GD 110
Instruction manual NILFISK GD 110

GD 110



BRUKSANVISING
BRUGSANVISING
KÄYTTÖOHJE
INSTRUCTIONS FOR USE
MODE D'EMPLOI
BEDIENUNGSANLEITUNG

INSTRUCCIONES DE USO
ISTRUZIONI PER L'USO
INSTRUÇÕES DE MANEJO
GEBRUIKSAANWIJZING
Инструкции по эксплуатации



Printed in Hungary



823 0011 000
P00 2008-01



[You're reading an excerpt. Click here to read official NILFISK GD 110 user guide](http://yourpdfguides.com/dref/2884922)

<http://yourpdfguides.com/dref/2884922>

Manual abstract:

De hulpstukken op de afbeeldingen kunnen van model tot model variëren. The suction efficiency of the vacuum cleaner depends on the size and quality of the dust bag. This appliance is protected by a construction with double insulation. @@@@Disconnect the cleaner before servicing and when not in use. Do not use with damaged cord or plug. to unplug grasp the plug , not the cord. Do not handle plug or cleaner with wet hands. Turn off all controls before unplugging. @@ do not run cleaner over cord. Keep cord away from hot surfaces.

@@Do not put any objects into openings or use with opening blocked. Keep openings free of dust, lint, hair, and anything else that could reduce the flow of air. This appliance is not to be used by children or persons with reduced physical, sen-sory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction. Children must be supervised not to play with the appliance. Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.

Take extra care when using on stairs. Do not use this cleaner to pick up flammable or combustible liquids such as gasoline, or use in areas where they may be present. Do not allow it to be used as a toy. Close attention is necessary when used near children. Caution: Do not use this appliance for vacuuming dust which may be considered hazardous to health.

Do not use unless filter and dustbag is fitted. Check the condition of the filter when you replace the dust bag. @@@@Replacement parts for a double-insulated appliance must be identical to the parts they replace. A double insulated appliance is marked with the words "DOUBLE INSULATION" or "DOUBLE INSULATED. " The symbol (square within a square) may also be used on the product. This vacuum cleaner is equipped with a specially designed cable, which if damaged, must be replaced by a cable of the same type. This cable is available from the manufacturerer and authorised dealers and must be installed by trained personnel. @@@@REGULAR SERVICING AND INSPECTION of your machine must be carried out by suitably qualified personnel in accordance with relevant legislation and regulations. In particular, electrical tests for earth continuity, insulation resistance, and condition of the flexible cord should be checked frequently. In the event of any defect, the machine MUST be withdrawn from service, completely checked and repaired.

@@Machine are fitted with a 13 amp. Only fuses that are ASTA approved to BS 1362 should be fitted. Never use the plug without the fuse cover fitted.

@@@@If it is necessary to fit a plug, the wires in this power supply cord are coloured in accordance with the following code: If using a three-pin plug, do not make any connection to the the terminal in the plug which is marked with the letter 'E' or by the safety earth symbol or coloured green or green & yellow. This machine is double-insulated and no earth connection is necessary. The blue wire must be connected to the terminal in the plug which is marked with the letter 'N' or is coloured black or blue. The brown wire which must be connected to the terminal in the plug which is marked with the letter 'L' or is coloured red or brown. @@@@Power Suction Power Vacuum Air flow Sound pressure level Sound power Paper bag capacity Weight 1000W 1100W 300W, at nozzle 25 kPa, at nozzle 36 l/s, at nozzle 55 dB(A) BS 5415 75 dB(A) IEC 704 10 L 4. Specifications and details are subject to change without prior notice .



[You're reading an excerpt. Click here to read official NILFISK GD](#)

[110 user guide](#)

<http://yourpdfguides.com/dref/2884922>