



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BEHRINGER MDX1400. You'll find the answers to all your questions on the BEHRINGER MDX1400 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BEHRINGER MDX1400
User guide BEHRINGER MDX1400
Operating instructions BEHRINGER MDX1400
Instructions for use BEHRINGER MDX1400
Instruction manual BEHRINGER MDX1400



User's Manual

ENGLISH

Version 1.4 June 2001



[You're reading an excerpt. Click here to read official BEHRINGER MDX1400 user guide](http://yourpdfguides.com/dref/2301859)
<http://yourpdfguides.com/dref/2301859>

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

... 8 Compressor Section .

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.. 9 Dynamic Enhancer Section ..

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

10 Rear Panel Control Elements Of The AUTOCOM PRO

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 10.3. APPLICATIONS ...

.....

.....

.....

.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

... 11 3.1 Compression/Levelling/Limiting/Clipping

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.... 11 3.2 Expander/Gate Section

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 12 3.2.

1 Controlling Leakage In The Studio

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 12 3.2.2 Initial Settings For The Expander/Gate Section .

.....
.....

.....
.....

.....
.....
.....
.....

..... 13 3.2.3 Reducing Leakage In Stage Mics ..

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 13 3.2.4 Reducing Feedback In Stage Mics ..

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.... 14 3.2.5 Noise Reduction On Effects Paths

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.. 14 3.2.6 Creative Use Of The Expander/Gate Section

.....
.....
.....

.....
.....
.....
.....

.....
.....

14 3.3 Compressor Section

.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

1 Initial Settings For The Compressor Section

.....
.....
.....
.....

.....
.....
.....

..... 15 3.3.2 The AUTOCOM PRO As A Sound Effects Unit ..

.....
.....
.....
.....

.....
.....
.....
.....

..... 16 3.3.3 The Muffling Effect Of A Compressor ..

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

..... 16 3.

4 Dynamic Enhancer Section

.....
.....
.....

.....
.....
.....
.....

.....

.....
.....
.....
.....
.....

.. 16 3.4.1 Initial Settings For The Dynamic Enhancer Section .



[You're reading an excerpt. Click here to read official BEHRINGER MDX1400 user guide](http://yourpdfguides.com/dref/2301859)
<http://yourpdfguides.com/dref/2301859>

.....
.....
.....
.....

.....
.....
.....
17 4. SPECIAL APPLICATIONS

.....
.....
.....

.....
.....
.....

.....
.....
.....

.. 17 4.1 Using The AUTOCOM PRO For Recording And Cassette Duplication

.....
.....
.....

.....
.....
.. 4.1.1 The AUTOCOM PRO In Digital Recording And Sampling .

.....
.....
.....
.....

.....
.. 4.1.2 The AUTOCOM PRO In Mastering .

.....
.....

.....
.....
.....

.....
.....
.....

.....
4.2 The AUTOCOM PRO As A Protective Device

.....
.....

.....
.....
.....

.....
.....
.....
.....

.. 4.2.1 Protection Of A System With A Passive Crossover

.....
.....
.....

.....
.....
.....
.....

..... 4.2.2 Protection Of A System With An Active Crossover ..

.....
.....
.....

.....
.....
.....
.....

. 4.2.3 Improving The Sound Of A Processor System ..

.....
.....

.....
.....
.....
.....

.....
.....
.....

.. 4.3 The AUTOCOM PRO In Broadcast

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

..... 5.

1 The Sidechain Function

.....
.....
.....

.....
.....
.....
.....

.....
.....

.....
.....

... 5.2 Using An Equalizer In The Sidechain Path

.....
.....
.....

.....
.....
.....

.....

.....

1 The AUTOCOM PRO As A De-Esser

.....
.....
.....

.....
.....
.....

. 5.2.2 Frequency Selective Filtering Of Unwanted Signals ..

.....
.....

.....
.....
.....

.....

2.3 Suppressing Instruments During Recording

.....

.....
.....
.....

.....

.....

2.4 Emphasizing Musical Instruments During Recording

.....
.....
.....

.....
.....
.....

the transition from signal to noise floor. This can mean, that the start or end of words can be cut on a vocal track. A newly developed IRC (Interactive Ratio Control) Expander has been integrated into the AUTOCOM PRO the ratio of which, is automatically adjusted, depending on the program material. The result is an expander which is less critical of adjustment and which is more tolerant in the presence of those signals which appear slightly above the noise floor. Because of its new IRC circuit design, the BEHRINGER AUTOCOM PROs Expander/ 6 1. INTRODUCTION AUTOCOM PRO MDX1400 Gate section can be used as an independent unit to eradicate noise offering almost limitless possibilities within this application. The BEHRINGER Dynamic Enhancer One of the most common negative effects of broadband compressors is the dulled or squashed sound that is produced when it is applied to composite music, since high-energy low frequency instruments cause a compressor to reduce the overall gain. Any high frequency instrument which occurs at the same time will also be reduced in level. This spectral intermodulation causes the squashed sound effect.

The solution to this problem is the new AUTOCOM PROs Dynamic Enhancer which allows for selective replacement of high-end loss accrued through use of compression. Since the Enhancer tracks the amount of compression, enhancement will not be added when no compression throughout the mix without any additional outboard enhancer etc. + The following instructions should familiarize you with the special terms used first, so that you can get to know all the functions of the unit. After you have read the instructions carefully, please put them away safely, so that you can refer to them again if necessary. 1.2 Before you begin Your BEHRINGER AUTOCOM PRO was carefully packed in the factory and the packaging is designed to protect the unit from rough handling. Nevertheless, we recommend that you carefully examine the packaging and its contents for any signs of physical damage, which may have occurred during transit. + If the unit is damaged, please do not return it to BEHRINGER, but notify your dealer and the shipping company immediately, otherwise claims for damage or replacement may not be granted. Shipping claims must be made by the consignee. The BEHRINGER AUTOCOM PRO fits into one standard 19" rack unit of space.

Please allow at least an additional 4" depth for the connectors on the back panel. Be sure that there is enough space around the unit for cooling and please do not place the ULTRA-GRAPH PRO on high temperature devices such as power amplifiers etc. to avoid overheating. Before you connect your AUTOCOM PRO to the mains, please make sure that your local voltage matches the voltage required by the unit! + The fuse holder on the female mains connector has 3 triangular markers, with two of these triangles opposing each other. Your AUTOCOM PRO is set to the operating voltage printed next to these markers, and can be set to another voltage by turning the fuse holder by 180°.

CAUTION: this instruction does not apply to export models exclusively designed, e.g., for 115 V operation! The mains connection of the AUTOCOM PRO is made by using the enclosed mains cable and a standard IEC receptacle. It meets all of the international safety certification requirements. + Please make sure that all units have a proper ground connection.

For your own safety, never remove or disable the ground conductor of the unit or of the AC power cable. 1. INTRODUCTION 7 AUTOCOM PRO MDX1400 2. CONTROLS 1 Fig. 2.1: AUTOCOM PRO front panel The BEHRINGER AUTOCOM PRO has two identical channels. Each channel is equipped with 8 backlit push-buttons, 7 rotary controls and 26 LEDs. The COUPLE switch is for stereo operation: 1 + By engaging the COUPLE switch the AUTOCOM PRO is converted to stereo mode, where the controls of the left channel take over the control of both audio channels. The control signal for the control characteristic consists of either the sum of the left and right audio signal or the sum of the external audio signals, which are being fed into both SC RETURN connectors. By pressing the COUPLE switch, you override all the controls and switches of channel 2 with the exception of the IN/OUT, SC EXT, SC MON, SC FILTER and I/O METER switches as well as the OUTPUT and PROCESS controls.

As a result, the controls of channel 1 take over the functions of channel 2. Should you wish to use the SC EXT function in stereo mode, then be sure that both SC RETURN jacks are connected to the external control signal, and that the SC EXT switches on both channels are engaged. 2.1 Expander/Gate Section 3 2 4 Fig. 2.2: Control elements of expander/gate section 2 Use the THRESHOLD control to determine the threshold point below which expansion occurs. The range of this control is from OFF to +10 dB. When a signal above the threshold value is applied, the - LED lights up, while the + LED lights up when expansion occurs. To optimally adapt the expander/gate to the program material, the RELEASE switch allows for selecting a SLOW or FAST release time. When you engage this switch, the expander responds with a slow release.



[You're reading an excerpt. Click here to read official BEHRINGER MDX1400 user guide](http://yourpdfguides.com/dref/2301859)
<http://yourpdfguides.com/dref/2301859>

As a general rule, percussive material with little or no ambience is processed using the FAST release mode, whereas signals with long decay or with heavy ambience require the SLOW release mode. 2. CONTROLS 3 4 8 AUTOCOM PRO MDX1400 2.2 Compressor Section 11 14 16 17 12 5 15 6 7 9 8 10 13 Fig. 2.

3: Control elements of the compressor section 5 The THRESHOLD control sets the threshold point for the compressor section. It has a range of -40 to +20 dB. If the channel is switched to INTERACTIVE mode (Interactive Knee Adaptation), a Soft Knee characteristic is applied to the signal exceeding the threshold point by a maximum of 10 dB. Above 10 dB, the signal would experience Hard Knee compression. The RATIO control determines the ratio between the input and output level for all signals exceeding the threshold point.

If the INTERACTIVE mode is used, this control determines the ratio between input and output levels for signals exceeding the threshold point by more than 10 dB. The control range can be adjusted from 1:1 to ∞:1. The ATTACK control determines the rate by which the compressor responds to the signal which exceeds the threshold. This control can be adjusted from 0.1 to 200 milliseconds. The RELEASE control determines the rate that the compressor returns to unity gain after falling below the threshold level. This control can be adjusted from 0.05 to 4 seconds. By activating the AUTO switch, the ATTACK and RELEASE controls are disabled and the attack and release rates are automatically derived from the program material. This function allows for unobtrusive musical compression of signals or mixes with widely varying dynamics.

Only if set to MANUAL the settings of the attack and release controls will function. The OUTPUT control allows for the increase or decrease of the output signal by a maximum of 20 dB. Thus, a level loss due to the compression or limiting process can be compensated for. When activated, the SC EXT switch severs the connection between the audio input and the sidechain path, whilst at the same time allowing an external signal to be sourced at the SC RETURN jack on the rear panel. Using the SC MON switch will enable you to connect the sidechain control signal to the audio output, whilst at the same time muting the audio input. This function provides you with the ability to monitor the sidechain signal that is returned via inserted equalizers or other external processors. The SC MONITOR function will assist you with tuning equalizer parameters for example. Please note when the SC MON switch is engaged, the audio processing facility of the respective channel is disabled. When this function is active, a visual indication will be provided by the switches LED, which will blink. The IN/OUT switch activates the corresponding channel.

This switch acts as a so-called hard-bypass, which means that when the switch is OUT, the input jack is directly linked to the output jack. Normally, this switch is used to perform a direct A/B comparison between the unprocessed and the compressed or limited signals. Press the INTERACTIVE switch to change from hard knee to IKA characteristics. IKA provides a very subtle and musical compression of the program material and should therefore be used whenever compression is expected to be more or less inaudible. 2.

CONTROLS 9 6 7 8 9 10 11 12 + 13 14 AUTOCOM PRO MDX1400 15 The SC FILTER switch activates a highpass filter in the sidechain path and thus limits the influence of low frequencies on the AUTOCOM PROs control processes. The 12-digit GAIN REDUCTION meter indicates how effectively the gain is reduced by the compressor, within a range from 1 to 30 dB. The 12-digit INPUT/OUTPUT LEVEL meter informs you depending on the setting of the I/O METER switch about the current input or output level, within a range from -30 to +18 dB. When the switch is set to IN (engaged), the meter reads the input level, when it is OUT (not engaged), the output level is displayed. The meter is referenced to the operating level (-10 dBV or +4 dBu) adjusted with the OPERATING LEVEL switch.

16 17 2.3 Dynamic Enhancer Section 18 Fig. 2.4: Control elements of the dynamic enhancer section 18 The PROCESS control sets the available amount of enhancement between Off and 6. Dynamic enhancement allows you to replenish any high frequencies lost through the compression process for absolutely natural sounding dynamics control. Enhancement is only added when compression is taking place. 2.4 Rear Panel Control Elements Of The AUTOCOM PRO 20 19 23 22 21 24 25 26 Fig. 2.5: Control elements of the rear panel 19 SERIAL NUMBER.

Please take the time to fill out and return the warranty card within 14 days from the date of purchase, so as to be entitled to benefit from our extended warranty. Or use our online registration option available on the Internet at www.behringer.com. FUSE HOLDER / VOLTAGE SELECTOR. Please make sure that your local voltage matches the voltage indicated on the unit, before you attempt to connect and operate the AUTOCOM PRO. Blown fuses may only be replaced by fuses of the same type and rating. MAINS CONNECTION. Use the enclosed power cord to connect the unit to the mains. Please also note the instructions given in the INSTALLATION chapter.

2. CONTROLS 20 21 10 AUTOCOM PRO MDX1400 22 AUDIO IN. These are the audio inputs of your AUTOCOM PRO, available both as balanced 1/4" TRS and XLR connectors. AUDIO OUT. These are the audio outputs of your AUTOCOM PRO.

Matching phone jack and XLR connectors are wired in parallel. These outputs can be transformer-balanced by retrofitting the optional output transformer OT-1. With the OPERATING LEVEL switch you can adapt the AUTOCOM PRO to various operating levels, i.e. you can select both the -10 dBV home recording level and the professional studio level of +4 dBu.

The level meters are referenced automatically to the selected level, i.e. an optimum operating range of the meters will always be ensured. SC SEND. This is the unbalanced sidechain output which allows for routing the audio signal to external processing devices. SC RETURN. This is the unbalanced sidechain input used to return any external or processed control signal. 23 24 25 26 3. APPLICATIONS In this section, several typical applications of the BEHRINGER AUTOCOM PRO are discussed. The following basic settings can resolve most dynamic problems.

They are the ideal starting point. Please take the time to study the application examples carefully, in order to be able to make full use of the AUTOCOM PROs capabilities in the future. Main Applications And Initial Settings The main applications of the BEHRINGER AUTOCOM PRO can be divided into three categories: 1. The EXPANDER/GATE section is used to eliminate interference and to suppress background noise and leakage on individual tracks in multitrack recording. 2. The COMPRESSOR section is used to compress the program material and to create special effects and unusual sounds, which are used for recording and musical performance.



[You're reading an excerpt. Click here to read official BEHRINGER MDX1400 user guide](http://yourpdfguides.com/dref/2301859)

<http://yourpdfguides.com/dref/2301859>

3. The subsequent DYNAMIC ENHANCER section is designed to freshen the signal after compression. 3.1 Compression/Levelling/Limiting/Clipping Now that the functions of the individual sections have been clearly explained, we would like to acquaint you with more terms and relationships of the dynamics process.

Compression A compressor converts a large dynamic level into a restricted range. The extent of the resulting dynamic level is dependent on the threshold, attack, release and ratio settings. As it is the desired effect of a compressor to increase a low level signal, generally the threshold is set low. The inaudible compression mode requires fast attack and release times and low ratios. The faster the chosen control times and the higher the compression ratio, the greater the effect on the short term dynamics.

This fact is often used to achieve audible and creative sound effects. Levelling The levelling mode is used to keep output level constant, i.e. to compensate for long term gain changes, without affecting the short term dynamics. Normally, the threshold is set quite low in order to be able to increase low level signals.

Levelling requires slow attack and release times, combined with a high ratio. Because of the very slow response time, levelling has no effect on signal peaks or short term changes in average level. *Limiting* The limiting function requires a fast attack time and a high ratio and release time setting, which is dependent on the specific use and the desired sound effect. As it is usually the task of a limiter to limit only high signal peaks, the threshold is usually set at a high level.

The dynamics are reduced dependent on the ratio setting and the degree by which the threshold point was exceeded. If the attack time is adjusted to control only the average level without affecting signal peaks above the threshold, this is referred to as the program limiter. For this purpose the attack time will be set above 20 ms. If the attack time is further reduced in order to also control signal peaks, this is defined as the peak limiter. 3. APPLICATIONS 11 AUTOCOM PRO MDX1400 *Clipping* In contrast to the two previously mentioned limiters, the clipping mode features infinitely fast control times, an infinite compression ratio and creates an unsurpassable barrier (brickwall) for all signals above a certain level.

To be able to control the signal peaks, the clipping function radically cuts signals above the threshold, without affecting the amplitude of the original signal. If used in normal applications, this function remains inaudible and under certain circumstances it can even lead to an improved sound, because cutting the transients creates artificial harmonics. If misused, clipping can cause very obvious and distasteful distortion, which in an extreme manner, will convert the signals waveform into a square wave signal. This effect is often produced in guitar distortion devices (fuzz boxes). 3.2 Expander/Gate Section *The main task of the Expander/Gate is to inaudibly eliminate undesirable background noise from the usable signal. As additionally described in chapter 6.4, a downward expander automatically reduces the overall level for all signals below an adjustable threshold. The expander therefore operates in opposite way to that of a compressor/limiter. Expanders generally function with a flat ratio curve, so that the signal continually fades.*

Noise gates however, can be seen as high ratio expanders. If the signal falls below the threshold, it is radically attenuated. The BEHRINGER AUTOCOM PRO is equipped with a newly developed IRC (Interactive Ratio Control) Expander, the ratio of which is automatically adjusted dependent on the program material. The response characteristics of conventional expanders tend to cut into the signal abruptly and the result of this is unacceptable most of the time.

Gain changes become audible.

The IRC Expander is therefore equipped with a soft, interactive non-linear ratio curve, which is best suited to human hearing. Critical signals in the vicinity of the threshold level are processed with a minute expansion ratio, whereas signals that reduce in level will be subjected to an increasingly higher ratio, which will result in greater attenuation. Output Gain 0 dB Threshold IRC-Curve Expander, 1:8 Noise Gate, 1:00 Input Fig. 3.1: IRC curve characteristic of the Expander The result is expansion, which is less critical to adjust and which is more tolerant of useable signals, whose level is slightly above that of the noise floor.

Expansion therefore occurs extremely soft with low ratio settings, while the known negative effects of expansion are inaudible. The Attack time of the IRC expander is set automatically and program-dependent, i.e. extremely short for quickly changing signals and slower for a more balanced program material.

Since the expander/gate adapts itself automatically to the program material, you will note that the new IRC (Interactive Ratio Control) circuit produces considerably better results than conventional expanders. 3.2.1 Controlling Leakage *In The Studio* Expanders/gates are most commonly used to suppress undesirable leakage of sound from one track to another during recording or playback. They are usually used when recording drum kits, where the mics are very close to each other. High volume levels of individual instruments often cause considerable leakage onto all the 12 3.

APPLICATIONS AUTOCOM PRO MDX1400 *adjacent mics and results in conflicting frequency and phase coherence problems, as well as unspecified sounds (comb filter effects). It is vitally important that every instrument is recorded into a separate mic and that each mic is individually gated. Patch the BEHRINGER AUTOCOM PRO into a snare drum channel for example and adjust it so that triggering only occurs on snare hits. Each mic should be set to its maximum operating level, monitored (see SC MON switch) and the THRESHOLD level set so that each snare hit sounds acoustically clean and separate, as though it was played on its own. The optimum use of the Expander/Gate depends principally on microphone technique. Be particularly careful, when high frequency instruments are located to the side or rear of a cardioid microphone. Most cardioids exhibit a sharply rising off-axis response characteristic at higher frequencies. If there is only a 2 or 3 dB difference between the on-axis and off-axis response in the 5 to 10 kHz region, cymbals may leak excessively into the tom mics and you may have hi-hat spilling all over the snare mic. Please make full use of the directional characteristic of the mics, to acoustically exclude all other instruments as much as possible. Make sure that you do everything possible to achieve source separation with good microphone technique. Otherwise the Expander/Gate is not able to undertake clear acoustic separation. Sometimes, it is necessary to prevent the Expander/Gate from responding to low frequencies (rumbles etc.), especially if a singer is moving the microphone around on a mic-stand.*



[You're reading an excerpt. Click here to read official BEHRINGER MDX1400 user guide](http://yourpdfguides.com/dref/2301859)
<http://yourpdfguides.com/dref/2301859>

The SC Filter switch allows you to activate a highpass filter in the control signal path of the compressor. This filter makes sure that midrange and treble range frequencies are taken into account to a greater extent, and that a low-frequency signal triggers less compression than a midrange/treble signal of comparable level. A major advantage of this design can be seen in the fact that the frequency response of the overall signal is not modified below the threshold adjusted with the Threshold control. In pop music the dynamics of both kick drum and bass guitar are usually processed individually. The sidechain filter is therefore ideally suited to apply overall compression in the mixdown, to compress the music while increasing its loudness, but without having to accept the drawbacks described above. 3.4 Dynamic Enhancer Section In addition to the above mentioned method with the sidechain filter the AUTOCOM PRO offers another alternative solution: the Dynamic Enhancer. It eliminates the problems without creating any additional negative side effects.

As the signal level rises towards the threshold point where compression will occur, high frequency enhancement is added at the same degree to which the input signal is compressed. The AUTOCOM PRO accurately tracks the amount of compression in order to compensate with the same amount of dynamic enhancement, even if there are heavy signal variations. When there is no compression taking place, the Dynamic Enhancer is inoperative and therefore, no additional noise or signal equalization is added to the signal. For more versatility, a PROCESS control allows you to control the available amount of dynamic enhancement. The range lies between Off and 6. The typical dynamic enhancement function is shown in the following figure: 16 3. APPLICATIONS AUTOCOM PRO MDX1400 Output 0 dB No Gain Reduction With Enhancer -20 dB 20 dB Gain Reduction Without Enhancer Frequency Fig. 3.3: The frequency response with and without dynamic enhancer 3.4.

1 Initial Settings For The Dynamic Enhancer Section Turn the PROCESS control beginning from Off to a value, where you have the impression of a correct frequency response at compression. Also check out the combination with the sidechain filter. Control PROCESS control Setting OFF Tab. 3.3: Initial settings for the dynamic enhancer section 4.

SPECIAL APPLICATIONS 4.1 Using The AUTOCOM PRO For Recording And Cassette Duplication In the recording and duplication field the goal should always be to achieve an optimum recording level onto the recording media. Too low or too high recording levels lead to side effects such as noise, distortion etc. In mastering and multitrack recording, as well as in duplication, one should always take care to utilize the full dynamic range of the tape recorder, DAT recorder etc. Principally, it is possible to control the recording level by riding faders, which means with low level signals, the gain is increased, whereas the amplitude of high level signal is reduced.

It is obvious that this method is insufficient because, especially in live recordings, the expected signal levels cannot be anticipated correctly. Especially with multitrack recordings, which are run under hectic circumstances, the signal level of all channels cannot be monitored and controlled at the same time. Generally, with manual control, it is not possible to achieve satisfying recording results. An automatic gain control system achieves better and more constant results. Use the AUTOCOM PRO by starting with the initial settings, and use its dynamic control functions in order to be able to drive an analog, as well as a digital recording, up to the limit of its maximum dynamic range while remaining noise- and distortionfree. 4. SPECIAL APPLICATIONS 17 AUTOCOM PRO MDX1400 4.1.1 The AUTOCOM PRO In Digital Recording And Sampling In an analog recording, too low recording levels lead to an increased noise level, whereas too high levels will cause a compressed and squashed sound. In extreme cases, it will cause distortion due to tape saturation.

In contrast to analog, side effects in the digital field always become extremely audible: with decreasing level, a tape previously recorded with insufficient level loses resolution: the recording sounds hard and loses atmosphere. With excessive level, the recording sounds harsh and heavily distorted. In order to avoid these effects, the AUTOCOM PRO as a limiter should be placed before for example a sampler. As a result of this process, a digital recording or a sampling event can be optimally set in level without any problem. 4.1.2 The AUTOCOM PRO In Mastering The mastering process is one of the most critical processing steps in recording. In this production step, it is the goal to achieve a maximum level copy of the recording, without any noise or distortion. In many applications it is further required to produce a high average volume. In the field of commercial media for example, this is apparent especially with records and cassettes which are processed with high average volumes.

Quite often in these cases, dynamics suffer drastically, because the program material has been compressed and limited too heavily. Using the Compressor section of the AUTOCOM PRO as a limiter allows you to drastically increase the overall volume, without audibly affecting the dynamics. Proceed as follows: Limit the dynamics of the program material by 6 dB using the AUTOCOM PRO as a Peak Limiter (Ratio 1:00). By softly clipping just the transients, the real audio signal will not be limited, resulting in a higher headroom. The overall gain can now be increased by 6 dB, which leads to a higher volume.

More than 6 dB should not be limited, otherwise side effects could become audible. This effect is particularly noticeable with DAT recorders, whose level indicators achieve a response time of less than 1 ms. Set the DAT recorder at unity and now reduce the LEVEL control of the peak limiter until a gain reduction of 6 dB is indicated. The cut signal peaks cause a reduced recording level of about 6 dB, which is visible on the level indicators of the DAT recorder. Now increase the recording level of the recorder back to unity.

The result is a clearly louder recording without any loss of sound. 4.2 The AUTOCOM PRO As A Protective Device Sound system distortion is usually a result of amplifiers and loudspeakers being driven beyond their limitations by signals clipping. The signal limitations that occur lead to unpleasant distortion that is dangerous to the speakers. A speaker diaphragm is required to accelerate, slow down, smoothly change direction and accelerate again in normal operation.

Distorted operation (clipping) leads to instant acceleration, instant stop, change of direction and instant acceleration again. Since speaker diaphragms are subject to the laws of physics, they will not take this kind of punishment for long: the diaphragm will either break up or its voice coil may overheat. In addition to the damage caused by sustained overload, the speaker may also be damaged by an occasional high level overload, e.



[You're reading an excerpt. Click here to read official BEHRINGER MDX1400 user guide](http://yourpdfguides.com/dref/2301859)
<http://yourpdfguides.com/dref/2301859>

g. the sound of a microphone falling onto a hard floor.

Even if this type of transient does not destroy a speaker outright, it may damage the speaker surround in such a way, as to cause mechanical abrasion and future failure. It is recommended that you use the Behringer AUTOCOM PRO in order to protect the speaker. Brick Wall peak limiters are not normally necessary for PA systems, as amplifiers and loudspeakers are tolerant of short signal peaks. Nevertheless, conventional limiters have to be generally driven far beyond the headroom limit of an amplifier, in order to limit the level and length of the transients responsible for overloading the system. The disadvantage of this principle is that the units full range cannot be completely used. If an increase in the average level of up to 3 dB is attained with the AUTOCOM PRO as a Limiter, this means that you effectively double the power amplification. The AUTOCOM PRO can act in this way to convert a PA system of 5,000 Watts into a distortion free 10,000 Watts system. The following instructions will help you to integrate the unit into your system. 4.2.

1 Protection Of A System With A Passive Crossover If your sound system incorporates a passive crossover network (included in the loudspeaker case), insert the BEHRINGER AUTOCOM PRO between your mixing console output and the power amplifier input. It is used as the last link in the chain preceding the power amp. Thus, you can effectively avoid the technical knockout of 18 4. SPECIAL APPLICATIONS AUTOCOM PRO MDX1400 the midrange/tweeter range caused by high-energy bass signals! This statement, as paradox as it may seem at first, can be explained with the fact that especially low-frequency signals with high amplitudes can overload the power supplies in the amplifier(s). The resulting clipping (cutting off of signal peaks) produces high-energy distortion (upper harmonics), which is abruptly added to the midrange/tweeter signals.

For this reason, weak power amps, in particular, must be protected by a limiter in their input dynamics. 4.2.2 Protection Of A System With An Active Crossover For systems using active crossovers, there are two ways to use the BEHRINGER AUTOCOM PRO. The unit may be inserted between the console output and the crossover input.

In this application, the BEHRINGER AUTOCOM PRO will process the entire audio frequency spectrum. Alternately, the BEHRINGER AUTOCOM PRO can be inserted between the output of an active crossover and the input of a power amplifier. In this application it will only affect a specific range of frequencies. This application is particularly suited to protect the most fragile components of a multi-way speaker system against harmful signal peaks. For example, when your tweeters keep on going up in smoke all the time, the entire system should be operated at lower sound pressure levels or the tweeters should be replaced by other models. Using the AUTOCOM PRO in the corresponding tweeter band avoids overloading and thus damage to the speakers. 4.2.3 Improving The Sound Of A Processor System A processor system is understood as a PA system which contains a special active crossover whose outputs are linked via separated power amplifiers to the loudspeakers. Each band has its own limiter whose task it is to limit dangerous signal peaks to a certain level.

This process avoids overloading the subsequent power amplifier or destruction of the loudspeaker. In some units, the crossover frequencies in the crossover unit are further changed during high signal levels to achieve a loudness contour suited to the human hearing. But in many cases, this function leads more to a disturbance than to an improvement of the sound quality. If the AUTOCOM PRO is preceding this system, the signal peaks can be eliminated before they reach the limiters of the processing system. The sound quality therefore remains natural and free of side effects caused by the changing frequencies of the crossover. 4.3 The AUTOCOM PRO In Broadcast The main aim of processing sound recordings for commercial radio and television is to achieve a maximum transmission volume at all costs. Owners of these radio and television stations strive to get bigger audience ratings, because principally, radio programs whose reception is louder than the average are preferred by the listener. By achieving a bigger audience, the broadcast station gains more money from the increasing number of promotion companies placing adverts. What Is Volume? Volume is defined as the relationship between the average level of program material to peak-to-peak level, in response to amplitude and duration.

The higher the average level and the time it remains at a high level, the louder the program material will be perceived by the listener. If you want to run your broadcast station at maximum average volume, proceed as mentioned in chapter 6.1.2 The AUTOCOM PRO In Mastering. Please make sure that the maximum peak level is below the threshold of the transmitters limiter, otherwise this could lead to very hard and audible use of the transmission limiters. Keep in mind that a heavy increase in average volume by means of compression always leads to a loss in dynamics and an increased perception of side effects. The intense use of all functions of the AUTOCOM PRO, including sidechain filtering, IKA, Attack and Release time constants, results in higher average volumes, free of distortion and side effects. 4. SPECIAL APPLICATIONS 19 AUTOCOM PRO MDX1400 5. EXTERNAL SIDECHAIN APPLICATIONS 5.

1 The Sidechain Function With the AUTOCOM PROs sidechain function you have a very useful external control option. By activating the SC EXT switch, the AUTOCOM PROs control path is disconnected from the audio input and therefore interrupted. The audio input is routed to the SC SEND output and the SC RETURN input now receives the new control signal which is derived from an inserted effects processor. Please note the correct wiring for mains powered units in order to avoid ground loops, as the sidechain inputs and outputs are unbalanced. The working level of external units must be at line level (-20 to +10 dBu) and must be at unity gain. 5.2 Using An Equalizer In The Sidechain Path It is very common to make the response threshold of a compressor frequency-dependent, where a graphic or parametric equalizer is connected to the sidechain path. To retain the threshold setting of the AUTOCOM PRO, unwanted frequencies should be reduced by an equalizer and the desired frequencies should be kept at the same level. Should for example, the compressor be controlled by a narrow mid-frequency band, it is advisable to lower the bass and treble controls. The middle frequency control remains at unity gain.

5.2.1 The AUTOCOM PRO As A De-Esser De-essing is a special application of frequency selective compression. A problem often encountered in recording, is the sibilant (Ssss) sound of the human voice. High frequency, sibilant sounds and pops can produce very high energy levels which can sometimes cause an otherwise normal and undistorted voice to sound very harsh, shrill and sometimes unintelligible.



[You're reading an excerpt. Click here to read official BEHRINGER MDX1400 user guide](http://yourpdfguides.com/dref/2301859)

<http://yourpdfguides.com/dref/2301859>

The solution is frequency conscious compression or limiting. The unit responds only to selected frequencies and reduces the level temporarily, as soon as sibilant sounds or pops are detected. If the detector circuit registers an excessive amount of high frequency information within the program material, as in a normal compressor, the VCA is activated and the overall level is reduced. As this type of compression affects the whole frequency range, this process is called broadband de-essing. Please note that this type of frequency selective compression is very different from simple, fixed equalization using notch filters, since de-essing has no effect on the signal except at the instant the sibilant occurs.

The general frequency response is principally not affected during this process. When de-essing, simply insert an equalizer not into the audio path but into the sidechain path of the BEHRINGER AUTOCOM PRO. The equalizer is inserted between the SC SEND output and the SC RETURN input of the BEHRINGER AUTOCOM PRO. While the SC EXT switch is pressed, the equalizer is inserted into the sidechain loop and controls the unit. With the help of the sidechain monitor function, the center frequencies of the equalizer are then adjusted exactly to match the frequencies of the sibilant sounds.

All other frequencies are filtered out, so that with maximum attenuation of these frequency bands, along with a correctly adjusted threshold point, the unit responds solely to the selected signal being produced by the equalizer. The level of the sibilant sounds can therefore be effectively limited. Turn the THRESHOLD control counterclockwise until the GAIN REDUCTION meter shows an appropriate drop in level. Now press the SC MON switch and adjust the equalizer corner frequencies (generally 6 - 10 kHz) by monitoring, until it is within the range of the sibilance. Release the SC MON switch and recalibrate the THRESHOLD control, so that the unit reacts only when the sibilant sound occurs.

Level compensation using the OUTPUT control is not necessary. Although the recommended attack and release times for this function are proven, the time parameters can be adjusted if necessary to achieve maximum results. The AUTO function should not be used. 20 5. EXTERNAL SIDECHAIN APPLICATIONS AUTOCOM PRO MDX1400 Control SC EXT switch SC MON switch INTERACTIVE switch SC FILTER switch THRESHOLD control RATIO control AUTO switch ATTACK control RELEASE control OUTPUT control Setting IN OUT OFF OUT +20 dB 1:4 OUT 0,5 ms 200 ms 0 dB Tab. 5.1: Initial settings for the De-Esser functions 5.2.2 Frequency Selective Filtering Of Unwanted Signals Based on the set-up described in the de-esser section, the unit may also be used to eliminate rumble, hum and equipment noise (air-conditioning systems, camera noise etc.).

Using the SC MON switch, adjust the frequencies of the equalizer to match the unwanted frequencies and use a peak filter with a high slope. Take care to decrease the amplitudes of the unrequired frequencies. Proceed now as described in the previous chapter 5.2.1. This will result in compression of the selected frequencies and thus a decrease in the gain of the program material. 5.2.3 Suppressing Instruments During Recording Another function of the BEHRINGER AUTOCOM PRO allows helpful correction of previously recorded material. If, for example, an excessively loud bass drum needs to be suppressed, reduce all the equalizers frequency bands above 150 Hz.

This setting causes frequency specific compression, which reacts as soon as increased energy is detected in this band. By increasing the threshold level, the compression can be made to react only to loud pedal or stick actions. Generally, it can be said that relatively high threshold settings prevent the overall sound from being impaired and lead to the compression of solo instruments or very loud sounds. 5.2.

4 Emphasizing Musical Instruments During Recording On the other hand, you can use the BEHRINGER AUTOCOM PRO to bring out an instrument solo or a lead vocal in a cluttered mix. Using the SC MON switch, match the frequencies of the equalizer to the frequencies of the instruments to be emphasized and for this it is best to use a notch filter with a high slope. Please make sure that in this application, you only reduce the amplitude of the selected frequencies.

The compression results in a subjective decrease in the volume of the overall program material. Only the selected frequencies coming from the equalizer remain uncompressed and are therefore perceived as being louder.

This inverse type of compression also helps to emphasize instruments during low level passages, so that they become more pronounced. 5.3 Anticipated Compression If you feed the audio signal directly into the SC RETURN input and send the audio signal through a delay before the audio input, the BEHRINGER AUTOCOM PRO can anticipate the need for gain change. With experimentation, the effect can create a zero attack time at a given frequency. Additional delay beyond this zero attack time will produce a special sound effect, similar to the dynamic envelope inversion you may already be familiar with from reverse tape playback. 5. EXTERNAL SIDECHAIN APPLICATIONS 21 AUTOCOM PRO MDX1400 5.4 Voice-Over Compression (Ducking) The BEHRINGER AUTOCOM PRO can be used to automatically reduce music to a background level, when an announcer is speaking through a microphone. For this purpose, the BEHRINGER AUTOCOM PRO is used as an automatic fader and is controlled by the announcers microphone, which is connected to the SC RETURN input via a preamplifier. The music output and the announcers voice, are then mixed.

This application is known as voice-over compression or ducking and is commonly used in discos, radio stations etc. 5.5 Triggering Additional Sounds From A Rhythm Track This technique is used to give a rhythm track more punch. For this purpose, only the Expander/Gate section is required and the Compressor and Dynamic Enhancer sections are switched off. The bass guitar track is connected to the audio chain of the BEHRINGER AUTOCOM PRO, while the bass drum is connected to the SC RETURN input. By activating the SC EXT switch, the bass guitar is now triggered by the bass drum. Another application allows the sound of the bass drum to be supported or extended by other instruments (synthesizers etc.), where the bass drum is used to trigger a new sound, which is then mixed into the track. 6. TECHNICAL BACKGROUND By employing current modern analog technology it is possible to manufacture audio equipment with a dynamic range of up to 125 dB.

In contrast to analog techniques, the dynamic range of digital equipment is approximately 25 dB less. With conventional record and tape recorder technology, as well as broadcasting, this value is further reduced. Generally, dynamic restrictions are due to noisy storage and transmission media and also the maximum headroom of these systems. 6.1 Noise As A Physical Phenomenon All electrical components produce a certain level of inherent noise.



[You're reading an excerpt. Click here to read official BEHRINGER MDX1400 user guide](http://yourpdfguides.com/dref/2301859)

<http://yourpdfguides.com/dref/2301859>

Current flowing through a conductor leads to uncontrolled random electron movements. For statistical reasons, this produces frequencies within the whole audio spectrum. If these currents are highly amplified, the result will be perceived as noise. Since all frequencies are equally affected, we term this white noise. It is fairly obvious that electronics cannot function without components.

Even if special low-noise components are used, a certain degree of basic noise cannot be avoided. This effect is similar when replaying a tape. The non-directional magnetic particles passing the replay head can also cause uncontrolled currents and voltages. The resulting sound of the various frequencies is heard as noise. Even the best possible tape biasing can only provide signal-to-noise ratios of about 70 dB, which is not acceptable today since the demands of listeners have increased. Due to the laws of physics, improving the design of the magnetic carrier is impossible using conventional means. 6.2 What Are Audio Dynamics? A remarkable feature of the human ear is that it can detect the most wide ranging amplitude changes from the slightest whisper to the deafening roar of a jet-plane. If one tried to record or reproduce this wide spectrum of sound with the help of amplifiers, cassette recorders, records or even digital recorders (CD, DAT etc.), one would immediately be restricted by the physical limitations of electronic and acoustic sound reproduction technology (see fig.

6.1). The usable dynamic range of electro-acoustic equipment is limited as much at the low end as at the high end. The thermal noise of the electrons in the components results in an audible basic noise floor and thus represents the bottom limit of the transmission range. The upper limit is determined by the levels of the internal operating voltages; if they are exceeded, audible signal distortion is the result. Although in theory, the usable dynamic range sits between these two limits, it is considerably smaller in practice, since a certain reserve must be maintained to avoid distortion of the audio signal if sudden level peaks occur.

Technically speaking, we refer to this reserve as headroom usually this is about 10 - 20 dB (see fig.1.2). A reduction of the operating level would allow for greater headroom, i.

e. the risk of signal distortion due to level peaks would be reduced. However, at the same time, the basic noise floor of the program material would be increased considerably. 22 6. TECHNICAL BACKGROUND AUTOCOM PRO MDX1400 P/dB 140 120 100 80 60 40 Ear Microphone Amplifier Power

Amplifier Tape Recorder Fig.

6.1: The dynamic range capabilities of various devices It is therefore useful to keep the operating level as high as possible without risking signal distortion in order to achieve optimum transmission quality. It is possible to further improve the transmission quality by constantly monitoring the program material with the aid of a volume fader, which manually levels the material. During low passages the gain is increased, during loud passages the gain is reduced. Of course it is fairly obvious that this kind of manual control is rather restrictive; it is difficult to detect signal peaks and it is almost impossible to level them out.

Manual control is simply not fast enough to be satisfactory. P/dB +20 0 -20 -40 Effective SNR -60 -80 Noise floor Headroom Operating level Cassette Recorder Radio Clipping t Fig. 6.2: The interactive relationship between the operating level and the headroom The need therefore arises for a fast acting automatic gain control system which will constantly monitor the signals and which will always adjust the gain to maximize the signal-to-noise ratio without incurring signal distortion. This device is called a compressor or limiter. This system is a part of the BEHRINGER AUTOCOM PRO. 6.3

Compressors/Limiters By measuring the dynamic range of musical instruments in live recording situations, you will find that extreme amplitudes occur which often lead to overload in subsequent signal processing equipment. Especially in broadcasting and record cutting techniques, these signal peaks can lead to heavy distortion. To avoid this kind 6.

TECHNICAL BACKGROUND 23 AUTOCOM PRO MDX1400 of distortion or, for example, to avoid loudspeakers being damaged by overload, Compressors or Limiters are used. The principal function used in these devices is dependent on an automatic gain control as mentioned in the previous section, which reduces the amplitude of loud passages and therefore restricts the original dynamics to a desired range. This application is particularly useful in microphone recording techniques, to compensate for level changes which are caused by varying microphone distances. Although compressors and limiters perform similar tasks, one essential point makes them different: Limiters abruptly limit the signal above a certain level, while compressors control the signal gently over a wider range. A limiter continuously monitors the signal and intervenes as soon as the level exceeds an user-adjustable threshold. Any signal exceeding this threshold will be immediately returned to the adjusted level. A Compressor also monitors the program material continuously and has a certain threshold level. With compression, in contrast to the action of a limiter, signals are not reduced in level abruptly once the threshold has been exceeded, but are returned to the threshold gradually. The signal is reduced in gain, relative to the amount the signal exceeds this point. Generally, threshold levels for compressors are set below the normal operating level to allow for the upper dynamics to be musically compressed.

For limiters, the threshold point is set above the normal operating level in order to provide reliable signal limiting, to protect subsequent equipment from signal overload. 6.4 Expanders/Noise Gates Audio, in general, is only as good as the source from which it was derived. The dynamic range of signals will often be restricted by noise. Synthesizers, effects devices, guitar pickups, amplifiers etc.

generally produce a high level of noise, hum or other ambient background hiss, which can disturb the quality of the program material. Normally these noises are inaudible if the level of the desired signal lies significantly above the level of the noise. This perception by the ear is based on the masking effect: noise will be masked and thus becomes inaudible as soon as considerably louder sound signals in the same frequency band are added. Nevertheless, the further the level that the desired signal decreases, the more the noise floor becomes a disturbing factor. Expanders or noise gates offer a solution for this problem: these devices attenuate signals when their amplitudes drop, thereby fading out the background noise.

Relying on this method, gain controlling amplifiers, like expanders, can extend the dynamic range of a signal and are therefore the opposite of a compressor.

In practice, it is shown that an expansion over the entire dynamic range is not desired.



[You're reading an excerpt. Click here to read official BEHRINGER MDX1400 user guide](http://yourpdfguides.com/dref/2301859)
<http://yourpdfguides.com/dref/2301859>