



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for DELONGHI DD95. You'll find the answers to all your questions on the DELONGHI DD95 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual DELONGHI DD95**  
**User guide DELONGHI DD95**  
**Operating instructions DELONGHI DD95**  
**Instructions for use DELONGHI DD95**  
**Instruction manual DELONGHI DD95**

---

**DEUMIDIFICATORE**  
**DEHUMIDIFIER**  
**DESHUMIDIFICATEUR**  
**ENTFEUCHTER**  
**ONTVOCHTIGINGSAPPARAAT**  
**DESHUMIDIFICADOR**  
**DESUMIDIFICADOR**



**Istruzioni per l'uso**  
**Instructions for use**  
**Mode d'emploi**  
**Gebrauchsanweisung**  
**Gebruiksaanwijzingen**  
**Instrucciones para el uso**  
**Manual de instruções**

---



[You're reading an excerpt. Click here to read official DELONGHI DD95 user guide](http://yourpdfguides.com/dref/5571947)  
<http://yourpdfguides.com/dref/5571947>

### Manual abstract:

**Introduction** The Dehumidifier removes humidity from the air in the areas in which it is installed. The appliance is compact and fitted with wheels and handles which facilitate its movement. It is therefore advisable to keep rooms within these values. **WARNING:** Very carefully dispose of the cut off plug after removing the fuse: do not insert in a 13 Amp socket elsewhere in the house as this could cause a shock hazard. With alternative plugs not incorporating a fuse, the circuit must be protected by a 15 Amp fuse. If the plug is a moulded-on typer, the fuse cover must be re-fitted when changing the fuse using a 13 Amp Asta approved fuse to BS 1362. In the event of losing the fuse cover, the plug must NOT be based until a replacement fuse cover can be obtained from your nearest electrical dealer. The colour of the correct replacement fuse cover is that as marked on the base of the plug. k. The blue wire must be connected to the terminal marked with the letter N or coloured black.

The brown wire must be connected to the terminal marked with the letter L or coloured red. Green and yellow: Blue: Brown: Earth Neutral Live L N  
**Technical characteristics** Power supply Absorbed power Absorbed current Maximum humidity removed per 24 hours Volume of air dehumidified Coolant Defrosting device Humidostat Dimensions (W x H x D) Weight (net) Capacity of canister Operating limits: • temperature • relative humidity Standard operating conditions: 27°C - 60% RH 220/240 290 1,8 7. Handle 10 Accessories Description Quantity rubber bung 1 11 Installation Place the appliance in the room that you wish to dehumidify. It is essential to leave a space of at least 50 cm. Around the appliance in order to ensure adequate ventilation. The condensation can be discharged in one of two ways: A) Discharge into the canister The condensation generated by the dehumidifier can be discharged directly into the canister. The canister is easy to extract when it needs to be emptied. It has an ergonomic form and is equipped with 2 handles which makes it easy to carry and to empty. B) Continuous External Discharge If you need to have the appliance working for a long period of time but are unable to empty the canister repeatedly, it is possible to use the continuous discharge. It is extremely easy to set the tank up for continuous discharge.  
1) On the tank there is a thin part easy to cut to allow the hose to pass through (fig. 1). 2) Remove the rubber cap from the spout. 3) Make a hole on the inside of the tank spout using a drill with a fine bit. 2) 5) Replace the canister into the appliance (Fig. The canister is full \ empty the canister 2. The canister is badly positioned \ position it correctly 4. The power socket must match the plug. If not, have the plug replaced by qualified personnel. The power socket must be adequately earthed.

The pilot lamp lights to show that the appliance is switched on. Turn the humidostat knob to the desired position.  
For safety, never use a jet of water to wash the appliance. Never spray the appliance with insecticides or similar products. These may cause the paint to flake or the pastic parts to become mis-shapen. Cleaning the air filter • The filter should be cleaned weekly. To remove the filter, remove the filter by pulling upwards (fig. 4). Use a vacuum cleaner to remove the dust that builds up on the filter. If the filter is very dirty, wash it in warm water and rinse several times.  
The temperature of the water should not exceed 40°C. After washing the filter, allow it to dry completely before replacing it in the appliance. To replace the filter, insert first the lower and then the upper hooks and push down. If the appliance is not used for long periods • Disconnect the plug from the power socket and empty the canister. • Clean and replace the filter.  
Protect the appliance from dust by covering with a large plastic bag. fig. 4 Important • This appliance is designed to dehumidify domestic living areas, and must not be used for other purposes. The appliance must not be modified in any way, as any modifications may be extremely dangerous. The power cable must not be replaced by the user, as this requires the use of special tools.  
if the power cable is damaged , contact an authorized Service Centre. If the appliance requires repair, always contact a Service Centre authorized by the manufacturer. Always insist on original spare parts. This appliance must be used by adults only. Do not allow children to play with the appliance. • The appliance must be adequately earthed. Have your electrical circuit checked by a qualified electrician. Do not use extension power cables. Do not move the appliance by pulling the power cable. Do not install the appliance near sources of heat.

Do not place heavy or hot objects on the top of the appliance. Clean the air filter at least once weekly. Remember to drain the canister before transporting the appliance. After transporting the appliance, wait at least one hour before using it. 14 Troubleshooting Before calling your local authorized Service Centre, check the following: Problem The dehumidifier does not switch on Cause • the appliance is not plugged in • the humidostat is set to the minimum position • the canister is full • the canister is not in position • the filter is dirty • the temperature or humidity in the room is too low Solution • insert the plug into the socket • adjust the humidostat to the desired position • empty the canister • position the canister correctly The appliance does not dehumidify • clean the filter • in certain conditions, the appliance will not dehumidify the room (see "Technical Characteristics") The appliance works but the humidity in the room is not reduced • the room is too big • too many sources of humidity in the room (e. .



[You're reading an excerpt. Click here to read official DELONGHI](http://yourpdfguides.com/dref/5571947)

[DD95 user guide](http://yourpdfguides.com/dref/5571947)

<http://yourpdfguides.com/dref/5571947>