



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for DELONGHI PAC A140HPEC. You'll find the answers to all your questions on the DELONGHI PAC A140HPEC in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual DELONGHI PAC A140HPEC
User guide DELONGHI PAC A140HPEC
Operating instructions DELONGHI PAC A140HPEC
Instructions for use DELONGHI PAC A140HPEC
Instruction manual DELONGHI PAC A140HPEC

Important safeguards

- Use this appliance only as described in this instruction manual.
 - As with any electrical appliance, the instructions aim to cover as many situations as possible. Caution and common sense should be used when operating and installing this air conditioner.
 - This appliance has been manufactured to cool and dehumidify domestic environments and must not be used for other purposes.
 - It is dangerous to alter or modify the unit's characteristics in any way.
 - The appliance must be installed in accordance with the relevant national legislation.
 - Should repairs be necessary, contact the nearest authorized Repair Service Center. Unauthorized servicing can be dangerous.
 - The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
 - Children should be supervised to ensure that they do not play with the appliance.
 - In the case that the power cord becomes damaged, this must be repaired only by specialized personnel authorized by the manufacturer in order to protect against fire.
 - Always ensure the appliance is plugged into a grounded 3-prong outlet. If you have any doubts check with a qualified electrician.
 - We strongly discourage the use of an extension cord due to potential safety hazards. For temporary situations, use only CSA certified and UL listed 3-prong grounded extension cord, attachment plug and connector, rated 15A, 125V.
 - Before cleaning or maintenance operations, always unplug the unit from the outlet.
 - Do not pull on or place strain on the power cord when moving the appliance.
 - The appliance should not be installed where the atmosphere may contain combustible gases, oil or sulphur, or near heat sources.
 - Do not rest hot or heavy objects on the appliance.
 - Clean the filters at least once a week.
 - Avoid using heaters near the unit.
 - The unit should be transported in a vertical position. If this is not possible secure the unit at an angle, do not lie it horizontally.
 - Before transporting the unit, drain the unit. After transportation, wait at least 6 hours before switching the unit on.
 - The packaging materials can be recycled. You are therefore recommended to place them in the special containers for differentiated waste collection.
 - This appliance is fitted with a special safety device. When the compressor switches off, this device prevents it from switching on again for at least 3 minutes.
 - **WARNING:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- ENVIRONMENTAL INFORMATION:** This unit contains fluorinated greenhouse gases covered by the Kyoto Protocol. Avoid perforating the refrigerant circuit of the appliance.
Maintenance and disposal must be carried out by qualified personnel only (R410A, GWP=1975).

SAVE THESE INSTRUCTIONS
THIS PRODUCT IS FOR HOUSEHOLD ONLY



[You're reading an excerpt. Click here to read official DELONGHI PAC A140HPEC user guide](http://yourpdfguides.com/dref/3960168)
<http://yourpdfguides.com/dref/3960168>

Manual abstract:

· The appliance must be installed in accordance with the relevant national legislation. · Should repairs be necessary, contact the nearest authorized Repair Service Center. Unauthorized servicing can be dangerous. · The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance. · In the case that the power cord becomes damaged, this must be repaired only by specialized personnel authorized by the manufacturer in order to protect against fire. · Always ensure the appliance is plugged into a grounded 3-prong outlet. If you have any doubts check with a qualified electrician. · We strongly discourage the use of an extension cord due to potential safety hazards. For temporary situations, use only CSA certified and UL listed 3-prong grounded extension cord, attachment plug and connector, rated 15A, 125V · Before cleaning or maintenance operations, always unplug the unit from the outlet. · Do not pull on or place strain on the power cord when moving the appliance. · The appliance should not be installed where the atmosphere may contain combustible gases, oil or sulphur, or near heat sources. · Do not rest hot or heavy objects on the appliance. · Clean the filters at least once a week. · Avoid using heaters near the unit. · The unit should be transported in a vertical position. If this is not possible secure the unit at an angle, do not lie it horizontally. · Before transporting the unit, drain the unit. After transportation, wait at least 6 hours before switching the unit on. · The packaging materials can be recycled. You are therefore recommended to place them in the special containers for differentiated waste collection. · This appliance is fitted with a special safety device. @@@@Avoid perforating the refrigerant circuit of the appliance. @@IF THIS OCCURS, WAIT 6 HOURS BEFORE TURNING THE APPLIANCE ON, 24 HOURS IS RECOMMENDED. @@Without allowing the unit this time (6-24 hours) The unit may function for only a short time, and then the compressor will break down from lack of oil). ELECTRICAL CONNECTIONS Before plugging the appliance into the outlet, check that: · The outlet's power supply corresponds to the value indicated on the rating label on the back of the appliance; · The outlet and electrical circuit are adequate for the appliance; · The outlet is a 3-hole grounded outlet. If this is not the case, you must choose another outlet. Failure to follow these important safety instructions absolves the manufacturer of all liability. If it becomes necessary, the power cable must be replaced by a qualified professional only. The instructions below will enable you to prepare your air conditioner for operation as efficiently as possible.

Before use, make sure the air intake and outlet grilles are unobstructed. 5 Setting up your portable air conditioner AIR CONDITIONING INSTALLATION WITHOUT Other set-up methods: · Thanks to the locking pins, it's possible to use the window bracket also for sliding windows. Position the hole of the bracket so to allow a correct installation of the exhaust hose (see figure C) NOTE: Keep the air hoses as short and free of curves as possible to avoid constrictions. FOR OPTIMAL RESULTS SET-UP IN A DOUBLE-HUNG WINDOW: 1) Place the bracket in the window sill, extend the bracket fully within the window frame, fix the bracket by using the pin then lower the window onto the bracket. (Should the window bracket be too large for the window. The plastic can be cut with a saw by a qualified professional.) 2) Fit the air exhaust hose in the housing at the back of the appliance. Insert it as shown in figure A. 3) Connect the window outlet 13 to the other end of the exhaust hose. C · If you have a casement window (figure D) follow steps 2 & 3 and place the window outlet 13 outside the window to exhaust the hot air.

A 4) Insert the window outlet end of the exhaust hose into the slot of the window bracket (fig. B). D For help with installation, operation, and for all accessories and spare/replacement parts, please contact our toll free customer service call center at: 1-800-322-3848 [US only] 1-888-335-6644 [Canada only] 01-800-711-8805 (Mexico only) or log onto our website at www.delonghi.com B 6 Semi-permanent installation SEMI-PERMANENT INSTALLATION If required, your appliance can also be installed semi-permanently (Fig.

E). · Fit the wall flange 11 into the hole. 12 · Fit the air exhaust hose into the air GB exhaust hose housing 8 located on the rear side of the appliance (fig. A page 6). · Fit the end of the hose flange 11 12 to the wall as shown in fig.

@@@@@@@@ · Press the (16) button until the appliance comes on. @@@@@@@@@ · Select the target temperature by pressing the or button until the desired temperature is reached. · Select the desired fan speed by pressing the FAN button. Four speeds are available: Maximum speed: to achieve the target temperature as rapidly as possible Medium speed: reduces noise levels while maintaining a comfortable temperature Low speed: for silent operation and maximum energy efficiency AUTO: the appliance automatically selects the most suitable fan speed in relation to the temperature set on the digital display.

The most suitable temperature for the room during the summer varies from 75°F to 81°F (24 to 27°C). You are recommended, however, not to set a temperature much below the outdoor temperature. DEHUMIDIFYING MODE Ideal to reduce room humidity (spring and autumn, damp rooms, rainy periods, etc). In dehumidifying mode, the appliance MUST be set-up in the same way as for air conditioning, with the air exhaust hose attached to enable the moisture to be discharged outside. To set this mode: · Press the MODE button a number of times until the dehumidifying symbol appears. In this mode, fan speed is selected automatically by the appliance and cannot be set manually.

FAN MODE When using the appliance in this mode, the air hose does not need to be attached. To set this mode: 9 Operation · Press the MODE button a number of times until the fan symbol appears. · Select the required fan speed by pressing the FAN button. Three speeds are available: Maximum speed: to achieve the target ventilation as rapidly as possible Medium speed: reduces noise levels while maintaining a comfortable ventilation Low speed: for silent operation and maximum energy efficiency In this mode, AUTO speed cannot be selected. HEATING MODE CERTAIN MODELS ONLY This is ideal in spring and autumn when outdoor temperatures are not particularly severe.



[You're reading an excerpt. Click here to read official DELONGHI](#)

[PAC A140HPEC user guide](#)

<http://yourpdfguides.com/dref/3960168>

When using the appliance in this mode, the air exhaust hose needs connected, and the unit must still be vented. After selecting HEATING mode, the unit may take several minutes to produce warm air, this is normal. To set this mode correctly proceed as follow: · Press the MODE button a number of times until the heating symbol appears. · Select the target temperature by pressing the or button until the corresponding value is displayed. In this mode, fan speed is selected automatically by the appliance and cannot be set manually.

Note: · When operating in very cold rooms, the appliance may defrost automatically, momentarily interrupting normal operation. " " appears on the display. · Select the required fan speed. · To set this mode: · Press the button. The appliance operates in air conditioning mode at maximum fan speed.

While this function is selected, it is not; Once the correct time has been reached, release the button and press the OK button to confirm. · To set this mode: · Press the button. The appliance operates in air conditioning mode at maximum fan speed. · Press the button.

· When that time is reached, press the OK button to confirm.

· Programming shutdown · Press the button. · When that time is reached, press the OK button to confirm. · The only e Close the window. Eliminate the heat source. Connect the exhaust hose. · absorbed power during air conditioning " Refrigerant " Cooling capacity " Absorbed power heating " (certain models only) LIMIT CONDITIONS Room temperature for air conditioning 69.8 ÷ 95°F (21° ÷ 35°C) Room temperature for heating 50° ÷ 77°F (10° ÷ 25°C) Transport, filling, cleaning, recovery and disposal of refrigerant should be performed by a technical service centre appointed by the manufacturer only. The appliance should be disposed of by a specialist centre appointed by the manufacturer only. NEVER TRANSPORT OR TURN THE APPLIANCE UPSIDE DOWN OR ON ITS SIDE. IF THIS OCCURS, WAIT 6 HOURS BEFORE TURNING THE APPLIANCE ON, 24 HOURS IS RECOMMENDED. · Do not modify the plug provided with the appliance.

· If the household electrical supply does not meet the above specifications, or if you are not sure your home has an effective electrical ground, have a qualified electrician or your local electrical utility company check it and correct any problems. SAFETY PLUG The appliance is fitted with a safety plug to protect the power cable. If power is cut off, unplug from the outlet and make sure the power cable is undamaged. If the cable is damaged, call the service center immediately. If power cuts off frequently and the power cable is undamaged, contact a qualified electrician. OPERATION OF THE SAFETY PLUG If the safety device incorporated in the plug trips and cuts off the power supply, check that the power cable and plug are not damaged. If the power cable is undamaged, to restore operation press the "RESET" button. To verify correct operation of the plug, press the "TEST" button periodically and make sure the appliance disconnects. If this is not the case, contact the service center. To restore operation, press the "RESET" button.

20 Limited Warranty De'Longhi is the distributor of Kenwood home appliances. GB This warranty applies to all home appliances with De'Longhi or Kenwood brand names LIMITED WARRANTY We warrant each De'Longhi AIR CONDITIONER to be free from defects in material and workmanship. From the purchase date, our obligation under this warranty is to provide two (2) years free parts and labor on the entire AIR CONDITIONER, with an additional four (4) years free on any part of the sealed system consisting of the compressor, evaporator, condenser and factory connected refrigerant tubing.

· This warranty is in lieu of all other warranties and representations, expressed or implied, and all other obligations or liabilities on our part. We do not authorize any other person or company to assume for us any liability in connection with the sale or use of our AIR CONDITIONER. This warranty shall not apply to any AIR CONDITIONER that has been repaired or altered outside our factory nor shall it apply to any AIR CONDITIONER that has been subjected to misuse, negligence or accidents. If repairs become necessary, see contact information below: U.S. Residents: Please contact our toll free hotline at 1-800-322-3848 or log onto our website at www.delonghi.com CANADA Residents: Please contact our toll free hotline at 1-888-335-6644 or log onto our website at www.delonghi.com MEXICO Residents: Please contact our toll free hotline at 01-800-711-8805 or log onto our website at www.delonghi.com The above warranty is in lieu of all other express warranties and representations. All implied warranties are limited to the applicable warranty period set forth above. This limitation does not apply if you enter into an extended warranty with De'Longhi. Some states/countries do not allow limitations on how long an implied warranty lasts, so the above exclusions may not apply to you. De'Longhi does not authorize any other person or company to assume for it any liability in connection with the sale or use of its appliance. How does country law apply? This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state/country to country.



[You're reading an excerpt. Click here to read official DELONGHI PAC A140HPEC user guide](http://yourpdfguides.com/dref/3960168)
<http://yourpdfguides.com/dref/3960168>