



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for FUJITSU SIEMENS SCENIC P320 (SIS661+). You'll find the answers to all your questions on the FUJITSU SIEMENS SCENIC P320 (SIS661+) in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual FUJITSU SIEMENS SCENIC P320 (SIS661+)**

**User guide FUJITSU SIEMENS SCENIC P320 (SIS661+)**

**Operating instructions FUJITSU SIEMENS SCENIC P320 (SIS661+)**

**Instructions for use FUJITSU SIEMENS SCENIC P320 (SIS661+)**

**Instruction manual FUJITSU SIEMENS SCENIC P320 (SIS661+)**

Mainboard

Deutsch, English, Русский,  
Français, Türkçe, Ελληνικά

Short Description

## Mainboard D1961



[You're reading an excerpt. Click here to read official FUJITSU SIEMENS SCENIC P320 \(SIS661+\) user guide](http://yourpdfguides.com/dref/1251095)

<http://yourpdfguides.com/dref/1251095>

**Manual abstract:**

@@@ offenders will be liable for damages. All rights, including rights created by patent grant or registration of a utility model or design, are reserved. 5 = Right line output 6 = Right line return 7 = Not connected 8 = Key 9 = Left line output 10 = Left line return Speaker 1) Cable is not included in the delivery scope 2) 2-pin or 3-pin connector possible 3) both connector positions possible Recovery inserted = The system starts from floppy and allows a BIOS recovery Password inserted = System- and BIOS Password are skipped when device is switched on Special Features Silent Fan LT Silent Drives Recovery BIOS Desk Update Multi Boot Independent temperature related processor-fan supervision and control Noise reduction for optical and hard disk drives Restores a disrupted BIOS Simple driver update with DU CD Comfortable boot from any boot device Resolution with 75Hz, 32, 64 or 128 MB shared memory, upgradeable with AGP Graphics Card, High performance 3D Engine, DirectX 7 complaint Unterstützte Bildschirmauflösungen Abhängig vom verwendeten Betriebssystem gelten die nachfolgend angegebenen Bildschirmauflösungen für den Bildschirm-Controller auf dem Mainboard. Information about boards Be sure to observe the following for boards with ESD: You must always discharge static build up (e. The equipment and tools you use must be free of static charges. Remove the power plug from the mains supply before inserting or removing boards containing ESDs. Always hold boards with ESDs by their edges. Never touch pins or conductors on boards fitted with ESDs. Your mainboard is available in different configuration levels. @@@@The location of the external connections of your mainboard is specified at the beginning of the manual.

Monitor port, blue Audio input (Line in), light blue Disconnect the system from the mains voltage before performing any of the tasks described below. Details are contained in the operating manual of your system. Technical data Intel Pentium 4 with 533 or 800 MHz front side bus in the LGA775 design (Value FMB) Intel Celeron D with 533 MHz Front Side Bus in the LGA775 design A current list of the processors supported by this mainboard is available on the Internet at: www. Even minor soiling such as grease from the skin can impair the processor's operation or destroy the processor. Place the processor in the socket with extreme care, as the spring contacts of the socket are very delicate and must not be bent.

@@@At least one memory module must be installed. Memory modules with different memory capacities can be combined. You may use unbuffered 2. 5 V memory modules without ECC. DDR-DRAM memory modules must meet the PC2700 or PC3200 specification.

@@@Expansion cards that do not require an interrupt can be installed in any desired slot. Multifunctional expansion cards or expansion cards with integrated PCI-PCI bridge These expansion cards require up to four PCI interrupts: INT A, INT B, INT C, INT D. How many and which of these interrupts are used is specified in the documentation provided with the card. @@@@Fujitsu Siemens Computers makes new BIOS versions available to ensure compatibility to new operating systems, new software or new hardware. In addition, new BIOS functions can also be integrated. A BIOS update should always also be carried out when a problem exists that cannot be solved with new drivers or new software. You have two ways of doing this: 1. BIOS update under

DOS with bootable BIOS update floppy disk - brief description Download the update file from our website to your PC. BIOS update under Windows with DeskFlash utility A BIOS update can also be carried out directly under Windows with the DeskFlash utility. @@@@Resolution with 75Hz, 32, 64 or 128 MB shared memory, upgradeable with AGP Graphics Card, High performance 3D Engine, DirectX 7 complaint Desteklenen ekran çözünürlükleri Anakart üzerindeki ekran controlleri için, kullanılan iletim sistemine baimli olarak aaida belirtilmi olan ekran çözünürlükleri geçerlidir.



[You're reading an excerpt. Click here to read official FUJITSU SIEMENS SCENIC P320 \(SIS661+\) user guide](http://yourpdfguides.com/dref/1251095)  
<http://yourpdfguides.com/dref/1251095>