




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for INDESIT DG 6145. You'll find the answers to all your questions on the INDESIT DG 6145 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual INDESIT DG 6145
User guide INDESIT DG 6145
Operating instructions INDESIT DG 6145
Instructions for use INDESIT DG 6145
Instruction manual INDESIT DG 6145



[You're reading an excerpt. Click here to read official INDESIT DG 6145 user guide](http://yourpdfguides.com/dref/3206322)
<http://yourpdfguides.com/dref/3206322>

Cold Water Connection Connect the cold water supply hose to a threaded 3/4 (gas) connector, inserting the small filter supplied with the dishwasher and making sure that it is fastened tightly in place (see figure 2). If the water pipes are new or have not been used for an extended period of time, let the water run to make sure that the water is clear and free of impurities. If this precaution is not taken, there is a risk that the water inlet can get blocked and damage the appliance. *Hot Water Connection* The water supply to the appliance can also be connected to the house's hot water line (centralised system, heating system), as long as it does not exceed a temperature of 60° C. Use the special plastic support that comes with the appliance (see figure to the right). The free end of the hose must be at a height between 40 and 100 cm and must not be immersed in water. **Attention:** The special plastic hose support must be solidly fastened to the wall to prevent the drain hose from moving and allowing water to spill outside the drain. *Electrical Connection* After making sure that the voltage and frequency values for the current in the home correspond to those on the rating plate (located on the stainless steel inner door of the appliance) and that the electrical system is sized for the maximum voltage on the rating plate, insert the plug into an electrical socket which is earthed properly (the earthing of the appliance is a safety requirement mandated by law).

If the electrical socket to which the appliance must be connected is not appropriate for the plug, replace the plug, rather than using adaptors or the like as they could cause overheating and burns. **GB 10 Electrical Connection** *Electrical Connection* If your appliance is supplied with a 13 amp. fused plug it can be plugged into a 13 amp socket for immediate use. Before using the appliance please read the instruction below. **WARNING: THIS APPLIANCE MUST BE EARTHED. THE FOLLOWING OPERATIONS SHOULD BE CARRIED OUT BY A QUALIFIED ELECTRICIAN.** Replacing the fuse: When replacing a faulty fuse, a 13 amp ASTA approved fuse to BS 1362 should always be used, and the fuse cover re-fitted. If the fuse cover is lost, the plug must not be used until a replacement is obtained. **Instruction for connecting cable to an alternative plug:** Important: the wires in the mains lead are coloured in accordance with the following code: Green & Yellow - Earth Blue - Neutral Brown - Live As the colours of the wires in the mains lead may not correspond with the coloured markings identifying the terminal in your plug, proceed as follows: connect Green & Yellow wire to terminal marked "E" or coloured Green or Green & Yellow. Connect Brown wire to terminal marked &quo.



[You're reading an excerpt. Click here to read official INDESIT DG 6145 user guide](http://yourpdfguides.com/dref/3206322)
<http://yourpdfguides.com/dref/3206322>