




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for INDESIT INCB31AA. You'll find the answers to all your questions on the INDESIT INCB31AA in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual INDESIT INCB31AA
User guide INDESIT INCB31AA
Operating instructions INDESIT INCB31AA
Instructions for use INDESIT INCB31AA
Instruction manual INDESIT INCB31AA



[You're reading an excerpt. Click here to read official INDESIT INCB31AA user guide](http://yourpdfguides.com/dref/5066875)
<http://yourpdfguides.com/dref/5066875>

Manual abstract:

- The appliance has not been altered, serviced, maintained, dismantled, or otherwise interfered with by any person not authorised by us. - Any repair work must be undertaken by us or our appointed agent. - Any parts removed during repair work or any appliance that is replaced become our property. - The appliance is used in the United Kingdom or Republic of Ireland. The guarantee does not cover: - Damage resulting from transportation, improper use, neglect or interference or as a result of improper installation. - Replacement of any consumable item or accessory. These included but not limited to: plugs, cables, batteries, light bulbs, fluorescent tubes and starters, covers and filters. - Replacement of any removable parts made of glass or plastic. **THIS GUARANTEE WILL NOT APPLY IF THE APPLIANCE HAS BEEN USED IN COMMERCIAL OR NON-DOMESTIC PREMISES. 12 months Parts and Labour Guarantee**

We pride ourselves on ensuring that you and your Hotpoint appliance receive the very highest level of service.

No one understands Hotpoint appliances like we do, so for service from the people that know your appliance best, simply call 08448 224 224. Our operators are on hand to answer your call every day including weekends and bank holidays. Our team of 1000 technicians are the largest white goods service organisation in the UK and Ireland available to provide fast, reliable and local service. They have all undergone extensive training at our Training Centre of Excellence and are equipped with the latest diagnostic tools to deliver expert servicing of your Hotpoint appliance. After Sales Service UK: 08448 224 224 Republic of Ireland: 0818 313 413 or visit www.hotpoint.co.uk

hotpoint.co.uk Model number: _____ Serial number: _____ We supply a full range of genuine replacement parts as well as accessory products that protect and hygienically clean your appliance to keep it looking good and functioning efficiently throughout its life. Parts and Accessories UK: 08448 225 225 Republic of Ireland: 0818 313 413 or visit www.hotpoint.co.uk We want to give you additional benefits of Hotpoint ownership. To activate your free 5 year parts guarantee you must register your appliance. By registering your appliance with us not only do you activate the guarantee all your information will be logged onto our repair system. In the unfortunate event that you need assistance we will have your appliance details to hand when you call us. Appliance Registration Hotpoint also offers you a free 5 year parts guarantee. This additional guarantee is conditional on you registering your appliance with us and the parts being fitted by one of our authorised engineers. There will be a charge for our engineer's time. To activate the extra parts warranty on your appliance, simply call our registration line on 08448 242424 (Republic of Ireland 01 230 0233). 5 Year Parts Guarantee UK: 08448 24 24 24 Republic of Ireland: 01 230 0800 or visit www.hotpoint.co.uk

hotpoint.co.uk Indesit Company UK Ltd. Morley Way, Peterborough, PE2 9JB Indesit Ireland Ltd. The Crescent Building, Northwood Park, Santry, Dublin 9. We offer a selection of protection plans that enable you to fully cover yourself against the expense of repair bills for the life of your policy. To find the ideal plan for you please call our advice line on 08448 226 226 (Republic of Ireland 01 230 0233). Extended Guarantees Recycling and Disposal Information - model - serial number We have a dedicated team who can provide free advice and assistance with your appliance if you experience any technical difficulties within the first 90 days of ownership. Simply call our Hotpoint Service Hotline on 08448 224 224 (Republic of Ireland 0818 313 413) for telephone assistance, or, where necessary, to arrange for an engineer to call. Helpdesk Service PLEASE PHONE US TO REGISTER YOUR APPLIANCE AND ACTIVATE YOUR 5 YEAR PARTS GUARANTEE ON 08448 24 24 24 2 Description of the appliance Overall view The instructions contained in this manual are applicable to different model refrigerators.

The diagrams may not directly represent the appliance purchased. For more complex features, consult the following pages. 1 STORAGE compartment * 2 FREEZER and STORAGE compartment 3 FRUIT and VEGETABLE bin * 4 FOOD CARE ZONE for MEAT and CHEESE * 5 WINE RACK * 6 SHELVES * 7 LAMP (see Maintenance) * 8 Removable multipurpose SHELVES * 9 BOTTLE shelf 10 FRESH BOX * 11 ACTIVE OXYGEN * 12 AIR * 13 TEMPERATURE REGULATING Knob 14 SUPER FREEZE * * Varies by number and/or position, available only on certain models. 11 7 12 6 10 5 6 4 3 14 2 13 7 9 8 1 PLEASE PHONE US TO REGISTER YOUR APPLIANCE AND ACTIVATE YOUR 5 YEAR PARTS GUARANTEE ON 08448 24 24 24 3 GB Installation ! Before placing your new appliance into operation please read these operating instructions carefully. They contain important information for safe use, for installation and for care of the appliance.

! Please keep these operating instructions for future reference. Pass them on to possible new owners of the appliance. Changing the plug: Positioning and connection Positioning 1. Place the appliance in a well-ventilated humidity-free room. 2.

Do not obstruct the rear fan grills. The compressor and condenser give off heat and require good ventilation to operate correctly and save energy. 3. Ensure the appliance is away from any sources of heat (direct sunlight, electric stove, etc.). Electrical connections After the appliance has been transported, carefully place it vertically and wait at least 3 hours before connecting it to the electricity mains. Before inserting the plug into the electrical socket ensure the following: • The appliance is earthed and the plug is compliant with the law. • The socket can withstand the maximum power of the appliance, which is indicated on the data plate located on the bottom left side of the fridge (e.g. 150 W).

• The voltage must be in the range between the values indicated on the data plate located on the bottom left side (e.g. 220-240V). • The socket is compatible with the plug of the appliance. If the socket is incompatible with the plug, ask an authorised technician to replace it (see Assistance). Do not use extension cords or multiple sockets. ! Once the appliance has been installed, the power supply cable and the electrical socket must be easily accessible. ! The cable must not be bent or compressed. ! The cable must be checked regularly and replaced by authorised technicians only (see Assistance). ! The manufacturer declines any liability should these safety measures not be observed.

WARNING: THIS APPLIANCE MUST BE EARTHED. Replacing fuse covers: When replacing a faulty fuse, a 13amp ASTA approved fuse to BS 1362 should always be used and the fuse cover re-fitted. If the fuse cover is lost, the plug must not be used until a replacement is obtained. Replacement fuse covers: If a replacement fuse cover is fitted, it must be of the correct colour as indicated by the coloured marking or the colour that is embossed in words on the base of the plug.



[You're reading an excerpt. Click here to read official INDESIT INCB31AA user guide](http://yourpdfguides.com/dref/5066875)
<http://yourpdfguides.com/dref/5066875>

Old appliances must be collected separately in order to optimise the recovery and recycling of the materials they contain and reduce the impact on human health and the environment. The crossed out "wheeled bin" symbol on the product reminds you of your obligation, that when you dispose of the appliance it must be separately collected. Consumers should contact their local authority or retailer for information concerning the correct disposal of their old appliance. PLEASE PHONE US TO REGISTER YOUR APPLIANCE AND ACTIVATE YOUR 5 YEAR PARTS GUARANTEE ON 08448 24 24 24 7 195100536.00 02/2012 GB Troubleshooting If the appliance does not work, before calling for Assistance (see Assistance), check for a solution from the following list. The internal light does not illuminate. •The plug has not been inserted into the electrical socket, or not far enough to make contact, or there is no power in the house. The refrigerator and the freezer do not cool well. •The doors do not close properly or the seals are damaged. •The doors are opened too frequently.

- The TEMPERATURE ADJUSTMENT knob is not in the correct position. •The refrigerator or the freezer have been over-filled. •The atmospheric temperature of the area surrounding the appliance is lower than 14°C. The food inside the refrigerator is beginning to freeze. •The TEMPERATURE ADJUSTMENT knob is not in the correct position. •The food is in contact with the back inside wall of the refrigerator. The AIR fan does not rotate •The refrigerator door is open. •The AIR system is only activated automatically when it becomes necessary to restore perfect operational conditions inside the refrigerator compartment. The motor runs continuously. •The door is not closed properly or is continuously opened.
- The outside ambient temperature is very high. •The thickness of the frost exceeds 2-3 mm (see Maintenance). The appliance makes a lot of noise. •The appliance has not been installed on a level surface (see Installation). •The appliance has been installed between cabinets that vibrate and make noise.
- The internal refrigerant makes a slight noise even when the compressor is off. This is not a defect, it is normal. Some of the external parts of the refrigerator become hot. •These raised temperatures are necessary in order to avoid the formation of condensation on certain parts of the product. The back wall of the refrigerator unit is covered in frost or droplets of water •This shows the appliance is operating normally.
- There is water at the bottom of the refrigerator. •The water discharge hole is blocked (see Maintenance). PLEASE PHONE US TO REGISTER YOUR APPLIANCE AND ACTIVATE YOUR 5 YEAR PARTS GUARANTEE ON 08448 24 24 24 8 .



[You're reading an excerpt. Click here to read official INDESIT](#)

[INCB31AA user guide](#)

<http://yourpdfguides.com/dref/5066875>