




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for KYOCERA TASKALFA 552CI. You'll find the answers to all your questions on the KYOCERA TASKALFA 552CI in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual KYOCERA TASKALFA 552CI
User guide KYOCERA TASKALFA 552CI
Operating instructions KYOCERA TASKALFA 552CI
Instructions for use KYOCERA TASKALFA 552CI
Instruction manual KYOCERA TASKALFA 552CI



[You're reading an excerpt. Click here to read official KYOCERA TASKALFA 552CI user guide](http://yourpdfguides.com/dref/3970762)
<http://yourpdfguides.com/dref/3970762>

Manual abstract:

Press ORIGINAL IMAGE. Choose the Color to be used. @@@@Destination ABCD TUVW Group1 On Hook 0001 AAA 0006 FFF Destination Status Destination Chain 002 BBB 007 GGG HHH Quick Setup CCC Detail/Edit 003 DDD 008 III Delete 004 EEE 009 JJJ 010 005 Recall No. FAX No. Entry i-FAX Addr Entry 1/10 WSD Scan Original/Sending Data Format Color/ Image Quality Advanced Setup 10/10/2008 10:10 Ready to send. Place original. Color Selection Select scanning color. Select [Auto Color] to automatically send color originals in full color and black & white originals in black & white. Place original. Destination Auto Color (Color/Gray) Original Zoom Paper : --: 100% : --Preview Add Shortcut Status Auto Color (Color/B & W) Full Color Grayscale Black & White Cancel OK 10/10/2008 10:10 Further settings Press SEND.

Press QUICK SETUP. Ready to send. Sending Image 600x600dpi 200x200dpi Fine 400x400dpi Ultra Fine 200x100dpi Normal 200x400dpi Super Fine Destination Shortcut 1 Shortcut 2 Shortcut 3 in the optional document processor. Press SEND/FAX. Enter the destination address.

From the address book: Press ADDRESS BOOK. Press the checkbox to select the desired destination from the list. Press SEARCH (NAME) to find the destination. Enter the name you search for. Confirm with OK.

You may choose multiple destinations. Enter the destination: Press FAX. NO. ENTRY. Enter the fax number with the TEN PAD keys. After that press OK. If you want to send the fax to several destinations, go back to step 3. To send the fax press START. Detail abcd@efg.com 10.

200.188.120 Group1 To: Auto 1/1 Address Book E-mail Addr Entry Folder Path Entry FAX No. Entry i-FAX Addr Entry Direct 0002 BBB 0007 GGG Chain 0003 CCC 0008 HHH Quick Setup Detail/Edit 0004 DDD 0009 III Original/Sending Data Format Delete 0005 EEE 0010 JJJ Recall No. 1/100 WSD Scan Advanced Setup 10/10/2008 10:10 Color/ Image Quality Address Book Addr Book Dest. No. Address Book Type Name Sort Name Detail 0001 0002 0003 0004 0005 ABC DEF GHI ABCD TUVW Group1 Group2 Group3 JKL MNO PQRS abcd@efg.com Search(Name) tuvw@xyz.com 1/2 Search(No.)

Register/Edit Address Book Detail TUV WXYZ 0-9 E-mail Folder FAX i-FAX Cancel Group OK 10/10/2008 10:10 Status Ready to send.

FAX No. @@Enter FAX number with the numeric keys. @@After changing confirm with OK. To enter a file name press ADVANCED SETTINGS. Press FILE NAME ENTRY and change the name.

Confirm with OK. @@ Press SENDING JOBS. @@@@ Press SEND. Enter the destination address. From the address book: Press ADDRESS BOOK.

Press the checkbox to select the desired destination from the list. Press SEARCH (NAME) to find the destination. Enter the name you search for. Confirm with OK. You may choose multiple destinations. Enter an e-mail address: Press E-MAIL ADDR. ENTRY and E-MAIL ADDRESS. Enter the E-Mail address on the touch screen. After that press OK. @@@@ Confirm with YES.

@@@ Press SENDING JOBS. Under Job Type, select FAX. Press LOG. Select a job to be checked. @@@@The section JOBNAME allows you to type in your name directly. Press DOCUMENT BOX. Press JOB BOX. Select the creator of the private print job. Select the document to be printed from the list.

@@ Press PRINT to start printing.

@@ Press COPY. Enter the number of copies with the TEN PAD keys. Choose the copy mode. @@ Confirm all settings with OK. Press START.

Optional functions: The color settings can be changed. Press COLOR/IMAGE QUALITY. Choose COLOR BALANCE, HUE ADJUST- Shortcut 1 Shortcut 2 Place original. Shortcut 3 Auto Original Zoom Paper : --: 100% : --Preview Quick Setup Status 100% Zoom 2 in 1 Combine Color/ Image Quality Normal 0 Density Shortcut 4 Paper Selection 2-sided >>2-sided Duplex Org./Paper/ Finishing Shortcut 5 Off Staple/Punch Layout/Edit Shortcut 6 Advanced Setup 10/10/2008 10:10 Ready to copy.

Original Image Select original image type for best results. Place original. Copies Close Status 10/10/2008 10:10 Job Box. User: File Name 1File 2File 3File 4File 5File Print Date and Time 10/10/2008 09:40 10/10/2008 09:45 10/10/2008 09:50 10/10/2008 09:55 10/10/2008 10:10 Size 21 MB 30 MB 36 MB 21 MB 30 MB Delete Close Status 10/10/2008 10:10 MENT, ONE-TOUCH IMAGE ADJUSTMENT, SHARPNESS, BACKGROUND ADJ. in the Text+Photo Original Zoom Paper : --: 100% : --Preview Add Shortcut Status Photo Print Photo Text Map sub menu from the main screen. Confirm all settings with OK. 1/1 Cancel OK 10/10/2008 10:10 Ready to copy. One-touch Image Adjust Adjust images as desired. Copies Detail Place original. Off Original Zoom Paper : --: 100% : --Preview Add Shortcut Status Vivid Smooth Dull Light Sharp Dark Color settings When printing from an application press PROPERTIES button.

Choose IMAGING tab. Choose COLOR (CMYK) or BLACK & WHITE. Cancel OK 10/10/2008 10:10 Ready to copy. Color Balance Off Cyan -5 -4 -3 -2 -1 0 1 2 Copies 3 4 5 Place original. On Magenta -5 -4 -3 -2 -1 0 1 2 3 4 5 Use PRINTER PROFILE to choose object types depending on your original to be printed. Standard selection is PRINTER SETTINGS. Options are: TEXT/ GRAPHICS, TEXT/PHOTOS, VIVID COLORS, PUBLICATIONS, LINE ART or ADVANCED. Yellow Original Zoom Paper : --: 100% : --Preview Add Shortcut Status -5 -4 -3 -2 -1 0 1 2 3 4 5 Black -5 -4 -3 -2 -1 0 1 2 3 4 5 Cancel OK 10/10/2008 10:10 Ready to copy. Background Density Adj. Off Background Lighter Place original.

@@ Press PRINTING JOBS. @@ Confirm with YES. .



[You're reading an excerpt. Click here to read official KYOCERA TASKALFA 552CI user guide](http://yourpdfguides.com/dref/3970762)
<http://yourpdfguides.com/dref/3970762>