



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for LA CROSSE TECHNOLOGY 302-604. You'll find the answers to all your questions on the LA CROSSE TECHNOLOGY 302-604 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual LA CROSSE TECHNOLOGY 302-604
User guide LA CROSSE TECHNOLOGY 302-604
Operating instructions LA CROSSE TECHNOLOGY 302-604
Instructions for use LA CROSSE TECHNOLOGY 302-604
Instruction manual LA CROSSE TECHNOLOGY 302-604



Tomorrow's Weather Today™

302-604

Indoor Comfort Level Station
Quick setup manual

Introduction

The Indoor Comfort Level Station is an ideal measuring instrument for checking room ambient conditions. Checking indoor temperature and humidity can help achieve a comfortable and healthy living environment and may even save you heating costs.

Features:

- Digital time
- Indoor temperature (°F or °C)
- Indoor relative humidity (%RH)
- Minimum and Maximum temperature and humidity records
- Comfort level icon (smiley face) for humidity levels between 40% - 60%RH.
- Display large temperature or large humidity with the touch of a button.
- Wall hanging or free standing.
- Temperature range: -4° F to 122° F (-20° C to 50° C).
- "Lo" icon when temperature is below -4° F (-20°).
- Humidity range 20% to 99% RH.
- CR 2032 button cell battery included.

Set up:


- Remove the stand (E) from the back of the station by carefully pulling it downwards.
- Open the battery compartment (F) by turning the lid with a coin counter clockwise.
- Remove the insulation strip from the battery.
- Close the battery compartment again.
- All LCD segments will light up for about a few seconds.
- The unit is now ready to use.
- The upper display shows the time and the comfort level, the middle display shows the current temperature and the lower display the relative humidity

Buttons:

- A: SET button
- B: SWITCH button
- C: MAX/MIN button

Housing:

- D: Wall mounting hole
- E: Removable stand
- F: Battery compartment



Display with removable stand.

Set Time:

Press and hold SET button for 3 seconds, to enter the time set mode.

- **HOUR:** The Hour digit is flashing. Press and release the SWITCH button to adjust the Hours. Be sure to AM or PM is showing as appropriate.
- **MINUTES:** Press and release the SET button again the Minutes digit is flashing. Press and release the SWITCH button to adjust the minutes. Hold the SWITCH button to change the Minutes quickly.
- **CONFIRM:** Press and release the SET button to confirm the time and return to a normal display.

Fahrenheit or Celsius:

- Press and release the SET button to change between °C (Celsius) or °F (Fahrenheit) as temperature unit in normal mode.

NOTE: With Fahrenheit as temperature unit, the clock automatically switches to the 12 HR system (PM appears on the display after noon).

Comfort Level Icon:

- When the humidity is between 40% and 60% a smiling face icon will display in the upper right corner of the station to indicate the comfort level of indoor climate.

MAX/MIN Values:

- **VIEW:** Press and release the MAX/MIN button. MAX appears on the display. The maximum temperature and humidity are displayed. Press and release the MAX/MIN button again. MIN appears on the display. The minimum

temperature and humidity are displayed. Press MAX/MIN button again to return to normal mode.

- **RESET:** Press and release the MAX/MIN button to show MAX or MIN. Hold the SET button in the respective mode to clear the recorded MAX/MIN reading. The temperature and humidity will appear as: --- F and --- % on the display.

Display options:

- Press and release the SWITCH button, to choose between the large-scale display of temperature or humidity.

Positioning and mounting:

- With the removable stand the instrument can be placed onto any flat surface or wall mounted at the desired location by the wall mounting hole at the back of the unit.

Battery replacement:

Change the battery CR 2032 button cell when the battery symbol appears on the display

- Remove the stand (E) from the back of the station by carefully pulling it downwards.
- Open the battery compartment (F) by turning the lid with a coin counter clockwise.
- Remove the old battery and install a fresh CR2032 battery. Observe correct polarity (+ facing up).
- Close the battery compartment again.

Low batteries should be changed soon to avoid the damage resulting from a leaking battery.

Attention:

If you notice that the LCD appears faint or is not working properly, try a fresh battery before contacting customer support. We recommend that you replace the batteries in all units regularly to ensure optimum accuracy of this unit.

Help us to keep our environment clean. Please do not dispose of old electronic devices and empty batteries in household waste. To protect the environment, take them to your retail store or to appropriate collection sites according to national or local regulations.



[You're reading an excerpt. Click here to read official LA CROSSE TECHNOLOGY 302-604 user guide](http://yourpdfguides.com/dref/4575883)
<http://yourpdfguides.com/dref/4575883>

Manual abstract:

Checking indoor temperature and humidity can help achieve a comfortable and healthy living environment and may even save you heating costs. @@@@ · Wall hanging or free standing. @@ · "Lo" icon when temperature is below -4°F (-20°). · Humidity range 20% to 99% RH. · CR 2032 button cell battery included. Set up: ····· Housing: D: Wall mounting hole E: Removable stand F: Battery compartment · temperature and humidity are displayed. Press MAX/MIN button again to return to normal mode. RESET: Press and release the MAX/MIN button to show MAX or MIN. Hold the SET button in the respective mode to clear the recorded MAX/MIN reading. The temperature and humidity will appear as: --. °F and --.% on the display. Display options: · Press and release the SWITCH button, to choose between the large-scale display of temperature or humidity. @@@@ · @@ · Remove the old battery and install a fresh CR 2032 battery. Observe correct polarity (+ facing up). · Close the battery compartment again. @@@@ · Help us to keep our environment clean. Please do not dispose of old electronic devices and empty batteries in household waste. To protect the environment, take them to your retail store or to appropriate collection sites according to national or local regulations. Display with removable stand.

Set Time: Press and hold SET button for 3 seconds, to enter the time set mode. · HOUR: The Hour digit is flashing. Press and release the SWITCH button to adjust the Hours. Be sure to AM or PM is showing as appropriate. · MINUTES: Press and release the SET button again the Minutes digit is flashing. Press and release the SWITCH button to adjust the minutes. Hold the SWITCH button to change the Minutes quickly. @@@@ · @@@@ · Remove the insulation strip from the battery. Close the battery compartment again. All LCD segments will light up for about a few seconds.

The unit is now ready to use. @@MAX appears on the display. The maximum temperature and humidity are displayed. Press and release the MAX/MIN button again. MIN appears on the display. @@@@ · Clean it with a soft damp cloth. Do not use solvents or scouring agents. · If the unit does not work properly, change the battery. @@Keep it out of reach of children. @@@@ · @@@@ · To receive warranty service, the purchaser must contact La Crosse Technology, Ltd for problem determination and service procedures.

Warranty service can only be performed by a La Crosse Technology, Ltd authorized service center. The original dated bill of sale must be presented upon request as proof of purchase to La Crosse Technology, Ltd or La Crosse Technology, Ltd's authorized service center. La Crosse Technology, Ltd will repair or replace this product, at our option and at no charge as stipulated herein, with new or reconditioned parts or products if found to be defective during the limited warranty period specified above. @@@@ · @@@@ · This warranty covers only actual defects within the product itself, and does not cover the cost of installation or removal from a fixed installation, normal set-up or adjustments, claims based on misrepresentation by the seller or performance variations resulting from installation-related circumstances. LA CROSSE TECHNOLOGY, LTD WILL NOT ASSUME LIABILITY FOR INCIDENTAL,

CONSEQUENTIAL, PUNITIVE, OR OTHER SIMILAR DAMAGES ASSOCIATED WITH THE OPERATION OR MALFUNCTION OF THIS PRODUCT. THIS PRODUCT IS NOT TO BE USED FOR MEDICAL PURPOSES OR FOR PUBLIC INFORMATION. THIS PRODUCT IS NOT A TOY. KEEP OUT OF CHILDREN'S REACH. This warranty gives you specific legal rights. You may also have other rights specific to your State.

@@@S. @@@@ · This handbook may contain mistakes and printing errors. The information in this handbook is regularly checked and corrections made in the next issue. We accept no liability for technical mistakes or printing errors, or their consequences. All trademarks and patents are acknowledged. Printed in China .



[You're reading an excerpt. Click here to read official LA CROSSE TECHNOLOGY 302-604 user guide](http://yourpdfguides.com/dref/4575883)
<http://yourpdfguides.com/dref/4575883>