



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for MCCULLOCH FG7000MA. You'll find the answers to all your questions on the MCCULLOCH FG7000MA in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual MCCULLOCH FG7000MA
User guide MCCULLOCH FG7000MA
Operating instructions MCCULLOCH FG7000MA
Instructions for use MCCULLOCH FG7000MA
Instruction manual MCCULLOCH FG7000MA



For problems or questions, **DO NOT** return this product to the store. Contact your Customer Service Agent.

En cas de problèmes ou pour des questions, **NE PAS** retourner ce produit au point de vente. S'adresser au préposé du Service à la clientèle en composant.

Para problemas o preguntas, **NO** devolver este producto a la tienda. Contacte a su Agente de Servicio al Cliente.

© 2006 McCulloch
12802 Leffingwell Rd.
Santa Fe Springs, CA • U.S.A.

For Consumer Assistance Please Call
L'Aide Du Consommateur Necessitez S'il Vous Plait
Para La Ayuda Del Consumidor Llame Por Favor



U.S.A.

1-800-521-8559

Made in China/Fabriqué en Chine/Hecho en China

www.mccullochpower.com



USER MANUAL Generator
MANUEL DE UTILISATION Générateur
MANUAL DEL USUARIO Generator

Model: **FG 7000MA**

SAFETY
OPERATION
MAINTENANCE

SECURE
FONCTIONNEMENT
ENTRETIEN

SEGURIDAD
OPERACION
MANTENIMIENTO



This generator is not equipped with park arrester which is required by U.S. forest service and the state of California.

WARNING • PLEASE READ

For your own safety please read this manual before attempting to operate your new unit. Failure to follow instructions can result in serious personal injury. Spend a few moments to familiarize yourself with your generator before each use.

Ce générateur n'est pas équipé du limiteur de surtension de parc exigé par le service des forêts américain et par l'état de la Californie.

AVERTISSEMENT • LIRE ATTENTIVEMENT

Pour votre propre sécurité, veuillez lire ce manuel avant toute tentative pour faire fonctionner votre nouvelle unité. Ne pas suivre les instructions peut conduire à de sérieuses blessures au personnel. Passez quelques instants pour vous familiariser avec votre générateur avant toute utilisation.

Este generador no está equipado con supresor de chispas que es requerido por el servicio forestal de los Estados Unidos y el estado de California.

ADVERTENCIA • FAVOR DE LEER

Por su propia seguridad por favor lea este manual antes de intentar operar su nueva unidad. El no seguir las instrucciones puede ocasionar lesiones personales graves. Dedique unos momentos a familiarizarse con su generador antes de cada uso.
PN 7096-FG7008

© 2006 McCulloch • Printed in China



[You're reading an excerpt. Click here to read official MCCULLOCH FG7000MA user guide](http://yourpdfguides.com/dref/3950815)
<http://yourpdfguides.com/dref/3950815>

Manual abstract:

PLEASE READ For your own safety please read this manual before attempting to operate your new unit. Failure to follow instructions can result in serious personal injury. Spend a few moments to familiarize yourself with your generator before each use. Dear Customer, Thank you for purchasing a McCulloch product. With proper operation and maintenance, it will provide you with years of service. In order to make the best use of your investment, be CERTAIN to familiarize yourself with the contents of the ENTIRE user manual before attempting to operate and maintain your unit. Be sure to carefully follow the step-by-step illustrations in this manual to start, operate and maintain your new product. In the manual there will be the following call-outs: NOTE:, WARNING / CAUTION and WARRANTY. A NOTE: is used to convey additional information, to highlight a particular explanation, or to expand a step description. A WARNING or CAUTION identifies a procedure which, if not undertaken or if improperly done, can result in serious personal injury and/or damage to the unit.

The (WARRANTY SYMBOL) serves notice that unless instructions or procedures are followed, any damage caused will void the warranty and repairs will be at owner's expense. Pay particular attention to the safety precautions. @@@@ read them carefully. N If a label comes off or becomes hard to read, contact McCulloch. @@@@Record the engine and frame serial numbers for your future reference.

Refer to these serial numbers when ordering parts, and when making technical inquiry. McCulloch generators are designed to give safe and dependable service if operated according to instructions. Read and understand this user manual before operating your generator. You can help prevent accidents by being familiar with your generator's controls, and by observing safety operating procedures. Know how to stop the generator quickly in case of emergency.

2. @@ 3. @@@@Always keep children away from the generator. If the generator is stored outdoors, unprotected from the weather, check all electrical components on the control panel, before each use. Moisture or ice can cause a malfunction or short circuit in electrical components which could result in electrocution. 4. Do not connect to a building's electrical system unless an isolation switch has been installed by a qualified electrician. The exhaust system gets hot enough to ignite some materials. - Keep the generator at least 1 meter (3 feet) away from buildings and other equipment during operation. G L - Do not enclose the generator in any structure.

The muffler becomes very hot during operation and remains hot for a while after stopping the engine. Be careful H not to touch the muffler while it is hot. Let the engine cool before storing the generator indoors. Do not smoke or allow flames or sparks where the generator is refueled or where gasoline is stored.

Refuel in a well-ventilated area with the engine stopped. 4. Fuel vapors are extremely flammable and may ignite after the engine has started. Make sure that any spilled fuel has been wiped up before starting the generator. @@ 2. @@To keep exhaust gas from building up, provide adequate ventilation.

@@ 2. @@@@E N G A battery can explode if you do not follow the correct procedure, seriously injuring anyone nearby. Keep all sparks, open flames, and smoking materials away from the battery. Battery posts, terminals and related accessories contain lead and lead compounds. Wash hands after handling.

Insert the battery lead wires (A) through the holder (B). Use the screw and nut to fasten the lead wire. Use the screw and nut to fasten the lead wire. Put the flat washer and spring washer underneath the lock nut. 4-1F) When disconnecting the battery cable, always disconnect the positive (+) battery cable and then disconnect the negative (-) battery cable.

This procedure is the right way to avoid short circuit to the battery system. Please complete the assembly procedure of screw and attachments-refer drawing (Fig. 4-1,4-2,4-3) so that you can Lock the screw on to generator. Secure screws with flat washers and nuts (B). @@@@Secure the wheel onto the axle using the cotter pin (G). 5-2D) N Repeat steps 2 through 4 for the other wheel assembly. @@Do not fill to top: Leave some space for fuel expansion. Refuel in a well-ventilated area with the engine stopped. @@@@Be careful not to spill fuel when refueling. spilled fuel or fuel vapor may ignite.

@@Avoid repeated or prolonged contact with skin or breathing of vapor. @@@@ this is no cause for concern. @@Make sure to disconnect all electrical loads from panel receptacles. Move the choke lever out to the CLOSED position. 4. @@ 5. Insert the key, and turn clockwise to the "on" position. @@Be sure to return the lever to OFF after stopping the engine. (See Fig. @@Move the lever out toward CLOSED to enrich the mixture.

@@@@(the engine switch will remain in the ON position). @@Release the key when the unit has started. To stop the engine in an emergency, turn the electric start key to the OFF L position. Turn the electric start key to the OFF position. Ground Terminal The generator ground terminal is connected to the frame of the generator, the metal non-current carrying parts of the generator, and the ground terminals of each receptacle.

Connections to a Building's Electrical System Connections for standby power to a building's electrical system must be made by a qualified electrician. The connection must isolate the generator power from utility power, and must comply with all applicable laws and electrical codes. Improper connections to a building's electrical system can allow electrical current from the generator to backfeed into the utility lines. Such backfeed may electrocute utility company workers or others who contact the lines during a power outage. consult the utility company or a qualified electrician.

@@@Check local regulations for proper registration and use procedures. @@The system ground is not connected to the AC neutral wire.

@@@Provide them with the electrical wiring diagram in this manual. Circuit Breaker The circuit breaker (A) will automatically switch OFF if there is a short circuit or a significant overload of the generator at the receptacle. If the circuit breaker is switched OFF automatically, check that the appliance is working properly and does not exceed the rated load capacity of the circuit before switching the circuit breaker ON again. The ground terminal can be used to earth the generator or bond the frame of the generator to the frame of a vehicle, but only if it is required by local law or electrical code. Before using the ground terminal consult a qualified electrician or electrical inspector for regulations in your area. aC Applications Before connecting an appliance or power cord to the generator: · Make sure that it is in good working order. Faulty appliances or power cords can create a potential for electrical shock. If an appliance begins to operate abnormally, becomes sluggish or stops suddenly, turn it off immediately.



[You're reading an excerpt. Click here to read official MCCULLOCH FG7000MA user guide](http://yourpdfguides.com/dref/3950815)
<http://yourpdfguides.com/dref/3950815>

@@@ nOTICE: Substantial overloading will open the circuit breaker. Exceeding the time limit for maximum power operation or slightly overloading the generator may not switch the circuit breaker OFF, but will shorten the service life of the generator. limit operation requiring maximum power to 30 minutes. Maximum power is : See the following chart. for continuous operation , do not exceed the rated power. Rated power is : See the following chart. In either case, the total power requige. Contact with a hot engine or exhaust system can cause serious burns or fires. Let the engine cool before transporting or storing the generator. Take care not to drop or strike the generator when transporting.

Do not place heavy objects on the generator. Before storing the unit for an extended period: 1. Be sure the storage area is free of excessive humidity and dust.

Put a tablespoon of engine oil into the cylinder. Turn the engine slowly with the pull rope to distribute the oil.

/ After removal from storage, drain the stored gasoline into a suitable container, and fill with fresh gasoline before starring. @@@@Crank the engine several revolutions to distribute the oil, then reinstall the spark plug. 4. Slowly pull the starter grip until resistance is felt. At this point, the piston is coming up on it's compression stroke and both the intake and exhaust valves are closed.

Storing the engine in this position will help to protect is from internal corrosion. Unit starts, but engine has low power. When choosing a generator, it's important to check the product manual to determine the starting and running wattage requirements of the tools to be used, if you are running more than one unit at a time, add the start-up wattage together to establish your power needs. Choose a generator that meets or exceeds your wattage needs. Note that induction motors require up to three times the normal wattage for starting Check your product manual for wattage requirement to start. Actual running watts may vary. .



[You're reading an excerpt. Click here to read official MCCULLOCH](#)

[FG7000MA user guide](#)

<http://yourpdfguides.com/dref/3950815>