



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for MOTOROLA HK110. You'll find the answers to all your questions on the MOTOROLA HK110 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual MOTOROLA HK110
User guide MOTOROLA HK110
Operating instructions MOTOROLA HK110
Instructions for use MOTOROLA HK110
Instruction manual MOTOROLA HK110



[You're reading an excerpt. Click here to read official MOTOROLA HK110 user guide](http://yourpdfguides.com/dref/5923350)
<http://yourpdfguides.com/dref/5923350>

Manual abstract:

We've crammed all of the main features of your headset into this handy guide, and in a matter of minutes we'll show you just how easy your headset is to use. So go on, check it out. More information on the Web: www.motorola.com/support Caution: Before using your headset for the first time, please read the important Safety, Regulatory & Legal information at the back of this guide (page 11). Congratulations! Your headset has the important parts Call Button Status Light Microphone (on side) Earhook Mini USB Charging Connector Ear Speaker 2 Your headset Charge it let's get you up and running Indicator Light Red/Purple = charging Blue = fully charged While your headset is charging, you won't be able to use it. Note: Your battery is designed to last the life of your product. It should only be removed by a recycling facility. Any attempt to remove or replace your battery will damage your headset. Charge it 3 Basics a few essentials to get you started Turn it on & off Press and hold the Call button until you hear a series of tones.

Note: For the Spanish and Mandarin versions, instead of tones, you hear voice prompts. Call Button Wear it Flex the ear hook and loop it over your ear. Make sure the speaker aligns with your ear canal, and the microphone is pointing towards your mouth. Your headset comes ready for use on your right ear.

To change for left ear, just pull off the earhook, turn, and reinstall.

4 Basics Pair & connect connect and go Pair & connect with your phone 1 Turn off any Bluetooth devices previously paired with your headset. 2 Turn on the Bluetooth feature on your phone. The status light becomes steadily lit in blue. Note: When prompted for the passkey, enter 0000. Your headset and phone will connect automatically.

Test your connection 1 Place the headset on your ear. If your phone and headset are successfully connected, you hear ringing on the headset. Pair & connect 5 Restore to factory settings Caution: This action erases all pairing information stored in your headset. 1 Turn your headset off. 2 Press and hold the Call button and wait for a tone after hearing the start up tones (or voice prompt for the Spanish and Mandarin versions). 6 Pair & connect Calls it's good to talk Note: Some call features are phone/network dependent. to. Answer call reject call make a voice dial call end a call answer or reject second call adjust call volume Press the Call button. use phone to reject call. Press the Call button and you hear a tone.

Use volume buttons on phone to adjust volume. Calls 7 Status light know your headset if light shows. Off three blue flashes steady blue rapid blue/purple flashes quick blue flash slow blue pulse slow blue flash slow red flash steady red quick red flash your headset is. Off powering on/off in pairing/connect mode connected to your phone receiving or making a call connected (on a call) in standby (not on a call) connected to the phone) idle (not connected to a phone) trying to connect to your phone in a low battery state Note: After 20 minutes of inactivity, the status light stops flashing to conserve power, but the headset remains on. Note: After 20 minutes of idle time (no connection to a phone), the headset turns off. 8 Status light Problems? We've got solutions My headset will not enter pairing mode. Make sure that any devices previously paired with the headset are turned off. If the status light is flashing in blue, first turn off the other device, then turn the headset off and on. The status light becomes steadily lit in blue. My phone doesn't find my headset when searching.

Make sure the status light on your headset is steadily lit in blue when your phone is searching for devices. If not, press and hold the Call button until you hear tones (or a voice prompt for Spanish and Mandarin versions), then turn the headset off and on, and the status light turns steady blue (see Pair & connect on page 5). My headset will not pair with my phone. If the status light is not steadily lit in blue when your phone is searching for your headset, press and hold the Call button until you hear tones (or a voice prompt for Spanish and Mandarin versions), then turn the headset off and on, and the status light turns steady blue (see Pair & connect on page 5). My headset connected before, but now it's not working.

Make sure the status light on your headset is steadily lit in blue when your phone is searching for devices. Press and hold the Call button until you hear tones (or a voice prompt for Spanish and Mandarin versions), then turn the headset off and on, and the status light turns steady blue (see Pair & connect on page 5). problems? 9 Support We're here to help If you have questions or need assistance, contact us at 1 877 MOTOBLU, or visit us at www.motorola.com. Safety Information Use & Safety for Battery-Powered Accessories Do not store or use your battery-powered accessory (such as a Bluetooth headset or other device) in temperatures below -10°C (14°F) or above 60°C (140°F). Do not recharge your accessory in temperatures below 0°C (32°F) or above 45°C (113°F).

Conditions inside a parked car can exceed this range. Do not store your accessory in a parked car. Do not store your accessory in direct sunlight.

Storing your fully charged accessory in high-temperature conditions may permanently reduce the life of the internal battery. Battery life may temporarily shorten in low-temperature conditions. Approved Accessories Use of accessories not approved by Motorola, including but not limited to batteries, antennas, and convertible covers, may cause your mobile device to exceed RF energy exposure guidelines and may void your mobile device's warranty.

For a list of approved Motorola accessories, visit our Web site at: www.motorola.com Driving Precautions Responsible and safe driving is your primary responsibility when behind the wheel of a vehicle. Using a mobile device or accessory for a call or other application while driving may cause distraction.

Using a mobile device or accessory may be prohibited or restricted in certain areas, always obey the laws and regulations on the use of these products. While driving, NEVER: Type or read texts. Perform any other functions that divert your attention from driving. While driving, ALWAYS: Keep your eyes on the road. Use a handsfree device if available or required by law in your area. Enter destination information into a navigation device before driving. Use voice activated features (such as voice dial) and speaking features (such as audible directions), if available.



[You're reading an excerpt. Click here to read official MOTOROLA](http://yourpdfguides.com/dref/5923350)

[HK110 user guide](http://yourpdfguides.com/dref/5923350)

<http://yourpdfguides.com/dref/5923350>

• Obey all local laws and regulations for the use of mobile devices and accessories in the vehicle. • End your call or other task if you cannot concentrate on driving. Responsible driving practices can be found at www.motorola.com.

Caution About High Volume Usage Warning: Exposure to loud noise from any source for extended periods of time may affect your hearing. The louder the volume sound level, the less time is required before your hearing could be affected. To protect your hearing: • Limit the amount of time you use headsets or headphones at high volume. • Avoid turning up the volume to block out noisy surroundings. • For more information about hearing, see our Web site at www.motorola.com.

• These products are not toys and may be hazardous to small children. • Do not dispose of your battery or mobile device in a fire. • See www.motorola.com for more information. For indoor use only. • This device complies with part 15 of the FCC Rules.

• Connect the equipment to an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. Industry Canada Notice to Users Operation is subject to the following two conditions: (1) This device may not cause interference and (2) This device must accept any interference, including interference that may cause undesired operation of the device. This Class B digital apparatus complies with Canadian ICES-003. Industry Canada Notice Privacy & Data Security Motorola understands that privacy and data security are important to everyone. Because some features of your product may affect your privacy or data security, please follow these recommendations to enhance protection of your information: • Monitor access • Keep your product with you and do not leave it where others may have unmonitored access. Lock your product's keypad where this feature is available. • Keep software up to date • If Motorola or a software/application vendor releases a patch or software fix for your product that updates the device's security, install it as soon as possible. • Secure Personal Information • Your product can store personal information. Registering permits us to contact you for product or software updates and allows you to subscribe to updates on new products or special promotions.

Registration is not required for warranty coverage. Please retain your original dated sales receipt for your records. For warranty service of your Motorola Personal Communications Product you will need to provide a copy of your dated sales receipt to confirm warranty status. Thank you for choosing a Motorola product. Registration Motorola Limited Warranty for the United States and Canada Warranty What Does this Warranty Cover? Subject to the exclusions contained below, Motorola Mobility, Inc. warrants its mobile telephones (Products), Motorola-branded or certified accessories sold for use with these Products (Accessories), and Motorola software contained on CD-ROMs or other tangible media and sold for use with these Products (Software) to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola Products, Accessories, and Software purchased by consumers in the United States or Canada, which are accompanied by this written warranty: 18 Products and Accessories Products Covered Products and Accessories as defined above, unless otherwise provided for below. Ear buds and boom headsets that transmit mono sound through a wired connection. products and Accessories that are Repaired or Replaced. Length of Coverage One (1) year from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below.

Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product. Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product. The balance of the original warranty or for ninety (90) days from the date returned to the consumer, whichever is longer. exclusions (Products and Accessories) Normal Wear and Tear. Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

batteries. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola, are excluded from coverage. 19 Use of Non-Motorola Products and Accessories. Defects or damage that result from the use of non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.

Unauthorized Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola, or its authorized service centers, are excluded from coverage. altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola housings, or parts, are excluded from coverage. communication Services. Defects, damages, or the failure of Products, Accessories or Software due to any communication service or signal you may subscribe to or use with the Products Accessories or Software is excluded from coverage. software Products Covered Software. Applies only to physical defects in the media that embodies the copy of the software (e. Length of Coverage Ninety (90) days from the date of purchase. exclusions (Software) Software Embodied in Physical Media.

No warranty is made that the software will meet your requirements or will work in combination with any hardware or software applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected. software NOT Embodied in Physical Media. Software that is not embodied in physical media (e. g. Software that is downloaded from the Internet), is provided as is and without warranty. 20 Who is Covered? This warranty extends only to the first consumer purchaser, and is not transferable. what Will Motorola Do? Motorola, at its option, will at no charge repair, replace or refund the purchase price of any Products, Accessories or Software that does not conform to this warranty.



[You're reading an excerpt. Click here to read official MOTOROLA](http://yourpdfguides.com/dref/5923350)

[HK110 user guide](http://yourpdfguides.com/dref/5923350)

<http://yourpdfguides.com/dref/5923350>

We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software, and applications, please create a back up prior to requesting service.

How to Obtain Warranty Service or Other Information USA Canada TTY All Products, Accessories, and Software: 1-800-331-6456 All Products: 1-800-461-4575 1-888-390-6456 You will receive instructions on how to ship the Products, Accessories or Software, at your expense, to a Motorola Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number. What Other Limitations are There? Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. @Com Note: Do not ship your product to the above address. @@Contact your service provider for details.

@@@MOTOROLA and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. The Bluetooth trademarks are owned by their proprietor and used by Motorola Mobility, Inc. under license. All other product or service names are the property of their respective owners. Caution: Changes or modifications made in the radio phone, not expressly approved by Motorola, will void the user's authority to operate the equipment.

MOTOROLA and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. .



[You're reading an excerpt. Click here to read official MOTOROLA](#)

[HK110 user guide](#)

<http://yourpdfguides.com/dref/5923350>