



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for OKI MPS5500MB. You'll find the answers to all your questions on the OKI MPS5500MB in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual OKI MPS5500MB
User guide OKI MPS5500MB
Operating instructions OKI MPS5500MB
Instructions for use OKI MPS5500MB
Instruction manual OKI MPS5500MB

Quick Reference

MB780
MB790b
MB790f
MPS5500mb
MPS5500mbf



[You're reading an excerpt. Click here to read official OKI
MPS5500MB user guide](http://yourpdfguides.com/dref/4311654)
<http://yourpdfguides.com/dref/4311654>

Manual abstract:

.....
.....
.....
.....

.....
.....
.....

.....11 Scanning to an FTP address..

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

....11 Scanning to an FTP address using the keypad .

.....
.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

@@11 Scanning to an FTP address using the address book

.....
.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... 11 Scanning to a computer or flash drive.

.....
.....
.....
.....
.....
..... 12 Scanning to a computer.

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 12 Scanning to a flash drive...

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 12 Contents 3 4 Copying Making copies Making a quick copy 1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass. Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. @ @ 3 From the printer control panel, press . 4 If you placed the document on the scanner glass, then touch Finish the Job to return to the home screen. Copying using the ADF 1 Load an original document faceup, short edge first into the ADF. Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass. 2 Adjust the paper guides. 3 On the home screen, touch Copy, or use the keypad to enter the number of copies. The copy screen appears. 4 Change the copy settings as needed.

Touch Copy It. *Note: The Job Interrupt setting must be On for this feature to function.* 1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass. *Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF.* 2 To cancel the copy job, touch Cancel Job on the touch screen.

A "Canceling scan job" screen appears. A "Canceling scan job" screen appears. 3 Touch Delete Selected Jobs. The remaining print job is canceled. The home screen appears. 3 Under Default Settings, click E-mail/FTP Settings. 4 Click E-mail Settings. 5 Click Setup E-mail Server. 6 Fill in the fields with the appropriate information. 3 Click E-mail/FTP Settings.

4 Click E-mail Settings. 5 Fill in the fields with the appropriate information. 4 Click E-mail Shortcut Setup. 4 Type a unique name for the shortcut, and then touch Enter. appears. appears or while Scan the Next Page / Finish the Job appears. E-mailing 8 Faxing Sending a fax Sending a fax using the printer control panel 1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass. *Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF.* 3 On the home screen, touch Fax. 4 Enter the fax number or a shortcut using the touch screen or keypad.

To add recipients, touch Next Number, and then enter the recipient's telephone number or shortcut number, or search the address book. *Note: To place a dial pause within a fax number, press . The dial pause appears as a comma in the "Fax to" box. Use this feature if you need to dial an outside line first.* 5 Touch Fax It.

Sending a fax using the computer Faxing from a computer lets you send electronic documents without leaving your desk. 3 Choose the Other Options tab, and then click Fax. 4 Click OK, and then click OK again. 5 On the Fax screen, type the name and number of the fax recipient. A shortcut can be created to a single fax number or a group of fax numbers.

1 Type the printer IP address into the address field of your Web browser. *Note: If you do not know the IP address of the printer, then print a network setup page and locate the IP address in the TCP/IP section.* 2 Click Settings. 3 Click Manage Shortcuts. *Note: A password may be required. If you do not have an ID and password, get one from your system.* Place these items on the scanner glass. b If you are loading a document into the ADF, then adjust the paper guides. If you touched Profiles on the home screen, then locate your shortcut on the list. 9 Return to the computer to view the file. The output file is saved in the location you specified or launched in the program you specified.

Scanning to a flash drive 1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass. *Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF.* 6 Touch Scan It. Scanning to a computer or flash drive 13 .



[You're reading an excerpt. Click here to read official OKI
MPS5500MB user guide
http://yourpdfguides.com/dref/4311654](http://yourpdfguides.com/dref/4311654)