

Manual abstract:

mark the mounting points on the wall. Drill holes in the wall at the points you have marked. Leave about 5 to 7 mm between the wall and the underside of the screw heads. • Hook the telephone on the wall, aligning the mounting slots with the screws in the wall, then push down firmly. •••••The other party can no longer hear you. •• • To switch off Mute mode : press button hear you again. B) Exclusions from Guarantee SAGEM shall have no liability under the guarantee in respect of: • Damage, defects, breakdown or malfunction due to one or more of the following: - Failure to properly follow the installation process and instructions for use - An external cause to the equipment (including but not limited to: lightning, fire, shock, vandalism, inappropriate conditions of electrical network or water damage of any nature) - Modifications made without the written approval of SAGEM • Unsuitable operating conditions, particularly of temperature and humidity - Repair or maintenance of the equipment by persons not authorised by SAGEM • Wear and tear from normal daily use of the equipment and its accessories • damage due to insufficient or bad packaging of equipment when returned to SAGEM • Usage of new versions of software without the previous approval of SAGEM • Work on any equipment or software modified or added without the prior written consent of SAGEM • Malfunctions not resulting from the Equipment or from software installed in user workstations for the purpose of use of the equipment. Communication problems related to an unsuitable environment including: - Problems related to access and/or connection to the Internet such as interruptions by access networks or malfunction of the line used by the subscriber or his correspondent - Transmission faults (for example poor geographical coverage by radio and TV transmitters, interference or poor line quality) - Local network faults (wiring, servers, workstations) or the failure of the transmission network (such as but not limited to interferences, fault or poor quality of the network) - Modification of the parameters of the cellular or broadcast network carried out after the sale of the Product • Normal servicing (as defined in the user guide supplied with the equipment) as well as malfunctioning due to servicing not being carried out. Servicing costs are in any event always borne by the customer. • Malfunctions resulting from the usage of products, consumables or accessories not compatible with the equipment.

C) Out of Guarantee Repairs In the cases set forth in B) as well as after expiry of the guarantee period, the customer must ask the Authorised Sagem Repair Centre for a cost estimation prior to work being carried out. in such cases , the repair and delivery costs will be invoiced to the customer. The foregoing shall apply unless otherwise agreed in writing with the customer and only for the United Kingdom and Ireland. Dear customer, congratulations on buying your SAGEM telephone and thank you for placing your confidence in us. This product has been manufactured with the utmost care.

If you should have difficulties in operating it, we recommend that you consult this user guide. You can also find information on the following site : <http://www.sagem-communications.com/support> To operate the device safely and easily, please read the following sections carefully. Opening the box Place the box in front of you, open the packaging and make sure that the following items are present: • Second call (depending on your telephone company) During a call you can receive a second incoming call or call a second party.

You can then switch from one party to the other. If you have subscribed to your operator's "Caller ID" service, your telephone gives you access to the list of incoming calls. Your correspondent can Do not install your telephone in a damp environment, such as a bathroom, washroom, kitchen etc, and not within 1.50 metres of a source of water or outside. •••••It will take up little space on your desk or can be fixed to a wall. •••••Press button R + 2 to accept this new call. •••••Proof of purchase will be required in either case. •••••In the case that no proof of purchase is enclosed, the SAGEM repair centre will use the production date as its reference for establishing the guarantee status of the product. Apart from all legal obligatory rules, Sagem Communications, do not give any Guarantee, either implicit or explicit which is not set force in the present section, and can not be held responsible for any direct or indirect, material or immaterial damage, either in or out of the frame of the present guarantee. If any provision of this guarantee shall be held to be in whole or in part invalid or illegal due to an obligatory rule applicable to consumers pursuant to their national legislation, such invalidity or illegality shall not impair or affect the remaining provisions or parts of this guarantee.

This guarantee does not affect the Customer statutory rights. Button R: Function button for accessing additional services (details from your telephone company) Button /P : last number redial / insert a pause. Calling a number from the incoming call list Switching from one call to the other The date and time are updated automatically when the first call is received, if you have subscribed to the "Caller ID" service. You can also adjust them manually: Press and hold button . The parameter to be adjusted (year, month, day, hour, minute) blinks. Press button or button to adjust the value as required, then press button confirm and move to the next parameter. Keep the telephone on its base. 2. Access the incoming call log, then select the number to call. It does not contain any user-replaceable parts.

the CE label confirms that the product complies with the 1999/5/EC regulations of the European Union Parliament regarding wireless systems and telecommunications for user protection and for preventing electromagnetic interference. The declaration of compliance may be looked up on the www.sagem-communications.com website, or can be obtained from the following address : Sagem Communications SAS - Customer relations department 4 rue du Petit Albi 95800 - Cergy Saint-Christophe - France Installing your telephone on a wall To mount your telephone on a wall, you will need three screws and three plugs. 2 : the current call is placed on hold and you resume the second If you have subscribed to the "Caller ID" service of your operator, the number of the caller is displayed on the screen.

Pick up the handset from its base: you can talk to your caller. At the end of the call, hang up the handset on its base. The telephone is ready to receive a call • If you are not in the same area as your caller, the screen displays "-----". ••Ending one call and continuing the other 1 to accept this new call.



[You're reading an excerpt. Click here to read official SAGEM C95 user guide](http://yourpdfguides.com/dref/3986663)
<http://yourpdfguides.com/dref/3986663>

Indicator lamp: flashes when a call is received.

@@@@@@@Making a second call Calling a number from the outgoing call list Keep the telephone on its base. 2. Access the outgoing call log, then select the number to call. Making a call With the handset on its base, press and hold button R until the flashing time is displayed (300 ms by default). Pick up the handset from its base: you should hear the dial tone. Dial the number of your correspondent using the numerical keypad. At the end of the call, hang up the handset on its base. .



[You're reading an excerpt. Click here to read official SAGEM C95 user guide](http://yourpdfguides.com/dref/3986663)
<http://yourpdfguides.com/dref/3986663>