



**Manual abstract:**

@@@ When a contact is selected, an icon is displayed in the title bar. Then press the Left soft key, various options are proposed: Call, Send message, Edit, Delete, Add contact etc. You can search for a contact quickly by typing the first letter. -----

Messages From Messages menu select the Write message menu and validate. The number of characters in an SMS is limited to 160 characters (or even less in the case of exotic languages). When typing a text, a counter showing the number of characters deducted is displayed at the top of the screen. When the text has been entered, press the Left soft key: - select Send, to send the message by entering the receiver's number or selecting it in the contacts. - select Save to drafts, if you do not want to send message immediately or if you want to send it several times; it is saved in the Drafts. - select Send and save, to send the message by entering the correspondent's number while saving a copy in the Sentbox. Switching on Using the contacts Compose & send message 1 Slide the SIM card, with cut corner as shown on the phone, into the card holder with fold face down.

ENGLISH VERSO Settings From the Date / Time menu, select: Set date / time: set the time by entering it directly in digital format or by using the Up/Down keys, then use the Right key or Left key to access the next (or previous) input field. Once the time is correct, accept it. Date: same procedure as for setting the time. Date format: it allows to choose which date format shall be used. Use the Up/Down keys to select date format and validate.

Date separator: it allows choosing which mark to use for dividing date display (19/01/07). Use the Up/Down keys to select and validate. Time format: it allows choosing which time format to use. Use the Up/Down keys to select 12 hours or 24 hours and validate. Display: select the desired display type, either None or Analog or Digital.

Date and Time Shortcuts ----- The Left/Right/Up/Down keys can be customized as shortcut of the following features: None, Main menu, Inbox, Contacts, Calls, Alarm. This menu allows you to customize the settings of your phone to make it as convenient as possible. In the menu Settings/Shortcuts, select the key that you wish to customize and validate. Choose then the function that you want to access through this key and validate. On the Settings menu, please select the Automatic keypad lock menu and validate. If the automatic keypad lock is activated, the keypad will be locked after 30 seconds of inactivity. When the keypad is locked, emergency calls are still possible. In order to unlock your keypad, press the key then the OK key. ----- Lock/unlock keypad

----- This menu allows you to customize the ringtones, to adjust the volume and set the vibrating mode. From the Sounds menu, choose Call/SMS/Alarm menu and validate.

Use the Up/Down keys to select the ringtones from the proposed list and validate. From the Sounds menu, choose Volume menu and validate. Adjust the volume of the ringtones using the Left and Right keys of the navigator. Note that the keypad beeps can be deactivated by reducing their volumes to zero.

During a call, you can also use the navigator keys to adjust the call volume. If you choose enable, you can press any key to answer the incoming call except the Red key and the Right soft key. On the Call menu, please select the Any key answer menu and validate. You can set the function to enable or disable.

Sounds Any key answer ----- Call waiting

----- While you are already in a call, the Call waiting function informs you thanks to a special tone that someone else is trying to call you. Simultaneously, the name and/or phone number of the person who is trying to call you is displayed on the screen. Note that the availability of this service depends on your operator. In the menu Call/Call waiting, you can activate, deactivate, or consult the status of the call waiting service. Call forward The Call forward function allows you to divert the incoming calls to your voicemail or to another phone number. Note that the availability of this service depends on your operator. In the menu Call/Call forward, choose the type of forwarding from the available options.

The information in this manual is subject to change without notice. Every effort has been made in the preparation of this manual to ensure accuracy of the contents, but all statements, information, and recommendations in this manual do not constitute a warranty of any kind, expressed or implied. Please read the safety precautions carefully to ensure the correct and safe use of your mobile phone. For detailed information, refer to the section "Care and safety information". User Manual my150X Notice www.

sagem.com/mobiles Le Ponant de Paris - 27, rue Leblanc - 75512 PARIS CEDEX 15 - FRANCE Société Anonyme Capital 300 272 000 - 480 108 158 RCS PARIS 2 Place the battery by first inserting the upper section into the opening. Key decription 3 Replace the back cover, making it slide. Red key: In idle screen: Long press : Switch on/off In call context: Reject a call - hang up In menus: Return to idle screen Green key : In idle screen: Short press: Fast access to the list of calls In call context: Call - receiving a call Right soft key: In idle screen: Access to certain functions (shortcuts) IIn other screens: Chooses the function shown directly above the soft key, usually Back, Delete or Cancel Left soft key: In idle screen: Access to main menu In other screens: Chooses the function shown directly above the soft key, usually Select, OK or Save In idle screen: short press the Up/Down/Left/Right key to access a certain menu directly (as defined in the menu Settings/Shortcuts) Up key: Previous choice/increase value/up Down key: Next choice/decrease value/down Left key: Previous input field/move left Right key: Next input field/move right During a call: Increase/Reduce volume In the remaining, we will refer to this key as OK key In idle screen: Access to main menu In menus: Context-sensitive access to different functions During a call: Access to in-call menu Long press: lock the keypad Short press: + OK key to unlock the keypad When composing a message: Short press: switch from one input mode to another (Eng, upper case/lower case, 123 mode) In idle screen: Long press: activate/deactivate the silent mode When composing a message: Short press: display the symbol table 0 to 9 Alphanumeric keys Press corresponding keys to input numbers when dialing or numbers and characters when editing Long press[0]: to input "+" for international access Long press[1]: to call voicemail Short press[2-9] then Green key: to call the contact specified in the menu Contacts/Contacts menu/Speed dial 2 - Network provider 3 - Date and time 4 - The following information may also be displayed: « 1 New message» or « 1 missed call » (incoming call failed).



[You're reading an excerpt. Click here to read official SAGEM](http://yourpdfguides.com/dref/1202758)

[MY150X user guide](http://yourpdfguides.com/dref/1202758)

<http://yourpdfguides.com/dref/1202758>

It can be deleted by pressing the Red key briefly. ----- WARNING When a wrong PIN number is entered three times consecutively, your SIM card will be locked. To activate it - Enter the PUK (Personal Unblocking Key) code provided by : your operator, and accept. - Enter your PIN number and accept. - Enter your PIN number again and accept. After 5 or 10 failed attempts (depending on the type of SIM card), the SIM card is definitely locked.

You must then contact your operator or your SMC to obtain a new card. Then the mobile searches a network to lock on and displays on the screen for you to use. ----- From the Contacts menu, select Add contact and press the Left soft key to enter the menu. - Select name and press the OK key, enter name of your correspondent and press the OK key again to confirm. - Select number and press the OK key, enter phone number and press the Left soft key or the OK key to confirm. - Press the Left soft key to store it. Note that the contact is stored in the SIM card memory only. Storing a new contact Mobile Communication Business Group ----- Receiving messages Delete contact Fixed dial From the Contacts menu, select Delete all to delete all the SIM entries. ----- Two soft keys (left and right) perform the actions indicated by the icon above them (respectively on the bottom left and bottom right sides of the screen). Here is the list of possible actions of the left soft key: and the right soft key: Enter the main menu Options Ok/Yes/Select Save Search Reset(Call duration) Shortcut Delete Back/No/Cancel Disconnect Resume/Hold Soft keys ----- When you receive a message, a melody (defined in the menu Setting /Sounds/SMS) warns you and a message icon is displayed on the screen.

You can press the Left soft key to read the new message directly. If you do not read the messages, this icon remains displayed on the screen. When it flashes, the memory is full. Received messages are stored in the SIM card or in the phone until you choose to delete them. Making a call Dial the number of your correspondent and press the Green key. During the call, the tones may indicate the establishment of the call.

Once communication has been established, you can adjust the sound level (volume) using the Up/Down keys. At the end of the conversation press the Red key to hang up. International call Long press 0 to display "+", then dial the country code without waiting for the dial tone, then the number of the called party.

Emergency services To obtain the international emergency service, dial 112 then press the Green key. Depending on the operators you can obtain the emergency service with or without SIM card or when the keypad is locked.

It is enough to be in an area served by a network. ----- This menu allows you to restrict the outgoing calls. The availability of this menu depends on your SIM. From the Contacts menu, select Fixed dial menu and validate. Enter PIN2 number and validate. When activating this function, only the numbers stored in the fixed dialling can be called. This phonebook is linked to the SIM card, and its size depends on the card's capacity. -----

----- This menu is used to activate reception of local information broadcast by the network. You can choose whether you want to receive this information or not (please contact your network provider for mor----- Calls This menu allows you to access the list of last numbers used. Enter Calls menu, you can access the call log divided into three lists that you can display with the navigator key: Received, Missed and Dialed calls.

Each call has information on type of call, date and time. Select a call from the list and validate, various options are proposed: Call, Send message, Delete, Save etc. You can also make a call to a number by pressing the Green key. Fast access to the list of calls from the idle screen: press the Green key. Alarm From the Alarm menu, select either Alarm 1, or Alarm 2, or Alarm 3 and validate. To activate or deactivate the alarm, select On or Off and validate. If On is selected, you can set the waking time by entering the numbers directly or using the Up/Down keys and validate. The alarm icon appears on the home page.

The alarm works even when the phone is switched off. Press the Red key for five (5) seconds.

The end message is displayed. The phone switches off. Switching off Call barring The Call barring function allows you to block the incoming and/or outgoing calls, either permanently or when you are abroad and if a roaming service is available. Note that the availability of this service depends on your operator and requires a specific password provided by your operator. ----- Care and safety information

**THIS MODEL MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES** Your mobile device is a radio transmitter and receiver.

It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health. The guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2 W/kg and the highest SAR value for this device when tested at the ear was 1.26 W/kg (\*).

As mobile devices offer a range of functions, they can be used in other positions, such as on the body as described in this user guide (\*\*).

@@@@@@@@@@@@@@@@@These digits do not appear on the screen for security reasons. After activate or deactivate the PIN, you must input the correct PIN. @@@@@@@@@@@@@@@@@@Do not use your phone in damp areas (bathroom, swimming pool...). Protect it from liquids and other moisture.

@@@@@@@@@@@@@@@@@Aircraft safety When travelling by plane, you will need to switch your phone off when so instructed by the cabin crew or the warning signs. Using a mobile phone may be dangerous to the operation of the aircraft and may disrupt the phone network.

Its use is illegal and you could be prosecuted or banned from using cellular networks in the future if you do not abide by these regulations. Explosive materials Please comply with warning signs at petrol station asking you to switch your phone off.



[You're reading an excerpt. Click here to read official SAGEM](http://yourpdfguides.com/dref/1202758)

[MY150X user guide](http://yourpdfguides.com/dref/1202758)

<http://yourpdfguides.com/dref/1202758>

You will need to comply with radio equipment usage restrictions in places such as chemical plants, fuel depots and at any location where blasting operations are under way. Safety Warranty You must always use your phone for the purpose for which it was designed, under normal operating conditions. Sagem Communication declines all responsibility for any use outside of the scope of its designed purpose and for any consequences of this use. The software program developed by SAGEM remains the exclusive property of Sagem Communication. It is therefore highly prohibited to modify, translate, de-compile or disassemble this software program or any part thereof. Usage precautions Your phone allows you to download ring tones, icons and animated screensavers. Some of these items may contain data that may cause malfunctions of your phone or data losses (virus for example). For this reason, Sagem Communication rejects all responsibility concerning (1) the reception of downloaded data or losses of the said data, (2) the impact on the operation of the phone and (3) damages resulting from receiving the said downloaded data or loss of said data.

In addition, Sagem Communication states that a failure caused by receiving downloaded data that do not comply with the specifications set by Sagem Communication is excluded from the warranty. Consequently, the diagnosis and repair of a phone infected by the said downloaded data will be at the expense of the customer. Any content that you download to your phone may be protected by copyright belonging to third parties and consequently you may not have the right to use this content or its use may be restricted. Consequently it is up to you to ensure that you have permission, such as under the terms of a license agreement, to use any content that you download. Furthermore, Sagem Communication does not guarantee the accuracy nor the quality of any content that you download.

You alone are responsible for the content that you download to your mobile phone and how you use it. Sagem Communication cannot be held responsible for this content nor for its use. Subject to essential legal provisions, Sagem Communication does not accept any warranty, explicit or implicit, other than the warranty provided expressly in this chapter, nor shall Sagem Communication accept responsibility for any immaterial and/or indirect damages (such as loss of orders, loss of profit or any other financial or commercial damage) under the warranty or not. 3. The acceptance of a phone under warranty demands that a purchase document that is legible and without modification, stating vendor's name and address, date and place of purchase, type of phone and IMEI, are attached to the warranty, and that the information on the phone identification label is legible and that this label or any other seal has not been tampered with.

The warranty applies in normal conditions of use. Prior to sending the phone for repair, it is the customer's responsibility to backup at his expense the customized data stored in the phone (phonebook, settings, wallpapers). A list of backup facilities can be provided by Sagem Communication on request. The responsibility of Sagem Communication cannot be invoked if damage occurs to customer files, programs or data. The information or operating elements and the contents of files will not be re-installed in any case in the event of loss. Sagem Communication may decide, at its option, to repair the phone with new or reconditioned parts, replace the phone with a new phone or, in any dispute, a phone in good working condition. During its work Sagem Communication reserves the facility to make, where necessary, any technical modifications to the phone where these modifications do not adversely affect its initial purpose. Faulty parts to be replaced during a repair under warranty will become the property of Sagem Communication. The phone repair and standstill time during the warranty period may not lead to an extension of the warranty period as stated in article 1 above, provided no other vital provisions have been agreed. The application of the warranty is subject to the full payment of the sums due for the phone when the request for support is made.

The opening or closing of a SIM operator key and call-outs resulting in the non-operation of the phone resulting from the opening or closing of SIM operator key done without the agreement of the original operator. 5. In the cases of warranty exclusion and of expiry of the warranty period, Sagem Communication shall draw up an estimate to be given to the customer for acceptance before any call-out. The repair and carriage costs (there and back) given in the accepted estimate will be charged to the customer. These provisions are valid unless a special written agreement has been made with the customer. If one of the provisions turns out to infringe a legally essential rule that consumers could have the benefit of under the national legislation, this provision will not be applied, but all other provisions will remain valid. Conformance Document Déclaration CE de Conformité Fabricant Manufacturer Adresse Address Nom du produit Product Name Sagem Communication Le Ponant de Paris 27 rue Leblanc F-75512 Paris cedex 15 FRANCE Dual Band GSM/DCS AX2007S1 (my150X) Dual Band GSM/DCS AX2007S1 (my150X) Declares under our sole responsibility that our product For individuals concerned about limiting their exposure to RF fields, the World Health Organization (WHO) provides the following advice: Precautionary measures: Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If individuals are concerned, they might choose to limit their own or their children's' RF exposure by limiting the length of calls, or using "hands-free" devices to keep mobile phones away from the head and body. Further information on this subject can be obtained from the WHO home page <http://www.who.int/peh-emf> WHO Fact sheet 193: June 2000. Advice for limiting exposure to radiofrequency (RF) fields est conforme aux exigences des directives européennes suivantes: conforms to the requirements of the following EEC directives: EEC Directive 1999/5/CE Sécurité (Safety) EN 60950 CEM (EMC) EN 301 489-1 EN 301 489-7 Réseau 3GPP TS 51.010-1 v 7.5.0 avec GCF-CC v 3.

25.0 inclus (Network) (3GPP TS 51.010-1 v 7.5.0 selected with GCF-CC v3. 25.0 included) EN 301 511 V9.0.2 Santé (Health) EN 50360, EN 50361 Place and date of issue Signature Packaging To facilitate the recycling of packaging materials, please obey the sorting rules instituted locally for this type of waste. Batteries Spent batteries must be deposited at the designated collection points. @@@@ Your doctor or the manufacturers of such equipment will be able to give you any advice you may need in this area. Hospitals Always make sure that your phone is switched off in hospitals when so instructed by warning signs or by medical staff.



[You're reading an excerpt. Click here to read official SAGEM MY150X user guide](http://yourpdfguides.com/dref/1202758)  
<http://yourpdfguides.com/dref/1202758>

*Road safety Do not use your phone when driving. In order to give your full attention to driving, stop and park safely before making a call. You must comply with any current legislation.*

*Distance of operation This phone model has been tested and meets radiofrequency exposure guidelines when used as follows: - against the ear: place or receive a phone call and hold the phone as you would a wireline telephone, - body worn: when transmitting, place the phone in a carry accessory that contains no metal and positions the phone a minimum of 1.5 cm from your body. Use of other accessories may not ensure compliance with radiofrequency exposure guidelines. If you do not use a body worn accessory and are not holding the phone at the ear, position the phone a minimum of 1.5 cm from your body, - data operation: when using a data feature, position the phone a minimum of 1.5 cm from your body for the whole duration of the data transmission. Accessories We advise you the use of SAGEM brand accessories for an optimal operating of your phone and of your accessories. It is your responsibility to ensure compliance, at your own expense, with the laws and regulations applicable in the country where you use your phone. Warranty conditions Whenever you wish to make use of the warranty, please contact your vendor and present him with the purchasing paperwork that he gave you. If a fault occurs, he will advise you.*

*1. The new phone (excluding consumables), including new accessories bundled with the phone, are guaranteed by Sagem Communication, parts and labour (apart from travel) against any manufacturing fault for a period of twelve (12) months with effect from the sale of the phone to the customer, on presentation of the paperwork stating the purchase date of the phone. Phones that have been repaired or replaced as standard during the warranty period stated above are guaranteed (parts and labour) until the later of these two dates: Expiry of the guarantee period of twelve (12) months stated above or three (3) months with effect from the date of support provided by Sagem Communication. Your legal rights under the terms of applicable national law as well as your rights in relation to your retailer, as set out in the sales contract, remain applicable and are not in any way affected by this guarantee. In any disputes, the phone is covered by the legal warranty against the consequences of faults or hidden defects in compliance with articles 1641 and subsequent of the French civil code. 2. All faulty phones under warranty will be replaced or repaired free of charge at Sagem Communication's option (with the exclusion of repair of any other damage), once it has been specified that the work required for the application of the warranty will be done in a workshop and that the return costs (transport and insurance) of the phone to the address to be indicated to it by the Sagem Communication after-sales service, whose phone number will appear on the delivery note, will be charged to the customer. 4. The following are excluded from the warranty: Breakdowns or malfunctions due to non-compliance with the installation and use instructions, to an external cause of the phone (shock, lightning, fire, vandalism, malice, water damage of any type, contact with various liquids or any harmful agent, unsuitable electric current..*

*), to modifications of the phone made without the written consent of Sagem Communication, to a servicing fault, as described in the documentation supplied with the phone, to lack of supervision or care, to poor environmental conditions of the phone (especially temperature and hygrometry, effects of variations in electric voltage, interference from the mains network or earth) or even due to a repair, a call-out (opening or trying to open the phone) or to servicing done by personnel not approved by Sagem Communication. Damage resulting from inadequate packaging and/or poor packing of the phone sent back to Sagem Communication. Normal wear and tear of the phone and accessories. Communication problems linked with a poor environment, especially: Problems accessing and/or logging onto the Internet, such as breakdowns of the access network, the failure of the subscriber's or his correspondent's line, transmission fault (poor geographic coverage by radio transmitters, interference, disturbance, failure or poor quality of phone lines...), a fault inherent to the local network (cabling, file server, user phone) and/or transmission network fault (interference, disturbance, failure or poor quality of the network...*

*) was sold. Supply of new software versions. Change of parameters of the cellular network made after the phone Current servicing work: delivery of consumables, installation or replacement of these consumables... Call-outs for phone or software modified or added without the written consent of Sagem Communication. Faults or disruptions resulting from the use of products or accessories not compatible with the phone. Phones returned to Sagem Communication without having complied with the return procedure specific to the phone covered by this warranty. Customer care Austria Belgium Denmark France Germany Greece Hungary Ireland Italy Netherlands Poland Portugal Romania Russia Slovakia South Africa Spain Sweden Switzerland United Kingdom 01 36 02 77 16 64 02 62 77 016 0 82 33 28 52 0 892 701 799 (0,34 /mn) 01805 843 850 0800 44 14 20 38 06 1 7774 839 0 160 58 355 800 800 485 020 65 45 724 0801 801 101 21 316 41 35 0800 89 45 21 495 258 54 33 (421) 02 68 629 355 011 369 7870 91 375 3376 08 519 923 21 02 25 67 53 99 0870 24 05 613 Customer Care e-mail address: support.*

*mobiles@sagem.com Web sites: www.sagem.com/mobiles www.planetsagem.com www.sagem-online.com .*



[You're reading an excerpt. Click here to read official SAGEM MY150X user guide](http://yourpdfguides.com/dref/1202758)  
<http://yourpdfguides.com/dref/1202758>