



Your PDF Guides


You can read the recommendations in the user guide, the technical guide or the installation guide for SENNHEISER RS 4200. You'll find the answers to all your questions on the SENNHEISER RS 4200 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual SENNHEISER RS 4200
User guide SENNHEISER RS 4200
Operating instructions SENNHEISER RS 4200
Instructions for use SENNHEISER RS 4200
Instruction manual SENNHEISER RS 4200

 **SENNHEISER**

RS 4200

Instructions for use



[You're reading an excerpt. Click here to read official SENNHEISER RS 4200 user guide](http://yourpdfguides.com/dref/3870021)
<http://yourpdfguides.com/dref/3870021>

Manual abstract:

.....
.....
.....
.....

.....
.....
.....
.....

.....
.... 2 The RS 4200 stethoset receiver system .

.....
.....

.....
.....
.....

..... 3 Delivery includes

.....
.....
.....
.....

.....
.....
.....
.....

.....
.... 4 RS 4200-2 product variant .

.....
.....

.....
.....
.....
.....

.....
.....
.....

. 4 Operating controls

.....
.....
.....
.....

.....
.....
.....
.....

..... 5 Receiver (see inside cover) ...

.....
.....
.....

.....
.....
.....
.....

.....
.... 5 Transmitter (see inside cover) .

.....
.....

.....
.....
.....

.....
.....

5 LED indications (see inside cover)

.....
.....
.....
.....

.....
5 Connection possibilities (see inside cover)

.....
.....
.....

.....
.... 5 Putting the system into operation .

.....
.....
.....
.....

..... @@@@9 Inserting a spare rechargeable battery into the transmitter's charging compartment .

.....
.....
.....

.....
.....
.....

..... 9 Using the system components ..

.....
.....
.....
.....

.....
.....
.....

.. 10 Switching the transmitter on

.....
.....
.....
.....

.....
.....
.....

... 10 Switching the stehoset receiver on

.....
.....

.....
.....

.....
.... 10 Adjusting the volume .

.....
.....

.....
.....

.....
.....

.....
.....

.....
.....

..... 11 Automatic transmitter search tuning ..

.....
.....

.....
.....

.....
.....

.... 11 Changing the transmission and receiver channel .

.....
.....

.....
.....

11 Adjusting the balance

.....
.....

.....
.....

.....
.....

.....
.....

.....
.....

.... 12 Enhancing speech intelligibility

.....
.....

.....
.....

.....
.....

.....
.....

. 12 Storing and charging the receiver

.....
.....

.....
.....

.....
.....

.... 12 Meaning of the LEDs and acoustic signals .

.....
.....

.....
.....

.....
.....

13 LEDs on the transmitter

.....
.....
.....
.....
.....
.....
.....
.....

13 Acoustic signals of the receiver

.....
.....
.....
.....
.....
.....

..... 13 Care and maintenance ...

.....
.....
.....
.....
.....
.....
.....
.....

..... 14 Cleaning the system

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.. 14 Cleaning the ear cushions

.....
.....
.....
.....
.....
.....
.....

..... 14 If problems occur.

.....
.....
.....
.....
.....
.....
.....
.....

.....
15 Accessories

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

. 16 Connector assignment

.....

.....

.....

.....

.....

.....

.....

.....

... 16 Specifications ..

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

17 Manufacturer Declarations

.....

.....

.....

.....

.....

.....

.....

18 Thank you for choosing Sennheiser! We have designed this product to give you reliable operation over many years. Over 60 years of accumulated expertise in the design and manufacture of high-quality electro-acoustic equipment have made Sennheiser a world-leading company in this field. Please take a few moments to read these instructions carefully, as we want you to enjoy your new Sennheiser products quickly and to the fullest. 1 Safety instructions Please read these instructions carefully and completely before using the system. Make these instructions easily accessible to all users at all times. Always include these instructions when passing the system on to third parties. Do not wear the headphones in situations which require special attention (e.g. when performing skilled jobs). Always keep the system dry and do not expose it to extreme temperatures (ideally 10-35°C). Use the system with care and set it up in a clean, dust-free environment. Varnish or furniture polish may degrade the feet of the transmitter, which could stain your furniture. You should therefore place the transmitter on a non-slip pad to avoid potential staining of furniture. This system allows you to set higher volumes than conventional stethoset systems. This can cause hearing damage in persons with healthy hearing and especially in children. Please observe the safety instructions for Lithium-Ion rechargeable batteries on the enclosed leaflet. Intended use of the system Intended use includes that: you have read these instructions, especially the chapter "Safety instructions". you are using the system within the operating conditions as described in these instructions. Improper use Improper use means use of the system other than as described in these instructions or under operating conditions which differ from those described in these instructions. 2 The RS 4200 stethoset receiver system The RS 4200 is a wireless radio frequency stethoset receiver system with which you can adjust the volume of your TV, radio, personal stereo and other hi-fi equipment to suit your individual needs.

@@The RS 4200 is particularly easy and intuitive to operate. @@The volume can be adjusted directly on the receiver. @@@@(@@@@TV). @@as this can decrease the transmitter's range. @@@@@@@This improves the quality of wireless sound transmission. If necessary, check the menu setting of

your TV. @@Depending on the socket, you may have to use the adapter . @@@@Connect the connecting cable to the SCART adapter . Plug in the SCART adapter to the SCART socket on your TV. @@Connect the microphone to the blue socket AUDIO transmitter.

@@@Plug the mains connector into a wall socket. Align the antenna ¾ vertically. @@when you are on holiday). @@on the 8 Inserting and removing the receiver's rechargeable battery Insert the battery into the compartment as shown on the left. Make sure that the battery is inserted correctly.

To remove the battery, use the finger catch projection to pull the battery out of the receiver. Note: The receiver is delivered with the battery inserted. Before you use the rechargeable battery for the first time, charge it until the LED lights up green (see "Storing and charging the receiver" on page 12). This can take a maximum of 3 hours. Inserting a spare rechargeable battery into the transmitter's charging compartment You can charge a spare battery (not included) in the charging compartment , at the side of the transmitter.

This spare battery is not required for operating the RS 4200 but offers extended listening time while the discharged first battery is being recharged. Insert the spare battery into the charging compartment , as shown on the left. If the battery is inserted correctly, the LED ¹ lights up red: The rechargeable battery is being charged. green: The rechargeable battery is fully charged. ¹, 9 Using the system components Switching the transmitter on The transmitter automatically switches on when a sufficient audio signal is present at the headphone socket of your sound source. Switch your sound source on. This automatically switches on the transmitter and the LED lights up green. If the transmitter does not switch on, increase the volume of your sound source. Note: If there is no sufficient audio signal for at least 3 minutes, the transmitter automatically switches off. Switching the stehoset receiver on Attention! Volume up? - No! When peoged Rechargeable battery is fully charged Speech enhancement is activated lit green lit yellow Acoustic signals of the receiver Acoustic signal 6 short beeps Meaning No audio signal (transmitter is not activated or out of range) Rechargeable battery is flat Commentary Automatic switch-off after approx.

3 minutes 2 long beeps Automatic switch-off after approx. 10 minutes These beeps can be switched off by pressing the TUNE button for 5 seconds while the receiver is switched on. 1, 2 or 3 beeps after Receiver is tuned to having pressed the channel 1, 2 or 3 TUNE button 13 Care and maintenance Cleaning the system Attention! Liquids can damage the electronics of the units! Liquids entering the housing of the units can cause a short-circuit and damage the electronics. Keep all liquids far away from the units. Before cleaning, disconnect the transmitter from the mains. Only use a slightly damp cloth to clean the units. Do not use any cleansing agents or solvents. Cleaning the ear cushions Carefully remove the ear cushions Clean the ear cushions thoroughly. Dry the ear cushions receiver. Note: For reasons of hygiene, the ear cushions should be replaced from time to time.

Please order the ear cushions from your Sennheiser dealer. from the receiver. with warm soapy water and rinse before putting them back on the 14 If problems occur...

Check if the problem you face is listed in the table below: Problem You cannot hear anything Possible cause Are all jack plugs connected correctly? Is the transmitter connected to the sound source? Is the transmitter connected to the mains? Is the volume of the sound source sufficient? Is the green operation indication lit? Is the volume of the receiver sufficient? Is the rechargeable battery fully charged and inserted properly into the receiver? The sound is subject to interference The speech intelligibility is reduced Is the receiver still within the transmitter's range? Is interference being received from an external source in close proximity? Is the "Speech intelligibility" button backlit in yellow? Is the volume of the headphone socket on the sound source sufficient? Is the balance adjusted correctly? Page 6 ff 6 ff 8 6 8 11 9 6 11 12 10 You hear the sound only with one ear 12 If problems occur that are not listed in the above table or if the problems cannot be solved with the proposed solutions, please contact your local Sennheiser agent for assistance.



[You're reading an excerpt. Click here to read official SENNHEISER](http://yourpdfguides.com/dref/3870021)

[RS 4200 user guide](http://yourpdfguides.com/dref/3870021)

<http://yourpdfguides.com/dref/3870021>

15 Accessories Attention! Components from other manufacturers (e.g. for power supply or rechargeable battery) may cause damage to the unit and will invalidate the warranty. Only use original Sennheiser accessories and spare parts.

The following accessories are available from your authorized Sennheiser dealer: BA 300 spare rechargeable battery Cat. No. 500898 RR 4200 receiver Cat. No. 500685 Ear cushions (normal), 5 pairs Cat. No. 517625 Ear cushions (lamellar form), 5 pairs Cat. No. 517626 SCART adapter Cat. No.

077798 MKE 800 TV-N Cat. No. 500974 external microphone (mono) Connector assignment The blue socket AUDIO is designed for use with two different connector types (Line/Mic). The connector type used is identified automatically. 3.5 mm 3-pole jack/standard stereo L R GND 3.5 mm 4-pole jack/microphone with additional power supply L R 8V GND 1k 16 Specifications System Modulation Carrier frequencies Range AF frequency response THD FM stereo 863.3 / 864.0 / 864.7 MHz up to 100 m in the open 50 Hz 16 kHz <1% Transmitter Audio /microphone connection Charging time of rechargeable battery Power supply Weight Dimensions 3.

5 mm stereo jack socket approx. 3 hrs 9 VDC/300 mA via NT 4200 mains unit approx. 150 g approx. 115 x 145 x 95 mm Receiver Max. SPL Power supply Operating time Weight Dimensions 125 dB (SPL) via BA 300 rechargeable battery (3.

7 V / 150 mAh) approx. 9 hrs approx. 50 g approx. 200 x 135 x 20 mm 17 Manufacturer Declarations Warranty regulations The guarantee period for this Sennheiser product is 24 months from the date of purchase. Excluded are accessory items, rechargeable or disposable batteries that are delivered with the product; due to their characteristics these products have a shorter service life that is principally dependent on the individual frequency of use.

The guarantee period starts from the date of original purchase. For this reason, we recommend that the sales receipt be retained as proof of purchase.

Without this proof (which is checked by the responsible Sennheiser service partner) you will not be reimbursed for any repairs that are carried out.

Depending on our choice, guarantee service comprises, free of charge, the removal of material and manufacturing defects through repair or replacement of either individual parts or the entire device. Inappropriate usage (e.g. operating faults, mechanical damages, incorrect operating voltage), wear and tear, force majeure and defects which were known at the time of purchase are excluded from guarantee claims. The guarantee is void if the product is manipulated by non-authorized persons or repair stations. In the case of a claim under the terms of this guarantee, send the device, including accessories and sales receipt, to the responsible service partner. To minimise the risk of transport damage, we recommend that the original packaging is used.

Your legal rights against the seller, resulting from the contract of sale, are not affected by this guarantee. The guarantee can be claimed in all countries outside the U.S. @@@@In order to protect the environment, only dispose of exhausted batteries. WEEE Declaration Your Sennheiser product was developed and manufactured with high-quality materials and components which can be recycled and/or reused. This symbol indicates that electrical and electronic equipment must be disposed of separately from normal waste at the end of its operational lifetime. Please dispose of this product by bringing it to your local collection point or recycling centre for such equipment. This will help to protect the environment in which we all live. 18 Sennheiser electronic

GmbH & Co. KG 30900 Wedemark, Germany Phone +49 (5130) 600 0 Fax +49 (5130) 600 300 www.

sennheiser.com Printed in China Publ. 10/06 517634 / A02 .



[You're reading an excerpt. Click here to read official SENNHEISER RS 4200 user guide](http://yourpdfguides.com/dref/3870021)

<http://yourpdfguides.com/dref/3870021>