



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for SMEG FQ60XP. You'll find the answers to all your questions on the SMEG FQ60XP in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual SMEG FQ60XP**  
**User guide SMEG FQ60XP**  
**Operating instructions SMEG FQ60XP**  
**Instructions for use SMEG FQ60XP**  
**Instruction manual SMEG FQ60XP**



**FQ60XP**

<b>en</b>	<b>Instruction Manual</b>
<b>it</b>	<b>Manuale di istruzioni</b>



[You're reading an excerpt. Click here to read official SMEG FQ60XP user guide](http://yourpdfguides.com/dref/3973793)  
<http://yourpdfguides.com/dref/3973793>

**Manual abstract:**

· Follow the instructions, especially those for safety. · Keep the manual in an easily accessible place as you may need it later. · Besides, read also the other documents provided with your product. Please note that this manual may be valid for other models as well. Symbols and their descriptions This instruction manual contains the following symbols: C Important information or useful usage tips. A Warning against dangerous conditions for life and property.

@ @ @ @ @ @ @ @ 12 Egg tray ....

.....  
.....

.....

.....

.....

.... 14 Sliding Body Shelves .

.....

.....

.. 14 Crisper ...

.....

.....

.....

.....

..... 14 Chiller compartment .....

.....

.....

.... 14 Rotating Middle Section .

.....

..... 15 Multi Zone Storage Compartment .. 15 Blue light .

.....

.....

.....

.....

.....

.....

15 Intended use .....

.....

.....

.....

..... 4 General safety ...

.....

.....

.....

.....

.. 4 Child safety.....

.....

.....

.....

.....

.. 6 HCA Warning ...

.....

.....

.....

.....

... 6 Things to be done for energy saving ..

7 3 Installation 8 Preparation .....

.....

.....

.....  
.....  
8 Points to be considered when retransporting your refrigerator .....

... 8 Before operating your refrigerator ..

.... 9 Electric connection .

.....

.....

.....

.. 9 Disposing of the packaging ...

.....

.. 9 Disposing of your old refrigerator ..... 9 Placing and Installation .

.....

.....

..... 10 Floor balance adjustment .

.....

.....

10 Adjusting the gap between the upper door .....

.....

.....

.....

.....

.....

... 11 5 Maintenance and cleaning 16 Protection of plastic surfaces .....

... 16 6 Recommended solutions for the problems 17 2 EN 1 Your refrigerator A 12 13 3 2 1 4 5 6 7 8 9 10 11 14 15 16 ABC- Fridge compartment Freezer compartment Multi Zone B C 1- Fridge compartment door shelves 2- Fridge compartment adjustable cabinet shelves 3- Diffuser cover 4- Illumination lens 5- Rotating middle section 6- Chiller compartment 7- Crisper 8910111213141516- Bottle shelf Icematic Icebox Frozen food storage compartments Butter & Cheese shelf cover Butter & Cheese shelf Bottle holder Multi Zone compartment shelves Multi Zone compartment C Figures that take place in this instruction manual are schematic and may not correspond exactly with your product. © 2013 EN 2 Important Safety Warnings Please review the following information. If these are not followed, personal injury or material damage may occur. Otherwise, all warranty and reliability commitments will become invalid. The usage life of the unit you purchased is 10 years. This is the period for keeping the spare parts required for the unit to operate as described. (This may cause frostbite in your mouth.

) Do not put bottled and canned liquid beverages in the freezer compartment. Otherwise, these may burst. Do not touch frozen food by hand; they may stick to your hand. Vapor and vaporized cleaning materials should never be used in cleaning and defrosting processes of your refrigerator. In such cases, the vapor might get in contact with the electrical parts and cause short circuit or electric shock. Never use the parts on your refrigerator such as the door as a means of support or step. Do not use electrical devices inside the refrigerator. Do not damage the cooling circuit, where the refrigerant is circulating, with drilling or cutting tools. The refrigerant that might blow out when the gas channels of the evaporator, pipe extensions or surface coatings are punctured may cause skin irritations and eye injuries. Do not cover or block the ventilation holes on your refrigerator with any material.

Repairs of the electrical appliances must only be made by qualified persons. Repairs performed by incompetent persons may create a risk for the user. In case of any failure or during a maintenance or repair work, disconnect your refrigerator's mains supply by either turning off the relevant fuse or unplugging your appliance. · Intended use · This appliance is intended to be used in household and similar applications such as staff kitchen areas in shops, offices and other working environments; farm houses and by clients in hotels, motels and other residential type environments; bed and breakfast type environments; catering and similar non-retail applications. · It should not be used outdoors. It is not appropriate to use it outdoor even if the place is covered with a roof. · · ·

General safety · When you want to dispose/scrap the product, we recommend you to consult the authorized service in order to learn the required information and authorized bodies. · Consult your authorized service for all your questions and problems related to the refrigerator. Do not intervene or let someone intervene to the refrigerator without notifying the authorized services. · Do not eat cone ice cream and ice cubes immediately after you take them out of the freezer compartment! 4 · · · EN · Do not pull by the cable when pulling off the plug.

· Place the beverage with higher proofs tightly closed and vertically. · Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance. · Do not use mechanical devices or other means to accelerate the defrosting process, others than those recommended by the manufacturer. ·

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. · Do not operate a damaged refrigerator.

Consult your service if you have any doubts. · Electrical safety of your refrigerator shall be guaranteed only if the earth system in your house complies with standards. · Exposing the product to rain, snow, sun and wind is dangerous with respect to electrical safety. · Contact the authorized service when there is a power cable damage and etc. so that it will not create a danger for you.

· Never plug the refrigerator into the wall outlet during installation. Otherwise, risk of death or serious injury may arise. · This refrigerator is designed solely for storing food. It should not be used for any other purposes. · The label that describes the technical specification of the product is 5 · · · · located on the inner left part of the refrigerator. Do not hook up the refrigerator to electronic energy saving systems as it may damage the product. @@@@ In order to prevent fire the power cord should not be twisted. Heavy objects should not be placed on the power cord. @@@@ · Do not overload the refrigerator with excess food. @@@@ · If refrigerator will not be operated for an extended period of time it should be unplugged.

*A problem in electrical cable insulation may result in fire. · The tip of the electric plug should be cleaned regularly otherwise it may cause fire. · The refrigerator may move when the adjustable feet is not positioned firmly on the floor. Using the adjustable feet you can unsure that the refrigerator is positioned firmly on the floor. · If the refrigerator has door handle do not pull the refrigerator via door handles when moving the product as it may disconnect the handle from the refrigerator.*



[You're reading an excerpt. Click here to read official SMEG FQ60XP user guide](http://yourpdfguides.com/dref/3973793)

<http://yourpdfguides.com/dref/3973793>

· If you must operate your appliance adjacent to another refrigerator or freezer, the distance between the appliances must be at least 8 cm. Otherwise condensation may occur on the side walls facing each other. · Water mains pressure must not be below 1 bar. Water mains pressure must not be above 8 bars. · Use only drinkable potable water.

6 Child safety · If the door has a lock, the key should be kept away from reach of children. · Children should be supervised to ensure that they do not play with the appliance HCA Warning If your product is equipped with a cooling system that contains R600a: This gas is flammable. Therefore, pay attention to not damaging the cooling system and piping during usage and transportation. In the event of damage, keep your product away from potential fire sources that can cause the product catch a fire and ventilate the room in which the unit is placed. Ignore the warning if your product is equipped with a cooling system that contains R134a.

You can see the gas used in production of your product on the rating plate that is located on the left inner part of it. Never dispose the product in fire. EN Things to be done for energy saving · Do not leave the doors of your refrigerator open for a long time. · Do not put hot food or drinks in your refrigerator. · Do not overload your refrigerator so that the air circulation inside of it is not prevented.

· Do not install your refrigerator under direct sunlight or near heat emitting appliances such as ovens, dishwashers or radiators. · Pay attention to keep your food in closed containers. · Maximum amount of food can be put in your refrigerator's freezer compartment when the freezer compartment shelf or drawer is removed. Declared energy consumption value of your refrigerator was determined when the freezer compartment shelf or drawer was removed and under maximum amount of food load. There is no risk in using a shelf or drawer according to the shapes and sizes of the foods to be frozen. 7 EN 3 Installation B Please remember that the manufacturer shall not be held liable if the information given in the instruction manual is not observed. · Original packaging and foam materials should be kept for future transportations or moving. Preparation · Your refrigerator should be installed at least 30 cm away from heat sources such as hobs, ovens, central heater and stoves and at least 5 cm away from electrical ovens and should not be located under direct sunlight. &middothere are any locks on the door, make them inoperable in order to protect children against any danger. from the floor.

4. Place your refrigerator on an even floor surface to prevent jolts. 5. @@@@The corner where the leg exists is lowered when you turn ilti Zone Storage Compartment may be set to 0 and 10 degrees in addition to the fridge compartment temperatures and to -6 degrees in addition to the freezer compartment temperatures. @@B We recommend that you unplug the appliance before cleaning. @@@@In case of spilling or smearing oil on the plastic surfaces, clean and rinse the relevant part of the surface at once with warm water. 16 EN 6 Recommended solutions for the problems Please review this list before calling the service. It might save you time and money. This list includes frequent complaints that are not arising from defective workmanship or material usage. Some of the features described here may not exist in your product.

The refrigerator does not operate · Is the refrigerator properly plugged in? Insert the plug to the wall socket. · Is the fuse of the socket which your refrigerator is connected to or the main fuse blown out? Check the fuse. Condensation on the side wall of the fridge compartment. (MULTI ZONE, COOL CONTROL ve FLEXI ZONE) · Very cold ambient conditions. Frequent opening and closing of the door.

Highly humid ambient conditions. Storage of food containing liquid in open containers. Leaving the door ajar. · Switching the thermostat to a colder degree. · Decreasing the time the door left open or using it less frequently.

· Covering the food stored in open containers with a suitable material. · Wipe the condensation using a dry cloth and check if it persists. Compressor is not running · Protective thermic of the compressor will blow out during sudden power failures or plug-out plug-ins as the refrigerant pressure in the cooling system of the refrigerator has not been balanced yet. · Your refrigerator will start running approximately after 6 minutes. Please call the service if your refrigerator does not startup at the end of this period. · The fridge is in defrost cycle. This is normal for a full-automatically defrosting refrigerator. Defrosting cycle occurs periodically. · Your refrigerator is not plugged into the socket. Make sure that he plug is inserted tightly to the wall socket.

· Are the temperature adjustments correctly made? There is a power failure. Call your electricity supplier. The fridge is running frequently or for a long time. 17 EN · Your new refrigerator may be wider than the previous one. This is quite normal. Large refrigerators operate for a longer period of time. · The ambient room temperature may be high. This is quite normal. @@@@Doors might have been opened frequently or left ajar for a long time. The warm air that has entered into the refrigerator causes the refrigerator to run for longer periods.

Open the doors less frequently. · Freezer or fridge compartment door might have been left ajar. Check if the doors are tightly closed. · The refrigerator is adjusted to a very low temperature. Adjust the refrigerator temperature to a warmer degree and wait until the temperature is achieved.

@@ Clean or replace the seal. @@@@Adjust the freezer temperature to a warmer degree and check. Fridge temperature is very low while the freezer temperature is sufficient. · The fridge temperature is adjusted to a very low temperature. Adjust the fridge temperature to a warmer degree and check. Food kept in the fridge compartment drawers are freezing. · The fridge temperature is adjusted to a very low temperature. Adjust the fridge temperature to a warmer degree and check. Temperature in the fridge or freezer is very high. · The fridge temperature is adjusted to a very high degree. Fridge adjustment has an effect on the temperature of the freezer. Change the temperature of the fridge or freezer until the fridge or freezer temperature reaches to a sufficient level. · The door might be left ajar. Close the door completely. @@Wait until the fridge or freezer reaches the desired temperature.

· Refrigerator might have been plugged in recently. Cooling down of the refrigerator completely takes time because of the size. Noise similar to the sound of seconds heard from an analog clock is coming from the refrigerator.



[You're reading an excerpt. Click here to read official SMEG FQ60XP user guide](http://yourpdfguides.com/dref/3973793)  
<http://yourpdfguides.com/dref/3973793>

18 EN · This noise is coming from the solenoid valve of the refrigerator. Solenoid valve functions for the purpose of ensuring coolant passage through the compartment which can be adjusted to cooling or freezing temperatures, and performing cooling functions. This is normal and is not fault cause. The operation noise increases when the refrigerator is running. · The operating performance characteristics of the refrigerator may change according to the changes in the ambient temperature. It is normal and not a fault. Vibrations or noise.

· The floor is not even or it is weak. The refrigerator rocks when moved slowly. Make sure that the floor is level, strong and capable to carry the refrigerator. The noise may be caused by the items put onto the refrigerator. Such items should be removed from the top of the refrigerator.

There are noises like liquid spilling or spraying. · Liquid and gas flows happen in accordance with the operating principles of your refrigerator. It is normal and not a fault. There is a noise like wind blowing. · Air activators (fans) are used in order to allow the refrigerator to cool efficiently.

It is normal and not a fault. Condensation on the inner walls of refrigerator. · Hot and humid weather increases icing and condensation. It is normal and not a fault. · The doors are ajar. Make sure that the doors are closed completely. · Doors might have been opened very frequently or they might have been left open for a long time. Open the door less frequently. Humidity occurs on the outside of the refrigerator or between the doors. · The weather may be humid.

This is quite normal in humid weather. When the humidity is less, condensation will disappear. Bad odor inside the refrigerator. · Inside of the refrigerator must be cleaned. Clean the inside of the refrigerator with a sponge, warm water or carbonated water. · Some containers or packaging materials might be causing the smell. Use a different container or different brand packaging material. The door(s) is (are) not closing. · Food packages may prevent the door's closing. Replace the packages that are obstructing the door.

· The refrigerator is probably not completely vertical on the floor and it might be rocking when slightly moved. Adjust the elevation screws. · The floor is not level or strong. Make sure that the floor is level and capable to carry the refrigerator. Crispers are stuck.

· The food might be touching the ceiling of the drawer. Rearrange food in the drawer. 19 EN 48 9828 0000/AA en-it .



[You're reading an excerpt. Click here to read official SMEG FQ60XP user guide](http://yourpdfguides.com/dref/3973793)

<http://yourpdfguides.com/dref/3973793>